

# **Airplane mode of automated testing**

**Version 1.0**

### Version History

Version	Date	Handled by	Comments
V1.0	27-May-2019	ZL Chen	First version release.

### Precondition Setting:

Please make sure the DUT is connected to the internet.

- Install the adb interface driver
  - ✓ Please refer to the “[ADB interface driver.pdf](#)” attachment.  
(\automation\sop\ADB interface driver.pdf)
- Install the Python 3.6.8.
  - ✓ Please refer to the “[Python 3.6.8 installation.pdf](#)” attachment.  
(\automation\sop\Python 3.6.8 installation.pdf)
- Install the third party library.
  - ✓ Double click the “[Envir\\_Install.exe](#)” under the installer folder.  
(\automation\installer\Envir Install.exe)


Please follow the implement as below:

Step 1:

Please make sure the Wi-Fi is connecting to the repeater.


SSID: [siot\\_dqa](#)

Password: [ad20151225](#)



Step 2:

Please delete all of the [known networks](#), because you need make sure the network just only attach to the “siot\_dqa” repeater.



### Step 3:

Please copy the airplane folder of the suite to the device's desktop.



Make sure the adb.exe should be worked, so please input the window command as below:

Command: “adb.exe kill-server” and “adb.exe start-server”

```
C:\Users\DQA\Desktop\airplane>adb.exe kill-server

C:\Users\DQA\Desktop\airplane>adb.exe start-server
* daemon not running. starting it now on port 5037 *
* daemon started successfully *


C:\Users\DQA\Desktop\airplane>
```

Command: “adb.exe devices”


```
C:\Users\DQA\Desktop\airplane>adb devices
List of devices attached
162219d4ee695b53      device
```

Make sure the “Allow USB debugging” alert is pop up on the DUT window.

Please check the “Always allow from this computer” box, then tap the “OK” button.



Implement the airplane.exe under the “\airplane\” folder.



A screenshot of a Windows command prompt window titled "C:\Users\DQA\Desktop\suite\airplane\airplane.exe". The window has a black background with white text. The text displayed is as follows:


```
-----  
Created on 2019/05/23  
Author: ZL Chen  
Title: The Wi-Fi should be worked after the airplane mode is switch on/off.  
-----  
The .txt is deleted.  
The .jpg is deleted.  
Please input the 'Cycle Times' you want : _
```

A red arrow points to the underscore character at the end of the prompt line.

Step 4:

Please input the “Cycle Times” you want. (Ex: 1), and then tap the “Enter”.

The program is start running.




A screenshot of the same Windows command prompt window. The text displayed is as follows:

```
-----  
Created on 2019/05/23  
Author: ZL Chen  
Title: The Wi-Fi should be worked after the airplane mode is switch on/off.  
-----  
The .txt is deleted.  
The .jpg is deleted.  
Please input the 'Cycle Times' you want : 1  
-----  
Cycle Times: 1
```

Step 5:

When the program is completed, the windows should be closed.

You can see the log under the “\airplane\” folder as below:




➤ ping\_server.txt is ping log.

```
-----  
Cycle Times: 1  
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.  
64 bytes from 8.8.8.8: icmp_seq=1 ttl=53 time=106 ms'  
64 bytes from 8.8.8.8: icmp_seq=2 ttl=53 time=203 ms'  
64 bytes from 8.8.8.8: icmp_seq=3 ttl=53 time=15.2 ms'  
64 bytes from 8.8.8.8: icmp_seq=4 ttl=53 time=11.9 ms'  
,  
--- 8.8.8.8 ping statistics ---  
4 packets transmitted, 4 received, 0% packet loss, time 3003ms'  
,  
The connection is Passed.(PASS)  
Cycle Times: 1, Passed: 1, Failed: 0  
Total Cycle Times: 1, Passed: 1, Failed: 0  
|  
< | >
```

The Total Cycle Times is 1, Passed is 1 and Failed is 0.

- airplane\_off\_1\_20190527\_155251.jpg is airplane switch off by screenshot.



- airplane\_on\_1\_20190527\_155231.jpg is airplane switch on by screenshot.

