


SETTINGS

The *SpectraView® Prism Client Settings* are available at the top of the window, as seen in **FIGURE ERROR! No text of specified style in document.-1**.



Figure **ERROR! No text of specified style in document.-1** Title Bar with Settings

1. To view settings, select the **settings** control in the *Title Bar* as in **FIGURE ERROR! No text of specified style in document.-1** above. This will result in two panes appearing, one on the left side, and the other on the right side of the main window.
2. The pane on the left side will contain the application status information; company name, site name, DAHS model and serial number, the system date and time, count of active alarms, login details, and the current version of the *SpectraView® Prism Client* software.



3. The right side pane, as seen in **FIGURE ERROR! No text of specified style in document.-2**, will contain the available settings for the *SpectraView® Prism Client*. In this pane you can change settings for whether the navigation tabs are visible, whether animations and previews are enabled, the visibility of the Daylog; whether the Tag Service is connected, and its update rate; and control the settings of the Alarm Service.
4. For the Alarm Service, the following steps can be used to control how alarms are reported.
 - a. These steps control the Alarm Service connectivity.
 - i. To turn the Alarm Service connectivity on, if gray, click on **Online**.
 - ii. To turn the Alarm Service off, if blue, click on **Online**.
 - b. These steps control the Alarm Sounds.
 - i. To turn Alarm Sounds on, if gray, click on **On**.
 - ii. To turn the Alarm Sounds off, if blue, click on **On**.
 - c. These steps control the repeating of the Alarm Sounds.
 - i. To cause Alarm Sounds to repeat, if gray, click on **On**.
 - ii. To cause Alarm Sounds to only sound one time, if blue, click on **On**.




Figure **Error! No text of specified style in document.-2** Settings Pane