

# UART Log Viewer — Installation Guide

This guide explains how to install **UART Log Viewer** on Ubuntu, macOS, and Windows. No Qt or Python is required for end users.

## Build From Source (All Platforms)

Use this only if you want to build the installers yourself.

### 1) Clone the repo

```
git clone https://github.com/jay28panchal/uart-log-viewer.git
cd uart-log-viewer
```

### 2) Build installers

Choose your platform below.

## Ubuntu 20.04+ (Minimum)

### Install

**Recommended (No extra installs): AppImage** 1. Download the AppImage (example: `uart-log-viewer_1.0.2-x86_64.AppImage`). 2. Right-click the file → **Properties** → enable **Allow executing file as program**. 3. Double-click to run.

**Alternative: DEB** 1. Download the .deb file (example: `uart-log-viewer_1.0.2_amd64.deb`). 2. Double-click the .deb file to open Ubuntu Software. 3. Click **Install**.

### AppImage (Terminal)

```
chmod +x uart-log-viewer_1.0.2-x86_64.AppImage
./uart-log-viewer_1.0.2-x86_64.AppImage
```

### DEB (Terminal)

```
sudo apt-get install ./uart-log-viewer_1.0.2_amd64.deb
```

### Download From GitHub (Terminal)

Replace `<version>` with the release tag (example: `v1.0.2`).

```
curl -L -o uart-log-viewer_1.0.2-x86_64.AppImage \
  https://github.com/jay28panchal/uart-log-viewer/releases/download/<version>/uart-log-viewer_1.0.2-x86_64.AppImage
chmod +x uart-log-viewer_1.0.2-x86_64.AppImage
./uart-log-viewer_1.0.2-x86_64.AppImage
```

*# Optional .deb:*

```
curl -L -o uart-log-viewer_1.0.2_amd64.deb \
  https://github.com/jay28panchal/uart-log-viewer/releases/download/<version>/uart-log-viewer_1.0.2_amd64.deb
sudo apt-get install ./uart-log-viewer_1.0.2_amd64.deb
```

## Launch

Open the application menu and run **UART Log Viewer**.

## If You See “Qt\_6.5 not found”

You installed a package built against a newer Qt than your system provides. Download the latest `.deb` from **GitHub Releases** and reinstall it; it is built against the system Qt version. If you still see the error, install the Qt 6 runtime packages:

```
sudo apt-get install -y libqt6core6 libqt6gui6 libqt6widgets6 libqt6serialport6
```

## Upgrading From Older Versions

If you already have an older version installed, installing the new `.deb` will **upgrade** it automatically. If you used the older Python/Tkinter package (`uart-tabs`), the new package will replace it.

## Build Installer (From Source)

From the repo folder:

```
./scripts/build-qt-linux.sh
```

Then install the generated `.deb` from `dist/`.

## Build AppImage (From Source)

From the repo folder:

```
./scripts/build-qt-linux-appimage.sh
```

Then run the generated AppImage from `dist/`.

---

## macOS 12+ (Minimum)

### Install

1. Download `UART-Log-Viewer.dmg`.
2. Double-click the `.dmg`.
3. Drag **UART Log Viewer** into **Applications**.

## Download From GitHub (Terminal)

Replace <version> with the release tag (example: v1.0.2).

```
curl -L -o UART-Log-Viewer.dmg \  
  https://github.com/jay28panchal/uart-log-viewer/releases/download/<version>/UART-Log-Viewer.dmg  
open UART-Log-Viewer.dmg
```

## Launch

Open **Applications** and run **UART Log Viewer**.

## Build Installer (From Source)

From the repo folder:

```
./scripts/build-qt-mac.sh
```

Then open `dist/UART-Log-Viewer.dmg` and drag the app into **Applications**.

## Notes

If macOS blocks the app: 1. Go to **System Settings -> Privacy & Security**.  
2. Click **Open Anyway** for UART Log Viewer.

---

## Windows 10+ (Minimum)

### Install

1. Download `UART-Log-Viewer-Setup.exe`.
2. Double-click the installer and follow the wizard.

## Download From GitHub (PowerShell)

Replace <version> with the release tag (example: v1.0.2).

```
Invoke-WebRequest -Uri "https://github.com/jay28panchal/uart-log-viewer/releases/download/<version>/UART-Log-Viewer-Setup.exe" -OutFile UART-Log-Viewer-Setup.exe  
Start-Process .\UART-Log-Viewer-Setup.exe
```

## Launch

Use Start Menu or Desktop shortcut (if chosen during install).

## Build Installer (From Source)

From the repo folder (PowerShell):

```
./scripts/build-qt-win.ps1
```

Then open `dist\UART-Log-Viewer-Setup.exe` and follow the wizard.

---

## **USB Driver Notes (All Platforms)**

If no serial ports appear, you may need a USB-serial driver: - CP210x (Silicon Labs) - CH340 (WCH) - FTDI

Install the correct driver for your device, then replug the USB cable.