

PARFLOW User's Manual

GMWI 2016-01 vv3.3.1-98-g8696947
July, 2019

Integrated GroundWater Modeling Center



Reed M. Maxwell¹, Stefan J. Kollet², Laura E. Condon³, Steven G. Smith⁴, Carol S. Woodward⁵, Robert D. Falgout⁶, Ian M. Ferguson⁷, Nicholas Engdahl⁸, Basile Hector⁹, Sonya Lopez¹⁰, James Gilbert¹, Lindsay Bearup¹, Jennifer Jefferson¹, Caitlin Collins¹, Inge de Graaf¹, Christine Pribulick¹, Chuck Baldwin, William J. Bosl¹¹, Richard Hornung¹², Steven Ashby¹³, Ketan B. Kulkarni¹⁴

¹Department of Geology and Geological Engineering and Integrated GroundWater Modeling Center, Colorado School of Mines, Golden, CO, USA. rmaxwell@mines.edu

²Institute for Bio- and Geosciences, Agrosphere (IBG-3) and Centre for High-Performance Scientific Computing in Terrestrial Systems, Research Centre Jülich, Jülich, Germany. s.kollet@fz-juelich.de

³Department of Hydrology and Atmospheric Sciences, University of Arizona, Tucson, USA. lecondon@email.arizona.edu

⁴Center for Applied Scientific Computing, Lawrence Livermore National Laboratory, Livermore, CA, USA.

⁵Center for Applied Scientific Computing, Lawrence Livermore National Laboratory, Livermore, CA, USA. cswoodward@llnl.gov

⁶Center for Applied Scientific Computing, Lawrence Livermore National Laboratory, Livermore, CA, USA.

⁷US Bureau of Reclamation, Denver, CO, USA.

⁸Civil and Environmental Engineering, Washington State University, Pullman, WA, USA. nick.engdahl@wsu.edu

⁹LTHE, Grenoble, FR.

¹⁰California State University, Los Angeles, CA, USA.

¹¹Children's Hospital Informatics Program, Harvard Medical School, Boston, MA, USA.

¹²Center for Applied Scientific Computing, Lawrence Livermore National Laboratory, Livermore, CA, USA.

¹³Pacific Northwest National Laboratory, Richland, WA, USA.

¹⁴Jülich Supercomputing Centre and Centre for High-Performance Scientific Computing in Terrestrial Systems, Research Centre Jülich, Jülich, Germany.

Suggested citation: Maxwell, R.M., S.J. Kollet, L.E. Condon, S.G. Smith, C.S. Woodward, R.D. Falgout, I.M. Ferguson, N. Engdahl, B. Hector, S.R. Lopez, J. Gilbert, L. Bearup, J. Jefferson, C. Collins, I. de Graaf, C. Prubilick, C. Baldwin, W.J. Bosl, R. Hornung, S. Ashby, PARFLOW User's Manual. Integrated GroundWater Modeling Center Report, 2019 169p.

ParFlow is released under the GNU LPGL License

Version 1.3, 3 November 2008

Copyright © 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc.

<http://fsf.org/>

This manual is licensed under the GNU Free Documentation License.

Copyright © 2019 Reed M. Maxwell, Stefan J. Kollet, Laura E. Condon, Ian M. Ferguson, Steven G. Smith, Carol S. Woodward, Nicholas Engdahl. Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License". Permission is granted to make and distribute verbatim copies of this manual provided the copyright notice and this permission notice are preserved on all copies.

This computer software and documentation was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial products, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

Contents

1	Introduction	1
1.1	How to use this manual	2
1.2	Published Studies That Have Used PARFLOW	2
2	Getting Started	19
2.1	Installing ParFlow	19
2.1.1	External Libraries	25
2.2	Running the Sample Problem	25
2.3	ParFlow Solvers	25
3	The ParFlow System	27
3.1	Defining the Problem	27
3.1.1	Basic Domain Definition	27
3.1.2	Setting Up a Real Domain	28
3.2	Running ParFlow	30
3.3	Restarting a Run	31
3.4	Visualizing Output	32
3.5	Directory of Test Cases	32
3.6	Annotated Input Scripts	33
3.6.1	Harvey Flow Example	34
3.6.2	Little Washita Example	46
4	Manipulating Data: PFTOOLS	61
4.1	Introduction to the PARFLOW TCL commands (PFTCL)	61
4.2	PFTCL Commands	61
4.3	Common examples using PARFLOW TCL commands (PFTCL)	75
5	Model Equations	79
5.1	Steady-State, Saturated Groundwater Flow	79
5.2	Richards' Equation	79
5.3	Terrain Following Grid	80
5.4	Flow Barriers	80
5.5	Overland Flow	81
5.6	Multi-Phase Flow Equations	82
5.7	Transport Equations	83
5.8	Notation and Units	84
5.9	Water Balance	85

6	ParFlow Files	87
6.1	Main Input File (.tcl)	88
6.1.1	Input File Format Number	89
6.1.2	Computing Topology	89
6.1.3	Computational Grid	90
6.1.4	Geometries	91
6.1.5	Timing Information	94
6.1.6	Time Cycles	96
6.1.7	Domain	97
6.1.8	Phases and Contaminants	97
6.1.9	Gravity, Phase Density and Phase Viscosity	98
6.1.10	Chemical Reactions	98
6.1.11	Permeability	99
6.1.12	Porosity	103
6.1.13	Specific Storage	104
6.1.14	dZMultipliers	104
6.1.15	Flow Barriers	106
6.1.16	Manning's Roughness Values	107
6.1.17	Topographical Slopes	107
6.1.18	Retardation	109
6.1.19	Full Multiphase Mobilities	109
6.1.20	Richards' Equation Relative Permeabilities	110
6.1.21	Phase Sources	112
6.1.22	Capillary Pressures	113
6.1.23	Saturation	113
6.1.24	Internal Boundary Conditions	116
6.1.25	Boundary Conditions: Pressure	116
6.1.26	Boundary Conditions: Saturation	120
6.1.27	Initial Conditions: Phase Saturations	121
6.1.28	Initial Conditions: Pressure	121
6.1.29	Initial Conditions: Phase Concentrations	122
6.1.30	Known Exact Solution	123
6.1.31	Wells	124
6.1.32	Code Parameters	127
6.1.33	SILO Options	131
6.1.34	Richards' Equation Solver Parameters	132
6.1.35	Spinup Options	135
6.1.36	CLM Solver Parameters	136
6.2	ParFlow NetCDF4 Parallel I/O	142
6.2.1	NetCDF4 Chunking	143
6.2.2	ROMIO Hints	144
6.2.3	Node Level Collective I/O	144
6.2.4	NetCDF4 Initial Conditions: Pressure	144
6.2.5	NetCDF4 Slopes	145
6.2.6	NetCDF4 Transient EvapTrans Forcing	146
6.2.7	NetCDF4 CLM Output	146
6.2.8	NetCDF4 CLM Input/Forcing	147
6.2.9	NetCDF Testing Little Washita Test Case	148

6.3	ParFlow Binary Files (.pfb)	148
6.4	ParFlow CLM Single Output Binary Files (.c.pfb)	148
6.5	ParFlow Scattered Binary Files (.pfsb)	149
6.6	ParFlow Solid Files (.pfsol)	150
6.7	ParFlow Well Output File (.wells)	151
6.8	ParFlow Simple ASCII and Simple Binary Files (.sa and .sb)	154
7	GNU Free Documentation License	155
	GNU Free Documentation License	155
1.	APPLICABILITY AND DEFINITIONS	155
2.	VERBATIM COPYING	156
3.	COPYING IN QUANTITY	156
4.	MODIFICATIONS	157
5.	COMBINING DOCUMENTS	158
6.	COLLECTIONS OF DOCUMENTS	158
7.	AGGREGATION WITH INDEPENDENT WORKS	158
8.	TRANSLATION	159
9.	TERMINATION	159
10.	FUTURE REVISIONS OF THIS LICENSE	159
11.	RELICENSING	159

Chapter 1

Introduction

PARFLOW (*PAR*allel *FLOW*) is an integrated hydrology model that simulates surface and subsurface flow. PARFLOW [4, 57, 65, 92] is a parallel simulation platform that operates in three modes:

1. steady-state saturated;
2. variably saturated;
3. and integrated-watershed flow.

PARFLOW is especially suitable for large scale problems on a range of single and multi-processor computing platforms. PARFLOW simulates saturated and variably saturated subsurface flow in heterogeneous porous media in three spatial dimensions using a multigrid-preconditioned conjugate gradient solver [4] and a Newton-Krylov nonlinear solver [57]. PARFLOW has recently been extended to coupled surface-subsurface flow to enable the simulation of hillslope runoff and channel routing in a truly integrated fashion [65]. PARFLOW is also fully-coupled with the land surface model CLM [27] as described in [83, 66]. The development and application of PARFLOW has been on-going for more than 20 years [99, 100, 98, 101, 111, 115, 118, 119, 120, 123, 137, 138, 37, 60, 62, 17, 18, 92, 62, 62, 118, 29, 5, 91, 90, 37, 68, 123, 45, 64, 89, 30, 88, 67, 66, 87, 86, 84, 85, 65, 83, 132, 82, 131, 136, 57, 81, 130, 129, 128, 4] and resulted in some of the most advanced numerical solvers and multigrid preconditioners for massively parallel computer environments that are available today. Many of the numerical tools developed within the PARFLOW platform have been turned into or are from libraries that are now distributed and maintained at LLNL (*Hypre* and *SUNDIALS*, for example). An additional advantage of PARFLOW is the use of a sophisticated octree-space partitioning algorithm to depict complex structures in three-space, such as topography, different hydrologic facies, and watershed boundaries. All these components implemented into PARFLOW enable large scale, high resolution watershed simulations.

PARFLOW is primarily written in *C*, uses a modular architecture and contains a flexible communications layer to encapsulate parallel process interaction on a range of platforms. CLM is fully-integrated into PARFLOW as a module and has been parallelized (including I/O) and is written in *FORTRAN 90/95*. PARFLOW is organized into a main executable `pfdir/pfsimulator/parflow_exe` and a library `pfdir/pfsimulator/parflow_lib` (where `pfdir` is the main directory location) and is comprised of more than 190 separate source files. PARFLOW is structured to allow it to be called from within another application (*e.g.* WRF, the Weather Research and Forecasting atmospheric model) or as a stand-alone application. There is also a directory structure for the message-passing layer `pfdir/pfsimulator/amps` for the associated tools `pfdir/pftools` for CLM `pfdir/pfsimulator/clm` and a directory of test cases `pfdir/test`.

1.1 How to use this manual

This manual describes how to use PARFLOW, and is intended for hydrologists, geoscientists, environmental scientists and engineers. This manual is written assuming the reader has a basic understanding of Linux / UNIX environments, how to compose and execute scripts in various programming languages (e.g. TCL), and is familiar with groundwater and surface water hydrology, parallel computing, and numerical modeling in general. In Chapter 2, we describe how to install PARFLOW, including building the code and associated libraries. Then, we lead the user through a simple PARFLOW run and discuss the automated test suite. In Chapter 3, we describe the PARFLOW system in more detail. This chapter contains a lot of useful information regarding how a run is constructed and most importantly contains two detailed, annotated scripts that run two classical PARFLOW problems, a fully saturated, heterogeneous aquifer and a variably saturated, transient, coupled watershed. Both test cases are published in the literature and are a terrific initial starting point for a new PARFLOW user.

Chapter 4 describes data analysis and processing. Chapter 5 provides the basic equations solved by PARFLOW. Chapter 6 describes the formats of the various files used by PARFLOW. These chapters are really intended to be used as reference material. This manual provides some overview of PARFLOW some information on building the code, examples of scripts that solve certain classes of problems and a compendium of keys that are set for code options.

1.2 Published Studies That Have Used PARFLOW

PARFLOW has been used in a number of research studies published in the literature. What follows are tables of PARFLOW references with information on topics, types of problem and application. 1.16 to 1.11 describe any coupled physics, categorize the scale and domain and discuss what processes within PARFLOW are used. For this last set of columns, **TB**=Turning Bands, **TFG**=Terrain Following Grid, **VS**= Variably Saturated and **Vdz**=Variable DZ.

Table 1.1: List of PARFLOW references with application and process details.

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[14] Bearup et al. (2016)		Hillslope Hydrologic Response; MPB	Hillslope	Idealized			X	
[95] Maxwell et al. (2016)		Residence Time Distributions	Continental	CONUS			X	X
[109] Reyes et al. (2015)	CLM	Surface Heterogeneity, Surface Energy Budget (SEB)	Urban Watershed Ballona Creek Watershed, CA		X	X	X	
[22] Condon and Maxwell (2015)		Subsurface Heterogeneity (groundwater fluxes and topography)	Continental	CONUS			X	X
[55] Jefferson et al. (2015)	CLM	Active subspaces; Dimension reduction; Energy fluxes	Hillslope	Idealized				
[54] Jefferson and Maxwell (2015)	CLM	Sensitivity Analysis (evaporation parameterization)	Column	Idealized				
[112] Rihani et al. (2015)	ARPS, CLM	Land-atmosphere feedbacks	Hillslope	Idealized		X	X	

Table 1.2: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[21] Condon et al. (2015)		Subsurface Heterogeneity (groundwater fluxes and topography)	Continental	CONUS		X	X	X
[95] Maxwell and Condon (2016)		Transpiration partitioning	Continental	CONUS		X	X	X
[94] Maxwell et al. (2015)		Model Development (continental-scale)	Continental	CONUS		X	X	X
[15] Beisman et al. (2015)	CrunchFlow	Parallel Reactive Transport; Subsurface Nutrient Cycling	Floodplain	Idealized				
[114] Seck et al. (2015)	CLM	Spin-up behavior; Initial Conditions Watershed	Regional	Monocacy, MD and PA			X	
[9] Bhaskar et al. (2015)	CLM	Urban Processes	Regional	Baltimore, MD			X	
[104] Pribulick (2016)	CLM	Land cover and climate change	Hillslope	East River Headwaters		X	X	X
[61] Koch et al. (2016)	CLM	Seasonal Variability of soil moisture	Catchment	WÄijstebach Catchment, Germany		X	X	X
[35] Fang et al. (2016)	CLM	Soil Hydraulic Conductivity	Catchment	WÄijstebach catchment, Germany		X	X	X

Table 1.3: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[70] Kollet (2016)	CLM	Entropy balance considerations						
[49] Gilbert et al. (2017)	WRF	Water-table effects on Planetary Boundary Layer	Catchment	San Joaquin Valley, California		X	X	X
[113] Schalge et al. (2019)	TerrSysMP	Improving overland flow parameterization	Catchment	Two: Idealized and Rhine-Neckar, Germany			X	
[13] Baroni et al. (2019)	CLM	Understanding differences in model structure, identification of observations needed for model assessment and improvement	Regional	Upper Neckar, Germany			X	
[28] Danesh-Yazdi et al. (2018)	SLIM	Influence of subsurface variables on solute travel time distributions and Storage Selection functions	Aquifer	Idealized	X		X	
[3] Ajami and Sharma (2018)	CLM	Comparing alternatives when disaggregating soil moisture to finer spatial resolutions	Subcatchment	Baldry subcatchment, Australia			X	

Table 1.4: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[8] Atchely et al. (2017)	CLM	Fire disturbance on ET and water balance	Hillslope	Frijoles Canyon of Bandelier National Monument, New Mexico			X	
[43] Foster et al. (2016)	CLM	Climate change impacts on energy budget and hydrology	Hillslope	2-D idealized domain		X	X	X
[77] Lopez et al. (2016)		Urban Hydrologic Modeling	Catchment	Parker, Colorado		X	X	X
[80] Markovich et al. (2016)	CLM	Climate change impacts on energy budget and hydrology in alpine hillslopes	Hillslope	Idealized		X	X	X
[103] Penn et al. (2016)	CLM	Multi-scale hydrological responses to tree mortality		Big Thomson Catchment, Colorado		X	X	X
[47] Gilbert et al. (2016)		sensitivity of runoff to subsurface permeability	Hillslope	Idealized		X	X	
[74] Kurtz et al. (2016)	TerrSysMP	land surface-subsurface modeling	Hillslope	Idealized			X	X

Table 1.5: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[107] Rahman et al. (2016)	CLM	subsurface-land surface interactions	Catchment	Rur Catchment, Germany		X	X	X
[58] Keune et al. (2016)	TerrSysMP	Land surface-atmosphere feedbacks	Continental	CORDEX		X	X	X
[70] Kollet et al. (2016)		Model Inter-comparison: Integrated hydrology and feedbacks	Hillslope	Idealized		X	X	
[56] Jefferson et al. (2017)	CLM	Land surface models	Single Column	Idealized			X	
[48] Gilbert and Maxwell (2017)	CLM	Surface water-groundwater dynamics	Catchment	San Joaquin Valley, California		X	X	X
[23] Condon and Maxwell (2017)	CLM	Budyko Relationships	Continental	CONUS		X	X	X
[124] Sulis et al. (2017)	WRF, TerrSysMP	Groudwater and atmospheric properties	Catchment	Idealized		X	X	X
[126] Sweetenham et al. (2017)	CLM	Seepage through fractured rock	Catchment	Idealized			X	
[46] Gebler et al. (2017)	TerrSysMP	Soil moisture	Catchment	Rollesbroich catchment, Germany		X	X	X

Table 1.6: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[12] Barnes et al. (2018)	CLM	Effects of urban development on catchment hydrology	Catchment	6 catchments near Baltimore, Maryland		X		X
[78] Maina and Siirila-Woodburn (2019)	CLM	Watershed dynamics after wildfires	Catchment	Cosumnes Watershed, California		X		
[117] Shrestha et al. (2018)	CLM	Evapotranspiration Partitioning	Catchment	Inde Catchment, Germany				
[24] Condon and Maxwell (2019)	CLM	Sensitivity of evapotranspiration and streamflow to groundwater depletion	Continental	CONUS		X	X	X
[53] Hein, Condon, and Maxwell (2019)	CLM	Hydrologic response to extreme drought conditions	Regional	southern High Plains and Rocky Mountains			X	X
[25] Condon and Maxwell (2019)		Software tool to develop consistent hydrological inputs for integrated hydrologic models					X	
[14] Bearup et al. (2016)		Hillslope response to insect-induced land cover change	Hillslope	Idealized			X	

Table 1.7: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[44] Foster and Maxwell (2019)	CLM	Sensitivity analysis to scale effective hydraulic conductivity	Catchment	East River Basin		X	X	X
[97] Maxwell et al. (2019)	CLM, EcoSLIM	Lagrangian particle tracking to explore transient residence time distributions	Hillslope	Idealized			X	X
[40] Ferguson et al. (2016)	CLM	Effects of root water uptake on water and energy budgets	catchment	Little Washita, USA			X	
[41] Forrester et al. (2018)	WRF	Atmospheric feedbacks caused by forest disturbance	Regional	Rocky Mountain Headwaters		X	X	X
[36] Fang et al. (2017)	CLM	Influence of landscape heterogeneity on water available to tropical rainforests	Catchment	Asu catchment, Amazonian watershed		X	X	
[51] Gou et al. (2018)	CLM	Groundwater uptake and hydraulic redistribution by phreatophytes	Hillslope	Idealized			X	

Table 1.8: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[110] Reyes et al. (2018)	CLM	Suppression in land surface temp and hydrologic regime changes from urban irrigation	Catchment	Los Angeles, CA			X	
[28] Danesh-Yazdi et al. (2018)	SLIM	Travel time distributions and analytical storage selection functions	Hillslope	Idealized	X		X	
[50] Gilbert and Maxwell (2018)	CLM	Revealing the role of elevation gradients in regional response to temperature change.	Regional	San Joaquin Valley, California		X	X	X
[139] Zhang et al. (2018)	TerrSysMP	Improved Predictions of Root Zone Soil Moisture	2000m x 2000m x 30m	Idealized				
[10] Baatz et al. (2017)	TerrSysMP	Catchment Tomography-Spatial Parameter Estimation	Catchment	Swist and Upper Erft Catchments (Germany)			X	
[72] Kollet et al. (2018)	CLM, COSMO	Experimental Terrestrial Forecasting/Monitoring System	Regional and Continental	North Rhine-Westphalia (Germany) and pan-European Domain			X	

Table 1.9: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[125] Sulis et al. (2018)	TerrSysMP	Quantifying the Impact of Subsurface–Land Surface Physical Processes on the Predictive Skill of Subseasonal Mesoscale Atmospheric Simulations	Regional	North Rhine-Westphalia (Germany)		X		
[140] Zipper, Keune, and Kollet (2019)	TerrSysMP	Land Use Change Impacts on European Heat and Drought	Continental	CORDEX			X	
[108] Rahman et al. (2018)		Computationally Efficient Free Surface Groundwater Flow Boundary Condition	Catchment	Idealized			X	
[121] Woodburn et al. (2018)	CLM	Predicting the impact of land management decisions on overland flow generation	Catchment	Fukushima Prefecture, Japan		X	X	X
[102] Moqbel and Abu-El-Sha’r (2018)	SLIM-FAST	Modeling groundwater flow and solute transport	Regional	Azraq Basin, Jordan				

Table 1.10: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[124] Sulis et al. (2017)	WRF	Comparing model simulation of variability in simulated soil-vegetation-atmosphere interactions	Regional	North Rhine-Westphalia (Germany)		X	X	
[33] Engdahl and Maxwell (2015)		Residence Time Distributions	Watershed	East Inlet watershed, CO	X		X	
[122] Srivastava et al. (2014)	CLM	Global Sensitivity Analysis	Watershed	Sante Fe River Basin, FL			X	
[69] Kollet (2015)	CLM	Entropy Production	Hillslope	Idealized			X	
[106] Rahman et al. (2015)	TerrSysMP	Aquifer-to-atmosphere	Regional	Rur Catchment, Germany			X	
[34] Fang et al. (2015)	CLM	Soil Moisture Dynamics	Catchment	Wüstebach catchment			X	
[75] Lim and Welty (2017)		Modeling green infrastructure effects on hydrologic response	Regional	Urbanized - Washington, DC		X	X	X
[76] Lim and Welty (2018)		Modeling overland flow to assess uncertainty and variability in green infrastructure planning	Catchment	Urbanized - Washington, DC		X	X	X

Table 1.11: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[116] Shrestha et al. (2015)	TerrSysMP	Grid Resolution; Surface Energy Fluxes	Catchment	Rür River sub-catchment			X	
[105] Rahman et al. (2015)	CLM	Dual-boundary Forcing Concept	Catchment	Rur Catchment, Germany			X	
[61] Koch et al. (2016)	CLM Model Comparison (Hydro-Geo-Sphere, MIKE SHE)	Catchment	Wüstebach catchment			X		
[2] Ajami et al. (2015)	CLM	Initial Conditions	Catchment	Skjern River basin in Denmark			X	
[11] Barnes et al. (2015)	Slope Processing Watershed	DR5, Gwynn Falls, Baltimore, MD	Urban subwatershed	DR5, Baltimore, MD		X	X	
[1] Ajami et al. (2014)	CLM	Spin Up (initial conditions)	Watershed	Ringkobing Fjord			X	
[19] Condon and Maxwell (2014)	CLM	Agriculture	Watershed	Little Washita, OK		X	X	
[20] Condon and Maxwell (2014)	CLM	Agriculture	Watershed	Little Washita, OK		X	X	
[93] Maxwell et al. (2014)	Model Comparison	Many	Idealized			X	X	

Table 1.12: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[26] Cui et al. (2014)	SLIM-FAST	Model Development (nitrogen biogeochemistry)	Column-Hillslope	Idealized	X		X	
[99] Meyerhoff et al. (2014)	-	Stochastic runoff generation, conditioning	Hillslope	Idealized	X		X	
[100] Meyerhoff et al. (2014)	SLIM-FAST	Karst Environments	Aquifer	Transects in Santa Fe River Watershed		X		
[115] Shrestha et al. (2014)	COSMO-CLM	Model Development (TerrSysMP)	Watershed	Idealized; Rur catchment		X	X	
[6] Atchley et al. (2013)	SLIM-FAST; Crunch-Flow	Risk Assessment	Aquifer	Idealized	X			
[7] Atchley et al. (2013)	SLIM-FAST; Crunch-Flow	Risk Assessment	Aquifer	Idealized		X	X	
[17] Condon and Maxwell (2013)	CLM	Agriculture	Sub-Watershed	Little Washita, OK		X	X	
[18] Condon et al. (2013)	CLM	Subsurface Heterogeneity (land surface fluxes)	Watershed	Upper Klamath, OR	X	X	X	
[31] de Rooij et al. (2013)	SLIM-FAST	Model Development (surface particles)	Hillslope	Idealized			X	

Table 1.13: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[92] Maxwell (2013)	Model Development	Idealized				X	X	X
[101] Mikkelsen et al. (2013)	CLM	Mountain Pine Beetle	Hillslope	Idealized		X	X	
[138] Williams et al. (2013)	WRF	Atmosphere, DART, Data Assimilation	Watershed	Idealized	X		X	
[16] Bürger et al. (2012)	ParFlow Web	Model Development (ParFlow Web)	-	-			X	
[39] Ferguson and Maxwell (2012)	CLM	Agriculture	Watershed	Little Washita, OK			X	
[118] Siirila et al. (2012)	SLIM-FAST	Risk Assessment	Aquifer	Idealized	X			
[119] Siirila and Maxwell (2012)	SLIM-FAST	Risk Assessment	Aquifer	Idealized	X			
[120] Siirila and Maxwell (2012)	SLIM-FAST	Risk Assessment	Aquifer	Idealized	X			
[5] Atchley and Maxwell (2011)	CLM	Subsurface Heterogeneity (land surface processes)	Hillslope	Golden, CO	X		X	
[29] Daniels et al. (2011)	-	Regional	Streamflow	Owens Valley, CA flood-plain			X	
[38] Ferguson and Maxwell (2011)	CLM	Agriculture	Watershed	Little Washita, OK			X	

Table 1.14: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[91] Maxwell et al. (2011)	WRF	Atmosphere	Watershed	Little Washita, OK			X	
[98] Meyerhoff and Maxwell (2011)	-	Subsurface Heterogeneity (runoff generation)	Hillslope	Idealized	X		X	
[137] Williams and Maxwell (2011)	WRF	Atmosphere	Watershed	Idealized	X		X	
[37] Ferguson and Maxwell (2010)	CLM	Agriculture	Watershed	Little Washita, OK			X	
[68] Kollet et al. (2010)	CLM	Computational Scaling	Hillslope	Idealized	X		X	
[90] Maxwell (2010)	CLM	Subsurface Heterogeneity (infiltration)	Hillslope	Rainer Mesa (Nevada Test Site)	X		X	
[111] Rihani et al. (2010)	CLM	Subsurface Heterogeneity (land energy fluxes)	Hillslope	Idealized			X	
[123] Sulis et al. (2010)	-	Model Comparison (CATHY)	Hillslope	Idealized			X	
[45] Frei et al. (2009)	-	Groundwater-Surface water exchange	Catchment	Consumnes River	X		X	
[64] Kollet et al. (2009)	CLM	Heat Transport (ParFlowE)	Column	Wagineng, NL			X	
[89] Maxwell et al. (2009)	SLIM	Subsurface Transport	Hillslope	Nevada Test Site			X	

Table 1.15: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[63] Kollet (2009)	CLM	Subsurface Heterogeneity (evapotranspiration)	Column, Hillslope	Idealized	X		X	
[67] Kollet and Maxwell (2008)	SLIM-FAST	Residence Time Distributions	Watershed	Little Washita, OK			X	
[66] Kollet and Maxwell (2008)	CLM	Subsurface Heterogeneity (land energy fluxes)	Watershed	Little Washita, OK			X	
[88] Maxwell and Kollet (2008)	-	Subsurface Heterogeneity (runoff)	Hillslope	Idealized	X		X	
[87] Maxwell and Kollet (2008)	CLM	Climate Change (land-energy feedbacks to groundwater)	Watershed	Little Washita, OK			X	
[85] Maxwell et al. (2007)	particles	Subsurface Transport	Aquifer	Cape Cod, MA	X			
[84] Maxwell et al. (2007)	ARPS, CLM	Model Development (ARPS)	Watershed	Little Washita, OK			X	
[65] Kollet and Maxwell (2006)	-	Model Development (Overland Flow) & Subsurface Heterogeneity (shallow overland flow)	Catchment	Idealized	X		X	

Table 1.16: List of PARFLOW references with application and process details (cont.).

Reference	Coupled Model	Application	Scale	Domain	TB	TFG	VS	Vdz
[83] Maxwell and Miller (2005)	CLM	Model Development (CLM)	Column	Valdai, Russia			X	
[132] Tompson et al. (2005)	-	Subsurface Transport	Aquifer	Nevada Test Site				
[82] Maxwell et al. (2003)	-	Subsurface Transport	Aquifer	Forebay Aquifer				
[129] Tompson et al. (1999)	-	Subsurface Transport	Aquifer	Nevada Test Site				
[128] Tompson et al. (1998)	-	Subsurface Transport	Aquifer	LLNL Site				

Chapter 2

Getting Started

This chapter is an introduction to setting up and running PARFLOW. In § 2.1, we describe how to install PARFLOW. In § 2.2, we lead the user through a simple groundwater problem, supplied with the PARFLOW distribution. In § 2.3 we describe the solver options available for use with PARFLOW applications.

2.1 Installing ParFlow

PARFLOW is distributed as source code only and must be configured and built (compiled) on each machine on which you would like to run simulations. PARFLOW uses the CMake for configuration. Though we will cover some basic guidelines for the installation of PARFLOW here, many tips and tricks for building PARFLOW on a range of systems may be found at the PARFLOW blog: <http://parflow.blogspot.com>

For greater portability the PARFLOW build process allows separate configuration and compilation of the simulator and support tools. This separation allows easier porting to platforms where the architecture is different on the nodes and the front-end.

These instructions are for building PARFLOW on a range of serial and parallel Linux, Unix and OSX machines, including stand-alone single and multi-core to large parallel clusters. These instructions do *NOT* include compilation on Windows machines.

PARFLOW requires a Standard *ANSI C* and *FORTRAN 90/95* compiler to build code. Many versions of **C** and **Fortran** are compatible with PARFLOW (e.g. Intel or IBM). However, **GCC** and **gFortran**, available for free on almost every platform, are good options. They may be found at:

<http://gcc.gnu.org/>

and

<http://gcc.gnu.org/wiki/GFortran>

PARFLOW also requires TCL/TK version 8.0 (or higher). TCL/TK can be obtained from:

<http://www.tcl.tk/>

These three packages are often pre-installed on most computers and generally do not need to be installed by the user. The following steps are designed to take you through the process of installing PARFLOW from a source distribution. PARFLOW uses the **gnu** package **autoconf** to create a configuration file for building and installing the PARFLOW program.

1. Setup

We will use the `~/pfdir` directory as the root directory for the source, build and install directory in this user manual; you can use a different directory if you wish.

Decide where you wish to install Parflow and associated libraries. The following environment variable should be set up in your `.profile`, `.cshrc`, or other file. Set the environment variable `PARFLOW_DIR` to your chosen location (if you are using `bash` or a bourne syntax shell):

```
export PARFLOW_DIR=~/pfdir/install
```

If you are using a `csh` like shell you will need the following in your `.cshrc` file:

```
setenv PARFLOW_DIR ~/pfdir/install
```

2. Extract the source

Extract the source files from the distribution compressed tar file or by cloning the repository from the PARFLOW github repository. This example assumes the `parflow.tar.Z` file is in your home directory and you are building it in a directory `~/parflow`.

```
mkdir ~/pfdir
cd ~/pfdir
tar -xvf ../parflow.tar.Z
```

3. Build and install PARFLOW with CMAKE

This step builds the PARFLOW and associated PFTOOLS executables. A PARFLOW library is also built which can be used when PARFLOW is used as a component of another simulation (*e.g.* WRF).

CMAKE can be invoked using a command line only version `cmake` or terminal based GUI `ccmake`. Most of the example below will use the command line version since it is easier to directly show the command. The `ccmake` version will show all the variables you may set in an interactive GUI.

The following commands configure and build a sequential version of PARFLOW. You can control build options for PARFLOW in the CMAKE configure step by adding other options to that command-line. Note we build in a separate directory from the source. This keeps the source directory free of files created during the build. Going back to a clean state can be done by removing the build directory and starting over. This is fairly common CMAKE practice.

Here we only set the directory to install in the CMAKE command.

```
cd ~/pfdir
mkdir build
cd build
cmake ../parflow -DCMAKE_INSTALL_PREFIX=$(PARFLOW_DIR)
make
make install
```

For a list of *all* the CMAKE configure options, the easiest method is to use the `ccmake` command:

```
ccmake ../parflow -DCMAKE_INSTALL_PREFIX=$(PARFLOW_DIR)
```

PARFLOW defaults to building a sequential version; setting the `PARFLOW_AMPS_LAYER` variable is required to build a parallel version. The easiest way to use the MPI version is to ensure that the `mpicc` command is in your path and set the `PARFLOW_AMPS_LAYER` to “`mpi1`”. The `PARFLOW_AMPS_LAYER` variable controls *AMPS* which stands for *Another Message Passing System*. *AMPS* is a flexible message-passing adapter layer within PARFLOW that allows a common code core to be quickly and easily adapted to different parallel environments.

Here is an example of the simplest MPI configuration:

```
cmake ../parflow -DCMAKE_INSTALL_PREFIX=$(PARFLOW_DIR) -DPARFLOW_AMPS_LAYER=mpi1
```

TCL is required for building PARFLOW. If TCL is not installed in the system locations (`/usr` or `/usr/local`) you need to specify the path with the `-DTCL_TCLSH=$(PARFLOW_TCL_DIR)/bin/tclsh8.6` `cmake` option.

4. Running a sample problem

There is a test directory that contains not only example scripts of PARFLOW problems but the correct output for these scripts as well. This may be used to test the compilation process and verify that PARFLOW is installed correctly. If all went well a sample PARFLOW problem can be run using:

```
cd $PARFLOW_DIR
cd test
tclsh default_single.tcl 1 1 1
```

Note that `PARFLOW_DIR` must be set for this to work and it assumes `tclsh` is in your path. Make sure to use the same TCL as was used in the CMAKE configure. The entire suite of test cases may be run using CTEST to test a range of functionality in PARFLOW. This may be done by:

```
cd build
make test
```

5. Notes and other options:

PARFLOW may be compiled with a number of options using the configure script. Some common options are compiling CLM as in [83, 66] to compile with timing and optimization or to use a compiler other than `gcc`. To compile with CLM add `-DPARFLOW_HAVE_CLM=ON` to the configure line such as:

```
cmake ../parflow -DPARFLOW_AMPS_LAYER=mpi1 -DPARFLOW_HAVE_CLM=ON -DCMAKE_INSTALL_PREFIX=$(PARFLOW_DIR)
```

Other common options are:

- to include the CLM module: `-DPARFLOW_HAVE_CLM=ON`
- to include the *SILO* library which provides greater file output formats that are compatible with the *VisIt* rendering package and must first be compiled separately (see below): `-DSILO_ROOT=$(PARFLOW_SILO_DIR)`
- to include the *HDF5* library which provides greater file output formats: `-DHDF5_ROOT=$(PARFLOW_HDF5_DIR)`
- to include the *Hypre* library which provides greater solver flexibility and options and also needs to be downloaded and built separately: `-DHYPRE_ROOT=$(PARFLOW_HYPRE_DIR)`
- to write a single, undistributed PARFLOW binary file: `-DPARFLOW_AMPS_SEQUENTIAL_IO=true`
- to write timing information in the log file: `-DPARFLOW_ENABLE_TIMING=true`

All these options combined in the configure line would look like:

```

cd build
cmake ../parflow \
  -DPARFLOW_AMPS_LAYER=mpi1 \
  -DPARFLOW_HAVE_CLM=ON \
  -DSILO_ROOT=$(PARFLOW_SILO_DIR) \
  -DHDF5_ROOT=$(PARFLOW_HDF5_DIR) \
  -DHYPRE_ROOT=$(PARFLOW_HYPRE_DIR) \
  -DCMAKE_INSTALL_PREFIX=$(PARFLOW_DIR))
make
make install

```

To enable detailed timing of the performance of several different components within PARFLOW use the `-enable-timing` option. The standard `CMAKE_BUILD_TYPE` variable controls if a debug or release (with optimization) is built. `-DCMAKE_BUILD_TYPE=RELEASE` will build a release version.

It is often desirable to use different C and F90/95 compilers (such as *Intel* or *Portland Group*) to generate optimized code for specific architectures or simply personal preference. To change compilers, set the `CC`, `FC` and `F77` variables (these may include a path too). For example, to change to the *Intel* compilers in the `bash` shell:

```

export CC=icc
export FC=ifort
export F77=ifort

```

6. Build and install PARFLOW with GNU autoconf

In addition configuration with `cmake`, PARFLOW has deprecated support for GNU `autoconf`. GNU `autoconf` support will be maintained while the `cmake` support is fully tested. Support will be removed in a future release. Please use `cmake` and report bugs.

This step builds the PARFLOW library and executable that runs on a serial or parallel machine. The library is used when PARFLOW is used as a component of another simulation (*e.g.* WRF).

```

cd $PARFLOW_DIR
cd pfsimulator
./configure --prefix=$PARFLOW_DIR --with-amps=mpi1
make
make install

```

This will build a parallel version of `/parflow` using the MPI1 libraries but no other options (a very basic installation with few features commonly used). You can control build options for `/parflow` in the configure step by adding other options to that command-line. For a list of *all* the configure options, use

```
./configure --help
```

to list them. Note that PARFLOW defaults to building a sequential version so `-with-amps` is needed when building for a parallel computer. You can explicitly specify the path to the MPI to use with the `-with-mpi` option to configure. This controls *AMPS* which stands for *Another Message Passing Sytem*. *AMPS* is a flexible message-passing layer within PARFLOW that allows a common code core to be quickly and easily adapted to different parallel environments.

7. Build and install pftools

pftools is a package of utilities and a TCL library that is used to setup and postprocess Parflow files. The input files to PARFLOW are TCL scripts so TCL must be installed on the system.

The first command will build PARFLOW and the bundled tools and install them in the `$PARFLOW_DIR` directory. The second command will build and install the documentation. A bare-bones configure and build looks like:

```
cd $PARFLOW_DIR
cd pftools
./configure --prefix=$PARFLOW_DIR --with-amps=mpi1
make
make install
make doc_install
```

Note that **pftools** is *NOT* parallel but some options for how files are written are based on the communication layer so **pftools** needs to have the same options that were used to build the PARFLOW library.

If TCL is not installed in the system locations (`/usr` or `/usr/local`) you need to specify the path with the `-with-tcl=<PATH>` configure option.

See `./configure -help` for additional configure options for **pftools**.

8. Running a sample problem

There is a test directory that contains not only example scripts of PARFLOW problems but the correct output for these scripts as well. This may be used to test the compilation process and verify that PARFLOW is installed correctly. If all went well a sample PARFLOW problem can be run using:

```
cd $PARFLOW_DIR
cd test
tclsh default_single.tcl 1 1 1
```

Note that `PARFLOW_DIR` must be set for this to work and it assumes `tclsh` is in your path. Make sure to use the same TCL as was used in the **pftools** configure. The entire suite of test cases may be run at once to test a range of functionality in PARFLOW. This may be done by:

```
cd $PARFLOW_DIR
cd test
make check
```

9. Notes and other options:

PARFLOW may be compiled with a number of options using the configure script. Some common options are compiling CLM as in [83, 66] to compile with timing and optimization or to use a compiler other than `gcc`. To compile with CLM add `-with-clm` to the configure line such as:

```
./configure --prefix=$PARFLOW_DIR --with-amps=mpi1 --with-clm
```

Common options are:

- to include the CLM module: `-with-clm`
- to include the *Silo* library which provides greater file output formats that are compatible with the *VisIt* rendering package and must first be compiled separately (see below): `-with-silo=$SILO_DIR`

- to include the *Hypre* library which provides greater solver flexibility and options and also needs to be downloaded and built separately: `-with-hypre=$HYPRE_DIR`
- to write a single, undistributed PARFLOW binary file: `-with-amps-sequential-io`
- to write timing information in the log file: `-enable-timing`

All these options combined in the configure line would look like:

```
cd $PARFLOW_DIR
cd pfsimulator
./configure --prefix=$PARFLOW_DIR --with-amps=mpi1 --with-clm
--enable-timing --with-silo=$SILO_DIR --with-hypre=$HYPRE_DIR
--with-amps-sequential-io
make
make install
```

`pftools` needs to be compiled and built with compatible options that correspond to PARFLOW. For the options above, `pftools` would be built as follows:

```
cd $PARFLOW_DIR
cd pftools
./configure --prefix=$PARFLOW_DIR --with-amps=mpi1 --with-silo=$SILO_DIR
--with-amps-sequential-io

make
make install
make doc_install
```

Note that CLM and *Hypre* are not used by `pftools` and those options do not need to be included, however the file formats (*SILO* and single file PFB) are very important and need to match exactly what is specified in `pfsimulator`.

To enable detailed timing of the performance of several different components within PARFLOW use the `-enable-timing` option. To use compiler optimizations use the `-enable-opt=STRING` where the `=STRING` is an optional flag to specify the level and type of optimization.

IMPORTANT NOTE: Optimization and debugging are controlled independent of one another. So to compile with optimization and no debugging you need to specify both `-enable-opt=STRING` AND `-disable-debug`.

It is often desirable to use different C and F90/95 compilers (such as *Intel* or *Portland Group*) to match hardware specifics, for performance reasons or simply personal preference. To change compilers, set the `CC`, `FC` and `F77` variables (these may include a path too). For example, to change to the *Intel* compilers in c-shell:

```
setenv CC icc
setenv FC ifort
setenv F77 ifort
```

2.1.1 External Libraries

Many of the features of PARFLOW use a file structure called Silo. Silo is a free, open-source, format detailed at:

<https://wci.llnl.gov/codes/silo/>

Support for Silo is integrated into PARFLOW but the Silo libraries must be built separately and then linked into PARFLOW during the build and configure process. This may be done using the `-with-silo=PATH` where the PATH is the location of the Silo libraries.

Some features of PARFLOW need to call the solver package *Hypre* externally. These include the command options **PFMG**, **SMG** and **PFMGOctree**. *Hypre* is a free, open-source, library detailed at:

<https://computation.llnl.gov/casc/hypre/software.html>

Support for *Hypre* 2.4.0b or later is integrated into PARFLOW but the libraries must be built separately and then linked into PARFLOW during the build and configure process. This may be done using the `-with-hypre=PATH` where the PATH is the location of the *Hypre* libraries.

2.2 Running the Sample Problem

Here, we assume that PARFLOW is already built. The following steps will allow you to run a simple test problem supplied with the distribution.

1. We first create a directory in which to run the problem, then copy into it some supplied default input files. So, do the following anywhere in your \$HOME directory:

```
mkdir foo
cd foo
cp $PARFLOW_DIR/examples/default_single.tcl .
chmod 640 *
```

We used the directory name `foo` above; you may use any name you wish¹. The last line changes the permissions of the files so that you may write to them.

2. Run PARFLOW using the `pftcl` file as a TCL script

```
tclsh default_single.tcl
```

You have now successfully run a simple PARFLOW problem. For more information on running PARFLOW, see § 3.2.

2.3 ParFlow Solvers

PARFLOW can operate using a number of different solvers. Two of these solvers, IMPES (running in single-phase, fully-saturated mode, not multiphase) and RICHARDS (running in variably-saturated mode, not multiphase, with the options of land surface processes and coupled overland flow) are detailed below. This is

¹We use *foo* and *bar* just as placeholders for whatever directory you wish you use, see also <http://en.wikipedia.org/wiki/Foobar>

a brief summary of solver settings used to simulate under three sets of conditions, fully-saturated, variably-saturated and variably-saturated with overland flow. A complete, detailed explanation of the solver parameters for ParFlow may be found later in this manual. To simulate fully saturated, steady-state conditions set the solver to IMPES, an example is given below. This is also the default solver in ParFlow, so if no solver is specified the code solves using IMPES.

```
pfset Solver          Impes
```

To simulate variably-saturated, transient conditions, using Richards' equation, variably/fully saturated, transient with compressible storage set the solver to RICHARDS. An example is below. This is also the solver used to simulate surface flow or coupled surface-subsurface flow.

```
pfset Solver          Richards
```

To simulate overland flow, using the kinematic wave approximation to the shallow-wave equations, set the solver to RICHARDS and set the upper patch boundary condition for the domain geometry to OverlandFlow, an example is below. This simulates overland flow, independently or coupled to Richards' Equation as detailed in [65]. The overland flow boundary condition can simulate both uniform and spatially-distributed sources, reading a distribution of fluxes from a binary file in the latter case.

```
pfset Patch.z-upper.BCPressure.Type OverlandFlow
```

For this case, the solver needs to be set to RICHARDS:

```
pfset Solver Richards
```

PARFLOW may also be coupled with the land surface model CLM [27]. This version of CLM has been extensively modified to be called from within PARFLOW as a subroutine, to support parallel infrastructure including I/O and most importantly with modified physics to support coupled operation to best utilize the integrated hydrology in PARFLOW [83, 66]. To couple CLM into PARFLOW first the `-with-clm` option is needed in the `./configure` command as indicated in § 2.1. Second, the CLM module needs to be called from within PARFLOW, this is done using the following solver key:

```
pfset Solver.LSM CLM
```

Note that this key is used to call CLM from within the nonlinear solver time loop and requires that the solver be set to RICHARDS to work. Note also that this key defaults to *not* call CLM so if this line is omitted CLM will not be called from within PARFLOW even if compiled and linked. Currently, CLM gets some of its information from PARFLOW such as grid, topology and discretization, but also has some of its own input files for land cover, land cover types and atmospheric forcing.

Chapter 3

The ParFlow System

The PARFLOW system is still evolving, but here we discuss how to define the problem in § 3.1, how to run PARFLOW in § 3.2, and restart a simulation in § 3.3. We also cover options for visualizing the results in § 3.4 and summarize the contents of a directory of test problems provided with PARFLOW in § 3.5. Finally in § 3.6 we walk through two PARFLOW input scripts in detail.

The reader is also referred to § 4 for a detailed listing of the of functions for manipulating PARFLOW data.

3.1 Defining the Problem

There are many ways to define a problem in PARFLOW, here we summarize the general approach for defining a domain (§ 3.1.1) and simulating a real watershed (§ 3.1.2).

In all cases the “main” PARFLOW input file is the `.tcl` file. This input file is a TCL script with some special routines to create a database which is used as the input for PARFLOW. See § 6.1 for details on the format of this file. The input values into PARFLOW are defined by a key/value pair. For each key you provide the associated value using the `pfset` command inside the input script.

Since the input file is a TCL script you can use any feature of TCL to define the problem. This manual will make no effort to teach TCL so refer to one of the available TCL manuals for more information (“Practical Programming in TCL and TK” by Brent Welch [134] is a good starting point). This is NOT required, you can get along fine without understanding TCL/TK.

Looking at the example programs in the `test` directory (§ 3.5) and going through the annotated input scripts included in this manual (§ 3.6) is one of the best ways to understand what a PARFLOW input file looks like.

3.1.1 Basic Domain Definition

ParFlow can handle complex geometries and defining the problem may involve several steps. Users can specify simple box domains directly in the `tcl` script. If a more complicated domain is required, the user may convert geometries into the `.pfsol` file format (§ 6.6) using the appropriate PFTOOLS conversion utility (§ 4). Alternatively, the topography can be specified using `.pfb` files of the slopes in the x and y directions.

Regardless of the approach the user must set the computational grid within the `.pfb` script as follows:

```
#-----  
# Computational Grid
```

```
#-----
pfset ComputationalGrid.Lower.X      -10.0
pfset ComputationalGrid.Lower.Y      10.0
pfset ComputationalGrid.Lower.Z      1.0

pfset ComputationalGrid.DX           8.89
pfset ComputationalGrid.DY           10.67
pfset ComputationalGrid.DZ           1.0

pfset ComputationalGrid.NX           18
pfset ComputationalGrid.NY           15
pfset ComputationalGrid.NZ           8
```

The value is normally a single string, double, or integer. In some cases, in particular for a list of names, you need to supply a space separated sequence. This can be done using either a double quote or braces.

```
pfset Geom.domain.Patches "left right front back bottom top"

pfset Geom.domain.Patches {left right front back bottom top}
```

For commands longer than a single line, the TCL continuation character can be used,

```
pfset Geom.domain.Patches "very_long_name_1 very_long_name_2 very_long_name_3 \
    very_long_name_4 very_long_name_5 very_long_name_6"
```

3.1.2 Setting Up a Real Domain

This section provides a brief outline of a sample workflow for setup PARFLOW CLM simulation of a real domain. Of course there are many ways to accomplish this and users are encouraged to develop a workflow that works for them.

This example assumes that you are running with PARFLOW CLM and it uses slope files and an indicator file to define the topography and geologic units of the domain. An alternate approach would be to define geometries by building a `.pfsol` file (§ 6.6) using the appropriate PFTOOLS conversion utility (§ 4).

The general approach is as follows:

1. Gather input datasets to define the domain. First decide the resolution that you would like to simulate at. Then gather the following datasets at the appropriate resolution for your domain:
 - (a) Elevation (DEM)
 - (b) Soil data for the near surface layers
 - (c) Geologic maps for the deeper subsurface
 - (d) Land Cover
2. Create consistent gridded layers that are all clipped to your domain and have the same number of grid cells
3. Convert gridded files to `.pfb` (§ 6.3). One way to accomplish this is by reformatting the gridded outputs to the correct PARFLOW `.sa` order (§ 6.8) and to convert the `.sa` file to `.pfb` using the conversion tools (see § 4.3 Example 1). If you have an elevation file in `.pfb` format, you may wish to preserve

it as provenance for the slopes and for use in post-processing tools. You may point ParFlow to the elevation:

```
pfset TopoSlopes.Elevation.FileName "elevation.pfb"
```

4. Calculate slopes in the x and y directions from the elevation dataset. This can be done with the built in tools as shown in § 4.3 Example 5. In most cases some additional processing of the DEM will be required to ensure that the drainage patterns are correct. To check this you can run a “parking lot test” by setting the permeability of surface to almost zero and adding a flux to the top surface. If the results from this test don’t look right (i.e. your runoff patterns don’t match what you expect) you will need to go back and modify your DEM. The built in PARFLOW tools pitfill and flatfill can be used to address some issues. (These tools are also shown in § 4.3 Example 5).
5. Create an indicator file for the subsurface. The indicator file is a 3D **.pfb** file with the same dimensions as your domain that has an integer for every cell designating which unit it belongs to. The units you define will correspond to the soil types and geologic units from your input datasets.
6. Determine the hydrologic properties for each of the subsurface units defined in the indicator file. You will need: Permeability, specific storage, porosity and vanGenuchten parameters.
7. At this point you are ready to run a PARFLOW model without CLM and if you don’t need to include the land surface model in your simulations you can ignore the following steps. Either way, at this point it is advisable to run a “spinup” simulation to initialize the water table. There are several ways to approach this. One way is to start with the water table at a constant depth and run for a long time with a constant recharge forcing until the water table reaches a steady state. There are some additional key for spinup runs that are provided in § 6.1.35.
8. Convert land cover classifications to the IGBP¹ land cover classes that are used in CLM.
 1. Evergreen Needleleaf Forest
 2. Evergreen Broadleaf Forest
 3. Deciduous Needleleaf Forest
 4. Deciduous Broadleaf Forest
 5. Mixed Forests
 6. Closed Shrublands
 7. Open Shrublands
 8. Woody Savannas
 9. Savannas
 10. Grasslands
 11. Permanent Wetlands
 12. Croplands
 13. Urban and Built-Up
 14. Cropland/Natural Vegetation Mosaic

¹<http://www.igbp.net>

15. Snow and Ice
 16. Barren or Sparsely Vegetated
 17. Water
 18. Wooded Tundra
9. Create a CLM vegm file that designates the land cover fractions for every cell (Refer to the `clm input` directory in the Washita Example for an sample of what a `vegm` file should look like).
 10. Create a CLM driver file to set the parameters for the CLM model (Refer to the `clm input` directory in the Washita Example for a sample of a CLM driver file).
 11. Assemble meteorological forcing data for your domain. CLM uses Greenwich Mean Time (GMT), not local time. The year, date and hour (in GMT) that the forcing begins should match the values in `drv_clmin.dat`. CLM requires the following variables (also described on p. 137):
 - DSWR: Visible or short-wave radiation [W/m^2].
 - DLWR: Long wave radiation [W/m^2]
 - APCP: Precipitation [mm/s]
 - Temp: Air Temperature [K]
 - UGRD: East-west wind speed [m/s]
 - VGRD: South-to-North wind speed [m/s]
 - Press: Atmospheric pressure [pa]
 - SPFH: Specific humidity [kg/kg]

If you choose to do spatially heterogenous forcings you will need to generate separate files for each variable. The files should be formatted in the standard ParFlow format with the third (i.e. z dimension) as time. If you are doing hourly simulations it is standard practice to put 24 hours in one file, but you can decide how many time steps per file. For an example of heterogenous forcing files refer to the NLDAS directory in the Washita Example)

Alternatively, if you would like to force the model with spatially homogenous forcings, then a single file can be provided where each variable is a column and rows designate time steps.

12. Run your simulation!

3.2 Running ParFlow

Once the problem input is defined, you need to add a few things to the script to make it execute PARFLOW. First you need to add the TCL commands to load the PARFLOW command package.

```
#
# Import the ParFlow TCL package
#
lappend auto_path $env(PARFLOW_DIR)/bin
package require parflow
namespace import Parflow::*
```

This loads the `pfset` and other PARFLOW commands into the TCL shell.

Since this is a script you need to actually run PARFLOW. These are normally the last lines of the input script.

```
#-----
# Run and Unload the ParFlow output files
#-----
pfrun default_single
pfundist default_single
```

The `pfrun` command runs PARFLOW with the database as it exists at that point in the file. The argument is the name to give to the output files (which will normally be the same as the name of the script). Advanced users can set up multiple problems within the input script by using different output names.

The `pfundist` command takes the output files from the PARFLOW run and undistributes them. PARFLOW uses a virtual file system which allows files to be distributed across the processors. The `pfundist` takes these files and collapses them into a single file. On some machines if you don't do the `pfundist` you will see many files after the run. Each of these contains the output from a single node; before attempting using them you should undistribute them.

Since the input file is a TCL script run it using TCL:

```
tclsh runname.tcl
```

NOTE: Make sure you are using TCL 8.0 or later. The script will not work with earlier releases.

One output file of particular interest is the `<run name>.out.log` file. This file contains information about the run such as number of processes used, convergence history of algorithms, timings and MFLOP rates. For Richards' equation problems (including overland flow) the `<run name>.out.kinsol.log` file contains the nonlinear convergence information for each timestep. Additionally, the `<run name>.out.tx` contains all information routed to `standard out` of the machine you are running on and often contains error messages and other control information.

3.3 Restarting a Run

A PARFLOW run may need to be restarted because either a system time limit has been reached, PARFLOW has been prematurely terminated or the user specifically sets up a problem to run in segments. In order to restart a run the user needs to know the conditions under which PARFLOW stopped. If PARFLOW was prematurely terminated then the user must examine the output files from the last "timed dump" to see if they are complete. If not then those data files should be discarded and the output files from the next to last "timed dump" will be used in the restarting procedure. As an important note, if any set of "timed dump" files are deleted remember to also delete corresponding lines in the well output file or recombining the well output files from the individual segments afterwards will be difficult. It is not necessary to delete lines from the log file as you will only be noting information from it. To summarize, make sure all the important output data files are complete, accurate and consistent with each other.

Given a set of complete, consistent output files - to restart a run follow this procedure :

1. Note the important information for restarting :

- Write down the dump sequence number for the last collection of "timed dump" data.
- Examine the log file to find out what real time that "timed dump" data was written out at and write it down.

2. Prepare input data files from output data files :
 - Take the last pressure output file before the restart with the sequence number from above and format them for regular input using the keys detailed in § 6.1.28 and possibly the `pfdist` utility in the input script.
3. Change the Main Input File § 6.1 :
 - Edit the `.tcl` file (you may want to save the old one) and utilize the pressure initial condition input file option (as referenced above) to specify the input files you created above as initial conditions for concentrations.
4. Restart the run :
 - Utilizing an editor recreate all the input parameters used in the run except for the following two items :
 - Use the dump sequence number from step 1 as the `start_count`.
 - Use the real time that the dump occurred at from step 1 as the `start_time`.
 - To restart with CLM, use the `Solver.CLM.IstepStart` key described in § 6.1.36 with a value equal to the dump sequence plus one. Make sure this corresponds to changes to `drv_clmin.dat`.

3.4 Visualizing Output

While PARFLOW does not have any visualization capabilities built-in, there are a number flexible, free options. Probably the best option is to use *VisIt*. *VisIt* is a powerful, free, open-source, rendering environment. It is multiplatform and may be downloaded directly from: <https://visit.llnl.gov/>
 The most flexible option for using *VisIt* to view PARFLOW output is to write files using the *SILO* format, which is available either as a direct output option (described in § 6.1.32) or a conversion option using *pftools*. Many other output conversion options exist as described in § 4 and this allows PARFLOW output to be converted into formats used by almost all visualization software.

3.5 Directory of Test Cases

PARFLOW comes with a directory containing a few simple input files for use as templates in making new files and for use in testing the code. These files sit in the `/test` directory described earlier. This section gives a brief description of the problems in this directory.

`crater2D.tcl` An example of a two-dimensional, variably-saturated crater infiltration problem with time-varying boundary conditions. It uses the solid file `crater2D.pfsol`.

`default_richards.tcl` The default variably-saturated Richards' Equation simulation test script.

`default_single.tcl` The default parflow, single-processor, fully-saturated test script.

`forsyth2.tcl` An example two-dimensional, variably-saturated infiltration problem with layers of different hydraulic properties. It runs problem 2 in [42] and uses the solid file `fors2_hf.pfsol`.

- harvey.flow.tcl** An example from [85] for the Cape Cod bacterial injection site. This example is a three-dimensional, fully-saturated flow problem with spatially heterogeneous media (using a correlated, random field approach). It also provides examples of how tcl/tk scripts may be used in conjunction with ParFlow to loop iteratively or to run other scripts or programs. It uses the input text file **stats4.txt**. This input script is fully detailed in § 3.6
- default_overland.tcl** An overland flow boundary condition test and example script based loosely on the V-catchment problem in [65]. There are options provided to expand this problem into other overland flow-type, transient boundary-type problems included in the file as well.
- LW_var_dz_spinup.tcl** An example that uses the Little Washita domain to demonstrate a steady-state spinup initialization using P-E forcing. It also demonstrates the variable dz keys.
- LW_var_dz.tcl** An example that uses the Little Washita domain to demonstrate surface flow network development. It also uses the variable dz keys.
- Evap_Trans_test.tcl** An example that modifies the **default_overland.tcl** to demonstrate steady-state external flux .pfb files.
- overland_flux.tcl** An example that modifies the **default_overland.tcl** to demonstrate transient external flux .pfb files.
- /clm/clm.tcl** An example of how to use PARFLOW coupled to clm. This directory also includes clm-specific input. Note: this problem will only run if **-with-clm** flag is used during the configure and build process.
- water_balance_x.tcl** and **water_balance_y.tcl**. An overland flow example script that uses the water-balance routines integrated into **pftools**. These two problems are based on simple overland flow conditions with slopes primarily in the x or y-directions. Note: this problem only will run if the Silo file capability is used, that is a **-with-silo=PATH** flag is used during the configure and build process.
- pfmg.tcl** and **pfmg_octree.tcl**. Tests of the external *Hypre* preconditioner options. Note: this problem only will run if the *Hypre* capability is used, that is a **-with-hypre=PATH** flag is used during the configure and build process.
- test_x.tcl** A test problem for the Richards' solver that compares output to an analytical solution.
- /washita/tcl_scripts/LW_Test.tcl** A three day simulation of the Little Washita domain using PARFLOW CLM with 3D forcings.

3.6 Annotated Input Scripts

This section contains two annotated input scripts:

- § 3.6.1 contains the harvey flow example (**harvey.flow.tcl**) which is an idealized domain with a heterogenous subsurface. The example also demonstrates how to generate multiple realizations of the subsurface and add pumping wells.
- § 3.6.2 contains the Little Washita example (**LW_Test.tcl**) which simulates a moderately sized (41km by 41km) real domain using PARFLOW CLM with 3D meteorological forcings.

To run PARFLOW, you use a script written in Tcl/Tk. This script has a lot of flexibility, as it is somewhere in between a program and a user interface. The tcl script gives PARFLOW the data it requires (or tells PARFLOW where to find or read in that data) and also tells PARFLOW to run.

To run the simulation:

1. make any modifications to the tcl input script (and give a new name, if you want to)
2. save the tcl script
3. For Linux/Unix/OSX: invoke the script from the command line using the tcl-shell, this looks like:
`>tclsh filename.tcl`
4. Wait patiently for the command prompt to return (Linux/Unix/OSX) indicating that PARFLOW has finished. Intermediate files are written as the simulation runs, however there is no other indication that PARFLOW is running.

To modify a tcl script, you right-click and select edit from the menu. If you select open, you will run the script.

Note: The units for **K** (m/d, usually) are critical to the entire construction. These length and time units for **K** set the units for all other variables (input or generated, throughout the entire simulation) in the simulation. PARFLOW can set to solve using hydraulic conductivity by literally setting density, viscosity and gravity to one (as is done in the script below). This means the pressure units are in length (meters), so pressure is now so-called pressure-head.

3.6.1 Harvey Flow Example

This tutorial matches the `harvey_flow.tcl` file found in the `/test` directory. This example is directly from [85]. This example demonstrates how to set up and run a fully saturated flow problem with heterogeneous hydraulic conductivity using the turning bands approach [127]. Given statistical parameters describing the geology of your site, this script can be easily modified to make as many realizations of the subsurface as you like, each different and yet having the same statistical parameters, useful for a Monte Carlo simulation. This example is the basis for several fully-saturated PARFLOW applications [119, 120, 118, 6, 7, 26].

When the script runs, it creates a new directory named `/flow` right in the directory where the tcl script is stored. PARFLOW then puts all its output in `/flow`. Of course, you can change the name and location of this output directory by modifying the tcl script that runs PARFLOW.

Now for the tcl script:

```
#
# Import the ParFlow TCL package
#
```

These first three lines are what link PARFLOW and the tcl script, thus allowing you to use a set of commands seen later, such as `pfset`, etc.

```
lappend auto_path $env(PARFLOW_DIR)/bin
package require parflow
namespace import Parflow::*
```

```
#-----
# File input version number
#-----
pfset FileVersion 4
```

These next lines set the parallel process topology. The domain is divided in x, y and z by P , Q and R . The total number of processors is $P*Q*R$ (*see* § 6.1.2).

```
#-----
# Process Topology
#-----

pfset Process.Topology.P      1
pfset Process.Topology.Q      1
pfset Process.Topology.R      1
```

Next we set up the computational grid (*see* § 3.1 and § 6.1.3).

```
#-----
# Computational Grid
#-----

Locate the origin in the domain.

pfset ComputationalGrid.Lower.X    0.0
pfset ComputationalGrid.Lower.Y    0.0
pfset ComputationalGrid.Lower.Z    0.0
```

Define the size of the domain grid block. Length units, same as those on hydraulic conductivity.

```
pfset ComputationalGrid.DX    0.34
pfset ComputationalGrid.DY    0.34
pfset ComputationalGrid.DZ    0.038
```

Define the number of grid blocks in the domain.

```
pfset ComputationalGrid.NX    50
pfset ComputationalGrid.NY    30
pfset ComputationalGrid.NZ    100
```

This next piece is comparable to a pre-declaration of variables. These will be areas in our domain geometry. The regions themselves will be defined later. You must always have one that is the name of your entire domain. If you want subsections within your domain, you may declare these as well. For Cape Cod, we have the entire domain, and also the 2 (upper and lower) permeability zones in the aquifer.

```
#-----
# The Names of the GeomInputs
#-----

pfset GeomInput.Names "domain_input upper_aquifer_input lower_aquifer_input"
```

Now you characterize your domain that you just pre-declared to be a **box** (*see* § 6.1.4), and you also give it a name, **domain**.

```
#-----
# Domain Geometry Input
#-----

pfset GeomInput.domain_input.InputType    Box
pfset GeomInput.domain_input.GeoName     domain
```

Here, you set the limits in space for your entire domain. The span from `Lower.X` to `Upper.X` will be equal to the product of `ComputationalGrid.DX` times `ComputationalGrid.NX`. Same for `Y` and `Z` (i.e. the number of grid elements times size of the grid element has to equal the size of the grid in each dimension). The `Patches` key assigns names to the outside edges, because the domain is the limit of the problem in space.

```
#-----
# Domain Geometry
#-----
pfset Geom.domain.Lower.X      0.0
pfset Geom.domain.Lower.Y      0.0
pfset Geom.domain.Lower.Z      0.0

pfset Geom.domain.Upper.X      17.0
pfset Geom.domain.Upper.Y      10.2
pfset Geom.domain.Upper.Z      3.8

pfset Geom.domain.Patches "left right front back bottom top"
```

Just like domain geometry, you also set the limits in space for the individual components (upper and lower, as defined in the Names of `GeomInputs` pre-declaration). There are no patches for these geometries as they are internal to the domain.

```
#-----
# Upper Aquifer Geometry Input
#-----
pfset GeomInput.upper_aquifer_input.InputType      Box
pfset GeomInput.upper_aquifer_input.GeoName        upper_aquifer

#-----
# Upper Aquifer Geometry
#-----
pfset Geom.upper_aquifer.Lower.X                    0.0
pfset Geom.upper_aquifer.Lower.Y                    0.0
pfset Geom.upper_aquifer.Lower.Z                    1.5

pfset Geom.upper_aquifer.Upper.X                    17.0
pfset Geom.upper_aquifer.Upper.Y                    10.2
pfset Geom.upper_aquifer.Upper.Z                    1.5

#-----
# Lower Aquifer Geometry Input
#-----
pfset GeomInput.lower_aquifer_input.InputType      Box
pfset GeomInput.lower_aquifer_input.GeoName        lower_aquifer

#-----
# Lower Aquifer Geometry
#-----
```

```

pfset Geom.lower_aquifer.Lower.X      0.0
pfset Geom.lower_aquifer.Lower.Y      0.0
pfset Geom.lower_aquifer.Lower.Z      0.0

pfset Geom.lower_aquifer.Upper.X      17.0
pfset Geom.lower_aquifer.Upper.Y      10.2
pfset Geom.lower_aquifer.Upper.Z      1.5

```

Now you add permeability data to the domain sections defined above (§ 6.1.11). You can reassign values simply by re-stating them – there is no need to comment out or delete the previous version – the final statement is the only one that counts.

```

#-----
# Perm
#-----

```

Name the permeability regions you will describe.

```

pfset Geom.Perm.Names "upper_aquifer lower_aquifer"

```

You can set, for example homogeneous, constant permeability, or you can generate a random field that meets your statistical requirements. To define a constant permeability for the entire domain:

```

#pfset Geom.domain.Perm.Type      Constant
#pfset Geom.domain.Perm.Value      4.0

```

However, for Cape Cod, we did not want a constant permeability field, so we instead generated a random permeability field meeting our statistical parameters for each the upper and lower zones. Third from the bottom is the *Seed*. This is a random starting point to generate the K field. Pick any large *ODD* number. First we do something tricky with *Tcl/TK*. We use the native commands within *tcl* to open a text file and read in locally set variables. Note we use *set* here and not *pfset*. One is a native *tcl* command, the other a *PARFLOW*-specific command. For this problem, we are linking the parameter estimation code, *PEST* to *PARFLOW*. *PEST* writes out the *ascii* file *stats4.txt* (also located in the */test* directory) as the result of a calibration run. Since we are not coupled to *PEST* in this example, we just read in the file and use the values to assign statistical properties.

```

# we open a file, in this case from PEST to set upper and lower # kg and sigma
#
set fileId [open stats4.txt r 0600]
set kgu [gets $fileId]
set varu [gets $fileId]
set kgl [gets $fileId]
set varl [gets $fileId]
close $fileId

```

Now we set the heterogeneous parameters for the Upper and Lower aquifers (*see* § 6.1.11). Note the special section at the very end of this block where we reset the geometric mean and standard deviation to our values we read in from a file. **Note:** *PARFLOW* uses *Standard Deviation* not *Variance*.

```

pfset Geom.upper_aquifer.Perm.Type "TurnBands"
pfset Geom.upper_aquifer.Perm.LambdaX 3.60
pfset Geom.upper_aquifer.Perm.LambdaY 3.60
pfset Geom.upper_aquifer.Perm.LambdaZ 0.19
pfset Geom.upper_aquifer.Perm.GeomMean 112.00

pfset Geom.upper_aquifer.Perm.Sigma 1.0
pfset Geom.upper_aquifer.Perm.Sigma 0.48989794
pfset Geom.upper_aquifer.Perm.NumLines 150
pfset Geom.upper_aquifer.Perm.RZeta 5.0
pfset Geom.upper_aquifer.Perm.KMax 100.0
pfset Geom.upper_aquifer.Perm.DelK 0.2
pfset Geom.upper_aquifer.Perm.Seed 33333
pfset Geom.upper_aquifer.Perm.LogNormal Log
pfset Geom.upper_aquifer.Perm.StratType Bottom
pfset Geom.lower_aquifer.Perm.Type "TurnBands"
pfset Geom.lower_aquifer.Perm.LambdaX 3.60
pfset Geom.lower_aquifer.Perm.LambdaY 3.60
pfset Geom.lower_aquifer.Perm.LambdaZ 0.19

pfset Geom.lower_aquifer.Perm.GeomMean 77.0
pfset Geom.lower_aquifer.Perm.Sigma 1.0
pfset Geom.lower_aquifer.Perm.Sigma 0.48989794
pfset Geom.lower_aquifer.Perm.NumLines 150
pfset Geom.lower_aquifer.Perm.RZeta 5.0
pfset Geom.lower_aquifer.Perm.KMax 100.0
pfset Geom.lower_aquifer.Perm.DelK 0.2
pfset Geom.lower_aquifer.Perm.Seed 33333
pfset Geom.lower_aquifer.Perm.LogNormal Log
pfset Geom.lower_aquifer.Perm.StratType Bottom

#pfset lower aqu and upper aq stats to pest/read in values

pfset Geom.upper_aquifer.Perm.GeomMean $kgu
pfset Geom.upper_aquifer.Perm.Sigma $varu

pfset Geom.lower_aquifer.Perm.GeomMean $kg1
pfset Geom.lower_aquifer.Perm.Sigma $var1

```

The following section allows you to specify the permeability tensor. In the case below, permeability is symmetric in all directions (x, y, and z) and therefore each is set to 1.0.

```

pfset Perm.TensorType TensorByGeom

pfset Geom.Perm.TensorByGeom.Names "domain"

pfset Geom.domain.Perm.TensorValX 1.0
pfset Geom.domain.Perm.TensorValY 1.0
pfset Geom.domain.Perm.TensorValZ 1.0

```

Next we set the specific storage, though this is not used in the IMPES/steady-state calculation.

```
#-----
# Specific Storage
#-----
# specific storage does not figure into the impes (fully sat)
# case but we still need a key for it

pfset SpecificStorage.Type          Constant
pfset SpecificStorage.GeomNames     ""
pfset Geom.domain.SpecificStorage.Value 1.0e-4
```

PARFLOW has the capability to deal with a multiphase system, but we only have one (water) at Cape Cod. As we stated earlier, we set density and viscosity artificially (and later gravity) both to 1.0. Again, this is merely a trick to solve for hydraulic conductivity and pressure head. If you were to set density and viscosity to their true values, the code would calculate k (permeability). By using the *normalized* values instead, you effectively embed the conversion of k to K (hydraulic conductivity). So this way, we get hydraulic conductivity, which is what we want for this problem.

```
#-----
# Phases
#-----

pfset Phase.Names "water"

pfset Phase.water.Density.Type Constant
pfset Phase.water.Density.Value 1.0

pfset Phase.water.Viscosity.Type Constant
pfset Phase.water.Viscosity.Value 1.0
```

We will not use the PARFLOW grid based transport scheme. We will then leave contaminants blank because we will use a different code to model (virus, tracer) contamination.

```
#-----
# Contaminants
#-----
pfset Contaminants.Names ""
```

As with density and viscosity, gravity is normalized here. If we used the true value (in the $[L]$ and $[T]$ units of hydraulic conductivity) the code would be calculating permeability. Instead, we normalize so that the code calculates hydraulic conductivity.

```
#-----
# Gravity
#-----

pfset Gravity 1.0

#-----
```

```
# Setup timing info
```

```
#-----
```

This basic time unit of 1.0 is used for transient boundary and well conditions. We are not using those features in this example.

```
pfset TimingInfo.BaseUnit 1.0
```

Cape Cod is a steady state problem, so these timing features are again unused, but need to be included.

```
pfset TimingInfo.StartCount -1
pfset TimingInfo.StartTime 0.0
pfset TimingInfo.StopTime 0.0
```

Set the `dump` interval to -1 to report info at the end of every calculation, which in this case is only when steady state has been reached.

```
pfset TimingInfo.DumpInterval -1
```

Next, we assign the porosity (*see* § 6.1.12). For the Cape Cod, the porosity is 0.39.

```
#-----
```

```
# Porosity
```

```
#-----
```

```
pfset Geom.Porosity.GeomNames domain
```

```
pfset Geom.domain.Porosity.Type Constant
pfset Geom.domain.Porosity.Value 0.390
```

Having defined the geometry of our problem before and named it `domain`, we are now ready to report/upload that problem, which we do here.

```
#-----
```

```
# Domain
```

```
#-----
```

```
pfset Domain.GeomName domain
```

Mobility between phases is set to 1.0 because we only have one phase (water).

```
#-----
```

```
# Mobility
```

```
#-----
```

```
pfset Phase.water.Mobility.Type Constant
pfset Phase.water.Mobility.Value 1.0
```

Again, PARFLOW has more capabilities than we are using here in the Cape Cod example. For this example, we handle monitoring wells in a separate code as we assume they do not remove a significant amount of water from the domain. Note that since there are no well names listed here, PARFLOW assumes we have no wells. If we had pumping wells, we would have to include them here, because they would affect the head distribution throughout our domain. See below for an example of how to include pumping wells in this script.

```
#-----
# Wells
#-----
pfset Wells.Names ""
```

You can give certain periods of time names if you want to (ie. Pre-injection, post-injection, etc). Here, however we do not have multiple time intervals and are simulating in steady state, so time cycle keys are simple. We have only one time cycle and it's constant for the duration of the simulation. We accomplish this by giving it a repeat value of -1, which repeats indefinitely. The length of the cycle is the length specified below (an integer) multiplied by the base unit value we specified earlier.

```
#-----
# Time Cycles
#-----
pfset Cycle.Names constant
pfset Cycle.constant.Names "alltime"
pfset Cycle.constant.alltime.Length 1
pfset Cycle.constant.Repeat -1
```

Now, we assign Boundary Conditions for each face (each of the Patches in the domain defined before). Recall the previously stated Patches and associate them with the boundary conditions that follow.

```
pfset BCPressure.PatchNames "left right front back bottom top"
```

These are Dirichlet BCs (i.e. constant head over cell so the pressure head is set to hydrostatic— see § 6.1.25). There is no time dependence, so use the `constant` time cycle we defined previously. `RefGeom` links this to the established domain geometry and tells PARFLOW what to use for a datum when calculating hydrostatic head conditions.

```
pfset Patch.left.BCPressure.Type          DirEquilRefPatch
pfset Patch.left.BCPressure.Cycle          "constant"
pfset Patch.left.BCPressure.RefGeom domain
```

Reference the current (left) patch to the bottom to define the line of intersection between the two.

```
pfset Patch.left.BCPressure.RefPatch bottom
```

Set the head permanently to 10.0m. Pressure-head will of course vary top to bottom because of hydrostatics, but head potential will be constant.

```
pfset Patch.left.BCPressure.alltime.Value 10.0
```

Repeat the declarations for the rest of the faces of the domain. The left to right (X) dimension is aligned with the hydraulic gradient. The difference between the values assigned to right and left divided by the length of the domain corresponds to the correct hydraulic gradient.

```
pfset Patch.right.BCPressure.Type          DirEquilRefPatch
pfset Patch.right.BCPressure.Cycle          "constant"
pfset Patch.right.BCPressure.RefGeom        domain
pfset Patch.right.BCPressure.RefPatch      bottom
pfset Patch.right.BCPressure.alltime.Value 9.97501
```



```

pfset Patch.front.BCPressure.Type          FluxConst
pfset Patch.front.BCPressure.Cycle          "constant"
pfset Patch.front.BCPressure.alltime.Value 0.0

pfset Patch.back.BCPressure.Type           FluxConst
pfset Patch.back.BCPressure.Cycle           "constant"
pfset Patch.back.BCPressure.alltime.Value 0.0

pfset Patch.bottom.BCPressure.Type         FluxConst
pfset Patch.bottom.BCPressure.Cycle         "constant"
pfset Patch.bottom.BCPressure.alltime.Value 0.0

pfset Patch.top.BCPressure.Type FluxConst
pfset Patch.top.BCPressure.Cycle "constant"
pfset Patch.top.BCPressure.alltime.Value 0.0

```

Next we define topographic slopes and Mannings n values. These are not used, since we do not solve for overland flow. However, the keys still need to appear in the input script.

```

#-----
# Topo slopes in x-direction
#-----
# topo slopes do not figure into the impes (fully sat) case but we still
# need keys for them

pfset TopoSlopesX.Type "Constant"
pfset TopoSlopesX.GeomNames ""

pfset TopoSlopesX.Geom.domain.Value 0.0

#-----
# Topo slopes in y-direction
#-----

pfset TopoSlopesY.Type "Constant"
pfset TopoSlopesY.GeomNames ""

pfset TopoSlopesY.Geom.domain.Value 0.0

# You may also indicate an elevation file used to derive the slopes.
# This is optional but can be useful when post-processing terrain-
# following grids:
pfset TopoSlopes.Elevation.FileName "elevation.pfb"

#-----
# Mannings coefficient
#-----
# mannings roughnesses do not figure into the impes (fully sat) case but we still

```

```
# need a key for them
```

```
pfset Mannings.Type "Constant"
pfset Mannings.GeomNames ""
pfset Mannings.Geom.domain.Value 0.
```

Phase sources allows you to add sources other than wells and boundaries, but we do not have any so this key is constant, 0.0 over entire domain.

```
#-----
# Phase sources:
#-----

pfset PhaseSources.water.Type           Constant
pfset PhaseSources.water.GeomNames      domain
pfset PhaseSources.water.Geom.domain.Value 0.0
```

Next we define solver parameters for **IMPES**. Since this is the default solver, we do not need a solver key.

```
#-----
# Solver Impes
#-----
```

We allow up to 50 iterations of the linear solver before it quits or converges.

```
pfset Solver.MaxIter 50
```

The solution must be accurate to this level

```
pfset Solver.AbsTol 1E-10
```

We drop significant digits beyond E-15

```
pfset Solver.Drop 1E-15
```

```
#-----
# Run and Unload the ParFlow output files
#-----
```

Here you set the number of realizations again using a local tcl variable. We have set only one run but by setting the `n_runs` variable to something else we can run more than one realization of hydraulic conductivity.

```
# this script is setup to run 100 realizations, for testing we just run one
###set n_runs 100
set n_runs 1
```

Here is where you tell PARFLOW where to put the output. In this case, it is a directory called flow. Then you cd (change directory) into that new directory. If you wanted to put an entire path rather than just a name, you would have more control over where your output file goes. For example, you would put file `mkdir "/cape_cod/revised_statistics/flow"` and then change into that directory.

```
file mkdir "flow"
cd "flow"
```

Now we loop through the realizations, again using tcl. `k` is the integer counter that is incremented for each realization. When you use a variable (rather than define it), you precede it with `$`. The hanging character `{` opens the do loop for `k`.

```
#
# Loop through runs
#
for {set k 1} {$k <= $n_runs} {incr k 1} {
```

The following expressions sets the variable `seed` equal to the expression in brackets, which increments with each turn of the do loop and each seed will produce a different random field of **K**. You set upper and lower aquifer, because in the Cape Cod site, these are the two subsets of the domain. Note the seed starts at a different point to allow for different random field generation for the upper and lower zones.

```
#
# set the random seed to be different for every run
#
pfset Geom.upper_aquifer.Perm.Seed [ expr 33333+2*$k ]
pfset Geom.lower_aquifer.Perm.Seed [ expr 31313+2*$k ]
```

The following command runs PARFLOW and gives you a suite of output files for each realization. The file names will begin `harvey_flow.1.xxxxx`, `harvey_flow.2.xxxx`, etc up to as many realizations as you run. The `.xxxxx` part will designate x, y, and z permeability, etc. Recall that in this case, since we normalized gravity, viscosity, and density, remember that we are really getting hydraulic conductivity.

```
pfrun harvey_flow.$k
```

This command removes a large number of superfluous dummy files or un-distributes parallel files back into a single file. If you compile with the `- with-amps-sequential-io` option then a single PARFLOW file is written with corresponding `XXXX.dist` files and the `pfundist` command just removes these `.dist` files (though you don't really need to remove them if you don't want to).

```
pfundist harvey_flow.$k
```

The following commands take advantage of PFTools (*see* § 4.2) and load pressure head output of the /parflow model into a pressure matrix.

```
# we use pf tools to convert from pressure to head
# we could do a number of other things here like copy files to different
# format
set press [pflload harvey_flow.$k.out.press.pfb]
```

The next command takes the pressures that were just loaded and converts it to head and loads them into a head matrix tcl variable.

```
set head [pfhhead $press]
```

Finally, the head matrix is saved as a PARFLOW binary file (`.pfb`) and the `k` do loop is closed by the `}` character. Then we move up to the root directory when we are finished

```

    pfsave $head -pfb harvey_flow.$k.head.pfb
}

cd ".."

```

Once you have modified the tcl input script (if necessary) and run PARFLOW, you will have as many realizations of your subsurface as you specified. Each of these realizations will be used as input for a particle or streamline calculation in the future. We can see below, that since we have a tcl script as input, we can do a lot of different operations, for example, we might run a particle tracking transport code simulation using the results of the PARFLOW runs. This actually corresponds to the example presented in the SLIM user's manual.

```

# this could run other tcl scripts now an example is below
#puts stdout "running SLIM"
#source bromide_trans.sm.tcl

```

We can add options to this script. For example if we wanted to add a pumping well these additions are described below.

Adding a Pumping Well

Let us change the input problem by adding a pumping well:

1. Add the following lines to the input file near where the existing well information is in the input file. You need to replace the "Wells.Names" line with the one included here to get both wells activated (this value lists the names of the wells):

```

pfset Wells.Names {new_well}

pfset Wells.new_well.InputType          Recirc

pfset Wells.new_well.Cycle      constant

pfset Wells.new_well.ExtractionType      Flux
pfset Wells.new_well.InjectionType       Flux

pfset Wells.new_well.X      10.0
pfset Wells.new_well.Y      10.0
pfset Wells.new_well.ExtractionZLower    0.5
pfset Wells.new_well.ExtractionZUpper    0.5
pfset Wells.new_well.InjectionZLower     0.2
pfset Wells.new_well.InjectionZUpper     0.2

pfset Wells.new_well.ExtractionMethod     Standard
pfset Wells.new_well.InjectionMethod      Standard

pfset Wells.new_well.alltime.Extraction.Flux.water.Value      0.50
pfset Wells.new_well.alltime.Injection.Flux.water.Value       0.75

```

For more information on defining the problem, see § 3.1.

We could also visualize the results of the PARFLOW simulations, using *VisIt*. For example, we can turn on *Silo* file output which allows these files to be directly read and visualized. We would do this by adding the following `pfset` commands, I usually add them to the solver section:

```
pfset Solver.WriteSiloSubsurfData True
pfset Solver.WriteSiloPressure True
pfset Solver.WriteSiloSaturation True
```

You can then directly open the file `harvey_flow.#.out.perm_x.silo` (where # is the realization number). The resulting image will be the hydraulic conductivity field of your domain, showing the variation in x-permeability in 3-D space. You can also generate representations of head or pressure (or y or z permeability) throughout your domain using PARFLOW output files. See the section on visualization for more details.

3.6.2 Little Washita Example

This tutorial matches the `LW_Test.tcl` file found in the `/test/washita/tcl_scripts` directory and corresponds to [19, 20]. This script runs the Little Washita domain for three days using PARFLOW CLM with 3D forcings. The domain is setup using terrain following grid (§ 5.3) and subsurface geologies are specified using a `.pfb` indicator file. Input files were generated using the workflow detailed in § 3.1.2.

Now for the tcl script:

```
#
# Import the ParFlow TCL package
#
```

These first three lines are what link PARFLOW and the tcl script, thus allowing you to use a set of commands seen later, such as `pfset`, etc.

```
lappend auto_path $env(PARFLOW_DIR)/bin
package require parflow
namespace import Parflow::*
```

```
#-----
# File input version number
#-----
pfset FileVersion 4
```

These next lines set the parallel process topology. The domain is divided in x, y and z by P, Q and R . The total number of processors is $P*Q*R$ (see § 6.1.2).

```
#-----
# Process Topology
#-----

pfset Process.Topology.P      1
pfset Process.Topology.Q      1
pfset Process.Topology.R      1
```

Before we really get started make a directory for our outputs and copy all of the required input files into the run directory. These files will be described in detail later as they get used.

```
#-----
# Make a directory for the simulation and copy inputs into it
#-----
exec mkdir "Outputs"
cd "./Outputs"

# ParFlow Inputs
file copy -force ".././parflow_input/LW.slopex.pfb" .
file copy -force ".././parflow_input/LW.slopey.pfb" .
file copy -force ".././parflow_input/IndicatorFile_Gleeson.50z.pfb" .
file copy -force ".././parflow_input/press.init.pfb" .

#CLM Inputs
file copy -force ".././clm_input/drv_clmin.dat" .
file copy -force ".././clm_input/drv_vegp.dat" .
file copy -force ".././clm_input/drv_vegm.alluv.dat" .

puts "Files Copied"
```

Next we set up the computational grid (*see* § 3.1 and § 6.1.3).

```
#-----
# Computational Grid
#-----
```

Locate the origin in the domain.

```
pfset ComputationalGrid.Lower.X    0.0
pfset ComputationalGrid.Lower.Y    0.0
pfset ComputationalGrid.Lower.Z    0.0
```

Define the size of the domain grid block. Length units, same as those on hydraulic conductivity.

```
pfset ComputationalGrid.DX    1000.0
pfset ComputationalGrid.DY    1000.0
pfset ComputationalGrid.DZ    2.0
```

Define the number of grid blocks in the domain.

```
pfset ComputationalGrid.NX    41
pfset ComputationalGrid.NY    41
pfset ComputationalGrid.NZ    50
```

This next piece is comparable to a pre-declaration of variables. These will be areas in our domain geometry. The regions themselves will be defined later. You must always have one that is the name of your entire domain. If you want subsections within your domain, you may declare these as well. Here we define two geometries one is the domain and one is for the indicator file (which will also span the entire domain).

```
#-----
# The Names of the GeomInputs
#-----
pfset GeomInput.Names           "box_input indi_input"
```

Now you characterize the domain that you just pre-declared to be a box (*see* § 6.1.4), and you also give it a name, `domain`.

```
#-----
# Domain Geometry Input
#-----
pfset GeomInput.box_input.InputType      Box
pfset GeomInput.box_input.GeoName        domain
```

Here, you set the limits in space for your entire domain. The span from `Lower.X` to `Upper.X` will be equal to the product of `ComputationalGrid.DX` times `ComputationalGrid.NX`. Same for `Y` and `Z` (i.e. the number of grid elements times size of the grid element has to equal the size of the grid in each dimension). The `Patches` key assigns names to the outside edges, because the domain is the limit of the problem in space.

```
#-----
# Domain Geometry
#-----
pfset Geom.domain.Lower.X      0.0
pfset Geom.domain.Lower.Y      0.0
pfset Geom.domain.Lower.Z      0.0

pfset Geom.domain.Upper.X      41000.0
pfset Geom.domain.Upper.Y      41000.0
pfset Geom.domain.Upper.Z      100.0

pfset Geom.domain.Patches      "x-lower x-upper y-lower y-upper z-lower z-upper"
```

Now we setup the indicator file. As noted above, the indicator file has integer values for every grid cell in the domain designating what geologic unit it belongs to. The `GeomNames` list should include a name for every unit in your indicator file. In this example we have thirteen soil units and eight geologic units. The `FileName` points to the indicator file that PARFLOW will read. Recall that this file into the run directory at the start of the script.

```
#-----
# Indicator Geometry Input
#-----
pfset GeomInput.indi_input.InputType      IndicatorField
pfset GeomInput.indi_input.GeoNames        "s1 s2 s3 s4 s5 s6 s7 s8 s9 s10 s11 s12 s13 g1 g2 g3 g4 g5 g6"
pfset GeomInput.indi_input.FileName        "IndicatorFile_Gleeson.50z.pfb"
```

For every name in the `GeomNames` list we define the corresponding value in the indicator file. For example, here we are saying that our first soil unit (`s1`) is represented by the number “1” in the indicator file, while the first geologic unit (`g1`) is represented by the number “21”. Note that the integers used in the indicator file do not need to be consecutive.

```
pfset GeomInput.s1.Value      1
pfset GeomInput.s2.Value      2
pfset GeomInput.s3.Value      3
pfset GeomInput.s4.Value      4
```

```

pfset GeomInput.s5.Value      5
pfset GeomInput.s6.Value      6
pfset GeomInput.s7.Value      7
pfset GeomInput.s8.Value      8
pfset GeomInput.s9.Value      9
pfset GeomInput.s10.Value     10
pfset GeomInput.s11.Value     11
pfset GeomInput.s12.Value     12
pfset GeomInput.s13.Value     13
pfset GeomInput.g1.Value      21
pfset GeomInput.g2.Value      22
pfset GeomInput.g3.Value      23
pfset GeomInput.g4.Value      24
pfset GeomInput.g5.Value      25
pfset GeomInput.g6.Value      26
pfset GeomInput.g7.Value      27
pfset GeomInput.g8.Value      28

```

Now you add permeability data to the domain sections defined above (§ 6.1.11). You can reassign values simply by re-stating them – there is no need to comment out or delete the previous version – the final statement is the only one that counts. Also, note that you do not need to assign permeability values to all of the geometries names. Any geometry that is not assigned its own permeability value will take the `domain` value. However, every geometry listed in `Porosity.GeomNames` must have values assigned.

```

#-----
# Permeability (values in m/hr)
#-----
pfset Geom.Perm.Names          "domain s1 s2 s3 s4 s5 s6 s7 s8 s9 g2 g3 g6 g8"

pfset Geom.domain.Perm.Type    Constant
pfset Geom.domain.Perm.Value   0.2

pfset Geom.s1.Perm.Type        Constant
pfset Geom.s1.Perm.Value       0.269022595

pfset Geom.s2.Perm.Type        Constant
pfset Geom.s2.Perm.Value       0.043630356

pfset Geom.s3.Perm.Type        Constant
pfset Geom.s3.Perm.Value       0.015841225

pfset Geom.s4.Perm.Type        Constant
pfset Geom.s4.Perm.Value       0.007582087

pfset Geom.s5.Perm.Type        Constant
pfset Geom.s5.Perm.Value       0.01818816

pfset Geom.s6.Perm.Type        Constant
pfset Geom.s6.Perm.Value       0.005009435

```



```

pfset Geom.s7.Perm.Type      Constant
pfset Geom.s7.Perm.Value    0.005492736

pfset Geom.s8.Perm.Type      Constant
pfset Geom.s8.Perm.Value    0.004675077

pfset Geom.s9.Perm.Type      Constant
pfset Geom.s9.Perm.Value    0.003386794

pfset Geom.g2.Perm.Type      Constant
pfset Geom.g2.Perm.Value    0.025

pfset Geom.g3.Perm.Type      Constant
pfset Geom.g3.Perm.Value    0.059

pfset Geom.g6.Perm.Type      Constant
pfset Geom.g6.Perm.Value    0.2

pfset Geom.g8.Perm.Type      Constant
pfset Geom.g8.Perm.Value    0.68

```

The following section allows you to specify the permeability tensor. In the case below, permeability is symmetric in all directions (x, y, and z) and therefore each is set to 1.0. Also note that we just specify this once for the whole domain because we want isotropic permeability everywhere. You can specify different tensors for different units by repeating these lines with different `Geom.Names`.

```

pfset Perm.TensorType      TensorByGeom
pfset Geom.Perm.TensorByGeom.Names "domain"
pfset Geom.domain.Perm.TensorValX  1.0d0
pfset Geom.domain.Perm.TensorValY  1.0d0
pfset Geom.domain.Perm.TensorValZ  1.0d0

```

Next we set the specific storage. Here again we specify one value for the whole domain but these lines can be easily repeated to set different values for different units.

```

#-----
# Specific Storage
#-----
pfset SpecificStorage.Type      Constant
pfset SpecificStorage.GeomNames "domain"
pfset Geom.domain.SpecificStorage.Value 1.0e-5

```

PARFLOW has the capability to deal with a multiphase system, but we only have one (water) in this example. As we stated earlier, we set density and viscosity artificially (and later gravity) both to 1.0. Again, this is merely a trick to solve for hydraulic conductivity and pressure head. If you were to set density and viscosity to their true values, the code would calculate \mathbf{k} (permeability). By using the *normalized* values instead, you effectively embed the conversion of \mathbf{k} to \mathbf{K} (hydraulic conductivity). So this way, we get hydraulic conductivity, which is what we want for this problem.

```
#-----
# Phases
#-----
pfset Phase.Names                "water"

pfset Phase.water.Density.Type    Constant
pfset Phase.water.Density.Value  1.0

pfset Phase.water.Viscosity.Type  Constant
pfset Phase.water.Viscosity.Value 1.0
```

This example does not include the PARFLOW grid based transport scheme. Therefore we leave contaminants blank.

```
#-----
# Contaminants
#-----
pfset Contaminants.Names        ""
```

As with density and viscosity, gravity is normalized here. If we used the true value (in the $[L]$ and $[T]$ units of hydraulic conductivity) the code would be calculating permeability. Instead, we normalize so that the code calculates hydraulic conductivity.

```
#-----
# Gravity
#-----
pfset Gravity                    1.0
```

Next we set up the timing for our simulation.

```
#-----
# Timing (time units is set by units of permeability)
#-----
```

This specifies the base unit of time for all time values entered. All time should be expressed as multiples of this value. To keep things simple here we set it to 1. Because we expressed our permeability in units of m/hr in this example this means that our basin unit of time is 1hr.

```
pfset TimingInfo.BaseUnit      1.0
```

This key specifies the time step number that will be associated with the first advection cycle of the transient problem. Because we are starting from scratch we set this to 0. If we were restarting a run we would set this to the last time step of your previous simulation. Refer to § 3.3 for additional instructions on restarting a run.

```
pfset TimingInfo.StartCount     0.0
```

StartTime and **StopTime** specify the start and stop times for the simulation. These values should correspond with the forcing files you are using.

```
pfset TimingInfo.StartTime      0.0
pfset TimingInfo.StopTime      72.0
```

This key specifies the timing interval at which PARFLOW time dependent outputs will be written. Here we have a base unit of 1hr so a dump interval of 24 means that we are writing daily outputs. Note that this key only controls the PARFLOW output interval and not the interval that CLM outputs will be written out at.

```
pfset TimingInfo.DumpInterval   24.0
```

Here we set the time step value. For this example we use a constant time step of 1hr.

```
pfset TimeStep.Type            Constant
pfset TimeStep.Value           1.0
```

Next, we assign the porosity (*see* § 6.1.12). As with the permeability we assign different values for different indicator geometries. Here we assign values for all of our soil units but not for the geologic units, they will default to the domain value of 0.4. Note that every geometry listed in `Porosity.GeomNames` must have values assigned.

```
#-----
# Porosity
#-----
pfset Geom.Porosity.GeomNames    "domain s1 s2 s3 s4 s5 s6 s7 s8 s9"

pfset Geom.domain.Porosity.Type  Constant
pfset Geom.domain.Porosity.Value 0.4

pfset Geom.s1.Porosity.Type      Constant
pfset Geom.s1.Porosity.Value     0.375

pfset Geom.s2.Porosity.Type      Constant
pfset Geom.s2.Porosity.Value     0.39

pfset Geom.s3.Porosity.Type      Constant
pfset Geom.s3.Porosity.Value     0.387

pfset Geom.s4.Porosity.Type      Constant
pfset Geom.s4.Porosity.Value     0.439

pfset Geom.s5.Porosity.Type      Constant
pfset Geom.s5.Porosity.Value     0.489

pfset Geom.s6.Porosity.Type      Constant
pfset Geom.s6.Porosity.Value     0.399

pfset Geom.s7.Porosity.Type      Constant
pfset Geom.s7.Porosity.Value     0.384

pfset Geom.s8.Porosity.Type      Constant
```

```

pfset Geom.s8.Porosity.Value      0.482

pfset Geom.s9.Porosity.Type       Constant
pfset Geom.s9.Porosity.Value      0.442

```

Having defined the geometry of our problem before and named it `domain`, we are now ready to re-port/upload that problem, which we do here.

```

#-----
# Domain
#-----
pfset Domain.GeomName              "domain"

```

Mobility between phases is set to 1.0 because we only have one phase (water).

```

#-----
# Mobility
#-----
pfset Phase.water.Mobility.Type    Constant
pfset Phase.water.Mobility.Value   1.0

```

Again, PARFLOW has more capabilities than we are using here in this example. Note that since there are no well names listed here, PARFLOW assumes we have no wells. If we had pumping wells, we would have to include them here, because they would affect the head distribution throughout our domain. See § 3.6.1 for an example of how to include pumping wells in this script.

```

#-----
# Wells
#-----
pfset Wells.Names                  ""

```

You can give certain periods of time names if you want. For example if you aren't running with CLM and you would like to have periods with rain and periods without. Here, however we have only one time cycle because CLM will handle the variable forcings. Therefore, we specify one time cycle and it's constant for the duration of the simulation. We accomplish this by giving it a repeat value of -1, which repeats indefinitely. The length of the cycle is the length specified below (an integer) multiplied by the base unit value we specified earlier.

```

#-----
# Time Cycles
#-----
pfset Cycle.Names                  "constant"
pfset Cycle.constant.Names         "alltime"
pfset Cycle.constant.alltime.Length 1
pfset Cycle.constant.Repeat        -1

```

Now, we assign Boundary Conditions for each face (each of the Patches in the domain defined before). Recall the previously stated Patches and associate them with the boundary conditions that follow.

```
#-----
# Boundary Conditions
#-----
pfset BCPressure.PatchNames          [pfget Geom.domain.Patches]
```

The bottom and sides of our domain are all set to no-flow (i.e. constant flux of 0) boundaries.

```
pfset Patch.x-lower.BCPressure.Type    FluxConst
pfset Patch.x-lower.BCPressure.Cycle    "constant"
pfset Patch.x-lower.BCPressure.alltime.Value    0.0

pfset Patch.y-lower.BCPressure.Type    FluxConst
pfset Patch.y-lower.BCPressure.Cycle    "constant"
pfset Patch.y-lower.BCPressure.alltime.Value    0.0

pfset Patch.z-lower.BCPressure.Type    FluxConst
pfset Patch.z-lower.BCPressure.Cycle    "constant"
pfset Patch.z-lower.BCPressure.alltime.Value    0.0

pfset Patch.x-upper.BCPressure.Type    FluxConst
pfset Patch.x-upper.BCPressure.Cycle    "constant"
pfset Patch.x-upper.BCPressure.alltime.Value    0.0

pfset Patch.y-upper.BCPressure.Type    FluxConst
pfset Patch.y-upper.BCPressure.Cycle    "constant"
pfset Patch.y-upper.BCPressure.alltime.Value    0.0
```

The top is set to an OverlandFlow boundary to turn on the fully-coupled overland flow routing.

```
pfset Patch.z-upper.BCPressure.Type    OverlandFlow
pfset Patch.z-upper.BCPressure.Cycle    "constant"
pfset Patch.z-upper.BCPressure.alltime.Value    0.0
```

Next we define topographic slopes and values. These slope values were derived from a digital elevation model of the domain following the workflow outlined in § 3.1.2. In this example we read the slope files in from .pfb files that were copied into the run directory at the start of this script.

```
#-----
# Topo slopes in x-direction
#-----
pfset TopoSlopesX.Type                "PFBFile"
pfset TopoSlopesX.GeomNames            "domain"
pfset TopoSlopesX.FileName              "LW.slopex.pfb"

#-----
# Topo slopes in y-direction
#-----
pfset TopoSlopesY.Type                "PFBFile"
pfset TopoSlopesY.GeomNames            "domain"
pfset TopoSlopesY.FileName              "LW.slopey.pfb"
```

And now we define the Mannings n , again just one value for the whole domain in this example.

```
#-----
# Mannings coefficient
#-----
pfset Mannings.Type                "Constant"
pfset Mannings.GeomNames            "domain"
pfset Mannings.Geom.domain.Value    5.52e-6
```

Following the same approach as we did for Porosity we define the relative permeability inputs that will be used for Richards' equation implementation (§ 6.1.20). Here we use **VanGenuchten** parameters. Note that every geometry listed in **Porosity.GeomNames** must have values assigned.

```
#-----
# Relative Permeability
#-----
pfset Phase.RelPerm.Type            VanGenuchten
pfset Phase.RelPerm.GeomNames        "domain s1 s2 s3 s4 s5 s6 s7 s8 s9 "

pfset Geom.domain.RelPerm.Alpha      3.5
pfset Geom.domain.RelPerm.N          2.0

pfset Geom.s1.RelPerm.Alpha          3.548
pfset Geom.s1.RelPerm.N              4.162

pfset Geom.s2.RelPerm.Alpha          3.467
pfset Geom.s2.RelPerm.N              2.738

pfset Geom.s3.RelPerm.Alpha          2.692
pfset Geom.s3.RelPerm.N              2.445

pfset Geom.s4.RelPerm.Alpha          0.501
pfset Geom.s4.RelPerm.N              2.659

pfset Geom.s5.RelPerm.Alpha          0.661
pfset Geom.s5.RelPerm.N              2.659

pfset Geom.s6.RelPerm.Alpha          1.122
pfset Geom.s6.RelPerm.N              2.479

pfset Geom.s7.RelPerm.Alpha          2.089
pfset Geom.s7.RelPerm.N              2.318

pfset Geom.s8.RelPerm.Alpha          0.832
pfset Geom.s8.RelPerm.N              2.514

pfset Geom.s9.RelPerm.Alpha          1.585
pfset Geom.s9.RelPerm.N              2.413
```

Next we do the same thing for saturation (§ 6.1.23) again using the `VanGenuchten` parameters. Note that every geometry listed in `Porosity.GeomNames` must have values assigned.

```
#-----
# Saturation
#-----
pfset Phase.Saturation.Type          VanGenuchten
pfset Phase.Saturation.GeomNames     "domain s1 s2 s3 s4 s5 s6 s7 s8 s9 "

pfset Geom.domain.Saturation.Alpha   3.5
pfset Geom.domain.Saturation.N       2.
pfset Geom.domain.Saturation.SRes    0.2
pfset Geom.domain.Saturation.SSat    1.0

pfset Geom.s1.Saturation.Alpha       3.548
pfset Geom.s1.Saturation.N           4.162
pfset Geom.s1.Saturation.SRes        0.000001
pfset Geom.s1.Saturation.SSat        1.0

pfset Geom.s2.Saturation.Alpha       3.467
pfset Geom.s2.Saturation.N           2.738
pfset Geom.s2.Saturation.SRes        0.000001
pfset Geom.s2.Saturation.SSat        1.0

pfset Geom.s3.Saturation.Alpha       2.692
pfset Geom.s3.Saturation.N           2.445
pfset Geom.s3.Saturation.SRes        0.000001
pfset Geom.s3.Saturation.SSat        1.0

pfset Geom.s4.Saturation.Alpha       0.501
pfset Geom.s4.Saturation.N           2.659
pfset Geom.s4.Saturation.SRes        0.000001
pfset Geom.s4.Saturation.SSat        1.0

pfset Geom.s5.Saturation.Alpha       0.661
pfset Geom.s5.Saturation.N           2.659
pfset Geom.s5.Saturation.SRes        0.000001
pfset Geom.s5.Saturation.SSat        1.0

pfset Geom.s6.Saturation.Alpha       1.122
pfset Geom.s6.Saturation.N           2.479
pfset Geom.s6.Saturation.SRes        0.000001
pfset Geom.s6.Saturation.SSat        1.0

pfset Geom.s7.Saturation.Alpha       2.089
pfset Geom.s7.Saturation.N           2.318
pfset Geom.s7.Saturation.SRes        0.000001
pfset Geom.s7.Saturation.SSat        1.0
```

```

pfset Geom.s8.Saturation.Alpha      0.832
pfset Geom.s8.Saturation.N          2.514
pfset Geom.s8.Saturation.SRes       0.000001
pfset Geom.s8.Saturation.SSat       1.0

pfset Geom.s9.Saturation.Alpha      1.585
pfset Geom.s9.Saturation.N          2.413
pfset Geom.s9.Saturation.SRes       0.000001
pfset Geom.s9.Saturation.SSat       1.0

```

Phase sources allows you to add sources other than wells and boundaries, but we do not have any so this key is constant, 0.0 over entire domain.

```

#-----
# Phase sources:
#-----
pfset PhaseSources.water.Type        "Constant"
pfset PhaseSources.water.GeomNames   "domain"
pfset PhaseSources.water.Geom.domain.Value 0.0

```

In this example we are using PARFLOW CLM so we must provide some parameters for CLM (§ 6.1.36). Note that CLM will also require some additional inputs outside of the tcl script. Refer to `/washita/clm_input/` for examples of the CLM `vegm` and `driver` files. These inputs are also discussed briefly in § 3.1.2.

```

#-----
# CLM Settings:
# -----

```

First we specify that we will be using CLM as the land surface model and provide the name of a directory that outputs will be written to. For this example we do not need outputs for each processor or a binary output directory. Finally we set the dump interval to 1, indicating that we will be writing outputs for every time step. Note that this does not have to match the dump interval for PARFLOW outputs. Recall that earlier we set the PARFLOW dump interval to 24.

```

pfset Solver.LSM                     CLM
pfset Solver.CLM.CLMFileDir          "clm_output/"
pfset Solver.CLM.PrintIdOut          False
pfset Solver.BinaryOutDir            False
pfset Solver.CLM.CLMDumpInterval     1

```

Next we specify the details of the meteorological forcing files that `clm` will read. First we provide the name of the files and the directory they can be found in. Next we specify that we are using 3D forcing files meaning that we have spatially distributed forcing with multiple time steps in every file. Therefore we must also specify the number of times steps (`MetFileNT`) in every file, in this case 24. Finally, we specify the initial value for the CLM counter.

```

pfset Solver.CLM.MetFileName          "NLDAS"
pfset Solver.CLM.MetFilePath          "../NLDAS/"
pfset Solver.CLM.MetForcing           3D
pfset Solver.CLM.MetFileNT            24
pfset Solver.CLM.IstepStart           1

```


This last set of CLM parameters refers to the physical properties of the system. Refer to § 6.1.36 for details.

```
pfset Solver.CLM.EvapBeta           Linear
pfset Solver.CLM.VegWaterStress     Saturation
pfset Solver.CLM.ResSat             0.1
pfset Solver.CLM.WiltingPoint       0.12
pfset Solver.CLM.FieldCapacity       0.98
pfset Solver.CLM.IrrigationType     none
```

Next we set the initial conditions for the domain. In this example we are using a pressure `.pfb` file that was obtained by spinning up the model in the workflow outlined in § 3.1.2. Alternatively, the water table can be set to a constant value by changing the `ICPressure.Type`. Again, the input file that is referenced here was copied into the run directory at the top of this script.

```
#-----
# Initial conditions: water pressure
#-----
pfset ICPressure.Type               PFBFile
pfset ICPressure.GeomNames          domain
pfset Geom.domain.ICPressure.RefPatch z-upper
pfset Geom.domain.ICPressure.FileName press.init.pfb
```

Now we specify what outputs we would like written. In this example we specify that we would like to write out CLM variables as well as `Pressure` and `Saturation`. However, there are many options for this and you should change these options according to what type of analysis you will be performing on your results. A complete list of print options is provided in § 6.1.32.

```
#-----
# Outputs
# -----
#Writing output (all pfb):
pfset Solver.PrintSubsurfData       False
pfset Solver.PrintPressure           True
pfset Solver.PrintSaturation         True
pfset Solver.PrintMask               True

pfset Solver.WriteCLMBinary          False
pfset Solver.PrintCLM                True
pfset Solver.WriteSiloSpecificStorage False
pfset Solver.WriteSiloMannings       False
pfset Solver.WriteSiloMask           False
pfset Solver.WriteSiloSlopes         False
pfset Solver.WriteSiloSubsurfData    False
pfset Solver.WriteSiloPressure       False
pfset Solver.WriteSiloSaturation     False
pfset Solver.WriteSiloEvapTrans      False
pfset Solver.WriteSiloEvapTransSum   False
pfset Solver.WriteSiloOverlandSum    False
pfset Solver.WriteSiloCLM            False
```

Next we specify the solver settings for the ParFlow (§ 6.1.34). First we turn on solver Richards and the terrain following grid. We turn off variable dz.

```
#-----
# Set solver parameters
#-----
# ParFlow Solution
pfset Solver                                Richards
pfset Solver.TerrainFollowingGrid           True
pfset Solver.Nonlinear.VariableDz          False
```

We then set the max solver settings and linear and nonlinear convergence tolerance settings. The linear system will be solved to a norm of 10^{-8} and the nonlinear system will be solved to less than 10^{-6} . Of note in latter key block is the EtaChoice and that we use the analytical Jacobian (*UseJacobian=***True**). We are using the *FullJacobian* preconditioner, which is a more robust approach but is more expensive.

```
pfset Solver.MaxIter                        25000
pfset Solver.Drop                          1E-20
pfset Solver.AbsTol                         1E-8
pfset Solver.MaxConvergenceFailures        8
pfset Solver.Nonlinear.MaxIter              80
pfset Solver.Nonlinear.ResidualTol          1e-6

pfset Solver.Nonlinear.EtaChoice            EtaConstant
pfset Solver.Nonlinear.EtaValue             0.001
pfset Solver.Nonlinear.UseJacobian          True
pfset Solver.Nonlinear.DerivativeEpsilon    1e-16
pfset Solver.Nonlinear.StepTol              1e-30
pfset Solver.Nonlinear.Globalization        LineSearch
pfset Solver.Linear.KrylovDimension         70
pfset Solver.Linear.MaxRestarts             2

pfset Solver.Linear.Preconditioner          PFMG
pfset Solver.Linear.Preconditioner.PCMatrixType FullJacobian
```

This key is just for testing the Richards' formulation, so we are not using it.

```
#-----
# Exact solution specification for error calculations
#-----
pfset KnownSolution                        NoKnownSolution
```

Next we distribute all the inputs as described by the keys in § 4.2. Note the slopes are 2D files, while the rest of the PARFLOW inputs are 3D so we need to alter the NZ accordingly following example 4 in § 4.3.

```
#-----
# Distribute inputs
#-----
pfset ComputationalGrid.NX                 41
pfset ComputationalGrid.NY                 41
```

```

pfset ComputationalGrid.NZ          1
pfdist LW.slopex.pfb
pfdist LW.slopey.pfb

pfset ComputationalGrid.NX          41
pfset ComputationalGrid.NY          41
pfset ComputationalGrid.NZ          50
pfdist IndicatorFile_Gleeson.50z.pfb
pfdist press.init.pfb

```

Now we run the simulation. Note that we use a tcl variable to set the run name.

```

#-----
# Run Simulation
#-----
set runname "LW"
puts $runname
pfrun    $runname

```

All that is left is to undistribute files.

```

#-----
# Undistribute Files
#-----
pfundist $runname
pfundist press.init.pfb
pfundist LW.slopex.pfb
pfundist LW.slopey.pfb
pfundist IndicatorFile_Gleeson.50z.pfb

puts "ParFlow run Complete"

```

Chapter 4

Manipulating Data: PFTOOLS

4.1 Introduction to the PARFLOW TCL commands (PFTCL)

Several tools for manipulating data are provided in PFTCL command set. Tools can be accessed directly from the TCL shell or within a PARFLOW input script. In both cases you must first load the PARFLOW package into the TCL shell as follows:

```
#
# To Import the ParFlow TCL package
#
lappend auto_path $env(PARFLOW_DIR)/bin
package require parflow
namespace import Parflow::*
```

In addition to these methods xpf tools provides GUI access to most of these features. However the simplest approach is generally to include the tools commands within a tcl script. The following section lists all of the available ParFlow TCL commands along with detailed instructions for their use. § 4.2 provides several examples of pre and post processing using the tools. In addition, a list of tools can be obtained by typing `pfhelp` into a TCL shell after importing ParFlow. Typing `pfhelp` followed by a command name will display a detailed description of the command in question.

4.2 PFTCL Commands

The tables that follow 4.1, 4.2 and 4.3 provide a list of ParFlow commands with short descriptions grouped according to their function. The last two columns in this table indicate what examples from § 4.3, if any, the command is used in and whether the command is compatible with a terrain following grid domain formulation.

Table 4.1: List of PFTOOLS commands by function.

Name	Short Description	Examples	Compatible with TFG?
pfhelp	Get help for PF Tools		X
Mathematical Operations			
pfcellsum	datasetx + datasety		X
pfcelldiff	datasetx - datasety		X
pfcellmult	datasetx * datasety		X
pfcelldiv	datasetx / datasety		X
pfcellsumconst	dataset + constant		X
pfcelldiffconst	dataset - constant		X
pfcellmultconst	dataset * constant		X
pfcelldivconst	dataset / constant		X
pfsum	Sum dataset	7, 9	X
pfdiffelt	Element difference		X
pfprntdiff	Print difference		X
pfmndiff	Calculate area where the difference between two datasets is less than a threshold		X
pfprntmdiff	Print the locations with differences greater than a minimum threshold		X
pfsavediff	Save the difference between two datasets		X
pfaxpy	y=alpha*x+y		X
pfgetstats	Calculate dataset statistics (min, max, mean, var, stdev)		X
pfprintstats	Print formatted statistics		X
pfstats	Calculate and print dataset statistics (min, max, mean, var, stdev)		X
Calculate physical parameters			
pfbcvel	Calculate block face centered velocity		
pfcvcl	Calculate Darcy velocity		
pfvvel	Calculate Darcy velocity at cell vertices		
pfvmag	Calculate velocity magnitude given components		
pfflux	Calculate Darcy flux		
pfhhead	Calculate hydraulic head	2	
pfphead	Calculate pressure head from hydraulic head		
pfSATtrans	calculate saturated transmissivity		X
pfupstreamarea	Calculate upstream area		X
pfeffective recharge	Calculate effective recharge		X
pfwatertabledepth	Calculate water table from saturation		X
pfhydrostatic	Calculate hydrostatic pressure field		
pfsubsurfacestorage	Calculate total sub-surface storage	7	X
pfgwstorage	Calculate saturated subsurface storage		X
pfSURFacerunoff	Calculate total surface runoff	9	X
pfSURFCEstorage	Calculate total surface storage	8	X

Table 4.2: List of PFTOOLS commands by function (cont.).

Name	Short Description	Examples	Compatible with TFG?
DEM Operations			
pfslopex	Calculate slopes in the x-direction	5	X
pfslopy	Calculate slope in the y-direction	5	X
pfchildD8	Calculate D8 child		X
pfsegmentD8	Calculate D8 segment lengths		X
pfslopeD8	Calculate D8 slopes		X
pfslopexD4	Calculate D4 slopes in the x-direction		X
pfslopyD4	Calculate D4 slopes in the y-direction		X
pfllflats	Fill DEM flats	5	X
pfmovingavgdem	Fill dem sinks with moving average		X
pfpitfilldem	Fill sinks in the dem using iterative pit-filling routine	5	X
pfllintslawfit	Calculate Flint's Law parameters		X
pfllintslaw	Smooth DEM using Flints Law		X
pfllintslawbybasin	Smooth DEM using Flints Law by basin		X
Topmodel functions			
pftopodeficit	Calculate TOPMODEL water deficit		X
pftopindex	Calculate topographic index		X
pftopowt	Calculate watertable based on topographic index		X
pftoporecharge	Calculate effective recharge		X
Domain Operations			
pfcomputedomain	Compute domain mask	3	X
pfcomputetop	Compute domain top	3, 6, 8, 9	X
pfextracttop	Extract domain top	6	X
pfcomputebottom	Compute domain bottom	3	X
pfsetgrid	Set grid	5	X
pfgridtype	Set grid type		X
pfgetgrid	Return grid information		X
pfgetelt	Extract element from domain	10	X
pfextract2Ddomain	Build 2D domain		X
pfenlargebox	Compute expanded dataset		X
pfgetsubbox	Return subset of data		X
pfprintdomain	Print domain	3	X
pfbulddomain	Build a subgrid array from a ParFlow database		X
Dataset operations			
pflistdata	Return dataset names and labels		X
pfgetlist	Return dataset descriptions		X
pfprintlist	Print list of datasets and their labels		X
pfnewlabel	Change dataset label		X
pfnewdata	Create new dataset		X
pfprintgrid	Print grid		X
pfnewgrid	Set grid for new dataset		X
pfdelete	Delete dataset		X
pfreload	Reload dataset		X
pfreloadall	Reload all current datasets		X
pfprintdata	Print all elements of a dataset		X
pfprintelt	Print a single element		X

Table 4.3: List of PFTOOLS commands by function (cont.).

Name	Short Description	Examples	Compatible with TFG?
File Operations			
pload	Load file	All	X
ploadsds	Load Scientific Data Set from HDF file		X
pfdist	Distribute files based on processor topology	4	X
pfdistondomain	Distribute files based on domain		X
pfundist	Undistribute files		X
pfsave	Save dataset	1,2,5,6	X
pfsavesds	Save dataset in an HDF format		X
pfvtksave	Save dataset in VTK format using DEM	X	X
pfwritedb	Write the settings for a PF run to a database		X
Solid file operations			
pfpatchysolid	Build a solid file between two complex surfaces and assign user-defined patches around the edges		X
pfsolidfmtconvert	Converts back and forth between ascii and binary formats for solid files		X

Detailed descriptions of every command are included below in alphabetical order. Note that the required inputs are listed following each command. Commands that perform operations on data sets will require an identifier for each data set it takes as input. Inputs listed in square brackets are optional and do not need to be provided.

pfaxpy alpha x y

This command computes $y = \alpha * x + y$ where alpha is a scalar and x and y are identifiers representing data sets. No data set identifier is returned upon successful completion since data set y is overwritten.

pfbcvel conductivity phead

This command computes the block face centered flow velocity at every grid cell. Conductivity and pressure head data sets are given as arguments. The output includes x, y, and z velocity components that are appended to the Tcl result.

pfbuilddomain database

This command builds a subgrid array given a ParFlow database that contains the domain parameters and the processor topology.

pfcelldiff datasetx datasety mask

This command computes cell-wise differences of two datasets ($\text{diff} = \text{datasetx} - \text{datasety}$). This is the difference at each individual cell, not over the domain. Datasets must have the same dimensions.

pfcelldiffconst dataset constant mask

This command subtracts a constant value from each (active) cell of dataset ($\text{dif} = \text{dataset} - \text{constant}$).

pfcelldiv datasetx datasety mask

This command computes the cell-wise quotient of datasetx and datasety ($\text{div} = \text{datasetx} / \text{datasety}$). This is the quotient at each individual cell. Datasets must have the same dimensions.

pfcelldivconst dataset constant mask

This command divides each (active) cell of dataset by a constant ($\text{div} = \text{dataset} / \text{constant}$).

pfcellmult datasetx datasety mask

This command computes the cell-wise product of datasetx and datasety ($\text{mult} = \text{datasetx} * \text{datasety}$). This is the product at each individual cell. Datasets must have the same dimensions.

pfcellmultconst dataset constant mask

This command multiplies each (active) cell of dataset by a constant ($\text{mult} = \text{dataset} * \text{constant}$).

pfcellsum datasetp datasetq mask

This command computes the cellwise sum of two datasets (i.e., the sum at each individual cell, not the sum over the domain). Datasets must have the same dimensions.

pfcellsumconst dataset constant mask

This command adds the value of constant to each (active) cell of dataset.

pfchildD8 dem

This command computes the unique D8 child for all cells. Child[i,j] is the elevation of the cell to which [i,j] drains (i.e. the elevation of [i,j]'s child). If [i,j] is a local minima the child elevation set the elevation of [i,j].

pfcomputebottom mask

This command computes the bottom of the domain based on the mask of active and inactive zones. The identifier of the data set created by this operation is returned upon successful completion.

pfcomputedomain top bottom

This command computes a domain based on the top and bottom data sets. The domain built will have a single subgrid per processor that covers the active data as defined by the top and bottom. This domain will more closely follow the topology of the terrain than the default single computation domain.

A typical usage pattern for this is to start with a mask file (zeros in inactive cells and non-zero in active cells), create the top and bottom from the mask, compute the domain and then write out the domain. Refer to example number 3 in the following section.

pfcomputetop mask

This command computes the top of the domain based on the mask of active and inactive zones. This is the land-surface in `clm` or overland flow simulations. The identifier of the data set created by this operation is returned upon successful completion.

pfcvcl conductivity phead

This command computes the Darcy velocity in cells for the conductivity data set represented by the identifier 'conductivity' and the pressure head data set represented by the identifier 'phead'. (note: This "cell" is not the same as the grid cells; its corners are defined by the grid vertices.) The identifier of the data set created by this operation is returned upon successful completion.

pfdelete dataset

This command deletes the data set represented by the identifier 'dataset'. This command can be useful when working with multiple datasets / time series, such as those created when many timesteps of a file are loaded and processed. Deleting these datasets in between reads can help with tcl memory management.

pfdiffelt datasetp datasetq i j k digits [zero]

This command returns the difference of two corresponding coordinates from 'datasetp' and 'datasetq' if the number of digits in agreement (significant digits) differs by more than 'digits' significant digits and the difference is greater than the absolute zero given by 'zero'.

pfdist [options] filename

Distribute the file onto the virtual file system. This utility must be used to create files which ParFlow can use as input. ParFlow uses a virtual file system which allows each node of the parallel machine to read from the input file independently. The utility does the inverse of the `pfundist` command. If you are using a ParFlow binary file for input you should do a `pfdist` just before you do the `pfrun`. This command requires that the processor topology and computational grid be set in the input file so that it knows how to distribute the data. Note that the old syntax for `pfdist` required the `NZ` key be set to 1 to indicate a two dimensional file but this can now be specified manually when `pfdist` is called by using the optional argument `-nz` followed by the number of layers in the file to be distributed, then the filename. If the `-nz` argument is absent the `NZ` key is used by default for the processor topology.

For example,

```
pfdist -nz 1 slopex.pfb
```

pfdistondomain filename domain

Distribute the file onto the virtual file system based on the domain provided rather than the processor topology as used by `pfdist`. This is used by the SAMRAI version of which allows for a more complicated computation domain specification with different sized subgrids on each processor and allows for more than one subgrid per processor. Frequently this will be used with a domain created by the `pfcomputedomain` command.

pfeffectiverecharge precip et slopex slopey dem

This command computes the effective recharge at every grid cell based on total precipitation minus evapotranspiration (P-ET) in the upstream area. Effective recharge is consistent with TOPMODEL definition, NOT local P-ET. Inputs are total annual (or average annual) precipitation (precip) at each point, total annual (or average annual) evapotranspiration (ET) at each point, slope in the x direction, slope in the y direction and elevation.

pfenlargebox dataset sx sy sz

This command returns a new dataset which is enlarged to be of the new size indicated by `sx`, `sy` and `sz`. Expansion is done first in the z plane, then y plane and x plane.

pfextract2Ddomain domain

This command builds a 2D domain based off a 3D domain. This can be used for a `pfdistondomain` command for Parflow 2D data (such as slopes and soil indices).

pfextracttop top data

This command computes the top of the domain based on the top of the domain and another dataset. The identifier of the data set created by this operation is returned upon successful completion.

pffillflats dem

This command finds the flat regions in the DEM and eliminates them by bilinearly interpolating elevations across flat region.

pfflintslaw dem c p

This command smooths the digital elevation model dem according to Flints Law, with Flints Law parameters specified by c and p, respectively. Flints Law relates the slope magnitude at a given cell to its upstream contributing area: $S = c \cdot A^p$. In this routine, elevations at local minima retain the same value as in the original dem. Elevations at all other cells are computed by applying Flints Law recursively up each drainage path, starting at its terminus (a local minimum) until a drainage divide is reached. Elevations are computed as:

$$\text{dem}[i,j] = \text{dem}[\text{child}] + c \cdot (A[i,j]^p) \cdot ds[i,j]$$

where child is the D8 child of [i,j] (i.e., the cell to which [i,j] drains according to the D8 method); ds[i,j] is the segment length between the [i,j] and its child; A[i,j] is the upstream contributing area of [i,j]; and c and p are constants.

pfflintslawbybasin dem c0 p0 maxiter

This command smooths the digital elevation model (dem) using the same approach as "pfflintslaw". However here the c and p parameters are fit for each basin separately. The Flint's Law parameters are calculated for the provided digital elevation model dem using the iterative Levenberg-Marquardt method of non-linear least squares minimization, as in "pfflintslawfit". The user must provide initial estimates of c0 and p0; results are not sensitive to these initial values. The user must also specify the maximum number of iterations as maxiter.

pfflintslawfit dem c0 p0 maxiter

This command fits Flint's Law parameters c and p for the provided digital elevation model dem using the iterative Levenberg-Marquardt method of non-linear least squares minimization. The user must provide initial estimates of c0 and p0; results are not sensitive to these initial values. The user must also specify the maximum number of iterations as maxiter. Final values of c and p are printed to the screen, and a dataset containing smoothed elevation values is returned. Smoothed elevations are identical to running pfflintslaw for the final values of c and p. Note that dem must be a ParFlow dataset and must have the correct grid information – dx, dy, nx, and ny are used in parameter estimation and Flint's Law calculations. If gridded elevation values are read in from a text file (e.g., using pload's simple ascii format), grid information must be specified using the pfsetgrid command.

pfflux conductivity hhead

This command computes the net Darcy flux at vertices for the conductivity data set 'conductivity' and the hydraulic head data set given by 'hhead'. An identifier representing the flux computed will be returned upon successful completion.

pfgetelt dataset i j k

This command returns the value at element (i,j,k) in data set 'dataset'. The i, j, and k above must range from 0 to (nx - 1), 0 to (ny - 1), and 0 to (nz - 1) respectively. The values nx, ny, and nz are the number of grid points along the x, y, and z axes respectively. The string 'dataset' is an identifier representing the data set whose element is to be retrieved.

pfgetgrid dataset

This command returns a description of the grid which serves as the domain of data set 'dataset'. The format of the description is given below.

- (nx, ny, nz)

The number of coordinates in each direction.

- (x, y, z)
The origin of the grid.
- (dx, dy, dz)
The distance between each coordinate in each direction.

The above information is returned in the following Tcl list format: nx ny nz x y z dx dy dz

pfgetlist dataset

This command returns the name and description of a dataset if an argument is provided. If no argument is given, then all of the data set names followed by their descriptions is returned to the TCL interpreter. If an argument (dataset) is given, it should be the name of a loaded dataset.

pfgetstats dataset

This command calculates the following statistics for the data set represented by the identifier `dataset`: minimum, maximum, mean, sum, variance, and standard deviation.

pfgetsubbox dataset il jl kl iu ju ku

This command computes a new dataset with the subbox starting at il, jl, kl and going to iu, ju, ku.

pfgridtype gridtype

This command sets the grid type to either cell centered if 'gridtype' is set to 'cell' or vertex centered if 'gridtype' is set to 'vertex'. If no new value for 'gridtype' is given, then the current value of 'gridtype' is returned. The value of 'gridtype' will be returned upon successful completion of this command.

pfgwstorage mask porosity pressure saturation specific_storage

This command computes the sub-surface water storage (compressible and incompressible components) based on mask, porosity, saturation, storativity and pressure fields, similar to `pfsurfacestorage`, but only for the saturated cells.

pfhelp [command]

This command returns a list of pftools commands. If a command is provided it gives a detailed description of the command and the necessary inputs.

pfhhead phead

This command computes the hydraulic head from the pressure head represented by the identifier 'phead'. An identifier for the hydraulic head computed is returned upon successful completion.

pfhydrostatic wtdepth top mask

Compute hydrostatic pressure field from water table depth

pflistdata dataset

This command returns a list of pairs if no argument is given. The first item in each pair will be an identifier representing the data set and the second item will be that data set's label. If a data set's identifier is given as an argument, then just that data set's name and label will be returned.

pfload [file format] filename

Loads a dataset into memory so it can be manipulated using the other utilities. A file format may precede the filename in order to indicate the file's format. If no file type option is given, then the extension of the filename is used to determine the default file type. An identifier used to represent the data set will be returned upon successful completion.

File type options include:

- **pfb**
ParFlow binary format. Default file type for files with a '.pfb' extension.
- **pfsb**
ParFlow scattered binary format. Default file type for files with a '.pfsb' extension.

- **sa**
ParFlow simple ASCII format. Default file type for files with a ‘.sa’ extension.
- **sb**
ParFlow simple binary format. Default file type for files with a ‘.sb’ extension.
- **silo**
Silo binary format. Default file type for files with a ‘.silo’ extension.
- **rsa**
ParFlow real scattered ASCII format. Default file type for files with a ‘.rsa’ extension

pflloadsds filename dsnum

This command is used to load Scientific Data Sets from HDF files. The SDS number ‘dsnum’ will be used to find the SDS you wish to load from the HDF file ‘filename’. The data set loaded into memory will be assigned an identifier which will be used to refer to the data set until it is deleted. This identifier will be returned upon successful completion of the command.

pfmdiff datasetp datasetq digits [zero]

If ‘digits’ is greater than or equal to zero, then this command computes the grid point at which the number of digits in agreement (significant digits) is fewest and differs by more than ‘digits’ significant digits. If ‘digits’ is less than zero, then the point at which the number of digits in agreement (significant digits) is minimum is computed. Finally, the maximum absolute difference is computed. The above information is returned in a Tcl list of the following form: mi mj mk sd adiff

Given the search criteria, (mi, mj, mk) is the coordinate where the minimum number of significant digits ‘sd’ was found and ‘adiff’ is the maximum absolute difference.

pfmovingaveragedem dem wsize maxiter

This command fills sinks in the digital elevation model dem by a standard iterative moving-average routine. Sinks are identified as cells with zero slope in both x- and y-directions, or as local minima in elevation (i.e., all adjacent cells have higher elevations). At each iteration, a moving average is taken over a window of width wsize around each remaining sink; sinks are thus filled by averaging over neighboring cells. The procedure continues iteratively until all sinks are filled or the number of iterations reaches maxiter. For most applications, sinks should be filled prior to computing slopes (i.e., prior to executing pfslope and pfslopey).

pfnewdata {nx ny nz} {x y z} {dx dy dz} label

This command creates a new data set whose dimension is described by the lists nx ny nz, x y z, and dx dy dz. The first list, describes the dimensions, the second indicates the origin, and the third gives the length intervals between each coordinate along each axis. The ‘label’ argument will be the label of the data set that gets created. This new data set that is created will have all of its data points set to zero automatically. An identifier for the new data set will be returned upon successful completion.

pfnewgrid {nx ny nz} {x y z} {dx dy dz} label

Create a new data set whose grid is described by passing three lists and a label as arguments. The first list will be the number of coordinates in the x, y, and z directions. The second list will describe the origin. The third contains the intervals between coordinates along each axis. The identifier of the data set created by this operation is returned upon successful completion.

pfnewlabel dataset newlabel

This command changes the label of the data set ‘dataset’ to ‘newlabel’.

pfphead hhead

This command computes the pressure head from the hydraulic head represented by the identifier ‘hhead’. An identifier for the pressure head is returned upon successful completion.

pfpatchsolid -top topdata -bot botdata -msk emaskdata [optional args]

Creates a solid file with complex upper and lower surfaces from a top surface elevation dataset (topdata), a bottom elevation dataset (botdata), and an enhanced mask dataset (emaskdata) all of which must be passed as

handles to 2-d datasets that share a common size and origin. The solid is built as the volume between the top and bottom surfaces using the mask to deactivate other regions. The “enhanced mask” used here is a gridded dataset containing integers where all active cells have values of one but inactive cells may be given a positive integer value that identifies a patch along the model edge or the values may be zero. Any mask cell with value 0 is omitted from the active domain and *is not* written to a patch. If an active cell is adjacent to a non-zero mask cell, the face between the active and inactive cell is assigned to the patch with the integer value of the adjacent inactive cell. Bottom and Top patches are always written for every active cell and the West, East, South, and North edges are written automatically anytime active cells touch the edges of the input dataset(s). Up to 30 user defined patches can be specified using arbitrary integer values that are *greater than* 1. Note that the -msk flag may be omitted and doing so will make every cell active.

The -top and -bot flags, and -msk if it is used, MUST each be followed by the handle for the relevant dataset. Optional argument flag-name pairs include:

- -pfsol <file name>.pfsol (or -pfsolb <file name>.pfsolb)
- -vtk <file name>.vtk
- -sub

where <file name> is replaced by the desired text string. The -pfsolb option creates a compact binary solid file; pfsolb cannot currently be read directly by ParFlow but it can be converted with *pfsolidfmtconvert* and full support is under development. If -pfsol (or -pfsolb) is not specified the default name "SolidFile.pfsol" will be used. If -vtk is omitted, no vtk file will be created. The vtk attributes will contain mean patch elevations and patch IDs from the enhanced mask. Edge patch IDs are shown as negative values in the vtk. The patchysolid tool also outputs the list of the patch names in the order they are written, which can be directly copied into a ParFlow TCL script for the list of patch names. The -sub option writes separate patches for each face (left,right,front,back), which are indicated in the output patch write order list.

Assuming \$Msk, \$Top, and \$Bot are valid dataset handles from pload, two valid examples are:

```
pfpitchysolid -msk $Msk -top $Top -bot $Bot -pfsol "MySolid.pfsol" -vtk "MySolid.vtk"
pfpitchysolid -bot $Bot -top $Top -vtk "MySolid.vtk" -sub
```

Note that all flag-name pairs may be specified in any order for this tool as long as the required argument immediately follows the flag. To use with a terrain following grid, you will need to subtract the surface elevations from the top and bottom datasets (this makes the top flat) then add back in the total thickness of your grid, which can be done using “pfcelldiff” and “pfcellsumconst”.

pfpitfilldem dem dpit maxiter

This command fills sinks in the digital elevation model dem by a standard iterative pit-filling routine. Sinks are identified as cells with zero slope in both x- and y-directions, or as local minima in elevation (i.e., all adjacent neighbors have higher elevations). At each iteration, the value dpit is added to all remaining sinks. The procedure continues iteratively until all sinks are filled or the number of iterations reaches maxiter. For most applications, sinks should be filled prior to computing slopes (i.e., prior to executing pfslope and pfslopey).

pfprntdata dataset

This command executes ‘pfgetgrid’ and ‘pfgetelt’ in order to display all the elements in the data set represented by the identifier ‘dataset’.

pfprntdiff datasetp datasetq digits [zero]

This command executes ‘pfdiffelt’ and ‘pfmdiff’ to print differences to standard output. The differences are printed one per line along with the coordinates where they occur. The last two lines displayed will show the point at which there is a minimum number of significant digits in the difference as well as the maximum absolute difference.

pfprntdomain domain

This command creates a set of TCL commands that setup a domain as specified by the provided domain input which can be then be written to a file for inclusion in a Parflow input script. Note that this kind of domain is only supported by the SAMRAI version of Parflow.

pfprintelt i j k dataset

This command prints a single element from the provided dataset given an i, j, k location.

pfprintgrid dataset

This command executes pfgetgrid and formats its output before printing it on the screen. The triples (nx, ny, nz), (x, y, z), and (dx, dy, dz) are all printed on separate lines along with labels describing each.

pfprintlist [dataset]

This command executes pflistdata and formats the output of that command. The formatted output is then printed on the screen. The output consists of a list of data sets and their labels one per line if no argument was given or just one data set if an identifier was given.

pfprintmdiff datasetp datasetq digits [zero]

This command executes 'pfndiff' and formats that command's output before displaying it on the screen. Given the search criteria, a line displaying the point at which the difference has the least number of significant digits will be displayed. Another line displaying the maximum absolute difference will also be displayed.

printstats dataset

This command executes 'pfstats' and formats that command's output before printing it on the screen. Each of the values mentioned in the description of 'pfstats' will be displayed along with a label.

pfreload dataset

This argument reloads a dataset. Only one arguments is required, the name of the dataset to reload.

pfreloadall

This command reloads all of the current datasets.

pfsattrans mask perm

Compute saturated transmissivity for all [i,j] as the sum of the permeability[i,j,k]*dz within a column [i,j]. Currently this routine uses dz from the input permeability so the dz in permeability must be correct. Also, it is assumed that dz is constant, so this command is not compatible with variable dz.

pfsave dataset -filetype filename

This command is used to save the data set given by the identifier 'dataset' to a file 'filename' of type 'filetype' in one of the ParFlow formats below.

File type options include:

- pfb ParFlow binary format.
- sa ParFlow simple ASCII format.
- sb ParFlow simple binary format.
- silo Silo binary format.
- vis Vizamrai binary format.

pfsavediff datasetp datasetq digits [zero] -file filename

This command saves to a file the differences between the values of the data sets represented by 'datasetp' and 'datasetq' to file 'filename'. The data points whose values differ in more than 'digits' significant digits and whose differences are greater than 'zero' will be saved. Also, given the above criteria, the minimum number of digits in agreement (significant digits) will be saved.

If 'digits' is less than zero, then only the minimum number of significant digits and the coordinate where the minimum was computed will be saved.

In each of the above cases, the maximum absolute difference given the criteria will also be saved.

pfsavesds dataset -filetype filename

This command is used to save the data set represented by the identifier 'dataset' to the file 'filename' in the format given by 'filetype'.

The possible HDF formats are:

- -float32
- -float64
- -int8
- -uint8
- -int16
- -uint16
- -int32
- -uint32

pfsegmentD8 dem

This command computes the distance between the cell centers of every parent cell $[i,j]$ and its child cell. Child cells are determined using the eight-point pour method (commonly referred to as the D8 method) based on the digital elevation model dem. If $[i,j]$ is a local minima the segment length is set to zero.

pfsetgrid {nx ny nz} {x0 y0 z0} {dx dy dz} dataset

This command replaces the grid information of dataset with the values provided.

pfslopeD8 dem

This command computes slopes according to the eight-point pour method (commonly referred to as the D8 method) based on the digital elevation model dem. Slopes are computed as the maximum downward gradient between a given cell and its lowest neighbor (adjacent or diagonal). Local minima are set to zero; where local minima occur on the edge of the domain, the 1st order upwind slope is used (i.e., the cell is assumed to drain out of the domain). Note that dem must be a ParFlow dataset and must have the correct grid information – dx and dy both used in slope calculations. If gridded elevation values are read in from a text file (e.g., using pfload's simple ascii format), grid information must be specified using the pfsetgrid command. It should be noted that ParFlow uses slopex and slopey (NOT D8 slopes!) in runoff calculations.

pfslopex dem

This command computes slopes in the x-direction using 1st order upwind finite differences based on the digital elevation model dem. Slopes at local maxima (in x-direction) are calculated as the maximum downward gradient to an adjacent neighbor. Slopes at local minima (in x-direction) do not drain in the x-direction and are therefore set to zero. Note that dem must be a ParFlow dataset and must have the correct grid information – dx in particular is used in slope calculations. If gridded elevation values are read from a text file (e.g., using pfload's simple ascii format), grid information must be specified using the pfsetgrid command.

pfslopexD4 dem

This command computes the slope in the x-direction for all $[i,j]$ using a four point (D4) method. The slope is set to the maximum downward slope to the lowest adjacent neighbor. If $[i,j]$ is a local minima the slope is set to zero (i.e. no drainage).

pfslopey dem

This command computes slopes in the y-direction using 1st order upwind finite differences based on the digital elevation model dem. Slopes at local maxima (in y-direction) are calculated as the maximum downward gradient to an adjacent neighbor. Slopes at local minima (in y-direction) do not drain in the y-direction and are therefore set to zero. Note that dem must be a ParFlow dataset and must have the correct grid information – dy in particular is used in slope calculations. If gridded elevation values are read in from a text file (e.g., using pfload's simple ascii format), grid information must be specified using the pfsetgrid command.

pfslopeyD4 dem

This command computes the slope in the y-direction for all $[i,j]$ using a four point (D4) method. The slope is set to the maximum downward slope to the lowest adjacent neighbor. If $[i,j]$ is a local minima the slope is set to zero (i.e. no drainage).

pfsolidfmtconvert filename1 filename2

This command converts solid files back and forth between the ascii .pfsol format and the binary .pfsolb format. The tool automatically detects the conversion mode based on the extensions of the input file names. The *filename1* is the name of source file and *filename2* is the target output file to be created or overwritten. Support to directly use a binary solid (.pfsolb) is under development but this allows a significant reduction in file sizes.

For example, to convert from ascii to binary, then back to ascii:

```
pfsolidfmtconvert "MySolid.pfsol" "MySolid.pfsolb"
pfsolidfmtconvert "MySolid.pfsolb" "NewSolid.pfsol"
```

pfstats dataset

This command prints various statistics for the data set represented by the identifier 'dataset'. The minimum, maximum, mean, sum, variance, and standard deviation are all computed. The above values are returned in a list of the following form: min max mean sum variance (standard deviation)

pfsubsurfacestorage mask porosity pressure saturation specific_storage

This command computes the sub-surface water storage (compressible and incompressible components) based on mask, porosity, saturation, storativity and pressure fields. The equations used to calculate this quantity are given in § 5.9. The identifier of the data set created by this operation is returned upon successful completion.

pfsun dataset

This command computes the sum over the domain of the dataset.

pfsurfacerrunoff top slope_x slope_y mannings pressure

This command computes the surface water runoff (out of the domain) based on a computed top, pressure field, slopes and mannings roughness values. This is integrated along all domain boundaries and is calculated at any location that slopes at the edge of the domain point outward. This data is in units of $[L^3 T^{-1}]$ and the equations used to calculate this quantity are given in § 5.9. The identifier of the data set created by this operation is returned upon successful completion.

pfsurfacestorage top pressure

This command computes the surface water storage (ponded water on top of the domain) based on a computed top and pressure field. The equations used to calculate this quantity are given in § 5.9. The identifier of the data set created by this operation is returned upon successful completion.

pftopodeficit profile m trans dem slopex slopey recharge ssat sres porosity mask

Compute water deficit for all [i,j] based on TOPMODEL/topographic index. For more details on methods and assumptions refer to toposlopes.c in pftools.

pftopindex dem sx sy

Compute topographic index for all [i,j]. Here topographic index is defined as the total upstream area divided by the contour length, divided by the local slope. For more details on methods and assumptions refer to toposlopes.c in pftools.

pftoporecharge riverfile nriver trans dem sx sy

Compute effective recharge at all [i,j] over upstream area based on topmodel assumptions and given list of river points. Notes: See detailed notes in toposlopes.c regarding assumptions, methods, etc. Input Notes: nriver is an integer (number of river points) river is an array of integers [nriver][2] (list of river indices, ordered from outlet to headwaters) is a Databox of saturated transmissivity dem is a Databox of elevations at each cell sx is a Databox of slopes (x-dir) – lets you use processed slopes! sy is a Databox of slopes (y-dir) – lets you use processed slopes!

pftopowt deficit porosity ssat sres mask top wtdepth

Compute water depth from column water deficit for all [i,j] based on TOPMODEL/topographic index.

pfundist filename, pfundist runname

The command undistributes a PARFLOW output file. PARFLOW uses a distributed file system where each node can write to its own file. The pfundist command takes all of these individual files and collapses them into a single file.

The arguments can be a runname or a filename. If a runname is given then all of the output files associated with that run are undistributed.

Normally this is done after every pfrun command.

pfupstreamarea slope_x slope_y

This command computes the upstream area contributing to surface runoff at each cell based on the x and y slope values provided in datasets **slope_x** and **slope_y**, respectively. Contributing area is computed recursively for each cell; areas are not weighted by slope direction. Areas are returned as the number of upstream (contributing) cells; to compute actual area, simply multiply by the cell area (dx*dy).

pfvmag datasetx datasety datasetz

This command computes the velocity magnitude when given three velocity components. The three parameters are identifiers which represent the x, y, and z components respectively. The identifier of the data set created by this operation is returned upon successful completion.

pfvtksave dataset filetype filename [options]

This command loads PFB or SILO output, reads a DEM from a file and generates a 3D VTK output field from that PARFLOW output.

The options: Any combination of these can be used and they can be specified in any order as long as the required elements immediately follow each option.

-var specifies what the variable written to the dataset will be called. This is followed by a text string, like "Pressure" or "Saturation" to define the name of the data that will be written to the VTK. If this isn't specified, you'll get a property written to the file creatively called "Variable". This option is ignored if you are using -clmvtk since all its variables are predefined.

-dem specifies that a DEM is to be used. The argument following -dem MUST be the handle of the dataset containing the elevations. If it cannot be found, the tool ignores it and reverts to non-dem mode. If the nx and ny dimensions of the grids don't match, the tool will error out. This option shifts the layers so that the top of the domain coincides with the land surface defined by the DEM. Regardless of the actual number of layers in the DEM file, the tool only uses the elevations in the top layer of this dataset, meaning a 1-layer PFB can be used.

-flt tells the tool to write the data as type float instead of double. Since the VTKs are really only used for visualization, this reduces the file size and speeds up plotting.

-tfg causes the tool to override the specified dz in the dataset PFB and uses a user specified list of layer thicknesses instead. This is designed for terrain following grids and can only be used in conjunction with a DEM. The argument following the flag is a text string containing the number of layers and the dz list of actual layer thicknesses (not dz multipliers) for each layer from the bottom up such as: -tfg "5 200.0 1.0 0.7 0.2 0.1" Note that the quotation marks around the list are necessary.

Example:

```
file copy -force CLM_dem.cpf fb CLM_dem.pfb

set CLMdat [pfload -pfb clm.out.clm_output.00005.C.pfb]
set Pdat [pfload -pfb clm.out.press.00005.pfb]
set Perm [pfload -pfb clm.out.perm_x.pfb]
set DEMdat [pfload -pfb CLM_dem.pfb]

set dzlist "10 6.0 5.0 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5"

pfvtksave $Pdat -vtk "CLM.out.Press.00005a.vtk" -var "Press"
```

```

pfvtksave $Pdat -vtk "CLM.out.Press.00005b.vtk" -var "Press" -flt
pfvtksave $Pdat -vtk "CLM.out.Press.00005c.vtk" -var "Press" -dem $DEMdat
pfvtksave $Pdat -vtk "CLM.out.Press.00005d.vtk" -var "Press" -dem $DEMdat -flt
pfvtksave $Pdat -vtk "CLM.out.Press.00005e.vtk" -var "Press" -dem $DEMdat -flt -tfg $dzlist
pfvtksave $Perm -vtk "CLM.out.Perm.00005.vtk" -var "Perm" -flt -dem $DEMdat -tfg $dzlist

pfvtksave $CLMdat -clmvtk "CLM.out.CLM.00005.vtk" -flt
pfvtksave $CLMdat -clmvtk "CLM.out.CLM.00005.vtk" -flt -dem $DEMdat

pfvtksave $DEMdat -vtk "CLM.out.Elev.00000.vtk" -flt -var "Elevation" -dem $DEMdat

```

pfvvel conductivity phead

This command computes the Darcy velocity in cells for the conductivity data set represented by the identifier 'conductivity' and the pressure head data set represented by the identifier 'phead'. The identifier of the data set created by this operation is returned upon successful completion.

pfwatertabledepth top saturation

This command computes the water table depth (distance from top to first cell with saturation = 1). The identifier of the data set created by this operation is returned upon successful completion.

pfwritedb runname

This command writes the settings of parflow run to a pfidb database that can be used to run the model at a later time. In general this command is used in lieu of the pfrun command.

4.3 Common examples using PARFLOW TCL commands (PFTCL)

This section contains some brief examples of how to use the pftools commands (along with standard *TCL* commands) to postprocess data.

1. Load a file as one format and write as another format.

```

set press [pfload harvey_flow.out.press.pfb]
pfsave $press -sa harvey_flow.out.sa

#####
# Also note that PFTCL automatically assigns
# identifiers to each data set it stores. In this
# example we load the pressure file and assign
# it the identifier press. However if you
# read in a file called foo.pfb into a TCL shell
# with assigning your own identifier, you get
# the following:

#parflow> pfload foo.pfb
#dataset0

# In this example, the first line is typed in by the
# user and the second line is printed out
# by PFTCL. It indicates that the data read
# from file foo.pfb is associated with the
# identifier dataset0.

```

2. Load pressure-head output from a file, convert to head-potential and write out as a new file.

```

set press [pload harvey_flow.out.press.pfb]
set head [pfhhead $press]
pfsave $head -pfb harvey_flow.head.pfb

```

3. Build a SAMRAI compatible domain decomposition based off of a mask file

```

#-----
# This example script takes 3 command line arguments
# for P,Q,R and then builds a SAMRAI compatible
# domain decomposition based off of a mask file.
#-----

# Processor Topology
set P [lindex $argv 0]
set Q [lindex $argv 1]
set R [lindex $argv 2]
pfset Process.Topology.P $P
pfset Process.Topology.Q $Q
pfset Process.Topology.R $R

# Computational Grid
pfset ComputationalGrid.Lower.X -10.0
pfset ComputationalGrid.Lower.Y 10.0
pfset ComputationalGrid.Lower.Z 1.0

pfset ComputationalGrid.DX 8.8888888888888893
pfset ComputationalGrid.DY 10.666666666666666
pfset ComputationalGrid.DZ 1.0

pfset ComputationalGrid.NX 10
pfset ComputationalGrid.NY 10
pfset ComputationalGrid.NZ 8

# Calculate top and bottom and build domain
set mask [pload samrai.out.mask.pfb]
set top [pfcomputetop $mask]
set bottom [pfcomputebottom $mask]

set domain [pfcomputedomain $top $bottom]
set out [pfprintdomain $domain]
set grid_file [open samrai_grid.tcl w]

puts $grid_file $out
close $grid_file

#-----
# The resulting TCL file samrai_grid.tcl may be read into
# a Parflow input file using source samrai_grid.tcl.
#-----

```

4. Distributing input files before running

```

#-----
# A common problem for new ParFlow users is to
# distribute slope files using
# the 3-D computational grid that is
# set at the begging of a run script.
# This results in errors because slope
# files are 2-D.
# To avoid this problem the computational
# grid should be reset before and after
# distributing slope files. As follows:
#-----

#First set NZ to 1 and distribute the 2D slope files
pfset ComputationalGrid.NX      40
pfset ComputationalGrid.NY      40
pfset ComputationalGrid.NZ      1
pfdist slopex.pfb
pfdist slopey.pfb

#Reset NZ to the correct value and distribute any 3D inputs
pfset ComputationalGrid.NX      40
pfset ComputationalGrid.NY      40
pfset ComputationalGrid.NZ      50
pfdist IndicatorFile.pfb

```

5. Calculate slopes from an elevation file

```

#Read in DEM
set dem [pload -sa dem.txt]
pfsetgrid {209 268 1} {0.0 0.0 0.0} {100 100 1.0} $dem

# Fill flat areas (if any)
set flatfill [pffillflats $dem]

# Fill pits (if any)
set pitfill [pfpitfilldem $flatfill 0.01 10000]

# Calculate Slopes
set slope_x [pfslopex $pitfill]
set slope_y [pfslopey $pitfill]

# Write to output...
pfsave $flatfill -silo klam.flatfill.silo
pfsave $pitfill -silo klam.pitfill.silo
pfsave $slope_x -pfb klam.slope_x.pfb
pfsave $slope_y -pfb klam.slope_y.pfb

```

6. Calculate and output the *subsurface storage* in the domain at a point in time.

```

set saturation [pload runname.out.satur.00001.silo]
set pressure [pload runname.out.press.00001.silo]
set specific_storage [pload runname.out.specific_storage.silo]
set porosity [pload runname.out.porosity.silo]

```

```

set mask [pload runname.out.mask.silo]

set subsurface_storage [pfsurfacestorage $mask $porosity \
$pressure $saturation $specific_storage]
set total_subsurface_storage [pfsum $subsurface_storage]
puts [format "Subsurface storage\t\t\t\t : %.16e" $total_subsurface_storage]

```

7. Calculate and output the *surface storage* in the domain at a point in time.

```

set pressure [pload runname.out.press.00001.silo]
set mask [pload runname.out.mask.silo]
set top [pfcomputetop $mask]
set surface_storage [pfsurfacestorage $top $pressure]
set total_surface_storage [pfsum $surface_storage]
puts [format "Surface storage\t\t\t\t : %.16e" $total_surface_storage]

```

8. Calculate and output the runoff out of the *entire domain* over a timestep.

```

set pressure [pload runname.out.press.00001.silo]
set slope_x [pload runname.out.slope_x.silo]
set slope_y [pload runname.out.slope_y.silo]
set mannings [pload runname.out.mannings.silo]
set mask [pload runname.out.mask.silo]
set top [pfcomputetop $mask]

set surface_runoff [pfsurfacerunoff $top $slope_x $slope_y $mannings $pressure]
set total_surface_runoff [expr [pfsum $surface_runoff] * [pfget TimeStep.Value]]
puts [format "Surface runoff from pftools\t\t\t : %.16e" $total_surface_runoff]

```

9. Calculate overland flow at a point using *Manning's* equation

```

#Set the location
set Xloc 2
set Yloc 2
set Zloc 50 #This should be a z location on the surface of your domain

#Set the grid dimension and Mannings roughness coefficient
set dx 1000.0
set n 0.000005

#Get the slope at the point
set slopex [pload runname.out.slope_x.pfb]
set slopey [pload runname.out.slope_y.pfb]
set sx1 [pfgetelt $slopex $Xloc $Yloc 0]
set sy1 [pfgetelt $slopey $Xloc $Yloc 0]
set S [expr ($sx**2+$sy**2)**0.5]

#Get the pressure at the point
set press [pload runname.out.press.00001.pfb]
set P [pfgetelt $press $Xloc $Yloc $Zloc]

#If the pressure is less than zero set to zero
if {$P < 0} { set P 0 }
set QT [expr ($dx/$n)*($S**0.5)*($P**(5./3.))]
puts $QT

```

Chapter 5

Model Equations

In this chapter, we discuss the model equations used by PARFLOW for its fully and variably saturated flow, overland flow, and multiphase flow and transport models. First, section 5.1 describes steady-state, groundwater flow (specified by solver **IMPES**). Next, section 5.2 describes the Richards' equation model (specified by solver **RICHARDS**) for variably saturated flow as implemented in PARFLOW. Section 5.3 describes the terrain following grid formulation. Next, the overland flow equations are presented in section 5.5. In section 5.6 we describe the multi-phase flow equations (specified by solver **IMPES**), and in section 5.7 we describe the transport equations. Finally, section 5.8 presents some notation and units and section 5.9 presents some basic water balance equations.

5.1 Steady-State, Saturated Groundwater Flow

Many groundwater problems are solved assuming steady-state, fully-saturated groundwater flow. This follows the form often written as:

$$\nabla \cdot \mathbf{q} = Q(x) \quad (5.1)$$

where Q is the spatially-variable source-sink term (to represent wells, etc) and \mathbf{q} is the Darcy flux [L^2T^{-1}] which is commonly written as:

$$\mathbf{q} = -\mathbf{K}\nabla H \quad (5.2)$$

where \mathbf{K} is the saturated, hydraulic conductivity tensor [LT^{-1}] and H [L] is the head-potential. Inspection of 5.19 and 5.20 show that these equations agree with the above formulation for a single-phase ($i = 1$), fully-saturated ($S_i = S = 1$), problem where the mobility, λ_i , is set to the saturated hydraulic conductivity, \mathbf{K} , below. This is accomplished by setting the relative permeability and viscosity terms to unity in 5.21 as well as the gravity and density terms in 5.20. This is shown in the example in § 3.6, but please note that the resulting solution is in pressure-head, h , not head potential, H , and will still contain a hydrostatic pressure gradient in the z direction.

5.2 Richards' Equation

The form of Richards' equation implemented in PARFLOW is given as,

$$S(p)S_s \frac{\partial p}{\partial t} - \frac{\partial(S(p)\rho(p)\phi)}{\partial t} - \nabla \cdot (\mathbf{K}(p)\rho(p)(\nabla p - \rho(p)\vec{g})) = Q, \text{ in } \Omega, \quad (5.3)$$

where Ω is the flow domain, p is the pressure-head of water [L], S is the water saturation, S_s is the specific storage coefficient [L^{-1}], ϕ is the porosity of the medium, $\mathbf{K}(p)$ is the hydraulic conductivity tensor [LT^{-1}], and Q is the

water source/sink term $[L^3T^{-1}]$ (includes wells and surface fluxes). The hydraulic conductivity can be written as,

$$K(p) = \frac{\bar{k}k_r(p)}{\mu} \quad (5.4)$$

Boundary conditions can be stated as,

$$p = p_D, \text{ on } \Gamma^D, \quad (5.5)$$

$$-K(p)\nabla p \cdot \mathbf{n} = g_N, \text{ on } \Gamma^N, \quad (5.6)$$

where $\Gamma^D \cup \Gamma^N = \partial\Omega$, $\Gamma^D \neq \emptyset$, and \mathbf{n} is an outward pointing, unit, normal vector to Ω . This is the mixed form of Richards' equation. Note here that due to the constant (or passive) air phase pressure assumption, Richards' equation ignores the air phase except through its effects on the hydraulic conductivity, K . An initial condition,

$$p = p^0(x), \quad t = 0, \quad (5.7)$$

completes the specification of the problem.

5.3 Terrain Following Grid

The terrain following grid formulation transforms the PARFLOW grid to conform to topography [92]. This alters the form of Darcy's law to include a topographic slope component:

$$q_x = \mathbf{K}(p)\rho(p)\left(\frac{\partial p}{\partial x} \cos \theta_x + \sin \theta_x\right) \quad (5.8)$$

where $\theta_x = \arctan(S_0, x)$ and $\theta_y = \arctan(S_0, y)$ which are assumed to be the same as the **TopoSlope** keys assigned for overland flow, described below. The terrain following grid formulation can be very useful for coupled surface-subsurface flow problems where groundwater flow follows the topography. As cells are distributed near the ground surface and can be combined with the variable δZ capability, the number of cells in the problem can be reduced dramatically over the orthogonal formulation. For complete details on this formulation, the stencil used and the function evaluation developed, please see [92]. NOTE: in the original formulation, θ_x and θ_y for a cell face is calculated as the average of the two adjacent cell slopes (i.e. assuming a cell centered slope calculation). The **TerrainFollowingGrid.SlopeUpwindFormulation** key provide options to use the slope of a grid cell directly (i.e. assuming face centered slope calculations) and removing the sine term from 5.8. The **Upwind** and **UpwindSine** options for this key will provide consistent results with **OverlandKinematic** and **OverlandDiffusive** boundary conditions while the **Original** option is consistent with the standard **OverlandFlow** boundary condition.

5.4 Flow Barriers

The the flow barrier multipliers allow for the reduction in flow across a cell face. This slightly alters Darcy's law to include a flow reduction in each direction, show here in x:

$$q_x = FB_x \mathbf{K}(p)\rho(p)\left(\frac{\partial p}{\partial x} \cos \theta_x + \sin \theta_x\right) \quad (5.9)$$

where FB_x , FB_y and FB_z are a dimensionless multipliers specified by the **FBx**, **FBy** and **FBz** keys. This creates behavior equivalent to the Hydraulic Flow Barrier (HFB) or *ITFC* (flow and transport parameters at interfaces) conditions in other models.

5.5 Overland Flow

As detailed in [65], PARFLOW may simulate fully-coupled surface and subsurface flow via an overland flow boundary condition. While complete details of this approach are given in that paper, a brief summary of the equations solved are presented here. Shallow overland flow is now represented in PARFLOW by the kinematic wave equation. In two spatial dimensions, the continuity equation can be written as:

$$\frac{\partial \psi_s}{\partial t} = \nabla \cdot (\vec{v} \psi_s) + q_r(x) \quad (5.10)$$

where \vec{v} is the depth averaged velocity vector [LT^{-1}]; ψ_s is the surface ponding depth [L] and $q_r(x)$ is the a general source/sink (e.g. rainfall) rate [LT^{-1}]. If diffusion terms are neglected the momentum equation can be written as:

$$S_{f,i} = S_{o,i} \quad (5.11)$$

which is commonly referred to as the kinematic wave approximation. In Equation 5.11 $S_{o,i}$ is the bed slope (gravity forcing term) $[-]$, which is equal to the friction slope $S_{f,i}$ [L]; i stands for the x - and y -direction. Manning's equation is used to establish a flow depth-discharge relationship:

$$v_x = -\frac{\sqrt{S_{f,x}}}{n} \psi_s^{2/3} \quad (5.12)$$

and

$$v_y = -\frac{\sqrt{S_{f,y}}}{n} \psi_s^{2/3} \quad (5.13)$$

where n [$TL^{-1/3}$] is the Manning's coefficient.

Though complete details of the coupled approach are given in [65], brief details of the approach are presented here. The coupled approach takes Equation 5.10 and adds a flux for subsurface exchanges, $q_e(x)$.

$$\frac{\partial \psi_s}{\partial t} = \nabla \cdot (\vec{v} \psi_s) + q_r(x) + q_e(x) \quad (5.14)$$

We then assign a continuity of pressure at the top cell of the boundary between the surface and subsurface systems by setting pressure-head, p in 5.3 equal to the vertically-averaged surface pressure, ψ_s as follows:

$$p = \psi_s = \psi \quad (5.15)$$

If we substitute this relationship back into Equation 5.14 as follows:

$$\frac{\partial \|\psi, 0\|}{\partial t} = \nabla \cdot (\vec{v} \|\psi, 0\|) + q_r(x) + q_e(x) \quad (5.16)$$

Where the $\|\psi, 0\|$ operator chooses the greater of the two quantities, ψ and 0. We may now solve this term for the flux $q_e(x)$ which we may set equal to flux boundary condition shown in Equation 5.6. This yields the following equation, which is referred to as the overland flow boundary condition [65]:

$$-K(\psi) \nabla \psi \cdot \mathbf{n} = \frac{\partial \|\psi, 0\|}{\partial t} - \nabla \cdot (\vec{v} \|\psi, 0\|) - q_r(x) \quad (5.17)$$

This results a version of the kinematic wave equation that is only active when the pressure at the top cell of the subsurface domain has a ponded depth and is thus greater than zero. This method solves both systems, where active in the domain, over common grids in a fully-integrated, fully-mass conservative manner.

The depth-discharge relationship can also be written as

$$v_x = -\frac{S_{f,x}}{n\sqrt{S_f}} \psi_s^{2/3} \quad (5.18)$$

Table 5.1: Notation and units for flow equations.

symbol	quantity	units
$\phi(\vec{x}, t)$	porosity	$[\]$
$S_i(\vec{x}, t)$	saturation	$[\]$
$\vec{V}_i(\vec{x}, t)$	Darcy velocity vector	$[LT^{-1}]$
$Q_i(\vec{x}, t)$	source/sink	$[T^{-1}]$
λ_i	mobility	$[L^3TM^{-1}]$
$p_i(\vec{x}, t)$	pressure	$[ML^{-1}T^{-2}]$
ρ_i	mass density	$[ML^{-3}]$
\vec{g}	gravity vector	$[LT^{-2}]$
$k(\vec{x}, t)$	intrinsic permeability tensor	$[L^2]$
$k_{ri}(\vec{x}, t)$	relative permeability	$[\]$
μ_i	viscosity	$[ML^{-1}T^{-1}]$
g	gravitational acceleration	$[LT^{-2}]$

where $\overline{S_f}$ is the magnitude of the friction slope. This formulation for overland flow is used in the **OverlandKinematic** and **OverlandDiffusive** boundary conditions. In **OverlandKinematic** case the friction slope equals the bed slope following Equation 5.11. For the **OverlandDiffusive** case the friction slope also includes the pressure gradient. The solution for both of these options is formulated to do the upwinding internally and assumes that the user provides face centered bedslopes ($S_{o,i}$). This is different from the original formulation which assumes the user provides grid centered bedslopes.

5.6 Multi-Phase Flow Equations

The flow equations are a set of *mass balance* and *momentum balance* (Darcy's Law) equations, given respectively by,

$$\frac{\partial}{\partial t}(\phi S_i) + \nabla \cdot \vec{V}_i - Q_i = 0, \quad (5.19)$$

$$\vec{V}_i + \lambda_i \cdot (\nabla p_i - \rho_i \vec{g}) = 0, \quad (5.20)$$

for $i = 0, \dots, n_p - 1$ ($n_p \in \{1, 2, 3\}$), where

$$\lambda_i = \frac{\bar{k} k_{ri}}{\mu_i}, \quad (5.21)$$

$$\vec{g} = [0, 0, -g]^T, \quad (5.22)$$

Table 5.1 defines the symbols in the above equations, and outlines the symbol dependencies and units. Here, ϕ describes the fluid capacity of the porous medium, and S_i describes the content of phase i in the porous medium, where we have that $0 \leq \phi \leq 1$ and $0 \leq S_i \leq 1$. The coefficient \bar{k} is considered a scalar here. We also assume that ρ_i and μ_i are constant. Also note that in PARFLOW, we assume that the relative permeability is given as $k_{ri}(S_i)$. The Darcy velocity vector is related to the *velocity vector*, \vec{v}_i , by the following:

$$\vec{V}_i = \phi S_i \vec{v}_i. \quad (5.23)$$

To complete the formulation, we have the following n_p *constitutive relations*

$$\sum_i S_i = 1, \quad (5.24)$$

$$p_{i0} = p_{i0}(S_0), \quad i = 1, \dots, n_p - 1. \quad (5.25)$$

where, $p_{ij} = p_i - p_j$ is the *capillary pressure* between phase i and phase j . We now have the $3n_p$ equations, (5.19), (5.20), (5.24), and (5.25), in the $3n_p$ unknowns, S_i , \vec{V}_i , and p_i .

For technical reasons, we want to rewrite the above equations. First, we define the *total mobility*, λ_T , and the *total velocity*, \vec{V}_T , by the relations

$$\lambda_T = \sum_i \lambda_i, \quad (5.26)$$

$$\vec{V}_T = \sum_i \vec{V}_i. \quad (5.27)$$

After doing a bunch of algebra, we get the following equation for p_0 :

$$- \sum_i \{ \nabla \cdot \lambda_i (\nabla(p_0 + p_{i0}) - \rho_i \vec{g}) + Q_i \} = 0. \quad (5.28)$$

After doing some more algebra, we get the following $n_p - 1$ equations for S_i :

$$\frac{\partial}{\partial t}(\phi S_i) + \nabla \cdot \left(\frac{\lambda_i}{\lambda_T} \vec{V}_T + \sum_{j \neq i} \frac{\lambda_i \lambda_j}{\lambda_T} (\rho_i - \rho_j) \vec{g} \right) + \sum_{j \neq i} \nabla \cdot \frac{\lambda_i \lambda_j}{\lambda_T} \nabla p_{ji} - Q_i = 0. \quad (5.29)$$

The capillary pressures p_{ji} in (5.29) are rewritten in terms of the constitutive relations in (5.25) so that we have

$$p_{ji} = p_{j0} - p_{i0}, \quad (5.30)$$

where by definition, $p_{ii} = 0$. Note that equations (5.29) are analytically the same equations as in (5.19). The reason we rewrite them in this latter form is because of the numerical scheme we are using. We now have the $3n_p$ equations, (5.28), (5.29), (5.27), (5.20), and (5.25), in the $3n_p$ unknowns, S_i , \vec{V}_i , and p_i .

5.7 Transport Equations

The transport equations in PARFLOW are currently defined as follows:

$$\begin{aligned} & \left(\frac{\partial}{\partial t}(\phi c_{i,j}) + \lambda_j \phi c_{i,j} \right) + \nabla \cdot (c_{i,j} \vec{V}_i) \\ &= \\ & - \left(\frac{\partial}{\partial t}((1 - \phi) \rho_s F_{i,j}) + \lambda_j (1 - \phi) \rho_s F_{i,j} \right) + \sum_k^{n_I} \gamma_k^{I;i} \chi_{\Omega_k^I} (c_{i,j} - \bar{c}_{ij}^k) - \sum_k^{n_E} \gamma_k^{E;i} \chi_{\Omega_k^E} c_{i,j} \end{aligned} \quad (5.31)$$

where $i = 0, \dots, n_p - 1$ ($n_p \in \{1, 2, 3\}$) is the number of phases, $j = 0, \dots, n_c - 1$ is the number of contaminants, and where $c_{i,j}$ is the concentration of contaminant j in phase i . Recall also, that χ_A is the characteristic function of set A , i.e. $\chi_A(x) = 1$ if $x \in A$ and $\chi_A(x) = 0$ if $x \notin A$. Table 5.2 defines the symbols in the above equation, and outlines the symbol dependencies and units. The equation is basically a statement of mass conservation in a convective flow (no diffusion) with adsorption and degradation effects incorporated along with the addition of injection and extraction wells. These equations will soon have to be generalized to include a diffusion term. At the present time, as an adsorption model, we take the mass concentration term ($F_{i,j}$) to be instantaneous in time and a linear function of contaminant concentration :

$$F_{i,j} = K_{d;j} c_{i,j}, \quad (5.32)$$

where $K_{d;j}$ is the distribution coefficient of the component ($[L^3 M^{-1}]$). If 5.32 is substituted into 5.31 the following equation results (which is the current model used in PARFLOW) :

$$\begin{aligned} & (\phi + (1 - \phi) \rho_s K_{d;j}) \frac{\partial}{\partial t} c_{i,j} + \nabla \cdot (c_{i,j} \vec{V}_i) \\ &= \\ & - (\phi + (1 - \phi) \rho_s K_{d;j}) \lambda_j c_{i,j} + \sum_k^{n_I} \gamma_k^{I;i} \chi_{\Omega_k^I} (c_{i,j} - \bar{c}_{ij}^k) - \sum_k^{n_E} \gamma_k^{E;i} \chi_{\Omega_k^E} c_{i,j} \end{aligned} \quad (5.33)$$

Table 5.2: Notation and units for transport equation.

symbol	quantity	units
$\phi(\vec{x})$	porosity	$[\]$
$c_{i,j}(\vec{x}, t)$	concentration fraction	$[\]$
$\vec{V}_i(\vec{x}, t)$	Darcy velocity vector	$[LT^{-1}]$
λ_j	degradation rate	$[T^{-1}]$
$\rho_s(\vec{x})$	density of the solid mass	$[ML^{-3}]$
$F_{i,j}(\vec{x}, t)$	mass concentration	$[L^3M^{-1}]$
n_I	number of injection wells	$[\]$
$\gamma_k^{I;i}(t)$	injection rate	$[T^{-1}]$
$\Omega_k^I(\vec{x})$	injection well region	$[\]$
$\bar{c}_{ij}^k()$	injected concentration fraction	$[\]$
n_E	number of extraction wells	$[\]$
$\gamma_k^{E;i}(t)$	extraction rate	$[T^{-1}]$
$\Omega_k^E(\vec{x})$	extraction well region	$[\]$

Table 5.3: Notation and units for reformulated flow equations.

symbol	quantity	units
\vec{V}_i	Darcy velocity vector	$[LT^{-1}]$
\bar{K}_i	hydraulic conductivity tensor	$[LT^{-1}]$
h_i	pressure head	$[L]$
γ	constant scale factor	$[ML^{-2}T^{-2}]$
\vec{g}	gravity vector	$[LT^{-2}]$

5.8 Notation and Units

In this section, we discuss other common formulations of the flow and transport equations, and how they relate to the equations solved by PARFLOW.

We can rewrite equation (5.20) as

$$\vec{V}_i + \bar{K}_i \cdot (\nabla h_i - \frac{\rho_i}{\gamma} \vec{g}) = 0, \quad (5.34)$$

where

$$\bar{K}_i = \gamma \lambda_i, \quad (5.35)$$

$$h_i = (p_i - \bar{p})/\gamma. \quad (5.36)$$

Table 5.3 defines the symbols and their units. We can then rewrite equations (5.28) and (5.29) as

$$- \sum_i \left\{ \nabla \cdot \bar{K}_i \left(\nabla(h_0 + h_{i0}) - \frac{\rho_i}{\gamma} \vec{g} \right) + Q_i \right\} = 0, \quad (5.37)$$

$$\frac{\partial}{\partial t}(\phi S_i) + \nabla \cdot \left(\frac{\bar{K}_i}{\bar{K}_T} \vec{V}_T + \sum_{j \neq i} \frac{\bar{K}_i \bar{K}_j}{\bar{K}_T} \left(\frac{\rho_i}{\gamma} - \frac{\rho_j}{\gamma} \right) \vec{g} \right) + \sum_{j \neq i} \nabla \cdot \frac{\bar{K}_i \bar{K}_j}{\bar{K}_T} \nabla h_{ji} - Q_i = 0. \quad (5.38)$$

Note that \bar{K}_i is supposed to be a tensor, but we treat it as a scalar here. Also, note that by carefully defining the input to PARFLOW, we can use the units of equations (5.37) and (5.38). To be more precise, let us denote PARFLOW

input symbols by appending the symbols in table 5.1 with (I) , and let $\gamma = \rho_0 g$ (this is a typical definition). Then, we want:

$$\bar{k}(I) = \gamma \bar{k} / \mu_0; \quad (5.39)$$

$$\mu_i(I) = \mu_i / \mu_0; \quad (5.40)$$

$$p_i(I) = h_i; \quad (5.41)$$

$$\rho_i(I) = \rho_i / \rho_0; \quad (5.42)$$

$$g(I) = 1. \quad (5.43)$$

By doing this, $\bar{k}(I)$ represents hydraulic conductivity of the base phase \bar{K}_0 (e.g. water) under saturated conditions (i.e. $k_{r0} = 1$).

5.9 Water Balance

PARFLOW can calculate a water balance for the Richards' equation, overland flow and `clm` capabilities. For a schematic of the water balance in PARFLOW please see [90]. This water balance is computed using `pftools` commands as described in § 4. There are two water balance storage components, subsurface and surface, and two flux calculations, overland flow and evapotranspiration. The storage components have units $[L^3]$ while the fluxes may be instantaneous and have units $[L^3 T^{-1}]$ or cumulative over an output interval with units $[L^3]$. Examples of water balance calculations and errors are given in the scripts `water_balance_x.tcl` and `water_balance_y.tcl`. The size of water balance errors depend on solver settings and tolerances but are typically very small, $< 10^{-10}[-]$.

The water balance takes the form:

$$\frac{\Delta[Vol_{subsurface} + Vol_{surface}]}{\Delta t} = Q_{overland} + Q_{evapotranspiration} + Q_{sourcesink} \quad (5.44)$$

where $Vol_{subsurface}$ is the subsurface storage $[L^3]$; $Vol_{surface}$ is the surface storage $[L^3]$; $Q_{overland}$ is the overland flux $[L^3 T^{-1}]$; $Q_{evapotranspiration}$ is the evapotranspiration flux passed from `clm` or other LSM, etc, $[L^3 T^{-1}]$; and $Q_{sourcesink}$ are any other source/sink fluxes specified in the simulation $[L^3 T^{-1}]$. The surface and subsurface storage routines are calculated using the PARFLOW toolset commands `pfsurfacestorage` and `pfsurfacestorage` respectively. Overland flow out of the domain is calculated by `pfsurfacerrunoff`. Details for the use of these commands are given in § 4.2 and § 4.3. $Q_{evapotranspiration}$ must be written out by PARFLOW as a variable (as shown in § refCode Parameters) and only contains the external fluxes passed from a module such as `clm` or `WRF`. Note that these volume and flux quantities are calculated spatially over the domain and are returned as array values, just like any other quantity in PARFLOW. The tools command `pfsum` will sum these arrays into a single value for the entire domain. All other fluxes must be determined by the user.

The subsurface storage is calculated over all active cells in the domain, Ω , and contains both compressible and incompressible parts based on Equation 5.3. This is computed on a cell-by-cell basis (with the result being an array of balances over the domain) as follows:

$$Vol_{subsurface} = \sum_{\Omega} [S(\psi) S_s \psi \Delta x \Delta y \Delta z + S(\psi) (\psi) \phi \Delta x \Delta y \Delta z] \quad (5.45)$$

The surface storage is calculated over the upper surface boundary cells in the domain, Γ , as computed by the mask and contains based on Equation 5.10. This is again computed on a cell-by-cell basis (with the result being an array of balances over the domain) as follows:

$$Vol_{surface} = \sum_{\Gamma} \psi \Delta x \Delta y \quad (5.46)$$

For the overland flow outflow from the domain, any cell at the top boundary that has a slope that points out of the domain and is ponded will remove water from the domain. This is calculated, for example in the y-direction, as the multiple of Equation 5.13 and the area:

$$Q_{overland} = vA = -\frac{\sqrt{S_{f,y}}}{n} \psi_s^{2/3} \psi \Delta x = -\frac{\sqrt{S_{f,y}}}{n} \psi_s^{5/3} \Delta x \quad (5.47)$$

Chapter 6

ParFlow Files

In this chapter, we discuss the various file formats used in PARFLOW. To help simplify the description of these formats, we use a pseudocode notation composed of *fields* and *control constructs*.

A field is a piece of data having one of the *field types* listed in Table 6.1 (note that field types may have one meaning in ASCII files and another meaning in binary files). Fields are denoted by enclosing the field name with a < on the left and a > on the right. The field name is composed of alphanumeric characters and underscores (_). In the defining entry of a field, the field name is also prepended by its field type and a :. The control constructs used in our pseudocode have the keyword names FOR, IF, and LINE, and the beginning and end of each of these constructs is delimited by the keywords BEGIN and END.

The FOR construct is used to describe repeated input format patterns. For example, consider the following file format:

```
<integer : num_coordinates>
FOR coordinate = 0 TO <num_coordinates> - 1
BEGIN
  <real : x> <real : y> <real : z>
END
```

The field <num_coordinates> is an integer specifying the number of coordinates to follow. The FOR construct indicates that <num_coordinates> entries follow, and each entry is composed of the three real fields, <x>, <y>, and <z>. Here is an example of a file with this format:

```
3
2.0 1.0 -3.5
1.0 1.1 -3.1
2.5 3.0 -3.7
```

The IF construct is actually an IF/ELSE construct, and is used to describe input format patterns that appear only under certain circumstances. For example, consider the following file format:

Table 6.1: Field types.

field type	ASCII	binary
integer	integer	XDR integer
real	real	-
string	string	-
double	-	IEEE 8 byte double
float	-	IEEE 4 byte float

```

<integer : type>
IF (<type> = 0)
BEGIN
    <real : x> <real : y> <real : z>
END
ELSE IF (<type> = 1)
BEGIN
    <integer : i> <integer : j> <integer : k>
END

```

The field `<type>` is an integer specifying the “type” of input to follow. The IF construct indicates that if `<type>` has value 0, then the three real fields, `<x>`, `<y>`, and `<z>`, follow. If `<type>` has value 1, then the three integer fields, `<i>`, `<j>`, and `<k>`, follow. Here is an example of a file with this format:

```

0
2.0 1.0 -3.5

```

The LINE construct indicates fields that are on the same line of a file. Since input files in PARFLOW are all in “free format”, it is used only to describe some output file formats. For example, consider the following file format:

```

LINE
BEGIN
    <real : x>
    <real : y>
    <real : z>
END

```

The LINE construct indicates that the three real fields, `<x>`, `<y>`, and `<z>`, are all on the same line. Here is an example of a file with this format:

```

2.0 1.0 -3.5

```

Comment lines may also appear in our file format pseudocode. All text following a # character is a comment, and is not part of the file format.

6.1 Main Input File (.tcl)

The main PARFLOW input file is a TCL script. This might seem overly combersome at first but the basic input file structure is not very complicated (although it is somewhat verbose). For more advanced users, the TCL scripting means you can very easily create programs to run PARFLOW. A simple example is creating a loop to run several hundred different simulations using different seeds to the random field generators. This can be automated from within the PARFLOW input file.

The basic idea behind PARFLOW input is a simple database. The database contains entries which have a key and a value associated with that key. This is very similiar in nature to the Windows XP/Vista registry and several other systems. When PARFLOW runs, it queries the database you have created by key names to get the values you have specified.

The command `pfset` is used to create the database entries. A simple PARFLOW input script contains a long list of `pfset` commands.

It should be noted that the keys are “dynamic” in that many are built up from values of other keys. For example if you have two wells named *northwell* and *southwell* then you will have to set some keys which specify the parameters for each well. The keys are built up in a simple sort of heirarchy.

The following sections contain a description of all of the keys used by PARFLOW. For an example of input files you can look at the `test` subdirectory of the PARFLOW distribution. Looking over some examples should give you a good feel for how the file scripts are put together.

Each key’s entry has the form:

type **KeyName** [default value]

Description

Example Usage:

The “type” is one of integer, double, string, list. Integer and double are IEEE numbers. String is a text string (for example, a filename). Strings can contain spaces if you use the proper TCL syntax (i.e. using double quotes). These types are standard TCL types. Lists are strings but they indicate the names of a series of items. For example you might need to specify the names of the geometries. You would do this using space separated names (what we are calling a list) “layer1 layer2 layer3”.

The descriptions that follow are organized into functional areas. An example for each database entry is given.

Note that units used for each physical quantity specified in the input file must be consistent with units used for all other quantities. The exact units used can be any consistent set as PARFLOW does not assume any specific set of units. However, it is up to the user to make sure all specifications are indeed consistent.

6.1.1 Input File Format Number

integer **FileVersion** [no default]

This gives the value of the input file version number that this file fits.

Example Usage:

```
pfset FileVersion 4
```

As development of the PARFLOW code continues, the input file format will vary. We have thus included an input file format number as a way of verifying that the correct format type is being used. The user can check in the `parflow/config/file_versions.h` file to verify that the format number specified in the input file matches the defined value of `PFIN_VERSION`.

6.1.2 Computing Topology

This section describes how processors are assigned in order to solve the domain in parallel. `Process.Topology.X` allocates the number of processes to the grid-cells in x. `Process.Topology.Y` allocates the number of processes to the grid-cells in y. `Process.Topology.Z` allocates the number of processes to the grid-cells in z. Please note `Process.Topology.Z` should always be 1 if you are running with Solver Richards [57] unless you’re running a totally saturated domain (solver IMPES).

integer **Process.Topology.P** [no default]

This assigns the process splits in the *x* direction.

Example Usage:

```
pfset Process.Topology.P            2
```

integer **Process.Topology.Q** [no default]

This assigns the process splits in the *y* direction.

Example Usage:

```
pfset Process.Topology.Q            1
```

integer **Process.Topology.R** [no default]

This assigns the process splits in the *z* direction.

Example Usage:

```
pfset Process.Topology.R            1
```

In addition, you can assign the computing topology when you initiate your parflow script using tcl. You must include the topology allocation when using tclsh and the parflow script.

Example Usage:

[from Terminal] `tclsh default_single.tcl 2 1 1`

[At the top of `default_single.tcl` you must include the following]

```
set NP [lindex $argv 0]
```

```
set NQ [lindex $argv 1]
```

```
pfset Process.Topology.P      $NP
```

```
pfset Process.Topology.Q      $NQ
```

```
pfset Process.Topology.R      1
```

6.1.3 Computational Grid

The computational grid is briefly described in § 3.1. The computational grid keys set the bottom left corner of the domain to a specific point in space. If using a `.pfsol` file, the bottom left corner location of the `.pfsol` file must be the points designated in the computational grid. The user can also assign the x , y and z location to correspond to a specific coordinate system (i.e. UTM).

double **ComputationalGrid.Lower.X** [no default]

This assigns the lower x coordinate location for the computational grid.

Example Usage:

```
pfset ComputationalGrid.Lower.X 0.0
```

double **ComputationalGrid.Lower.Y** [no default]

This assigns the lower y coordinate location for the computational grid.

Example Usage:

```
pfset ComputationalGrid.Lower.Y 0.0
```

double **ComputationalGrid.Lower.Z** [no default]

This assigns the lower z coordinate location for the computational grid.

Example Usage:

```
pfset ComputationalGrid.Lower.Z 0.0
```

integer **ComputationalGrid.NX** [no default]

This assigns the number of grid cells in the x direction for the computational grid.

Example Usage:

```
pfset ComputationalGrid.NX 10
```

integer **ComputationalGrid.NY** [no default]

This assigns the number of grid cells in the y direction for the computational grid.

Example Usage:

```
pfset ComputationalGrid.NY 10
```

integer **ComputationalGrid.NZ** [no default]

This assigns the number of grid cells in the z direction for the computational grid.

Example Usage:

```
pfset ComputationalGrid.NZ 10
```

real **ComputationalGrid.DX** [no default]

This defines the size of grid cells in the x direction. Units are L and are defined by the units of the hydraulic conductivity used in the problem.

Example Usage:

```
pfset ComputationalGrid.DX 10.0
```

real **ComputationalGrid.DY** [no default]

This defines the size of grid cells in the y direction. Units are L and are defined by the units of the hydraulic conductivity used in the problem.

Example Usage:

```
pfset ComputationalGrid.DY 10.0
```

real **ComputationalGrid.DZ** [no default]

This defines the size of grid cells in the z direction. Units are L and are defined by the units of the hydraulic conductivity used in the problem.

Example Usage:

```
pfset ComputationalGrid.DZ 1.0
```

Example Usage:

```
#-----
# Computational Grid
#-----
pfset ComputationalGrid.Lower.X -10.0
pfset ComputationalGrid.Lower.Y 10.0
pfset ComputationalGrid.Lower.Z 1.0

pfset ComputationalGrid.NX 18
pfset ComputationalGrid.NY 18
pfset ComputationalGrid.NZ 8

pfset ComputationalGrid.DX 8.0
pfset ComputationalGrid.DY 10.0
pfset ComputationalGrid.DZ 1.0
```

string **UseClustering** [True]

Run a clustering algorithm to create boxes in index space for iteration. By default an octree representation is used for iteration, this may result in iterating over many nodes in the octree. The UseClustering key will run a clustering algorithm to build a set of boxes for iteration.

This does not always have a significant impact on performance and the clustering algorithm can be expensive to compute. For small problems and short running problems clustering is not recommended. Long running problems may or may not see a benefit. The result varies significantly based on the geometries in the problem.

The Berger-Rigoutsos algorithm is currently used for clustering.

Example Usage:

```
pfset UseClustering False
```

6.1.4 Geometries

Here we define all “geometrical” information needed by PARFLOW. For example, the domain (and patches on the domain where boundary conditions are to be imposed), lithology or hydrostratigraphic units, faults, initial plume shapes, and so on, are considered geometries.

This input section is a little confusing. Two items are being specified, geometry inputs and geometries. A geometry input is a type of geometry input (for example a box or an input file). A geometry input can contain more than one geometry. A geometry input of type Box has a single geometry (the square box defined by the extents of the two points). A SolidFile input type can contain several geometries.

list **GeomInput.Names** [no default]

This is a list of the geometry input names which define the containers for all of the geometries defined for this problem.

Example Usage:

```
pfset GeomInput.Names "solidinput indinput boxinput"
```

string **GeomInput.geom_input_name.InputType** [no default]

This defines the input type for the geometry input with *geom_input_name*. This key must be one of: **SolidFile**, **IndicatorField**, **Box**.

Example Usage:

```
pfset GeomInput.solidinput.InputType SolidFile
```

list **GeomInput.geom_input_name.GeomNames** [no default]

This is a list of the names of the geometries defined by the geometry input. For a geometry input type of **Box**, the list should contain a single geometry name. For the **SolidFile** geometry type this should contain a list with the same number of geometries as were defined using GMS. The order of geometries in the **SolidFile** should match the names. For **IndicatorField** types you need to specify the value in the input field which matches the name using *GeomInput.geom_input_name.Value*.

Example Usage:

```
pfset GeomInput.solidinput.GeomNames "domain bottomlayer \
middlelayer toplayer"
```

string **GeomInput.geom_input_name.Filename** [no default]

For **IndicatorField** and **SolidFile** geometry inputs this key specifies the input filename which contains the field or solid information.

Example Usage:

```
pfset GeomInput.solidinput.FileName ocwd.pfsol
```

integer **GeomInput.geometry_input_name.Value** [no default]

For **IndicatorField** geometry inputs you need to specify the mapping between values in the input file and the geometry names. The named geometry will be defined wherever the input file is equal to the specified value.

Example Usage:

```
pfset GeomInput.sourceregion.Value 11
```

For box geometries you need to specify the location of the box. This is done by defining two corners of the the box.

double **Geom.box_geom_name.Lower.X** [no default]

This gives the lower \bar{X} real space coordinate value of the previously specified box geometry of name *box_geom_name*.

Example Usage:

```
pfset Geom.background.Lower.X -1.0
```

double **Geom.box_geom_name.Lower.Y** [no default]

This gives the lower \bar{Y} real space coordinate value of the previously specified box geometry of name *box_geom_name*.

Example Usage:

```
pfset Geom.background.Lower.Y -1.0
```

double **Geom.box_geom_name.Lower.Z** [no default]

This gives the lower \bar{Z} real space coordinate value of the previously specified box geometry of name *box_geom_name*.

Example Usage:

```
pfset Geom.background.Lower.Z -1.0
```

double **Geom.box_geom_name.Upper.X** [no default]

This gives the upper \bar{X} real space coordinate value of the previously specified box geometry of name *box_geom_name*.

Example Usage:

```
pfset Geom.background.Upper.X 151.0
```



```

pfset GeomInput.sourceregion.Value 11
pfset GeomInput.concenregion.Value 12

#
# A box is just a box defined by two points.
#

pfset GeomInput.boxinput.InputType Box
pfset GeomInput.boxinput.GeomName background
pfset Geom.background.Lower.X -1.0
pfset Geom.background.Lower.Y -1.0
pfset Geom.background.Lower.Z -1.0
pfset Geom.background.Upper.X 151.0
pfset Geom.background.Upper.Y 171.0
pfset Geom.background.Upper.Z 11.0

#
# The patch order is fixed in the .pfsol file, but you
# can call the patch name anything you
# want (i.e. left right front back bottom top)
#

pfset Geom.domain.Patches          " z-upper x-lower y-lower \
                                   x-upper y-upper z-lower"

```

6.1.5 Timing Information

The data given in the timing section describe all the “temporal” information needed by PARFLOW. The data items are used to describe time units for later sections, sequence iterations in time, indicate actual starting and stopping values and give instructions on when data is printed out.

double **TimingInfo.BaseUnit** [no default]

This key is used to indicate the base unit of time for entering time values. All time should be expressed as a multiple of this value. This should be set to the smallest interval of time to be used in the problem. For example, a base unit of “1” means that all times will be integer valued. A base unit of “0.5” would allow integers and fractions of 0.5 to be used for time input values.

The rationale behind this restriction is to allow time to be discretized on some interval to enable integer arithmetic to be used when computing/comparing times. This avoids the problems associated with real value comparisons which can lead to events occurring at different timesteps on different architectures or compilers.

This value is also used when describing “time cycling data” in, currently, the well and boundary condition sections. The lengths of the cycles in those sections will be integer multiples of this value, therefore it needs to be the smallest divisor which produces an integral result for every “real time” cycle interval length needed.

Example Usage:

```
pfset TimingInfo.BaseUnit      1.0
```

integer **TimingInfo.StartCount** [no default]

This key is used to indicate the time step number that will be associated with the first advection cycle in a transient problem. The value **-1** indicates that advection is not to be done. The value **0** indicates that advection should begin with the given initial conditions. Values greater than **0** are intended to mean “restart” from some previous “checkpoint” time-step, but this has not yet been implemented.

Example Usage:

```
pfset TimingInfo.StartCount    0
```

double **TimingInfo.StartTime** [no default]

This key is used to indicate the starting time for the simulation.

Example Usage:

```
pfset TimingInfo.StartTime    0.0
```

double **TimingInfo.StopTime** [no default]

This key is used to indicate the stopping time for the simulation.

Example Usage:

```
pfset TimingInfo.StopTime    100.0
```

double **TimingInfo.DumpInterval** [no default]

This key is the real time interval at which time-dependent output should be written. A value of **0** will produce undefined behavior. If the value is negative, output will be dumped out every n time steps, where n is the absolute value of the integer part of the value.

Example Usage:

```
pfset TimingInfo.DumpInterval    10.0
```

integer **TimingInfo.DumpIntervalExecutionTimeLimit** [0]

This key is used to indicate a wall clock time to halt the execution of a run. At the end of each dump interval the time remaining in the batch job is compared with the user supplied value, if remaining time is less than or equal to the supplied value the execution is halted. Typically used when running on batch systems with time limits to force a clean shutdown near the end of the batch job. Time units is seconds, a value of **0** (the default) disables the check.

Currently only supported on SLURM based systems, “-with-slurm” must be specified at configure time to enable.

Example Usage:

```
pfset TimingInfo.DumpIntervalExecutionTimeLimit 360
```

For *Richards’ equation cases only* input is collected for time step selection. Input for this section is given as follows:

list **TimeStep.Type** [no default]

This key must be one of: **Constant** or **Growth**. The value **Constant** defines a constant time step. The value **Growth** defines a time step that starts as dt_0 and is defined for other steps as $dt^{new} = \gamma dt^{old}$ such that $dt^{new} \leq dt_{max}$ and $dt^{new} \geq dt_{min}$.

Example Usage:

```
pfset TimeStep.Type    Constant
```

double **TimeStep.Value** [no default]

This key is used only if a constant time step is selected and indicates the value of the time step for all steps taken.

Example Usage:

```
pfset TimeStep.Value    0.001
```

double **TimeStep.InitialStep** [no default]

This key specifies the initial time step dt_0 if the **Growth** type time step is selected.

Example Usage:

```
pfset TimeStep.InitialStep    0.001
```

double **TimeStep.GrowthFactor** [no default]

This key specifies the growth factor γ by which a time step will be multiplied to get the new time step when the **Growth** type time step is selected.

Example Usage:

```
pfset TimeStep.GrowthFactor 1.5
```

double **TimeStep.MaxStep** [no default]

This key specifies the maximum time step allowed, dt_{max} , when the **Growth** type time step is selected.

Example Usage:

```
pfset TimeStep.MaxStep 86400
```

double **TimeStep.MinStep** [no default]

This key specifies the minimum time step allowed, dt_{min} , when the **Growth** type time step is selected.

Example Usage:

```
pfset TimeStep.MinStep 1.0e-3
```

Here is a detailed example of how timing keys might be used in a simulation.

```
#-----
# Setup timing info [hr]
# 8760 hours in a year. Dumping files every 24 hours. Hourly timestep
#-----
pfset TimingInfo.BaseUnit 1.0
pfset TimingInfo.StartCount 0
pfset TimingInfo.StartTime 0.0
pfset TimingInfo.StopTime 8760.0
pfset TimingInfo.DumpInterval -24

## Timing constant example
pfset TimeStep.Type Constant
pfset TimeStep.Value 1.0

## Timing growth example
pfset TimeStep.Type Growth
pfset TimeStep.InitialStep 0.0001
TimeStep.GrowthFactor 1.4
TimeStep.MaxStep 1.0
TimeStep.MinStep 0.0001
```

6.1.6 Time Cycles

The data given in the time cycle section describe how time intervals are created and named to be used for time-dependent boundary and well information needed by PARFLOW. All the time cycles are synced to the **Timing-Info.BaseUnit** key described above and are *integer multipliers* of that value.

list **CycleNames** [no default]

This key is used to specify the named time cycles to be used in a simulation. It is a list of names and each name defines a time cycle and the number of items determines the total number of time cycles specified. Each named cycle is described using a number of keys defined below.

Example Usage:

```
pfset Cycle.Names constant onoff
```

list **Cycle.cycle_name.Names** [no default]

This key is used to specify the named time intervals for each cycle. It is a list of names and each name defines a time interval when a specific boundary condition is applied and the number of items determines the total number of intervals in that time cycle.

Example Usage:

```
pfset Cycle.onoff.Names "on off"
```

integer **Cycle.cycle_name.interval_name.Length** [no default]

This key is used to specify the length of a named time intervals. It is an *integer multiplier* of the value set for the **TimingInfo.BaseUnit** key described above. The total length of a given time cycle is the sum of all the intervals multiplied by the base unit.

Example Usage:

```
pfset Cycle.onoff.on.Length      10
```

integer **Cycle.cycle_name.Repeat** [no default]

This key is used to specify the how many times a named time interval repeats. A positive value specifies a number of repeat cycles a value of -1 specifies that the cycle repeat for the entire simulation.

Example Usage:

```
pfset Cycle.onoff.Repeat      -1
```

Here is a detailed example of how time cycles might be used in a simualtion.

```
#-----
# Time Cycles
#-----
pfset Cycle.Names "constant rainrec"
pfset Cycle.constant.Names "alltime"
pfset Cycle.constant.alltime.Length 8760
pfset Cycle.constant.Repeat -1

# Creating a rain and recession period for the rest of year
pfset Cycle.rainrec.Names "rain rec"
pfset Cycle.rainrec.rain.Length 10
pfset Cycle.rainrec.rec.Length 8750
pfset Cycle.rainrec.Repeat -1
```

6.1.7 Domain

The domain may be represented by any of the solid types in § 6.1.4 above that allow the definition of surface patches. These surface patches are used to define boundary conditions in § 6.1.25 and § 6.1.26 below. Subsequently, it is required that the union (or combination) of the defined surface patches equal the entire domain surface. NOTE: This requirement is NOT checked in the code.

string **Domain.GeomName** [no default]

This key specifies which of the named geometries is the problem domain.

Example Usage:

```
pfset Domain.GeomName      domain
```

6.1.8 Phases and Contaminants

list **Phase.Names** [no default]

This specifies the names of phases to be modeled. Currently only 1 or 2 phases may be modeled.

Example Usage:

```
pfset Phase.Names      "water"
```

list **Contaminant.Names** [no default]

This specifies the names of contaminants to be advected.

Example Usage:

```
pfset Contaminants.Names      "tce"
```


6.1.9 Gravity, Phase Density and Phase Viscosity

double **Gravity** [no default]

Specifies the gravity constant to be used.

Example Usage:

```
pfset Gravity 1.0
```

string **Phase.*phase_name*.Density.Type** [no default]

This key specifies whether density will be a constant value or if it will be given by an equation of state of the form $(rd)exp(cP)$, where P is pressure, rd is the density at atmospheric pressure, and c is the phase compressibility constant. This key must be either **Constant** or **EquationOfState**.

Example Usage:

```
pfset Phase.water.Density.Type Constant
```

double **Phase.*phase_name*.Density.Value** [no default]

This specifies the value of density if this phase was specified to have a constant density value for the phase *phase_name*.

Example Usage:

```
pfset Phase.water.Density.Value 1.0
```

double **Phase.*phase_name*.Density.ReferenceDensity** [no default]

This key specifies the reference density if an equation of state density function is specified for the phase *phase_name*.

Example Usage:

```
pfset Phase.water.Density.ReferenceDensity 1.0
```

double **Phase.*phase_name*.Density.CompressibilityConstant** [no default]

This key specifies the phase compressibility constant if an equation of state density function is specified for the phase *phase/-name*.

Example Usage:

```
pfset Phase.water.Density.CompressibilityConstant 1.0
```

string **Phase.*phase_name*.Viscosity.Type** [Constant]

This key specifies whether viscosity will be a constant value. Currently, the only choice for this key is **Constant**.

Example Usage:

```
pfset Phase.water.Viscosity.Type Constant
```

double **Phase.*phase_name*.Viscosity.Value** [no default]

This specifies the value of viscosity if this phase was specified to have a constant viscosity value.

Example Usage:

```
pfset Phase.water.Viscosity.Value 1.0
```

6.1.10 Chemical Reactions

double **Contaminants.*contaminant_name*.Degradation.Value** [no default]

This key specifies the half-life decay rate of the named contaminant, *contaminant_name*. At present only first order decay reactions are implemented and it is assumed that one contaminant cannot decay into another.

Example Usage:

```
pfset Contaminants.tce.Degradation.Value 0.0
```

6.1.11 Permeability

In this section, permeability property values are assigned to grid points within geometries (specified in § 6.1.4 above) using one of the methods described below. Permeabilities are assumed to be a diagonal tensor with entries given as,

$$\begin{pmatrix} k_x(\mathbf{x}) & 0 & 0 \\ 0 & k_y(\mathbf{x}) & 0 \\ 0 & 0 & k_z(\mathbf{x}) \end{pmatrix} K(\mathbf{x}),$$

where $K(\mathbf{x})$ is the permeability field given below. Specification of the tensor entries (k_x, k_y and k_z) will be given at the end of this section.

The random field routines (*turning bands* and *pgs*) can use conditioning data if the user so desires. It is not necessary to use conditioning as PARFLOW automatically defaults to not use conditioning data, but if conditioning is desired, the following key should be set:

string **Perm.Conditioning.FileName** ["NA"]

This key specifies the name of the file that contains the conditioning data. The default string **NA** indicates that conditioning data is not applicable.

Example Usage:

```
pfset Perm.Conditioning.FileName "well_cond.txt"
```

The file that contains the conditioning data is a simple ascii file containing points and values. The format is:

```
nlines
x1 y1 z1 value1
x2 y2 z2 value2
. . . .
. . . .
. . . .
xn yn zn valuen
```

The value of *nlines* is just the number of lines to follow in the file, which is equal to the number of data points.

The variables *xi,yi,zi* are the real space coordinates (in the units used for the given parflow run) of a point at which a fixed permeability value is to be assigned. The variable *valuei* is the actual permeability value that is known.

Note that the coordinates are not related to the grid in any way. Conditioning does not require that fixed values be on a grid. The PGS algorithm will map the given value to the closest grid point and that will be fixed. This is done for speed reasons. The conditioned turning bands algorithm does not do this; conditioning is done for every grid point using the given conditioning data at the location given. Mapping to grid points for that algorithm does not give any speedup, so there is no need to do it.

NOTE: The given values should be the actual measured values - adjustment in the conditioning for the lognormal distribution that is assumed is taken care of in the algorithms.

The general format for the permeability input is as follows:

list **Geom.Perm.Names** [no default]

This key specifies all of the geometries to which a permeability field will be assigned. These geometries must cover the entire computational domain.

Example Usage:

```
pfset GeomInput.Names "background domain concen_region"
```

string **Geom.geometry_name.Perm.Type** [no default]

This key specifies which method is to be used to assign permeability data to the named geometry, *geometry_name*. It must be either **Constant**, **TurnBands**, **ParGuass**, or **PFBFile**. The **Constant** value indicates that a constant is to be assigned to all grid cells within a geometry. The **TurnBand** value indicates that Tompson's Turning Bands method is to be used to assign permeability data to all grid cells within a geometry [127]. The **ParGauss** value indicates that a Parallel Gaussian Simulator method is to be used to assign permeability data to all grid cells within

a geometry. The **PFBFile** value indicates that premeabilities are to be read from the “ParFlow Binary” file. Both the Turning Bands and Parallel Gaussian Simulators generate a random field with correlation lengths in the 3 spatial directions given by λ_x , λ_y , and λ_z with the geometric mean of the log normal field given by μ and the standard deviation of the normal field given by σ . In generating the field both of these methods can be made to stratify the data, that is follow the top or bottom surface. The generated field can also be made so that the data is normal or log normal, with or without bounds truncation. Turning Bands uses a line process, the number of lines used and the resolution of the process can be changed as well as the maximum normalized frequency K_{\max} and the normalized frequency increment δK . The Parallel Gaussian Simulator uses a search neighborhood, the number of simulated points and the number of conditioning points can be changed.

Example Usage:

```
pfset Geom.background.Perm.Type    Constant
```

double **Geom.geometry_name.Perm.Value** [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset Geom.domain.Perm.Value      1.0
```

double **Geom.geometry_name.Perm.LambdaX** [no default]

This key specifies the x correlation length, λ_x , of the field generated for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen.

Example Usage:

```
pfset Geom.domain.Perm.LambdaX    200.0
```

double **Geom.geometry_name.Perm.LambdaY** [no default]

This key specifies the y correlation length, λ_y , of the field generated for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen.

Example Usage:

```
pfset Geom.domain.Perm.LambdaY    200.0
```

double **Geom.geometry_name.Perm.LambdaZ** [no default]

This key specifies the z correlation length, λ_z , of the field generated for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen.

Example Usage:

```
pfset Geom.domain.Perm.LambdaZ    10.0
```

double **Geom.geometry_name.Perm.GeomMean** [no default]

This key specifies the geometric mean, μ , of the log normal field generated for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen.

Example Usage:

```
pfset Geom.domain.Perm.GeomMean   4.56
```

double **Geom.geometry_name.Perm.Sigma** [no default]

This key specifies the standard deviation, σ , of the normal field generated for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen.

Example Usage:

```
pfset Geom.domain.Perm.Sigma      2.08
```

integer **Geom.geometry_name.Perm.Seed** [1]

This key specifies the initial seed for the random number generator used to generate the field for the named geometry, *geometry_name*, if either the Turning Bands or Parallel Gaussian Simulator are chosen. This number must be positive.

Example Usage:

```
pfset Geom.domain.Perm.Seed 1
```

integer **Geom.geometry_name.Perm.NumLines** [100]

This key specifies the number of lines to be used in the Turning Bands algorithm for the named geometry, *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.NumLines 100
```

double **Geom.geometry_name.Perm.RZeta** [5.0]

This key specifies the resolution of the line processes, in terms of the minimum grid spacing, to be used in the Turning Bands algorithm for the named geometry, *geometry_name*. Large values imply high resolution.

Example Usage:

```
pfset Geom.domain.Perm.RZeta 5.0
```

double **Geom.geometry_name.Perm.KMax** [100.0]

This key specifies the the maximum normalized frequency, K_{\max} , to be used in the Turning Bands algorithm for the named geometry, *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.KMax 100.0
```

double **Geom.geometry_name.Perm.DelK** [0.2]

This key specifies the normalized frequency increment, δK , to be used in the Turning Bands algorithm for the named geometry, *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.DelK 0.2
```

integer **Geom.geometry_name.Perm.MaxNPts** [no default]

This key sets limits on the number of simulated points in the search neighborhood to be used in the Parallel Gaussian Simulator for the named geometry, *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.MaxNPts 5
```

integer **Geom.geometry_name.Perm.MaxCpts** [no default]

This key sets limits on the number of external conditioning points in the search neighborhood to be used in the Parallel Gaussian Simulator for the named geometry, *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.MaxCpts 200
```

string **Geom.geometry_name.Perm.LogNormal** ["LogTruncated"]

The key specifies when a normal, log normal, truncated normal or truncated log normal field is to be generated by the method for the named geometry, *geometry_name*. This value must be one of **Normal**, **Log**, **NormalTruncated** or **LogTruncate** and can be used with either Turning Bands or the Parallel Gaussian Simulator.

Example Usage:

```
pfset Geom.domain.Perm.LogNormal "LogTruncated"
```

string **Geom.geometry_name.Perm.StratType** ["Bottom"]

This key specifies the stratification of the permeability field generated by the method for the named geometry, *geometry_name*. The value must be one of **Horizontal**, **Bottom** or **Top** and can be used with either the Turning Bands or the Parallel Gaussian Simulator.

Example Usage:

```
pfset Geom.domain.Perm.StratType "Bottom"
```

double *Geom.geometry_name*.Perm.LowCutoff [no default]

This key specifies the low cutoff value for truncating the generated field for the named geometry, *geometry_name*, when either the NormalTruncated or LogTruncated values are chosen.

Example Usage:

```
pfset Geom.domain.Perm.LowCutoff    0.0
```

double *Geom.geometry_name*.Perm.HighCutoff [no default]

This key specifies the high cutoff value for truncating the generated field for the named geometry, *geometry_name*, when either the NormalTruncated or LogTruncated values are chosen.

Example Usage:

```
pfset Geom.domain.Perm.HighCutoff    100.0
```

string *Geom.geometry_name*.Perm.FileName [no default]

This key specifies that permeability values for the specified geometry, *geometry_name*, are given according to a user-supplied description in the “ParFlow Binary” file whose filename is given as the value. For a description of the ParFlow Binary file format, see § 6.3. The ParFlow Binary file associated with the named geometry must contain a collection of permeability values corresponding in a one-to-one manner to the entire computational grid. That is to say, when the contents of the file are read into the simulator, a complete permeability description for the entire domain is supplied. Only those values associated with computational cells residing within the geometry (as it is represented on the computational grid) will be copied into data structures used during the course of a simulation. Thus, the values associated with cells outside of the geounit are irrelevant. For clarity, consider a couple of different scenarios. For example, the user may create a file for each geometry such that appropriate permeability values are given for the geometry and “garbage” values (e.g., some flag value) are given for the rest of the computational domain. In this case, a separate binary file is specified for each geometry. Alternatively, one may place all values representing the permeability field on the union of the geometries into a single binary file. Note that the permeability values must be represented in precisely the same configuration as the computational grid. Then, the same file could be specified for each geounit in the input file. Or, the computational domain could be described as a single geounit (in the ParFlow input file) in which case the permeability values would be read in only once.

Example Usage:

```
pfset Geom.domain.Perm.FileName "domain_perm.pfb"
```

string Perm.TensorType [no default]

This key specifies whether the permeability tensor entries k_x , k_y and k_z will be specified as three constants within a set of regions covering the domain or whether the entries will be specified cell-wise by files. The choices for this key are **TensorByGeom** and **TensorByFile**.

Example Usage:

```
pfset Perm.TensorType    TensorByGeom
```

string Geom.Perm.TensorByGeom.Names [no default]

This key specifies all of the geometries to which permeability tensor entries will be assigned. These geometries must cover the entire computational domain.

Example Usage:

```
pfset Geom.Perm.TensorByGeom.Names    "background domain"
```

double *Geom.geometry_name*.Perm.TensorValX [no default]

This key specifies the value of k_x for the geometry given by *geometry_name*.

Example Usage:

```
pfset Geom.domain.Perm.TensorValX    1.0
```

double *Geom.geometry_name*.Perm.TensorValY [no default]

This key specifies the value of k_y for the geometry given by *geom_name*.

Example Usage:

```
pfset Geom.domain.Perm.TensorValY    1.0
```

double *Geom.geometry_name*.Perm.TensorValZ [no default]

This key specifies the value of k_z for the geometry given by *geom_name*.

Example Usage:

```
pfset Geom.domain.Perm.TensorValZ    1.0
```

string *Geom.geometry_name*.Perm.TensorFileX [no default]

This key specifies that k_x values for the specified geometry, *geometry_name*, are given according to a user-supplied description in the “ParFlow Binary” file whose filename is given as the value. The only choice for the value of *geometry_name* is “domain”.

Example Usage:

```
pfset Geom.domain.Perm.TensorByFileX    "perm_x.pfb"
```

string *Geom.geometry_name*.Perm.TensorFileY [no default]

This key specifies that k_y values for the specified geometry, *geometry_name*, are given according to a user-supplied description in the “ParFlow Binary” file whose filename is given as the value. The only choice for the value of *geometry_name* is “domain”.

Example Usage:

```
pfset Geom.domain.Perm.TensorByFileY    "perm_y.pfb"
```

string *Geom.geometry_name*.Perm.TensorFileZ [no default]

This key specifies that k_z values for the specified geometry, *geometry_name*, are given according to a user-supplied description in the “ParFlow Binary” file whose filename is given as the value. The only choice for the value of *geometry_name* is “domain”.

Example Usage:

```
pfset Geom.domain.Perm.TensorByFileZ    "perm_z.pfb"
```

6.1.12 Porosity

Here, porosity values are assigned within geounits (specified in § 6.1.4 above) using one of the methods described below.

The format for this section of input is:

list *Geom.Porosity.GeomNames* [no default]

This key specifies all of the geometries on which a porosity will be assigned. These geometries must cover the entire computational domain.

Example Usage:

```
pfset Geom.Porosity.GeomNames    "background"
```

string *Geom.geometry_name*.Porosity.Type [no default]

This key specifies which method is to be used to assign porosity data to the named geometry, *geometry_name*. The only choice currently available is **Constant** which indicates that a constant is to be assigned to all grid cells within a geometry.

Example Usage:

```
pfset Geom.background.Porosity.Type    Constant
```

double *Geom.geometry_name*.Porosity.Value [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset Geom.domain.Porosity.Value    1.0
```

6.1.13 Specific Storage

Here, specific storage (S_s in Equation 5.3) values are assigned within geounits (specified in § 6.1.4 above) using one of the methods described below.

The format for this section of input is:

list **SpecificStorage.GeomNames** [no default]

This key specifies all of the geometries on which a different specific storage value will be assigned. These geometries must cover the entire computational domain.

Example Usage:

```
pfset SpecificStorage.GeomNames      "domain"
```

string **SpecificStorage.Type** [no default]

This key specifies which method is to be used to assign specific storage data. The only choice currently available is **Constant** which indicates that a constant is to be assigned to all grid cells within a geometry.

Example Usage:

```
pfset SpecificStorage.Type           Constant
```

double **Geom.geometry_name.SpecificStorage.Value** [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset Geom.domain.SpecificStorage.Value 1.0e-4
```

6.1.14 dZMultipliers

Here, dZ multipliers ($\delta Z * m$) values are assigned within geounits (specified in § 6.1.4 above) using one of the methods described below.

The format for this section of input is:

string **Solver.Nonlinear.VariableDz** [False]

This key specifies whether dZ multipliers are to be used, the default is False. The default indicates a false or non-active variable dz and each layer thickness is 1.0 [L].

Example Usage:

```
pfset Solver.Nonlinear.VariableDz     True
```

list **dzScale.GeomNames** [no default]

This key specifies which problem domain is being applied a variable dz subsurface. These geometries must cover the entire computational domain.

Example Usage:

```
pfset dzScale.GeomNames domain
```

string **dzScale.Type** [no default]

This key specifies which method is to be used to assign variable vertical grid spacing. The choices currently available are **Constant** which indicates that a constant is to be assigned to all grid cells within a geometry, **nzList** which assigns all layers of a given model to a list value, and **PFBFile** which reads in values from a distributed pfb file.

Example Usage:

```
pfset dzScale.Type           Constant
```

list **Specific dzScale.GeomNames** [no default]

This key specifies all of the geometries on which a different dz scaling value will be assigned. These geometries must cover the entire computational domain.

Example Usage:

```
pfset dzScale.GeomNames      "domain"
```

double **Geom.geometry_name.dzScale.Value** [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset Geom.domain.dzScale.Value 1.0
```

string **Geom.geometry_name.dzScale.FileName** [no default]

This key specifies file to be read in for variable dz values for the given geometry, *geometry_name*, if the type was set to **PFBFile**.

Example Usage:

```
pfset Geom.domain.dzScale.FileName vardz.pfb
```

integer **dzScale.nzListNumber** [no default]

This key indicates the number of layers with variable dz in the subsurface. This value is the same as the *ComputationalGrid.NZ* key.

Example Usage:

```
pfset dzScale.nzListNumber 10
```

double **Cell.nzListNumber.dzScale.Value** [no default]

This key assigns the thickness of each layer defined by *nzListNumber*. ParFlow assigns the layers from the bottom-up (i.e. the bottom of the domain is layer 0, the top is layer *NZ*-1). The total domain depth (*Geom.domain.Upper.Z*) does not change with variable dz. The layer thickness is calculated by *ComputationalGrid.DZ * dzScale*.

Example Usage:

```
pfset Cell.0.dzScale.Value 1.0
```

Example Usage:

```
#-----
# Variable dz Assignments
#-----
# Set VariableDz to be true
# Indicate number of layers (nzlistnumber), which is the same as nz
# (1) There is nz*dz = total depth to allocate,
# (2) Each layer's thickness is dz*dzScale, and
# (3) Assign the layer thickness from the bottom up.
# In this example nz = 5; dz = 10; total depth 40;
# Layers    Thickness [m]
# 0    15    Bottom layer
# 1    15
# 2    5
# 3    4.5
# 4    0.5    Top layer
pfset Solver.Nonlinear.VariableDz    True
pfset dzScale.GeomNames            domain
pfset dzScale.Type                nzList
pfset dzScale.nzListNumber        5
pfset Cell.0.dzScale.Value 1.5
pfset Cell.1.dzScale.Value 1.5
pfset Cell.2.dzScale.Value 0.5
pfset Cell.3.dzScale.Value 0.45
pfset Cell.4.dzScale.Value 0.05
```


6.1.15 Flow Barriers

Here, the values for Flow Barriers described in 5.4 can be input. These are only available with Solver **Richards** and can be specified in X, Y or Z directions independently using PFB files. These barriers are applied at the cell face at the location $i + 1/2$. That is a value of FB_x specified at i will be applied to the cell face at $i + 1/2$ or /em between cells i and $i + 1$. The same goes for FB_y ($j + 1/2$) and FB_z ($k + 1/2$). The flow barrier values are unitless and multiply the flux equation as shown in 5.9.

The format for this section of input is:

string **Solver.Nonlinear.FlowBarrierX** [False]

This key specifies whether Flow Barriers are to be used in the X direction, the default is False. The default indicates a false or FB_x value of one [-] everywhere in the domain.

Example Usage:

```
pfset Solver.Nonlinear.FlowBarrierX     True
```

string **Solver.Nonlinear.FlowBarrierY** [False]

This key specifies whether Flow Barriers are to be used in the Y direction, the default is False. The default indicates a false or FB_y value of one [-] everywhere in the domain.

Example Usage:

```
pfset Solver.Nonlinear.FlowBarrierY     True
```

string **Solver.Nonlinear.FlowBarrierZ** [False]

This key specifies whether Flow Barriers are to be used in the Z direction, the default is False. The default indicates a false or FB_z value of one [-] everywhere in the domain.

Example Usage:

```
pfset Solver.Nonlinear.FlowBarrierZ     True
```

string **FBx.Type** [no default]

This key specifies which method is to be used to assign flow barriers in X. The only choice currently available is **PFBFile** which reads in values from a distributed pfb file.

Example Usage:

```
pfset FBx.Type                          PFBFile
```

string **FBy.Type** [no default]

This key specifies which method is to be used to assign flow barriers in Y. The only choice currently available is **PFBFile** which reads in values from a distributed pfb file.

Example Usage:

```
pfset FBy.Type                          PFBFile
```

string **FBz.Type** [no default]

This key specifies which method is to be used to assign flow barriers in Z. The only choice currently available is **PFBFile** which reads in values from a distributed pfb file.

Example Usage:

```
pfset FBz.Type                          PFBFile
```

The Flow Barrier values may be read in from a PFB file over the entire domain. This is done as follows:

string **Geom.domain.FBx.FileName** [no default]

This key specifies file to be read in for the X flow barrier values for the domain, if the type was set to **PFBFile**.

Example Usage:

```
pfset Geom.domain.FBx.FileName     Flow_Barrier_X.pfb
```

string **Geom.domain.FBy.FileName** [no default]

This key specifies file to be read in for the Y flow barrier values for the domain, if the type was set to **PFBFile**.

Example Usage:

```
pfset Geom.domain.FBy.FileName Flow_Barrier_Y.pfb
```

string **Geom.domain.FBz.FileName** [no default]

This key specifies file to be read in for the Z flow barrier values for the domain, if the type was set to **PFBFile**.

Example Usage:

```
pfset Geom.domain.FBz.FileName Flow_Barrier_Z.pfb
```

6.1.16 Manning's Roughness Values

Here, Manning's roughness values (n in Equations 5.12 and 5.13) are assigned to the upper boundary of the domain using one of the methods described below.

The format for this section of input is:

list **Mannings.GeomNames** [no default]

This key specifies all of the geometries on which a different Mannings roughness value will be assigned. Mannings values may be assigned by **PFBFile** or as **Constant** by geometry. These geometries must cover the entire upper surface of the computational domain.

Example Usage:

```
pfset Mannings.GeomNames        "domain"
```

string **Mannings.Type** [no default]

This key specifies which method is to be used to assign Mannings roughness data. The choices currently available are **Constant** which indicates that a constant is to be assigned to all grid cells within a geometry and **PFBFile** which indicates that all values are read in from a distributed, grid-based PARFLOW binary file.

Example Usage:

```
pfset Mannings.Type "Constant"
```

double **Mannings.Geom.geometry_name.Value** [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset Mannings.Geom.domain.Value 5.52e-6
```

double **Mannings.FileName** [no default]

This key specifies the value assigned to all points be read in from a PARFLOW binary file.

Example Usage:

```
pfset Mannings.FileName roughness.pfb
```

Complete example of setting Mannings roughness n values by geometry:

```
pfset Mannings.Type "Constant"
pfset Mannings.GeomNames "domain"
pfset Mannings.Geom.domain.Value 5.52e-6
```

6.1.17 Topographical Slopes

Here, topographical slope values ($S_{f,x}$ and $S_{f,y}$ in Equations 5.12 and 5.13) are assigned to the upper boundary of the domain using one of the methods described below. Note that due to the negative sign in these equations $S_{f,x}$ and $S_{f,y}$ take a sign in the direction *opposite* of the direction of the slope. That is, negative slopes point "downhill" and positive slopes "uphill".

The format for this section of input is:

list **ToposlopesX.GeomNames** [no default]

This key specifies all of the geometries on which a different x topographic slope values will be assigned. Topographic slopes may be assigned by **PFBFile** or as **Constant** by geometry. These geometries must cover the entire

upper surface of the computational domain.

Example Usage:

```
pfset TopoSlopesX.GeoNames "domain"
```

list **TopoSlopesY.GeoNames** [no default]

This key specifies all of the geometries on which a different *y* topographic slope values will be assigned. Topographic slopes may be assigned by **PFBFile** or as **Constant** by geometry. These geometries must cover the entire upper surface of the computational domain.

Example Usage:

```
pfset TopoSlopesY.GeoNames "domain"
```

string **TopoSlopesX.Type** [no default]

This key specifies which method is to be used to assign topographic slopes. The choices currently available are **Constant** which indicates that a constant is to be assigned to all grid cells within a geometry and **PFBFile** which indicates that all values are read in from a distributed, grid-based PARFLOW binary file.

Example Usage:

```
pfset TopoSlopesX.Type "Constant"
```

double **TopoSlopeX.Geo.geometry_name.Value** [no default]

This key specifies the value assigned to all points in the named geometry, *geometry_name*, if the type was set to constant.

Example Usage:

```
pfset TopoSlopeX.Geo.domain.Value 0.001
```

double **TopoSlopesX.FileName** [no default]

This key specifies the value assigned to all points be read in from a PARFLOW binary file.

Example Usage:

```
pfset TopoSlopesX.FileName lw.1km.slope_x.pfb
```

double **TopoSlopesY.FileName** [no default]

This key specifies the value assigned to all points be read in from a PARFLOW binary file.

Example Usage:

```
pfset TopoSlopesY.FileName lw.1km.slope_y.pfb
```

Example of setting *x* and *y* slopes by geometry:

```
pfset TopoSlopesX.Type "Constant"
pfset TopoSlopesX.GeoNames "domain"
pfset TopoSlopesX.Geo.domain.Value 0.001
```

```
pfset TopoSlopesY.Type "Constant"
pfset TopoSlopesY.GeoNames "domain"
pfset TopoSlopesY.Geo.domain.Value -0.001
```

Example of setting *x* and *y* slopes by file:

```
pfset TopoSlopesX.Type "PFBFile"
pfset TopoSlopesX.GeoNames "domain"
pfset TopoSlopesX.FileName lw.1km.slope_x.pfb
```

```
pfset TopoSlopesY.Type "PFBFile"
pfset TopoSlopesY.GeoNames "domain"
pfset TopoSlopesY.FileName lw.1km.slope_y.pfb
```

6.1.18 Retardation

Here, retardation values are assigned for contaminants within geounits (specified in § 6.1.4 above) using one of the functions described below. The format for this section of input is:

list **Geom.Retardation.GeomNames** [no default]

This key specifies all of the geometries to which the contaminants will have a retardation function applied.

Example Usage:

```
pfset Geom.Input.Names     "background"
```

string **Geom.geometry_name.contaminant_name.Retardation.Type** [no default]

This key specifies which function is to be used to compute the retardation for the named contaminant, *contaminant_name*, in the named geometry, *geometry_name*. The only choice currently available is **Linear** which indicates that a simple linear retardation function is to be used to compute the retardation.

Example Usage:

```
pfset Geom.background.tce.Retardation.Type     Linear
```

double **Geom.geometry_name.contaminant_name.Retardation.Value** [no default]

This key specifies the distribution coefficient for the linear function used to compute the retardation of the named contaminant, *contaminant_name*, in the named geometry, *geometry_name*. The value should be scaled by the density of the material in the geometry.

Example Usage:

```
pfset Geom.domain.Retardation.Value     0.2
```

6.1.19 Full Multiphase Mobilities

Here we define phase mobilities by specifying the relative permeability function. Input is specified differently depending on what problem is being specified. For full multi-phase problems, the following input keys are used. See the next section for the correct Richards' equation input format.

string **Phase.phase_name.Mobility.Type** [no default]

This key specifies whether the mobility for *phase_name* will be a given constant or a polynomial of the form, $(S - S_0)^a$, where S is saturation, S_0 is irreducible saturation, and a is some exponent. The possibilities for this key are **Constant** and **Polynomial**.

Example Usage:

```
pfset Phase.water.Mobility.Type     Constant
```

double **Phase.phase_name.Mobility.Value** [no default]

This key specifies the constant mobility value for phase *phase_name*.

Example Usage:

```
pfset Phase.water.Mobility.Value     1.0
```

double **Phase.phase_name.Mobility.Exponent** [2.0]

This key specifies the exponent used in a polynomial representation of the relative permeability. Currently, only a value of 2.0 is allowed for this key.

Example Usage:

```
pfset Phase.water.Mobility.Exponent     2.0
```

double **Phase.phase_name.Mobility.IrreducibleSaturation** [0.0]

This key specifies the irreducible saturation used in a polynomial representation of the relative permeability. Currently, only a value of 0.0 is allowed for this key.

Example Usage:

```
pfset Phase.water.Mobility.IrreducibleSaturation     0.0
```

6.1.20 Richards' Equation Relative Permeabilities

The following keys are used to describe relative permeability input for the Richards' equation implementation. They will be ignored if a full two-phase formulation is used.

string **Phase.RelPerm.Type** [no default]

This key specifies the type of relative permeability function that will be used on all specified geometries. Note that only one type of relative permeability may be used for the entire problem. However, parameters may be different for that type in different geometries. For instance, if the problem consists of three geometries, then **VanGenuchten** may be specified with three different sets of parameters for the three different geometries. However, once **VanGenuchten** is specified, one geometry cannot later be specified to have **Data** as its relative permeability. The possible values for this key are **Constant**, **VanGenuchten**, **Haverkamp**, **Data**, and **Polynomial**.

Example Usage:

```
pfset Phase.RelPerm.Type    Constant
```

The various possible functions are defined as follows. The **Constant** specification means that the relative permeability will be constant on the specified geounit. The **VanGenuchten** specification means that the relative permeability will be given as a Van Genuchten function [133] with the form,

$$k_r(p) = \frac{(1 - \frac{(\alpha p)^{n-1}}{(1 + (\alpha p)^n)^m})^2}{(1 + (\alpha p)^n)^{m/2}}, \quad (6.1)$$

where α and n are soil parameters and $m = 1 - 1/n$, on each region. The **Haverkamp** specification means that the relative permeability will be given in the following form [52],

$$k_r(p) = \frac{A}{A + p^\gamma}, \quad (6.2)$$

where A and γ are soil parameters, on each region. The **Data** specification is currently unsupported but will later mean that data points for the relative permeability curve will be given and PARFLOW will set up the proper interpolation coefficients to get values between the given data points. The **Polynomial** specification defines a polynomial relative permeability function for each region of the form,

$$k_r(p) = \sum_{i=0}^{degree} c_i p^i. \quad (6.3)$$

list **Phase.RelPerm.GeomNames** [no default]

This key specifies the geometries on which relative permeability will be given. The union of these geometries must cover the entire computational domain.

Example Usage:

```
pfset Phase.RelPerm.Geomnames    domain
```

double **Geom.geom_name.RelPerm.Value** [no default]

This key specifies the constant relative permeability value on the specified geometry.

Example Usage:

```
pfset Geom.domain.RelPerm.Value    0.5
```

integer **Phase.RelPerm.VanGenuchten.File** [0]

This key specifies whether soil parameters for the VanGenuchten function are specified in a pfb file or by region. The options are either 0 for specification by region, or 1 for specification in a file. Note that either all parameters are specified in files (each has their own input file) or none are specified by files. Parameters specified by files are: α and N .

Example Usage:

```
pfset Phase.RelPerm.VanGenuchten.File    1
```

string Geom.geom_name.RelPerm.Alpha.Filename [no default]

This key specifies a pfb filename containing the alpha parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is “domain”.

Example Usage:

```
pfset Geom.domain.RelPerm.Alpha.Filename    alphas.pfb
```

string Geom.geom_name.RelPerm.N.Filename [no default]

This key specifies a pfb filename containing the N parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is “domain”.

Example Usage:

```
pfset Geom.domain.RelPerm.N.Filename    Ns.pfb
```

double Geom.geom_name.RelPerm.Alpha [no default]

This key specifies the α parameter for the Van Genuchten function specified on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.Alpha    0.005
```

double Geom.geom_name.RelPerm.N [no default]

This key specifies the N parameter for the Van Genuchten function specified on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.N    2.0
```

int Geom.geom_name.RelPerm.NumSamplePoints [0]

This key specifies the number of sample points for a spline base interpolation table for the Van Genuchten function specified on *geom_name*. If this number is 0 (the default) then the function is evaluated directly. Using the interpolation table is faster but is less accurate.

Example Usage:

```
pfset Geom.domain.RelPerm.NumSamplePoints    20000
```

int Geom.geom_name.RelPerm.MinPressureHead [no default]

This key specifies the lower value for a spline base interpolation table for the Van Genuchten function specified on *geom_name*. The upper value of the range is 0. This value is used only when the table lookup method is used (*NumSamplePoints* is greater than 0).

Example Usage:

```
pfset Geom.domain.RelPerm.MinPressureHead    -300
```

double Geom.geom_name.RelPerm.A [no default]

This key specifies the A parameter for the Haverkamp relative permeability on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.A    1.0
```

double Geom.geom_name.RelPerm.Gamma [no default]

This key specifies the γ parameter for the Haverkamp relative permeability on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.Gamma    1.0
```

integer Geom.geom_name.RelPerm.Degree [no default]

This key specifies the degree of the polynomial for the Polynomial relative permeability given on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.Degree    1
```

double Geom.geom_name.RelPerm.Coeff.coeff_number [no default]

This key specifies the *coeff_number*th coefficient of the Polynomial relative permeability given on *geom_name*.

Example Usage:

```
pfset Geom.domain.RelPerm.Coeff.0 0.5
pfset Geom.domain.RelPerm.Coeff.1 1.0
```

NOTE: For all these cases, if only one region is to be used (the domain), the background region should NOT be set as that single region. Using the background will prevent the upstream weighting from being correct near Dirichlet boundaries.

6.1.21 Phase Sources

The following keys are used to specify phase source terms. The units of the source term are $1/T$. So, for example, to specify a region with constant flux rate of L^3/T , one must be careful to convert this rate to the proper units by dividing by the volume of the enclosing region. For *Richards' equation* input, the source term must be given as a flux multiplied by density.

string **PhaseSources.phase_name.Type** [no default]

This key specifies the type of source to use for phase *phase_name*. Possible values for this key are **Constant** and **PredefinedFunction**. **Constant** type phase sources specify a constant phase source value for a given set of regions. **PredefinedFunction** type phase sources use a preset function (choices are listed below) to specify the source. Note that the **PredefinedFunction** type can only be used to set a single source over the entire domain and not separate sources over different regions.

Example Usage:

```
pfset PhaseSources.water.Type    Constant
```

list **PhaseSources.phase_name.GeomNames** [no default]

This key specifies the names of the geometries on which source terms will be specified. This is used only for **Constant** type phase sources. Regions listed later “overlay” regions listed earlier.

Example Usage:

```
pfset PhaseSources.water.GeomNames    "bottomlayer middlelayer toplayer"
```

double **PhaseSources.phase_name.Geom.geom_name.Value** [no default]

This key specifies the value of a constant source term applied to phase *phase_name* on geometry *geom_name*.

Example Usage:

```
pfset PhaseSources.water.Geom.toplayer.Value    1.0
```

string **PhaseSources.phase_name.PredefinedFunction** [no default]

This key specifies which of the predefined functions will be used for the source. Possible values for this key are **X**, **XPlusYPlusZ**, **X3Y2PlusSinXYPlus1**, **X3Y4PlusX2PlusSinXYCosYPlus1**, **XYZTPlus1** and **XYZTPlus1PermTensor**.

Example Usage:

```
pfset PhaseSources.water.PredefinedFunction    XPlusYPlusZ
```

The choices for this key correspond to sources as follows:

X: source = 0.0

XPlusYPlusX: source = 0.0

X3Y2PlusSinXYPlus1: source = $-(3x^2y^2 + y \cos(xy))^2 - (2x^3y + x \cos(xy))^2 - (x^3y^2 + \sin(xy) + 1)(6xy^2 + 2x^3 - (x^2 + y^2) \sin(xy))$

This function type specifies that the source applied over the entire domain is as noted above. This corresponds to $p = x^3y^2 + \sin(xy) + 1$ in the problem $-\nabla \cdot (p\nabla p) = f$.

X3Y4PlusX2PlusSinXYCosYPlus1: source = $-(3x^2y^4 + 2x + y \cos(xy) \cos(y))^2 - (4x^3y^3 + x \cos(xy) \cos(y) - \sin(xy) \sin(y))^2 - (x^3y^4 + x^2 + \sin(xy) \cos(y) + 1)(6xy^4 + 2 - (x^2 + y^2 + 1) \sin(xy) \cos(y) + 12x^3y^2 - 2x \cos(xy) \sin(y))$

This function type specifies that the source applied over the entire domain is as noted above. This corresponds to $p = x^3y^4 + x^2 + \sin(xy) \cos(y) + 1$ in the problem $-\nabla \cdot (p\nabla p) = f$.

XYZTPlus1: source = $xyz - t^2(x^2y^2 + x^2z^2 + y^2z^2)$

This function type specifies that the source applied over the entire domain is as noted above. This corresponds to $p = xyz + 1$ in the problem $\frac{\partial p}{\partial t} - \nabla \cdot (p \nabla p) = f$.

XYZTPlus1PermTensor: source = $xyz - t^2(x^2y^23 + x^2z^22 + y^2z^2)$

This function type specifies that the source applied over the entire domain is as noted above. This corresponds to $p = xyz + 1$ in the problem $\frac{\partial p}{\partial t} - \nabla \cdot (Kp \nabla p) = f$, where $K = \text{diag}(1 \ 2 \ 3)$.

6.1.22 Capillary Pressures

Here we define capillary pressure. Note: this section needs to be defined *only* for multi-phase flow and should not be defined for single phase and Richards' equation cases. The format for this section of input is:

string **CapPressure.phase_name.Type** ["Constant"]

This key specifies the capillary pressure between phase 0 and the named phase, *phase_name*. The only choice available is **Constant** which indicates that a constant capillary pressure exists between the phases.

Example Usage:

```
pfset CapPressure.water.Type    Constant
```

list **CapPressure.phase_name.GeomNames** [no default]

This key specifies the geometries that capillary pressures will be computed for in the named phase, *phase_name*. Regions listed later "overlay" regions listed earlier. Any geometries not listed will be assigned 0.0 capillary pressure by PARFLOW.

Example Usage:

```
pfset CapPressure.water.GeomNames    "domain"
```

double **Geom.geometry_name.CapPressure.phase_name.Value** [0.0]

This key specifies the value of the capillary pressure in the named geometry, *geometry_name*, for the named phase, *phase_name*.

Example Usage:

```
pfset Geom.domain.CapPressure.water.Value    0.0
```

Important note: the code currently works only for capillary pressure equal zero.

6.1.23 Saturation

This section is *only* relevant to the Richards' equation cases. All keys relating to this section will be ignored for other cases. The following keys are used to define the saturation-pressure curve.

string **Phase.Saturation.Type** [no default]

This key specifies the type of saturation function that will be used on all specified geometries. Note that only one type of saturation may be used for the entire problem. However, parameters may be different for that type in different geometries. For instance, if the problem consists of three geometries, then **VanGenuchten** may be specified with three different sets of parameters for the three different geometries. However, once **VanGenuchten** is specified, one geometry cannot later be specified to have **Data** as its saturation. The possible values for this key are **Constant**, **VanGenuchten**, **Haverkamp**, **Data**, **Polynomial** and **PFBFile**.

Example Usage:

```
pfset Phase.Saturation.Type    Constant
```

The various possible functions are defined as follows. The **Constant** specification means that the saturation will be constant on the specified geounit. The **VanGenuchten** specification means that the saturation will be given as a Van Genuchten function [133] with the form,

$$s(p) = \frac{s_{sat} - s_{res}}{(1 + (\alpha p)^n)^m} + s_{res}, \quad (6.4)$$

where s_{sat} is the saturation at saturated conditions, s_{res} is the residual saturation, and α and n are soil parameters with $m = 1 - 1/n$, on each region. The **Haverkamp** specification means that the saturation will be given in the following form [52],

$$s(p) = \frac{\alpha(s_{sat} - s_{res})}{A + p^\gamma} + s_{res}, \quad (6.5)$$

where A and γ are soil parameters, on each region. The **Data** specification is currently unsupported but will later mean that data points for the saturation curve will be given and PARFLOW will set up the proper interpolation coefficients to get values between the given data points. The **Polynomial** specification defines a polynomial saturation function for each region of the form,

$$s(p) = \sum_{i=0}^{degree} c_i p^i. \quad (6.6)$$

The **PFBFile** specification means that the saturation will be taken as a spatially varying but constant in pressure function given by data in a PARFLOW binary (.pfb) file.

list **Phase.Saturation.GeomNames** [no default]

This key specifies the geometries on which saturation will be given. The union of these geometries must cover the entire computational domain.

Example Usage:

```
pfset Phase.Saturation.GeomNames     domain
```

double **Geom.geom_name.Saturation.Value** [no default]

This key specifies the constant saturation value on the *geom_name* region.

Example Usage:

```
pfset Geom.domain.Saturation.Value     0.5
```

integer **Phase.Saturation.VanGenuchten.File** [0]

This key specifies whether soil parameters for the VanGenuchten function are specified in a pfb file or by region. The options are either 0 for specification by region, or 1 for specification in a file. Note that either all parameters are specified in files (each has their own input file) or none are specified by files. Parameters specified by files are α , N , S_{Res} , and S_{Sat} .

Example Usage:

```
pfset Phase.Saturation.VanGenuchten.File     1
```

string **Geom.geom_name.Saturation.Alpha.Filename** [no default]

This key specifies a pfb filename containing the alpha parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is "domain".

Example Usage:

```
pfset Geom.domain.Saturation.Filename     alphas.pfb
```

string **Geom.geom_name.Saturation.N.Filename** [no default]

This key specifies a pfb filename containing the N parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is "domain".

Example Usage:

```
pfset Geom.domain.Saturation.N.Filename     Ns.pfb
```

string **Geom.geom_name.Saturation.SRes.Filename** [no default]

This key specifies a pfb filename containing the S_{Res} parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is "domain".

Example Usage:

```
pfset Geom.domain.Saturation.SRes.Filename  SRes.pfb
```

string **Geom.geom_name.Saturation.SSat.Filename** [no default]

This key specifies a pfb filename containing the SSat parameters for the VanGenuchten function cell-by-cell. The ONLY option for *geom_name* is “domain”.

Example Usage:

```
pfset Geom.domain.Saturation.SSat.Filename  SSats.pfb
```

double **Geom.geom_name.Saturation.Alpha** [no default]

This key specifies the α parameter for the Van Genuchten function specified on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.Alpha  0.005
```

double **Geom.geom_name.Saturation.N** [no default]

This key specifies the N parameter for the Van Genuchten function specified on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.N  2.0
```

Note that if both a Van Genuchten saturation and relative permeability are specified, then the soil parameters should be the same for each in order to have a consistent problem.

double **Geom.geom_name.Saturation.SRes** [no default]

This key specifies the residual saturation on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.SRes  0.0
```

double **Geom.geom_name.Saturation.SSat** [no default]

This key specifies the saturation at saturated conditions on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.SSat  1.0
```

double **Geom.geom_name.Saturation.A** [no default]

This key specifies the A parameter for the Haverkamp saturation on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.A  1.0
```

double **Geom.geom_name.Saturation.Gamma** [no default]

This key specifies the γ parameter for the Haverkamp saturation on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.Gamma  1.0
```

integer **Geom.geom_name.Saturation.Degree** [no default]

This key specifies the degree of the polynomial for the Polynomial saturation given on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.Degree  1
```

double **Geom.geom_name.Saturation.Coeff.coeff_number** [no default]

This key specifies the *coeff_number*th coefficient of the Polynomial saturation given on *geom_name*.

Example Usage:

```
pfset Geom.domain.Saturation.Coeff.0  0.5
```

```
pfset Geom.domain.Saturation.Coeff.1  1.0
```

string **Geom.geom_name.Saturation.FileName** [no default]

This key specifies the name of the file containing saturation values for the domain. It is assumed that *geom_name* is “domain” for this key.

Example Usage:

```
pfset Geom.domain.Saturation.FileName "domain_sats.pfb"
```

6.1.24 Internal Boundary Conditions

In this section, we define internal Dirichlet boundary conditions by setting the pressure at points in the domain. The format for this section of input is:

string **InternalBC.Names** [no default]

This key specifies the names for the internal boundary conditions. At each named point, x, y and z will specify the coordinate locations and h will specify the hydraulic head value of the condition. This real location is “snapped” to the nearest gridpoint in PARFLOW.

NOTE: Currently, PARFLOW assumes that internal boundary conditions and pressure wells are separated by at least one cell from any external boundary. The user should be careful of this when defining the input file and grid.

Example Usage:

```
pfset InternalBC.Names "fixedvalue"
```

double **InternalBC.internal_bc_name.X** [no default]

This key specifies the x-coordinate, x, of the named, *internal_bc_name*, condition.

Example Usage:

```
pfset InternalBC.fixedheadvalue.X 40.0
```

double **InternalBC.internal_bc_name.Y** [no default]

This key specifies the y-coordinate, y, of the named, *internal_bc_name*, condition.

Example Usage:

```
pfset InternalBC.fixedheadvalue.Y 65.2
```

double **InternalBC.internal_bc_name.Z** [no default]

This key specifies the z-coordinate, z, of the named, *internal_bc_name*, condition.

Example Usage:

```
pfset InternalBC.fixedheadvalue.Z 12.1
```

double **InternalBC.internal_bc_name.Value** [no default]

This key specifies the value of the named, *internal_bc_name*, condition.

Example Usage:

```
pfset InternalBC.fixedheadvalue.Value 100.0
```

6.1.25 Boundary Conditions: Pressure

Here we define the pressure boundary conditions. The Dirichlet conditions below are hydrostatic conditions, and it is assumed that at each phase interface the pressure is constant. *It is also assumed here that all phases are distributed within the domain at all times such that the lighter phases are vertically higher than the heavier phases.*

Boundary condition input is associated with domain patches (see § 6.1.7). Note that different patches may have different types of boundary conditions on them.

list **BCPressure.PatchNames** [no default]

This key specifies the names of patches on which pressure boundary conditions will be specified. Note that these must all be patches on the external boundary of the domain and these patches must “cover” that external boundary.

Example Usage:

```
pfset BCPressure.PatchNames "left right front back top bottom"
```

string **Patch.patch_name.BCPressure.Type** [no default]

This key specifies the type of boundary condition data given for patch *patch_name*. Possible values for this key are **DirEquilRefPatch**, **DirEquilPLinear**, **FluxConst**, **FluxVolumetric**, **PressureFile**, **FluxFile**, **OverlandFlow**, **OverlandFlowPFB**, **SeepageFace**, **OverlandKinematic**, **OverlandDiffusive** and **ExactSolution**. The choice **DirEquilRefPatch** specifies that the pressure on the specified patch will be in hydrostatic equilibrium with a constant reference pressure given on a reference patch. The choice **DirEquilPLinear** specifies that the pressure on the specified patch will be in hydrostatic equilibrium with pressure given along a piecewise line at elevation $z = 0$. The choice **FluxConst** defines a constant normal flux boundary condition through the domain patch. This flux must be specified in units of $[L]/[T]$. For *Richards' equation*, fluxes must be specified as a mass flux and given as the above flux multiplied by the density. Thus, this choice of input type for a Richards' equation problem has units of $([L]/[T])([M]/[L]^3)$. The choice **FluxVolumetric** defines a volumetric flux boundary condition through the domain patch. The units should be consistent with all other user input for the problem. For *Richards' equation* fluxes must be specified as a mass flux and given as the above flux multiplied by the density. The choice **PressureFile** defines a hydraulic head boundary condition that is read from a properly distributed .pfb file. Only the values needed for the patch are used. The choice **FluxFile** defines a flux boundary condition that is read from a properly distributed .pfb file defined on a grid consistent with the pressure field grid. Only the values needed for the patch are used. The choices **OverlandFlow** and **OverlandFlowPFB** both turn on fully-coupled overland flow routing as described in [65] and in § 5.5. The key **OverlandFlow** corresponds to a **Value** key with a positive or negative value, to indicate uniform fluxes (such as rainfall or evapotranspiration) over the entire domain while the key **OverlandFlowPFB** allows a .pfb file to contain grid-based, spatially-variable fluxes. The **OverlandKinematic** and **OverlandDiffusive** both turn on an kinematic and diffusive wave overland flow routing boundary that solve equation 5.18 and do the upwinding internally (i.e. assuming that the user provides cell face slopes, as opposed to the traditional cell centered slopes). The key **SeepageFace** simulates a boundary that allows flow to exit but keeps the surface pressure at zero. The choice **ExactSolution** specifies that an exact known solution is to be applied as a Dirichlet boundary condition on the respective patch. Note that this does not change according to any cycle. Instead, time dependence is handled by evaluating at the time the boundary condition value is desired. The solution is specified by using a predefined function (choices are described below). NOTE: These last six types of boundary condition input is for *Richards' equation cases only!*

Example Usage:

```
pfset Patch.top.BCPressure.Type DirEquilRefPatch
```

string **Patch.patch_name.BCPressure.Cycle** [no default]

This key specifies the time cycle to which boundary condition data for patch *patch_name* corresponds.

Example Usage:

```
pfset Patch.top.BCPressure.Cycle Constant
```

string **Patch.patch_name.BCPressure.RefGeom** [no default]

This key specifies the name of the solid on which the reference patch for the **DirEquilRefPatch** boundary condition data is given. Care should be taken to make sure the correct solid is specified in cases of layered domains.

Example Usage:

```
pfset Patch.top.BCPressure.RefGeom domain
```

string **Patch.patch_name.BCPressure.RefPatch** [no default]

This key specifies the reference patch on which the **DirEquilRefPatch** boundary condition data is given. This patch must be on the reference solid specified by the **Patch.patch_name.BCPressure.RefGeom** key.

Example Usage:

```
pfset Patch.top.BCPressure.RefPatch bottom
```

double **Patch.patch_name.BCPressure.interval_name.Value** [no default]

This key specifies the reference pressure value for the **DirEquilRefPatch** boundary condition or the constant flux value for the **FluxConst** boundary condition, or the constant volumetric flux for the **FluxVolumetric** boundary condition.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.Value -14.0
```

double **Patch.patch_name.BCPressure.interval_name.phase_name.IntValue** [no default]

Note that the reference conditions for types **DirEquilPLinear** and **DirEquilRefPatch** boundary conditions are for phase 0 *only*. This key specifies the constant pressure value along the interface with phase *phase_name* for cases with two phases present.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.water.IntValue -13.0
```

double **Patch.patch_name.BCPressure.interval_name.XLower** [no default]

This key specifies the lower *x* coordinate of a line in the xy-plane.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.XLower 0.0
```

double **Patch.patch_name.BCPressure.interval_name.YLower** [no default]

This key specifies the lower *y* coordinate of a line in the xy-plane.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.YLower 0.0
```

double **Patch.patch_name.BCPressure.interval_name.XUpper** [no default]

This key specifies the upper *x* coordinate of a line in the xy-plane.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.XUpper 1.0
```

double **Patch.patch_name.BCPressure.interval_name.YUpper** [no default]

This key specifies the upper *y* coordinate of a line in the xy-plane.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.YUpper 1.0
```

integer **Patch.patch_name.BCPressure.interval_name.NumPoints** [no default]

This key specifies the number of points on which pressure data is given along the line used in the type **DirEqui-IPLinear** boundary conditions.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.NumPoints 2
```

double **Patch.patch_name.BCPressure.interval_name.point_number.Location** [no default]

This key specifies a number between 0 and 1 which represents the location of a point on the line on which data is given for type **DirEquiIPLinear** boundary conditions. Here 0 corresponds to the lower end of the line, and 1 corresponds to the upper end.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.0.Location 0.0
```

double **Patch.patch_name.BCPressure.interval_name.point_number.Value** [no default]

This key specifies the pressure value for phase 0 at point number *point_number* and *z* = 0 for type **DirEqui-IPLinear** boundary conditions. All pressure values on the patch are determined by first projecting the boundary condition coordinate onto the line, then linearly interpolating between the neighboring point pressure values on the line.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.0.Value 14.0
```

string **Patch.patch_name.BCPressure.interval_name.FileName** [no default]

This key specifies the name of a properly distributed .pfb file that contains boundary data to be read for types **PressureFile** and **FluxFile**. For flux data, the data must be defined over a grid consistent with the pressure field. In both cases, only the values needed for the patch will be used. The rest of the data is ignored.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.FileName ocwd_bc.pfb
```

string **Patch.patch_name.BCPressure.interval_name.PredefinedFunction** [no default]

This key specifies the predefined function that will be used to specify Dirichlet boundary conditions on patch *patch_name*. Note that this does not change according to any cycle. Instead, time dependence is handled by evaluating at the time the boundary condition value is desired. Choices for this key include **X**, **XPlusYPlusZ**, **X3Y2PlusSinXYPlus1**, **X3Y4PlusX2PlusSinXYCosYPlus1**, **XYZTPlus1** and **XYZTPlus1PermTensor**.

Example Usage:

```
pfset Patch.top.BCPressure.alltime.PredefinedFunction XPlusYPlusZ
```

The choices for this key correspond to pressures as follows.

X: $p = x$

XPlusYPlusZ: $p = x + y + z$

X3Y2PlusSinXYPlus1: $p = x^3y^2 + \sin(xy) + 1$

X3Y4PlusX2PlusSinXYCosYPlus1: $p = x^3y^4 + x^2 + \sin(xy) \cos y + 1$

XYZTPlus1: $p = xyzt + 1$

XYZTPlus1PermTensor: $p = xyzt + 1$

Example Script:

```
#-----
# Initial conditions: water pressure [m]
#-----
# Using a patch is great when you are not using a box domain
# If using a box domain HydroStaticDepth is fine
# If your RefPatch is z-lower (bottom of domain), the pressure is positive.
# If your RefPatch is z-upper (top of domain), the pressure is negative.
### Set water table to be at the bottom of the domain, the top layer is initially dry
pfset ICPressure.Type HydroStaticPatch
pfset ICPressure.GeomNames domain
pfset Geom.domain.ICPressure.Value 2.2

pfset Geom.domain.ICPressure.RefGeom domain
pfset Geom.domain.ICPressure.RefPatch z-lower

### Using a .pfb to initialize
pfset ICPressure.Type                                PFBFile
pfset ICPressure.GeomNames "domain"
pfset Geom.domain.ICPressure.FileName press.00090.pfb

pfset Geom.domain.ICPressure.RefGeom domain
pfset Geom.domain.ICPressure.RefPatch z-upper
```

6.1.26 Boundary Conditions: Saturation

Note: this section needs to be defined *only* for multi-phase flow and should *not* be defined for the single phase and Richards' equation cases.

Here we define the boundary conditions for the saturations. Boundary condition input is associated with domain patches (see § 6.1.7). Note that different patches may have different types of boundary conditions on them.

list **BCSaturation.PatchNames** [no default]

This key specifies the names of patches on which saturation boundary conditions will be specified. Note that these must all be patches on the external boundary of the domain and these patches must “cover” that external boundary.

Example Usage:

```
pfset BCSaturation.PatchNames    "left right front back top bottom"
```

string **Patch.patch_name.BCSaturation.phase_name.Type** [no default]

This key specifies the type of boundary condition data given for the given phase, *phase_name*, on the given patch *patch_name*. Possible values for this key are **DirConstant**, **ConstantWTHeight** and **PLinearWTHeight**. The choice **DirConstant** specifies that the saturation is constant on the whole patch. The choice **ConstantWTHeight** specifies a constant height of the water-table on the whole patch. The choice **PLinearWTHeight** specifies that the height of the water-table on the patch will be given by a piecewise linear function.

Note: the types **ConstantWTHeight** and **PLinearWTHeight** assume we are running a 2-phase problem where phase 0 is the water phase.

Example Usage:

```
pfset Patch.left.BCSaturation.water.Type    ConstantWTHeight
```

double **Patch.patch_name.BCSaturation.phase_name.Value** [no default]

This key specifies either the constant saturation value if **DirConstant** is selected or the constant water-table height if **ConstantWTHeight** is selected.

Example Usage:

```
pfset Patch.top.BCSaturation.air.Value 1.0
```

double **Patch.patch_name.BCSaturation.phase_name.XLower** [no default]

This key specifies the lower *x* coordinate of a line in the xy-plane if type **PLinearWTHeight** boundary conditions are specified.

Example Usage:

```
pfset Patch.left.BCSaturation.water.XLower -10.0
```

double **Patch.patch_name.BCSaturation.phase_name.YLower** [no default]

This key specifies the lower *y* coordinate of a line in the xy-plane if type **PLinearWTHeight** boundary conditions are specified.

Example Usage:

```
pfset Patch.left.BCSaturation.water.YLower 5.0
```

double **Patch.patch_name.BCSaturation.phase_name.XUpper** [no default]

This key specifies the upper *x* coordinate of a line in the xy-plane if type **PLinearWTHeight** boundary conditions are specified.

Example Usage:

```
pfset Patch.left.BCSaturation.water.XUpper 125.0
```

double **Patch.patch_name.BCSaturation.phase_name.YUpper** [no default]

This key specifies the upper *y* coordinate of a line in the xy-plane if type **PLinearWTHeight** boundary conditions are specified.

Example Usage:

```
pfset Patch.left.BCSaturation.water.YUpper 82.0
```

integer **Patch.patch_name.BCPressure.phase_name.NumPoints** [no default]

This key specifies the number of points on which saturation data is given along the line used for type **DirEqui-IPLinear** boundary conditions.

Example Usage:

```
pfset Patch.left.BCPressure.water.NumPoints 2
```

double **Patch.patch_name.BCPressure.phase_name.point_number.Location** [no default]

This key specifies a number between 0 and 1 which represents the location of a point on the line for which data is given in type **DirEquiPLinear** boundary conditions. The line is parameterized so that 0 corresponds to the lower end of the line, and 1 corresponds to the upper end.

Example Usage:

```
pfset Patch.left.BCPressure.water.0.Location 0.333
```

double **Patch.patch_name.BCPressure.phase_name.point_number.Value** [no default]

This key specifies the water-table height for the given point if type **DirEquiPLinear** boundary conditions are selected. All saturation values on the patch are determined by first projecting the water-table height value onto the line, then linearly interpolating between the neighboring water-table height values onto the line.

Example Usage:

```
pfset Patch.left.BCPressure.water.0.Value 4.5
```

6.1.27 Initial Conditions: Phase Saturations

Note: this section needs to be defined *only* for multi-phase flow and should *not* be defined for single phase and Richards' equation cases.

Here we define initial phase saturation conditions. The format for this section of input is:

string **ICSaturation.phase_name.Type** [no default]

This key specifies the type of initial condition that will be applied to different geometries for given phase, *phase_name*. The only key currently available is **Constant**. The choice **Constant** will apply constants values within geometries for the phase.

Example Usage:

```
ICSaturation.water.Type Constant
```

string **ICSaturation.phase_name.GeomNames** [no default]

This key specifies the geometries on which an initial condition will be given if the type is set to **Constant**.

Note that geometries listed later “overlay” geometries listed earlier.

Example Usage:

```
ICSaturation.water.GeomNames "domain"
```

double **Geom.geom_input_name.ICSaturation.phase_name.Value** [no default]

This key specifies the initial condition value assigned to all points in the named geometry, *geom_input_name*, if the type was set to **Constant**.

Example Usage:

```
Geom.domain.ICSaturation.water.Value 1.0
```

6.1.28 Initial Conditions: Pressure

The keys in this section are used to specify pressure initial conditions for Richards' equation cases *only*. These keys will be ignored if any other case is run.

string **ICPressure.Type** [no default]

This key specifies the type of initial condition given. The choices for this key are **Constant**, **HydroStaticDepth**, **HydroStaticPatch** and **PFBFile**. The choice **Constant** specifies that the initial pressure will be constant over the regions given. The choice **HydroStaticDepth** specifies that the initial pressure within a region will be in hydrostatic equilibrium with a given pressure specified at a given depth. The choice **HydroStaticPatch** specifies that the initial pressure within a region will be in hydrostatic equilibrium with a given pressure on a specified patch. Note that all regions must have the same type of initial data - different regions cannot have different types of initial data. However, the parameters for the type may be different. The **PFBFile** specification means that the initial pressure will be taken as a spatially varying function given by data in a PARFLOW binary (.pfb) file.

Example Usage:

```
pfset ICPressure.Type    Constant
```

list **ICPressure.GeomNames** [no default]

This key specifies the geometry names on which the initial pressure data will be given. These geometries must comprise the entire domain. Note that conditions for regions that overlap other regions will have unpredictable results. The regions given must be disjoint.

Example Usage:

```
pfset ICPressure.GeomNames    "toplayer middlelayer bottomlayer"
```

double **Geom.geom_name.ICPressure.Value** [no default]

This key specifies the initial pressure value for type **Constant** initial pressures and the reference pressure value for types **HydroStaticDepth** and **HydroStaticPatch**.

Example Usage:

```
pfset Geom.toplayer.ICPressure.Value    -734.0
```

double **Geom.geom_name.ICPressure.RefElevation** [no default]

This key specifies the reference elevation on which the reference pressure is given for type **HydroStaticDepth** initial pressures.

Example Usage:

```
pfset Geom.toplayer.ICPressure.RefElevation    0.0
```

double **Geom.geom_name.ICPressure.RefGeom** [no default]

This key specifies the geometry on which the reference patch resides for type **HydroStaticPatch** initial pressures.

Example Usage:

```
pfset Geom.toplayer.ICPressure.RefGeom    bottomlayer
```

double **Geom.geom_name.ICPressure.RefPatch** [no default]

This key specifies the patch on which the reference pressure is given for type **HydroStaticPatch** initial pressures.

Example Usage:

```
pfset Geom.toplayer.ICPressure.RefPatch    bottom
```

string **Geom.geom_name.ICPressure.FileName** [no default]

This key specifies the name of the file containing pressure values for the domain. It is assumed that *geom_name* is "domain" for this key.

Example Usage:

```
pfset Geom.domain.ICPressure.FileName    "ic_pressure.pfb"
```

6.1.29 Initial Conditions: Phase Concentrations

Here we define initial concentration conditions for contaminants. The format for this section of input is:

string **PhaseConcen.phase_name.contaminant_name.Type** [no default]

This key specifies the type of initial condition that will be applied to different geometries for given phase, *phase_name*, and the given contaminant, *contaminant_name*. The choices for this key are **Constant** or **PFBFile**. The choice **Constant** will apply constants values to different geometries. The choice **PFBFile** will read values from a “ParFlow Binary” file (see § 6.3).

Example Usage:

```
PhaseConcen.water.tce.Type Constant
```

string **PhaseConcen.phase_name.GeomNames** [no default]

This key specifies the geometries on which an initial condition will be given, if the type was set to **Constant**.

Note that geometries listed later “overlay” geometries listed earlier.

Example Usage:

```
PhaseConcen.water.GeomNames "ic_concen_region"
```

double **PhaseConcen.phase_name.contaminant_name.geom_input_name.Value** [no default]

This key specifies the initial condition value assigned to all points in the named geometry, *geom_input_name*, if the type was set to **Constant**.

Example Usage:

```
PhaseConcen.water.tce.ic_concen_region.Value 0.001
```

string **PhaseConcen.phase_name.contaminant_name.FileName** [no default]

This key specifies the name of the “ParFlow Binary” file which contains the initial condition values if the type was set to **PFBFile**.

Example Usage:

```
PhaseConcen.water.tce.FileName "initial_concen_tce.pfb"
```

6.1.30 Known Exact Solution

For *Richards equation cases only* we allow specification of an exact solution to be used for testing the code. Only types that have been coded and predefined are allowed. Note that if this is specified as something other than no known solution, corresponding boundary conditions and phase sources should also be specified.

string **KnownSolution** [no default]

This specifies the predefined function that will be used as the known solution. Possible choices for this key are **NoKnownSolution**, **Constant**, **X**, **XPlusYPlusZ**, **X3Y2PlusSinXYPlus1**, **X3Y4PlusX2PlusSinXYCosYPlus1**, **XYZTPlus1** and **XYZTPlus1PermTensor**.

Example Usage:

```
pfset KnownSolution XPlusYPlusZ
```

Choices for this key correspond to solutions as follows.

NoKnownSolution: No solution is known for this problem.

Constant: $p = \text{constant}$

X: $p = x$

XPlusYPlusZ: $p = x + y + z$

X3Y2PlusSinXYPlus1: $p = x^3 y^2 + \sin(xy) + 1$

X3Y4PlusX2PlusSinXYCosYPlus1: $p = x^3 y^4 + x^2 + \sin(xy) \cos y + 1$

XYZTPlus1: $p = xyz t + 1$

XYZTPlus1: $p = xyz t + 1$

double **KnownSolution.Value** [no default]

This key specifies the constant value of the known solution for type **Constant** known solutions.

Example Usage:

```
pfset KnownSolution.Value 1.0
```

Only for known solution test cases will information on the L^2 -norm of the pressure error be printed.

6.1.31 Wells

Here we define wells for the model. The format for this section of input is:

string **Wells.Names** [no default]

This key specifies the names of the wells for which input data will be given.

Example Usage:

```
Wells.Names "test_well inj_well ext_well"
```

string **Wells.well_name.InputType** [no default]

This key specifies the type of well to be defined for the given well, *well_name*. This key can be either **Vertical** or **Recirc**. The value **Vertical** indicates that this is a single segmented well whose action will be specified by the user. The value **Recirc** indicates that this is a dual segmented, recirculating, well with one segment being an extraction well and another being an injection well. The extraction well filters out a specified fraction of each contaminant and recirculates the remainder to the injection well where the diluted fluid is injected back in. The phase saturations at the extraction well are passed without modification to the injection well.

Note with the recirculating well, several input options are not needed as the extraction well will provide these values to the injection well.

Example Usage:

```
Wells.test_well.InputType Vertical
```

string **Wells.well_name.Action** [no default]

This key specifies the pumping action of the well. This key can be either **Injection** or **Extraction**. A value of **Injection** indicates that this is an injection well. A value of **Extraction** indicates that this is an extraction well.

Example Usage:

```
Wells.test_well.Action Injection
```

double **Wells.well_name.Type** [no default]

This key specifies the mechanism by which the well works (how PARFLOW works with the well data) if the input type key is set to **Vertical**. This key can be either **Pressure** or **Flux**. A value of **Pressure** indicates that the data provided for the well is in terms of hydrostatic pressure and PARFLOW will ensure that the computed pressure field satisfies this condition in the computational cells which define the well. A value of **Flux** indicates that the data provided is in terms of volumetric flux rates and PARFLOW will ensure that the flux field satisfies this condition in the computational cells which define the well.

Example Usage:

```
Wells.test_well.Type Flux
```

string **Wells.well_name.ExtractionType** [no default]

This key specifies the mechanism by which the extraction well works (how PARFLOW works with the well data) if the input type key is set to **Recirc**. This key can be either **Pressure** or **Flux**. A value of **Pressure** indicates that the data provided for the well is in terms of hydrostatic pressure and PARFLOW will ensure that the computed pressure field satisfies this condition in the computational cells which define the well. A value of **Flux** indicates that the data provided is in terms of volumetric flux rates and PARFLOW will ensure that the flux field satisfies this condition in the computational cells which define the well.

Example Usage:

```
Wells.ext_well.ExtractionType Pressure
```

string **Wells.well_name.InjectionType** [no default]

This key specifies the mechanism by which the injection well works (how PARFLOW works with the well data) if the input type key is set to **Recirc**. This key can be either **Pressure** or **Flux**. A value of **Pressure** indicates that the data provided for the well is in terms of hydrostatic pressure and PARFLOW will ensure that the computed pressure field satisfies this condition in the computational cells which define the well. A value of **Flux** indicates that the data provided is in terms of volumetric flux rates and PARFLOW will ensure that the flux field satisfies this

condition in the computational cells which define the well.

Example Usage:

```
Wells.inj_well.InjectionType Flux
```

double **Wells.well_name.X** [no default]

This key specifies the x location of the vectical well if the input type is set to **Vectical** or of both the extraction and injection wells if the input type is set to **Recirc**.

Example Usage:

```
Wells.test_well.X 20.0
```

double **Wells.well_name.Y** [no default]

This key specifies the y location of the vectical well if the input type is set to **Vectical** or of both the extraction and injection wells if the input type is set to **Recirc**.

Example Usage:

```
Wells.test_well.Y 36.5
```

double **Wells.well_name.ZUpper** [no default]

This key specifies the z location of the upper extent of a vectical well if the input type is set to **Vectical**.

Example Usage:

```
Wells.test_well.ZUpper 8.0
```

double **Wells.well_name.ExtractionZUpper** [no default]

This key specifies the z location of the upper extent of a extraction well if the input type is set to **Recirc**.

Example Usage:

```
Wells.ext_well.ExtractionZUpper 3.0
```

double **Wells.well_name.InjectionZUpper** [no default]

This key specifies the z location of the upper extent of a injection well if the input type is set to **Recirc**.

Example Usage:

```
Wells.inj_well.InjectionZUpper 6.0
```

double **Wells.well_name.ZLower** [no default]

This key specifies the z location of the lower extent of a vectical well if the input type is set to **Vectical**.

Example Usage:

```
Wells.test_well.ZLower 2.0
```

double **Wells.well_name.ExtractionZLower** [no default]

This key specifies the z location of the lower extent of a extraction well if the input type is set to **Recirc**.

Example Usage:

```
Wells.ext_well.ExtractionZLower 1.0
```

double **Wells.well_name.InjectionZLower** [no default]

This key specifies the z location of the lower extent of a injection well if the input type is set to **Recirc**.

Example Usage:

```
Wells.inj_well.InjectionZLower 4.0
```

string **Wells.well_name.Method** [no default]

This key specifies a method by which pressure or flux for a vertical well will be weighted before assignment to computational cells. This key can only be **Standard** if the type key is set to **Pressure**; or this key can be either **Standard**, **Weighted** or **Patterned** if the type key is set to **Flux**. A value of **Standard** indicates that the pressure or flux data will be used as is. A value of **Weighted** indicates that the flux data is to be weighted by the cells permeability divided by the sum of all cell permeabilities which define the well. The value of **Patterned** is not implemented.

Example Usage:

```
Wells.test_well.Method Weighted
```

string **Wells.well_name.ExtractionMethod** [no default]

This key specifies a method by which pressure or flux for an extraction well will be weighted before assignment to computational cells. This key can only be **Standard** if the type key is set to **Pressure**; or this key can be either **Standard**, **Weighted** or **Patterned** if the type key is set to **Flux**. A value of **Standard** indicates that the pressure or flux data will be used as is. A value of **Weighted** indicates that the flux data is to be weighted by the cells permeability divided by the sum of all cell permeabilities which define the well. The value of **Patterned** is not implemented.

Example Usage:

```
Wells.ext_well.ExtractionMethod Standard
```

string **Wells.well_name.InjectionMethod** [no default]

This key specifies a method by which pressure or flux for an injection well will be weighted before assignment to computational cells. This key can only be **Standard** if the type key is set to **Pressure**; or this key can be either **Standard**, **Weighted** or **Patterned** if the type key is set to **Flux**. A value of **Standard** indicates that the pressure or flux data will be used as is. A value of **Weighted** indicates that the flux data is to be weighted by the cells permeability divided by the sum of all cell permeabilities which define the well. The value of **Patterned** is not implemented.

Example Usage:

```
Wells.inj_well.InjectionMethod Standard
```

string **Wells.well_name.Cycle** [no default]

This key specifies the time cycles to which data for the well *well_name* corresponds.

Example Usage:

```
Wells.test_well.Cycle "all_time"
```

double **Wells.well_name.interval_name.Pressure.Value** [no default]

This key specifies the hydrostatic pressure value for a vectical well if the type key is set to **Pressure**.

Note This value gives the pressure of the primary phase (water) at $z = 0$. The other phase pressures (if any) are computed from the physical relationships that exist between the phases.

Example Usage:

```
Wells.test_well.all_time.Pressure.Value 6.0
```

double **Wells.well_name.interval_name.Extraction.Pressure.Value** [no default]

This key specifies the hydrostatic pressure value for an extraction well if the extraction type key is set to **Pressure**.

Note This value gives the pressure of the primary phase (water) at $z = 0$. The other phase pressures (if any) are computed from the physical relationships that exist between the phases.

Example Usage:

```
Wells.ext_well.all_time.Extraction.Pressure.Value 4.5
```

double **Wells.well_name.interval_name.Injection.Pressure.Value** [no default]

This key specifies the hydrostatic pressure value for an injection well if the injection type key is set to **Pressure**.

Note This value gives the pressure of the primary phase (water) at $z = 0$. The other phase pressures (if any) are computed from the physical relationships that exist between the phases.

Example Usage:

```
Wells.inj_well.all_time.Injection.Pressure.Value 10.2
```

double **Wells.well_name.interval_name.Flux.phase_name.Value** [no default]

This key specifies the volumetric flux for a vectical well if the type key is set to **Flux**.

Note only a positive number should be entered, PARFLOW assigns the correct sign based on the chosen action for the well.

Example Usage:

```
Wells.test_well.all_time.Flux.water.Value 250.0
```

double **Wells.well_name.interval_name.Extraction.Flux.phase_name.Value** [no default]

This key specifies the volumetric flux for an extraction well if the extraction type key is set to **Flux**.

Note only a positive number should be entered, PARFLOW assigns the correct sign based on the chosen action for the well.

Example Usage:

```
Wells.ext_well.all_time.Extraction.Flux.water.Value 125.0
```

double **Wells.well_name.interval_name.Injection.Flux.phase_name.Value** [no default]

This key specifies the volumetric flux for an injection well if the injection type key is set to **Flux**.

Note only a positive number should be entered, PARFLOW assigns the correct sign based on the chosen action for the well.

Example Usage:

```
Wells.inj_well.all_time.Injection.Flux.water.Value 80.0
```

double **Wells.well_name.interval_name.Saturation.phase_name.Value** [no default]

This key specifies the saturation value of a vertical well.

Example Usage:

```
Wells.test_well.all_time.Saturation.water.Value 1.0
```

double **Wells.well_name.interval_name.Concentration.phase_name.contaminant_name.Value** [no default]

This key specifies the contaminant value of a vertical well.

Example Usage:

```
Wells.test_well.all_time.Concentration.water.tce.Value 0.0005
```

double **Wells.well_name.interval_name.Injection.Concentration.phase_name.contaminant_name.Fraction** [no default]

This key specifies the fraction of the extracted contaminant which gets resupplied to the injection well.

Example Usage:

```
Wells.inj_well.all_time.Injection.Concentration.water.tce.Fraction 0.01
```

Multiple wells assigned to one grid location can occur in several instances. The current actions taken by the code are as follows:

- If multiple pressure wells are assigned to one grid cell, the code retains only the last set of overlapping well values entered.
- If multiple flux wells are assigned to one grid cell, the code sums the contributions of all overlapping wells to get one effective well flux.
- If multiple pressure and flux wells are assigned to one grid cell, the code retains the last set of overlapping hydrostatic pressure values entered and sums all the overlapping flux well values to get an effective pressure/flux well value.

6.1.32 Code Parameters

In addition to input keys related to the physics capabilities and modeling specifics there are some key values used by various algorithms and general control flags for PARFLOW. These are described next :

string **Solver.Linear** [PCG]

This key specifies the linear solver used for solver **IMPES**. Choices for this key are **MGSemi**, **PPCG**, **PCG**

and **CGHS**. The choice **MGSEmi** is an algebraic multigrid linear solver (not a preconditioned conjugate gradient) which may be less robust than **PCG** as described in [4]. The choice **PPCG** is a preconditioned conjugate gradient solver. The choice **PCG** is a conjugate gradient solver with a multigrid preconditioner. The choice **CGHS** is a conjugate gradient solver.

Example Usage:

```
pfset Solver.Linear MGSemi
```

integer **Solver.SadvectOrder** [2]

This key controls the order of the explicit method used in advancing the saturations. This value can be either 1 for a standard upwind first order or 2 for a second order Godunov method.

Example Usage:

```
pfset Solver.SadvectOrder 1
```

integer **Solver.AdvectOrder** [2]

This key controls the order of the explicit method used in advancing the concentrations. This value can be either 1 for a standard upwind first order or 2 for a second order Godunov method.

Example Usage:

```
pfset Solver.AdvectOrder 2
```

double **Solver.CFL** [0.7]

This key gives the value of the weight put on the computed CFL limit before computing a global timestep value. Values greater than 1 are not suggested and in fact because this is an approximation, values slightly less than 1 can also produce instabilities.

Example Usage:

```
pfset Solver.CFL 0.7
```

integer **Solver.MaxIter** [1000000]

This key gives the maximum number of iterations that will be allowed for time-stepping. This is to prevent a run-away simulation.

Example Usage:

```
pfset Solver.MaxIter 100
```

double **Solver.RelTol** [1.0]

This value gives the relative tolerance for the linear solve algorithm.

Example Usage:

```
pfset Solver.RelTol 1.0
```

double **Solver.AbsTol** [1E-9]

This value gives the absolute tolerance for the linear solve algorithm.

Example Usage:

```
pfset Solver.AbsTol 1E-8
```

double **Solver.Drop** [1E-8]

This key gives a clipping value for data written to PFSB files. Data values greater than the negative of this value and less than the value itself are treated as zero and not written to PFSB files.

Example Usage:

```
pfset Solver.Drop 1E-6
```

double **Solver.OverlandDiffusive.Epsilon** [1E-5]

This key provides a minimum value for the \bar{S}_f used in the **OverlandDiffusive** boundary condition.

Example Usage:

```
pfset Solver.OverlandDiffusive.Epsilon 1E-7
```

double **Solver.OverlandKinematic.Epsilon** [1E-5]

This key provides a minimum value for the \tilde{S}_f used in the **OverlandKinematic** boundary condition.

Example Usage:

```
pfset Solver.OverlandKinematic.Epsilon 1E-7
```

string **Solver.PrintSubsurf** [True]

This key is used to turn on printing of the subsurface data, Permeability and Porosity. The data is printed after it is generated and before the main time stepping loop - only once during the run. The data is written as a PFB file.

Example Usage:

```
pfset Solver.PrintSubsurf False
```

string **Solver.PrintPressure** [True]

This key is used to turn on printing of the pressure data. The printing of the data is controlled by values in the timing information section. The data is written as a PFB file.

Example Usage:

```
pfset Solver.PrintPressure False
```

string **Solver.PrintVelocities** [False]

This key is used to turn on printing of the x, y and z velocity data. The printing of the data is controlled by values in the timing information section. The data is written as a PFB file.

Example Usage:

```
pfset Solver.PrintVelocities True
```

string **Solver.PrintSaturation** [True]

This key is used to turn on printing of the saturation data. The printing of the data is controlled by values in the timing information section. The data is written as a PFB file.

Example Usage:

```
pfset Solver.PrintSaturation False
```

string **Solver.PrintConcentration** [True]

This key is used to turn on printing of the concentration data. The printing of the data is controlled by values in the timing information section. The data is written as a PFSB file.

Example Usage:

```
pfset Solver.PrintConcentration False
```

string **Solver.PrintWells** [True]

This key is used to turn on collection and printing of the well data. The data is collected at intervals given by values in the timing information section. Printing occurs at the end of the run when all collected data is written.

Example Usage:

```
pfset Solver.PrintWells False
```

string **Solver.PrintLSMSink** [False]

This key is used to turn on printing of the flux array passed from CLM to PARFLOW. Printing occurs at each **DumpInterval** time.

Example Usage:

```
pfset Solver.PrintLSMSink True
```

string **Solver.WriteSiloSubsurfData** [False]

This key is used to specify printing of the subsurface data, Permeability and Porosity in silo binary file format. The data is printed after it is generated and before the main time stepping loop - only once during the run. This data may be read in by VisIT and other visualization packages.

Example Usage:


```
pfset Solver.WriteSiloSubsurfData True
```

string **Solver.WriteSiloPressure** [False]

This key is used to specify printing of the saturation data in silo binary format. The printing of the data is controlled by values in the timing information section. This data may be read in by VisIT and other visualization packages.

Example Usage:

```
pfset Solver.WriteSiloPressure True
```

string **Solver.WriteSiloSaturation** [False]

This key is used to specify printing of the saturation data using silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloSaturation True
```

string **Solver.WriteSiloConcentration** [False]

This key is used to specify printing of the concentration data in silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloConcentration True
```

string **Solver.WriteSiloVelocities** [False]

This key is used to specify printing of the x, y and z velocity data in silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloVelocities True
```

string **Solver.WriteSiloSlopes** [False]

This key is used to specify printing of the x and y slope data using silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloSlopes True
```

string **Solver.WriteSiloMannings** [False]

This key is used to specify printing of the Manning's roughness data in silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloMannings True
```

string **Solver.WriteSiloSpecificStorage** [False]

This key is used to specify printing of the specific storage data in silo binary format. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloSpecificStorage True
```

string **Solver.WriteSiloMask** [False]

This key is used to specify printing of the mask data using silo binary format. The mask contains values equal to one for active cells and zero for inactive cells. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloMask True
```

string **Solver.WriteSiloEvapTrans** [False]

This key is used to specify printing of the evaporation and rainfall flux data using silo binary format. This data comes from either `clm` or from external calls to PARFLOW such as *WRF*. This data is in units of $[L^3T^{-1}]$. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloEvapTrans  True
```

string **Solver.WriteSiloEvapTransSum** [False]

This key is used to specify printing of the evaporation and rainfall flux data using silo binary format as a running, cumulative amount. This data comes from either `clm` or from external calls to PARFLOW such as *WRF*. This data is in units of $[L^3]$. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloEvapTransSum  True
```

string **Solver.WriteSiloOverlandSum** [False]

This key is used to specify calculation and printing of the total overland outflow from the domain using silo binary format as a running cumulative amount. This is integrated along all domain boundaries and is calculated any location that slopes at the edge of the domain point outward. This data is in units of $[L^3]$. The printing of the data is controlled by values in the timing information section.

Example Usage:

```
pfset Solver.WriteSiloOverlandSum  True
```

string **Solver.TerrainFollowingGrid** [False]

This key specifies that a terrain-following coordinate transform is used for solver Richards. This key sets x and y subsurface slopes to be the same as the Topographic slopes (a value of False sets these subsurface slopes to zero). These slopes are used in the Darcy fluxes to add a density, gravity -dependent term. This key will not change the output files (that is the output is still orthogonal) or the geometries (they will still follow the computational grid)—these two things are both to do items. This key only changes solver Richards, not solver Impes.

Example Usage:

```
pfset Solver.TerrainFollowingGrid.                True
```

string **Solver.TerrainFollowingGrid.SlopeUpwindFormulation** [Original]

This key specifies optional modifications to the terrain following grid formulation (Equation 5.8) . Choices for this key are **Original**, **Upwind**, **UpwindSine**. **Original** is the original TFG formulation shown in Equation 5.8 and documented in [92]. The **Original** option calculates the θ_x and θ_y for a cell face as the average of the two adjacent cell slopes (i.e. assuming a cell centered slope calculation). The **Upwind** option uses the θ_x and θ_y of a cell directly without averaging (i.e. assuming a face centered slope calculation). The **UpwindSine** is the same as the **Upwind** option but it also removes the Sine term from 5.8. Note the **UpwindSine** option is for experimental purposes only and should not be used in standard simulations. Also note that the choice of **upwind** or **Original** formulation should consistent with the choice of overland flow boundary condition if overland flow is being used. The **upwind** and **UpwindSine** are consistent with **OverlandDiffusive** and **OverlandKinematic** while **Original** is consistent with **OverlandFow**

Example Usage:

```
pfset Solver.TerrainFollowingGrid.SlopeUpwindFormulation  Upwind
```

6.1.33 SILO Options

The following keys are used to control how SILO writes data. SILO allows writing to PDB and HDF5 file formats. SILO also allows data compression to be used, which can save significant amounts of disk space for some problems.

string **SILO.Filetype** [PDB]

This key is used to specify the SILO filetype. Allowed values are PDB and HDF5. Note that you must have

configured SILO with HDF5 in order to use that option.

Example Usage:

```
pfset SILO.Filetype PDB
```

string **SILO.CompressionOptions** []

This key is used to specify the SILO compression options. See the SILO manual for the DB_SetCompression command for information on available options. NOTE: the options available are highly dependent on the configure options when building SILO.

Example Usage:

```
pfset SILO.CompressionOptions 'METHOD=GZIP'
```

6.1.34 Richards' Equation Solver Parameters

The following keys are used to specify various parameters used by the linear and nonlinear solvers in the Richards' equation implementation. For information about these solvers, see [135] and [4].

double **Solver.Nonlinear.ResidualTol** [1e-7]

This key specifies the tolerance that measures how much the relative reduction in the nonlinear residual should be before nonlinear iterations stop. The magnitude of the residual is measured with the l^1 (max) norm.

Example Usage:

```
pfset Solver.Nonlinear.ResidualTol 1e-4
```

double **Solver.Nonlinear.StepTol** [1e-7]

This key specifies the tolerance that measures how small the difference between two consecutive nonlinear steps can be before nonlinear iterations stop.

Example Usage:

```
pfset Solver.Nonlinear.StepTol 1e-4
```

integer **Solver.Nonlinear.MaxIter** [15]

This key specifies the maximum number of nonlinear iterations allowed before iterations stop with a convergence failure.

Example Usage:

```
pfset Solver.Nonlinear.MaxIter 50
```

integer **Solver.Linear.KrylovDimension** [10]

This key specifies the maximum number of vectors to be used in setting up the Krylov subspace in the GMRES iterative solver. These vectors are of problem size and it should be noted that large increases in this parameter can limit problem sizes. However, increasing this parameter can sometimes help nonlinear solver convergence.

Example Usage:

```
pfset Solver.Linear.KrylovDimension 15
```

integer **Solver.Linear.MaxRestarts** [0]

This key specifies the number of restarts allowed to the GMRES solver. Restarts start the development of the Krylov subspace over using the current iterate as the initial iterate for the next pass.

Example Usage:

```
pfset Solver.Linear.MaxRestarts 2
```

integer **Solver.MaxConvergenceFailures** [3]

This key gives the maximum number of convergence failures allowed. Each convergence failure cuts the timestep in half and the solver tries to advance the solution with the reduced timestep.

The default value is 3.

Note that setting this value to a value greater than 9 may result in errors in how time cycles are calculated. Time is discretized in terms of the base time unit and if the solver begins to take very small timesteps

*smallerthanbasetimeunit*1000 the values based on time cycles will be change at slightly incorrect times. If the problem is failing converge so poorly that a large number of restarts are required, consider setting the timestep to a smaller value.

Example Usage:

```
pfset Solver.MaxConvergenceFailures 4
```

string **Solver.Nonlinear.PrintFlag** [HighVerbosity]

This key specifies the amount of informational data that is printed to the `*.out.kinsol.log` file. Choices for this key are **NoVerbosity**, **LowVerbosity**, **NormalVerbosity** and **HighVerbosity**. The choice **NoVerbosity** prints no statistics about the nonlinear convergence process. The choice **LowVerbosity** outputs the nonlinear iteration count, the scaled norm of the nonlinear function, and the number of function calls. The choice **NormalVerbosity** prints the same as for **LowVerbosity** and also the global strategy statistics. The choice **HighVerbosity** prints the same as for **NormalVerbosity** with the addition of further Krylov iteration statistics.

Example Usage:

```
pfset Solver.Nonlinear.PrintFlag NormalVerbosity
```

string **Solver.Nonlinear.EtaChoice** [Walker2]

This key specifies how the linear system tolerance will be selected. The linear system is solved until a relative residual reduction of η is achieved. Linear residual norms are measured in the l^2 norm. Choices for this key include **EtaConstant**, **Walker1** and **Walker2**. If the choice **EtaConstant** is specified, then η will be taken as constant. The choices **Walker1** and **Walker2** specify choices for η developed by Eisenstat and Walker [32]. The choice **Walker1** specifies that η will be given by $\|F(u^k)\| - \|F(u^{k-1}) + J(u^{k-1}) * p\| / \|F(u^{k-1})\|$. The choice **Walker2** specifies that η will be given by $\gamma \|F(u^k)\| / \|F(u^{k-1})\|^\alpha$. For both of the last two choices, η is never allowed to be less than $1e-4$.

Example Usage:

```
pfset Solver.Nonlinear.EtaChoice EtaConstant
```

double **Solver.Nonlinear.EtaValue** [1e-4]

This key specifies the constant value of η for the EtaChoice key **EtaConstant**.

Example Usage:

```
pfset Solver.Nonlinear.EtaValue 1e-7
```

double **Solver.Nonlinear.EtaAlpha** [2.0]

This key specifies the value of α for the case of EtaChoice being **Walker2**.

Example Usage:

```
pfset Solver.Nonlinear.EtaAlpha 1.0
```

double **Solver.Nonlinear.EtaGamma** [0.9]

This key specifies the value of γ for the case of EtaChoice being **Walker2**.

Example Usage:

```
pfset Solver.Nonlinear.EtaGamma 0.7
```

string **Solver.Nonlinear.UseJacobian** [False]

This key specifies whether the Jacobian will be used in matrix-vector products or whether a matrix-free version of the code will run. Choices for this key are **False** and **True**. Using the Jacobian will most likely decrease the number of nonlinear iterations but require more memory to run.

Example Usage:

```
pfset Solver.Nonlinear.UseJacobian True
```

double **Solver.Nonlinear.DerivativeEpsilon** [1e-7]

This key specifies the value of ϵ used in approximating the action of the Jacobian on a vector with approximate directional derivatives of the nonlinear function. This parameter is only used when the UseJacobian key is **False**.

Example Usage:

```
pfset Solver.Nonlinear.DerivativeEpsilon 1e-8
```

string **Solver.Nonlinear.Globalization** [LineSearch]

This key specifies the type of global strategy to use. Possible choices for this key are **InexactNewton** and **LineSearch**. The choice **InexactNewton** specifies no global strategy, and the choice **LineSearch** specifies that a line search strategy should be used where the nonlinear step can be lengthened or decreased to satisfy certain criteria.

Example Usage:

```
pfset Solver.Nonlinear.Globalization LineSearch
```

string **Solver.Linear.Preconditioner** [MGSemi]

This key specifies which preconditioner to use. Currently, the three choices are **NoPC**, **MGSemi**, **PFMG**, **PFMGOctree** and **SMG**. The choice **NoPC** specifies that no preconditioner should be used. The choice **MGSemi** specifies a semi-coarsening multigrid algorithm which uses a point relaxation method. The choice **SMG** specifies a semi-coarsening multigrid algorithm which uses plane relaxations. This method is more robust than **MGSemi**, but generally requires more memory and compute time. The choice **PFMGOctree** can be more efficient for problems with large numbers of inactive cells.

Example Usage:

```
pfset Solver.Linear.Preconditioner MGSemi
```

string **Solver.Linear.Preconditioner.SymmetricMat** [Symmetric]

This key specifies whether the preconditioning matrix is symmetric. Choices for this key are **Symmetric** and **Nonsymmetric**. The choice **Symmetric** specifies that the symmetric part of the Jacobian will be used as the preconditioning matrix. The choice **Nonsymmetric** specifies that the full Jacobian will be used as the preconditioning matrix. NOTE: ONLY **Symmetric** CAN BE USED IF MGSemi IS THE SPECIFIED PRECONDITIONER!

Example Usage:

```
pfset Solver.Linear.Preconditioner.SymmetricMat Symmetric
```

integer **Solver.Linear.Preconditioner.precond_method.MaxIter** [1]

This key specifies the maximum number of iterations to take in solving the preconditioner system with *precond_method* solver.

Example Usage:

```
pfset Solver.Linear.Preconditioner.SMG.MaxIter 2
```

integer **Solver.Linear.Preconditioner.SMG.NumPreRelax** [1]

This key specifies the number of relaxations to take before coarsening in the specified preconditioner method. Note that this key is only relevant to the SMG multigrid preconditioner.

Example Usage:

```
pfset Solver.Linear.Preconditioner.SMG.NumPreRelax 2
```

integer **Solver.Linear.Preconditioner.SMG.NumPostRelax** [1]

This key specifies the number of relaxations to take after coarsening in the specified preconditioner method. Note that this key is only relevant to the SMG multigrid preconditioner.

Example Usage:

```
pfset Solver.Linear.Preconditioner.SMG.NumPostRelax 0
```

string **Solver.Linear.Preconditioner.PFMG.RAPType** [NonGalerkin]

For the PFMG solver, this key specifies the *Hypre* RAP type. Valid values are **Galerkin** or **NonGalerkin**

Example Usage:

```
pfset Solver.Linear.Preconditioner.PFMG.RAPType Galerkin
```

logical **Solver.EvapTransFile** [False]

This key specifies that the Flux terms for Richards' equation are read in from a .pfb file. This file has $[T^{-1}]$ units. Note this key is for a steady-state flux and should *not* be used in conjunction with the transient key below.

Example Usage:

```
pfset Solver.EvapTransFile    True
```

logical **Solver.EvapTransFileTransient** [False]

This key specifies that the Flux terms for Richards' equation are read in from a series of flux .pfb files. Each file has $[T^{-1}]$ units. Note this key should not be used with the key above, only one of these keys should be set to **True** at a time, not both.

Example Usage:

```
pfset Solver.EvapTransFileTransient    True
```

string **Solver.EvapTrans.FileName** [no default]

This key specifies filename for the distributed .pfb file that contains the flux values for Richards' equation. This file has $[T^{-1}]$ units. For the steady-state option (*Solver.EvapTransFile=True*) this key should be the complete filename. For the transient option (*Solver.EvapTransFileTransient=True*) then the filename is a header and PARFLOW will load one file per timestep, with the form **filename.00000.pfb**.

Example Usage:

```
pfset Solver.EvapTrans.FileName    evap.trans.test.pfb
```

string **Solver.LSM** [none]

This key specifies whether a land surface model, such as CLM, will be called each solver timestep. Choices for this key include **none** and **CLM**. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.LSM CLM
```

6.1.35 Spinup Options

These keys allow for *reduced or dampened physics* during model spinup or initialization. They are **only** intended for these initialization periods, **not** for regular runtime.

integer **OverlandFlowSpinUp** [0]

This key specifies that a *simplified* form of the overland flow boundary condition (Equation 5.17) be used in place of the full equation. This formulation *removes lateral flow* and drives and ponded water pressures to zero using a **SeepageFace** boundary condition. While this can be helpful in spinning up the subsurface, this is no longer coupled subsurface-surface flow. If set to zero (the default) this key behaves normally.

Example Usage:

```
pfset OverlandFlowSpinUp    1
```

double **OverlandFlowSpinUpDampP1** [0.0]

This key sets P_1 and provides exponential dampening to the pressure relationship in the overland flow equation by adding the following term: $P_2 * \exp(\psi * P_2)$

Example Usage:

```
pfset OverlandSpinUpDampP1    10.0
```

double **OverlandFlowSpinUpDampP2** [0.0]

This key sets P_2 and provides exponential dampening to the pressure relationship in the overland flow equation adding the following term: $P_2 * \exp(\psi * P_2)$

Example Usage:

```
pfset OverlandSpinUpDampP2    0.1
```

6.1.36 CLM Solver Parameters

string **Solver.CLM.Print1dOut** [False]

This key specifies whether the CLM one dimensional (averaged over each processor) output file is written or not. Choices for this key include **True** and **False**. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.Print1dOut     False
```

integer **Solver.CLM.IstepStart** [1]

This key specifies the value of the counter, *istep* in CLM. This key primarily determines the start of the output counter for CLM. It is used to restart a run by setting the key to the ending step of the previous run plus one. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.IstepStart     8761
```

String **Solver.CLM.MetForcing** [no default]

This key specifies defines whether 1D (uniform over the domain), 2D (spatially distributed) or 3D (spatially distributed with multiple timesteps per .pfb forcing file) forcing data is used. Choices for this key are **1D**, **2D** and **3D**. This key has no default so the user *must* set it to 1D, 2D or 3D. Failure to set this key will cause CLM to still be run but with unpredictable values causing CLM to eventually crash. 1D meteorological forcing files are text files with single columns for each variable and each timestep per row, while 2D forcing files are distributed PARFLOW binary files, one for each variable and timestep. File names are specified in the **Solver.CLM.MetFileName** variable below. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.MetForcing     2D
```

String **Solver.CLM.MetFileName** [no default]

This key specifies defines the file name for 1D, 2D or 3D forcing data. 1D meteorological forcing files are text files with single columns for each variable and each timestep per row, while 2D and 3D forcing files are distributed PARFLOW binary files, one for each variable and timestep (2D) or one for each variable and *multiple* timesteps (3D). Behavior of this key is different for 1D and 2D and 3D cases, as specified by the **Solver.CLM.MetForcing** key above. For 1D cases, it is the *FULL FILE NAME*. Note that in this configuration, this forcing file is **not** distributed, the user does not provide copies such as **narr.1hr.txt.0**, **narr.1hr.txt.1** for each processor. PARFLOW only needs the single original file (*e.g.* **narr.1hr.txt**). For 2D cases, this key is the *BASE FILE NAME* for the 2D forcing files, currently set to NLDAS, with individual files determined as follows **NLDAS.<variable>.<time step>.pfb**. Where the **<variable>** is the forcing variable and **<time step>** is the integer file counter corresponding to *istep* above. Forcing is needed for following variables:

DSWR: Downward Visible or Short-Wave radiation [W/m^2].

DLWR: Downward Infa-Red or Long-Wave radiation [W/m^2]

APCP: Precipitation rate [mm/s]

Temp: Air temperature [K]

UGRD: West-to-East or U-component of wind [m/s]

VGRD: South-to-North or V-component of wind [m/s]

Press: Atmospheric Pressure [pa]

SPFH: Water-vapor specific humidity [kg/kg]

Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.MetFileName     narr.1hr.txt
```

String **Solver.CLM.MetFilePath** [no default]

This key specifies defines the location of 1D, 2D or 3D forcing data. For 1D cases, this is the path to a single forcing file (e.g. `narr.1hr.txt`). For 2D and 3D cases, this is the path to the directory containing all forcing files. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.MetFilePath "path/to/met/forcing/data/"
```

integer **Solver.CLM.MetFileNT** [no default]

This key specifies the number of timesteps per file for 3D forcing data.

Example Usage:

```
pfset Solver.CLM.MetFileNT 24
```

string **Solver.CLM.ForceVegetation** [False]

This key specifies whether vegetation should be forced in CLM. Currently this option only works for 1D and 3D forcings, as specified by the key **Solver.CLM.MetForcing**. Choices for this key include **True** and **False**. Forced vegetation variables are :

LAI: Leaf Area Index [-]

SAI: Stem Area Index [-]

ZOM: Aerodynamic roughness length [*m*]

DISPLA: Displacement height [*m*]

In the case of 1D meteorological forcings, CLM requires four files for vegetation time series and one vegetation map. The four files should be named respectively `lai.dat`, `sai.dat`, `zom.dat`, `displa.dat`. They are ASCII files and contain 18 time-series columns (one per IGBP vegetation class, and each timestep per row). The vegetation map should be a properly distributed 2D PARFLOW binary file (`.pfb`) which contains vegetation indices (from 1 to 18). The vegetation map filename is `veg_map.pfb`. PARFLOW uses the vegetation map to pass to CLM a 2D map for each vegetation variable at each time step. In the case of 3D meteorological forcings, PARFLOW expects four distincts properly distributed PARFLOW binary file (`.pfb`), the third dimension being the timesteps. The files should be named `LAI.pfb`, `SAI.pfb`, `ZOM.pfb`, `DISPLA.pfb`. No vegetation map is needed in this case.

Example Usage:

```
pfset Solver.CLM.ForceVegetation True
```

string **Solver.WriteSiloCLM** [False]

This key specifies whether the CLM writes two dimensional binary output files to a silo binary format. This data may be read in by VisIT and other visualization packages. Note that CLM and silo must be compiled and linked at runtime for this option to be active. These files are all written according to the standard format used for all PARFLOW variables, using the *runname*, and *istep*. Variables are either two-dimensional or over the number of CLM layers (default of ten).

Example Usage:

```
pfset Solver.WriteSiloCLM True
```

The output variables are:

`eflx_lh_tot` for latent heat flux total [W/m^2] using the silo variable *LatentHeat*;

`eflx_lwrad_out` for outgoing long-wave radiation [W/m^2] using the silo variable *LongWave*;

`eflx_sh_tot` for sensible heat flux total [W/m^2] using the silo variable *SensibleHeat*;

`eflx_soil_grnd` for ground heat flux [W/m^2] using the silo variable *GroundHeat*;

`qflx_evap_tot` for total evaporation [mm/s] using the silo variable *EvaporationTotal*;

`qflx_evap_grnd` for ground evaporation without condensation [mm/s] using the silo variable *EvaporationGround-NoSublimation*;

`qflx_evap_soi` for soil evaporation [mm/s] using the silo variable *EvaporationGround*;

qflx_evap_veg for vegetation evaporation [mm/s] using the silo variable *EvaporationCanopy*;
qflx_tran_veg for vegetation transpiration [mm/s] using the silo variable *Transpiration*;
qflx_infl for soil infiltration [mm/s] using the silo variable *Infiltration*;
swe_out for snow water equivalent [mm] using the silo variable *SWE*;
t_grnd for ground surface temperature [K] using the silo variable *TemperatureGround*; and
t_soil for soil temperature over all layers [K] using the silo variable *TemperatureSoil*.

string Solver.PrintCLM [False]

This key specifies whether the CLM writes two dimensional binary output files to a PFB binary format. Note that CLM must be compiled and linked at runtime for this option to be active. These files are all written according to the standard format used for all PARFLOW variables, using the *runname*, and *istep*. Variables are either two-dimensional or over the number of CLM layers (default of ten).

Example Usage:

```
pfset Solver.PrintCLM True
```

The output variables are:

eflx_lh_tot for latent heat flux total [W/m^2] using the silo variable *LatentHeat*;
eflx_lwrad_out for outgoing long-wave radiation [W/m^2] using the silo variable *LongWave*;
eflx_sh_tot for sensible heat flux total [W/m^2] using the silo variable *SensibleHeat*;
eflx_soil_grnd for ground heat flux [W/m^2] using the silo variable *GroundHeat*;
qflx_evap_tot for total evaporation [mm/s] using the silo variable *EvaporationTotal*;
qflx_evap_grnd for ground evaporation without sublimation [mm/s] using the silo variable *EvaporationGroundNoSublimation*;
qflx_evap_soi for soil evaporation [mm/s] using the silo variable *EvaporationGround*;
qflx_evap_veg for vegetation evaporation [mm/s] using the silo variable *EvaporationCanopy*;
qflx_tran_veg for vegetation transpiration [mm/s] using the silo variable *Transpiration*;
qflx_infl for soil infiltration [mm/s] using the silo variable *Infiltration*;
swe_out for snow water equivalent [mm] using the silo variable *SWE*;
t_grnd for ground surface temperature [K] using the silo variable *TemperatureGround*; and
t_soil for soil temperature over all layers [K] using the silo variable *TemperatureSoil*.

string Solver.WriteCLMBinary [True]

This key specifies whether the CLM writes two dimensional binary output files in a generic binary format. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.WriteCLMBinary False
```

string Solver.CLM.BinaryOutDir [True]

This key specifies whether the CLM writes each set of two dimensional binary output files to a corresponding directory. These directories may be created before PARFLOW is run (using the tcl script, for example). Choices for this key include **True** and **False**. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.BinaryOutDir True
```

These directories are:

/qflx_top_soil for soil flux;
/qflx_infl for infiltration;

/qflx_evap_grnd for ground evaporation;
 /eflx_soil_grnd for ground heat flux;
 /qflx_evap_veg for vegetation evaporation;
 /eflx_sh_tot for sensible heat flux;
 /eflx_lh_tot for latent heat flux;
 /qflx_evap_tot for total evaporation;
 /t_grnd for ground surface temperature;
 /qflx_evap_soi for soil evaporation;
 /qflx_tran_veg for vegetation transpiration;
 /eflx_lwrad_out for outgoing long-wave radiation;
 /swe_out for snow water equivalent; and
 /diag_out for diagnostics.

string **Solver.CLM.CLMFileDir** [no default]

This key specifies what directory all output from the CLM is written to. This key may be set to `"/"` or `"` to write output to the PARFLOW run directory. This directory must be created before PARFLOW is run. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.CLMFileDir "CLM_Output/"
```

integer **Solver.CLM.CLMDumpInterval** [1]

This key specifies how often output from the CLM is written. This key is in integer multipliers of the CLM timestep. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.CLMDumpInterval 2
```

string **Solver.CLM.EvapBeta** [Linear]

This key specifies the form of the bare soil evaporation β parameter in CLM. The valid types for this key are **None**, **Linear**, **Cosine**.

None: No beta formulation, $\beta = 1$.

Linear: $\beta = \frac{\phi S - \phi S_{res}}{\phi - \phi S_{res}}$

Cosine: $\beta = \frac{1}{2} (1 - \cos(\frac{(\phi - \phi S_{res})}{(\phi S - \phi S_{res})} \pi))$

Note that S_{res} is specified by the key **Solver.CLM.ResSat** below, that β is limited between zero and one and also that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.EvapBeta Linear
```

double **Solver.CLM.ResSat** [0.1]

This key specifies the residual saturation for the β function in CLM specified above. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.ResSat 0.15
```

string **Solver.CLM.VegWaterStress** [Saturation]

This key specifies the form of the plant water stress function β_t parameter in CLM. The valid types for this key are **None**, **Saturation**, **Pressure**.

None: No transpiration water stress formulation, $\beta_t = 1$.

Saturation: $\beta_t = \frac{\phi S - \phi S_{wp}}{\phi S_{fc} - \phi S_{wp}}$

Pressure: $\beta_t = \frac{P - P_{wp}}{P_{fc} - P_{wp}}$

Note that the wilting point, S_{wp} or p_{wp} , is specified by the key `Solver.CLM.WiltingPoint` below, that the field capacity, S_{fc} or p_{fc} , is specified by the key `Solver.CLM.FieldCapacity` below, that β_t is limited between zero and one and also that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.VegWaterStress Pressure
```

double **Solver.CLM.WiltingPoint** [0.1]

This key specifies the wilting point for the β_t function in CLM specified above. Note that the units for this function are pressure [m] for a **Pressure** formulation and saturation [–] for a **Saturation** formulation. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.WiltingPoint 0.15
```

double **Solver.CLM.FieldCapacity** [1.0]

This key specifies the field capacity for the β_t function in CLM specified above. Note that the units for this function are pressure [m] for a **Pressure** formulation and saturation [–] for a **Saturation** formulation. Note that CLM must be compiled and linked at runtime for this option to be active.

Example Usage:

```
pfset Solver.CLM.FieldCapacity 0.95
```

string **Solver.CLM.IrrigationTypes** [none]

This key specifies the form of the irrigation in CLM. The valid types for this key are **none**, **Spray**, **Drip**, **Instant**.

Example Usage:

```
pfset Solver.CLM.IrrigationTypes Drip
```

string **Solver.CLM.IrrigationCycle** [Constant]

This key specifies the cycle of the irrigation in CLM. The valid types for this key are **Constant**, **Deficit**. Note only **Constant** is currently implemented. Constant cycle applies irrigation each day from IrrigationStartTime to IrrigationStopTime in GMT.

Example Usage:

```
pfset Solver.CLM.IrrigationCycle Constant
```

double **Solver.CLM.IrrigationRate** [no default]

This key specifies the rate of the irrigation in CLM in [mm/s].

Example Usage:

```
pfset Solver.CLM.IrrigationRate 10.
```

double **Solver.CLM.IrrigationStartTime** [no default]

This key specifies the start time of the irrigation in CLM GMT.

Example Usage:

```
pfset Solver.CLM.IrrigationStartTime 0800
```

double **Solver.CLM.IrrigationStopTime** [no default]

This key specifies the stop time of the irrigation in CLM GMT.

Example Usage:

```
pfset Solver.CLM.IrrigationStopTime 1200
```

double Solver.CLM.IrrigationThreshold [0.5]

This key specifies the threshold value for the irrigation in CLM [-].

Example Usage:

```
pfset Solver.CLM.IrrigationThreshold 0.2
```

integer Solver.CLM.ReuseCount [1]

How many times to reuse a CLM atmospheric forcing file input. For example timestep=1, reuse =1 is normal behavior but reuse=2 and timestep=0.5 subdivides the time step using the same CLM input for both halves instead of needing two files. This is particularly useful for large, distributed runs when the user wants to run PARFLOW at a smaller timestep than the CLM forcing. Forcing files will be re-used and total fluxes adjusted accordingly without needing duplicate files.

Example Usage:

```
pfset Solver.CLM.ReuseCount 5
```

string Solver.CLM.WriteLogs [True]

When **False**, this disables writing of the CLM output log files for each processor. For example, in the clm.tcl test case, if this flag is added **False**, washita.output.txt.p and washita.para.out.dat.p (were *p* is the processor #) are not created, assuming *washita* is the run name.

Example Usage:

```
pfset Solver.CLM.WriteLogs False
```

string Solver.CLM.WriteLastRST [False]

Controls whether CLM restart files are sequentially written or whether a single file *restart file name.00000.p* is overwritten each time the restart file is output, where *p* is the processor number. If "True" only one file is written/overwritten and if "False" outputs are written more frequently. Compatible with DailyRST and ReuseCount; for the latter, outputs are written every *n* steps where *n* is the value of ReuseCount.

Example Usage:

```
pfset Solver.CLM.WriteLastRST True
```

string Solver.CLM.DailyRST [True]

Controls whether CLM writes daily restart files (default) or at every time step when set to False; outputs are numbered according to the istep from ParFlow. If **ReuseCount=n**, with *n* greater than 1, the output will be written every *n* steps (i.e. it still writes hourly restart files if your time step is 0.5 or 0.25, etc...). Fully compatible with **WriteLastRST=False** so that each daily output is overwritten to time 00000 in *restart file name.00000.p* where *p* is the processor number.

Example Usage:

```
pfset Solver.CLM.DailyRST False
```

string Solver.CLM.SingleFile [False]

Controls whether PARFLOW writes all CLM output variables as a single file per time step. When "True", this combines the output of all the CLM output variables into a special multi-layer PFB with the file extension ".C.pfb". The first 13 layers correspond to the 2-D CLM outputs and the remaining layers are the soil temperatures in each layer. For example, a model with 4 soil layers will create a SingleFile CLM output with 17 layers at each time step. The file pseudo code is given below in § 6.4 and the variables and units are as specified in the multiple PFB and SILO formats as above.

Example Usage:

```
pfset Solver.CLM.SingleFile True
```

integer Solver.CLM.RootZoneNZ [10]

This key sets the number of soil layers the PARFLOW expects from CLM. It will allocate and format all the arrays for passing variables to and from CLM accordingly. This value now sets the CLM number as well so recompilation is not required anymore. Most likely the key **Solver.CLM.SoiLayer**, described below, will also need to be changed.

Example Usage:

```
pfset Solver.CLM.RootZoneNZ 4
```

integer **Solver.CLM.SoiLayer** [7]

This key sets the soil layer, and thus the soil depth, that CLM uses for the seasonal temperature adjustment for all leaf and stem area indices.

Example Usage:

```
pfset Solver.CLM.SoiLayer 4
```

6.2 ParFlow NetCDF4 Parallel I/O

NetCDF4 parallel I/O is being implemented in ParFlow. As of now only output capability is implemented. Input functionality will be added in later version. Currently user has option of printing 3-D time varying pressure or saturation or both in a single NetCDF file containing multiple time steps. User should configure ParFlow(pfsimulation part) "- -with-netcdf" option and link the appropriate NetCDF4 library. Naming convention of output files is analogues to binary file names. Following options are available for NetCDF4 output along with various performance tuning options. User is advised to explore NetCDF4 chunking and ROMIO hints option for better I/O performance.

HDF5 Library version 1.8.16 or higher is required for NetCDF4 parallel I/O

integer **NetCDF.NumStepsPerFile** []

This key sets number of time steps user wishes to output in a NetCDF4 file. Once the time step count increases beyond this number, a new file is automatically created.

Example Usage:

```
pfset NetCDF.NumStepsPerFile 5
```

string **NetCDF.WritePressure** [False]

This key sets pressure variable to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WritePressure True
```

string **NetCDF.WriteSaturation** [False]

This key sets saturation variable to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteSaturation True
```

string **NetCDF.WriteMannings** [False]

This key sets Mannings coefficients to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteMannings True
```

string **NetCDF.WriteSubsurface** [False]

This key sets subsurface data(permeabilities, porosity, specific storage) to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteSubsurface True
```

string **NetCDF.WriteSlopes** [False]

This key sets x and y slopes to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteSlopes True
```

string **NetCDF.WriteMask** [False]

This key sets mask to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteMask      True
```

```
string  NetCDF.WriteDZMultiplier [False]
```

This key sets DZ multipliers to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteDZMultiplier      True
```

```
string  NetCDF.WriteEvapTrans [False]
```

This key sets Evaptrans to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteEvapTrans      True
```

```
string  NetCDF.WriteEvapTransSum [False]
```

This key sets Evaptrans sum to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteEvapTransSum      True
```

```
string  NetCDF.WriteOverlandSum [False]
```

This key sets overland sum to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteOverlandSum      True
```

```
string  NetCDF.WriteOverlandBCFlux [False]
```

This key sets overland bc flux to be written in NetCDF4 file.

Example Usage:

```
pfset NetCDF.WriteOverlandBCFlux      True
```

6.2.1 NetCDF4 Chunking

Chunking may have significant impact on I/O. If this key is not set, default chunking scheme will be used by NetCDF library. Chunks are hypercube(hyperslab) of any dimension. When chunking is used, chunks are written in single write operation which can reduce access times. For more information on chunking, refer to NetCDF4 user guide.

```
string  NetCDF.Chunking [False]
```

This key sets chunking for each time varying 3-D variable in NetCDF4 file.

Example Usage:

```
pfset NetCDF.Chunking      True
```

Following keys are used only when **NetCDF.Chunking** is set to true. These keys are used to set chunk sizes in x, y and z direction. A typical size of chunk in each direction should be equal to number of grid points in each direction for each processor. e.g. If we are using a grid of 400(x)X400(y)X30(z) with 2-D domain decomposition of 8X8, then each core has 50(x)X50(y)X30(z) grid points. These values can be used to set chunk sizes each direction. For unequal distribution, chunk sizes should as large as largest value of grid points on the processor. e.g. If one processor has grid distribution of 40(x)X40(y)X30(z) and another has 50(x)X50(y)X30(z), the later values should be used to set chunk sizes in each direction.

```
integer  NetCDF.ChunkX [None]
```

This key sets chunking size in x-direction.

Example Usage:

```
pfset NetCDF.ChunkX      50
```

```
integer  NetCDF.ChunkY [None]
```

This key sets chunking size in y-direction.

Example Usage:

```
pfset NetCDF.ChunkY 50
```

integer **NetCDF.ChunkZ** [None]

This key sets chunking size in z-direction.

Example Usage:

```
pfset NetCDF.ChunkZ 30
```

6.2.2 ROMIO Hints

ROMIO is a portable MPI-IO implementation developed at Argonne National Laboratory, USA. Currently it is released as a part of MPICH. ROMIO sets hints to optimize I/O operations for MPI-IO layer through MPI_Info object. This object is passed on to NetCDF4 while creating a file. ROMIO hints are set in a text file in "key" and "value" pair. *For correct settings contact your HPC site administrator.* As in chunking, ROMIO hints can have significant performance impact on I/O.

string **NetCDF.ROMIOhints** [None]

This key sets ROMIO hints file to be passed on to NetCDF4 interface. If this key is set, the file must be present and readable in experiment directory.

Example Usage:

```
pfset NetCDF.ROMIOhints romio.hints
```

An example ROMIO hints file looks as follows.

```
romio_ds_write disable
romio_ds_read disable
romio_cb_write enable
romio_cb_read enable
cb_buffer_size 33554432
```

6.2.3 Node Level Collective I/O

A node level collective strategy has been implemented for I/O. One process on each compute node gathers the data, indices and counts from the participating processes on same compute node. All the root processes from each compute node open a parallel NetCDF4 file and write the data. e.g. If ParFlow is running on 3 compute nodes where each node consists of 24 processors(cores); only 3 I/O streams to filesystem would be opened by each root processor each compute node. This strategy could be particularly useful when ParFlow is running on large number of processors and every processor participating in I/O may create a bottleneck. ***Node level collective I/O is currently implemented for 2-D domain decomposition and variables Pressure and Saturation only. All the other ParFlow NetCDF output Tcl flags should be set to false(default value). CLM output is independently handled and not affected by this key. Moreover on speciality architectures, this may not be a portable feature. Users are advised to test this feature on their machine before putting into production.***

string **NetCDF.NodeLevelIO** [False]

This key sets flag for node level collective I/O.

Example Usage:

```
pfset NetCDF.NodeLevelIO True
```

6.2.4 NetCDF4 Initial Conditions: Pressure

Analogues to ParFlow binary files, NetCDF4 based option can be used to set the initial conditions for pressure to be read from an "nc" file containing single time step of pressure. The name of the variable in "nc" file should be "pressure". A sample NetCDF header of an initial condition file looks as follows. The names of the dimensions are not important. The order of dimensions is important e.g. *(time, lev, lat, lon)* or *(time,z, y, x)*

```
netcdf initial_condition {
dimensions:
x = 200 ;
y = 200 ;
z = 40 ;
time = UNLIMITED ; // (1 currently)
variables:
double time(time) ;
double pressure(time, z, y, x) ;
}
```

Node level collective I/O is currently not implemented for setting initial conditions.

`string ICPressure.Type` [no default]

This key sets flag for initial conditions to be read from a NetCDF file.

Example Usage:

```
pfset ICPressure.Type NCFFile
pfset Geom.domain.ICPressure.FileName "initial_condition.nc"
```

6.2.5 NetCDF4 Slopes

NetCDF4 based option can be used slopes to be read from an "nc" file containing single time step of slope values. The name of the variable in "nc" file should be "slopex" and "slopey". A sample NetCDF header of slope file looks as follows. The names of the dimensions are not important. The order of dimensions is important e.g. *(time, lat, lon)* or *(time, y, x)*

```
netcdf slopex {
dimensions:
time = UNLIMITED ; // (1 currently)
lon = 41 ;
lat = 41 ;
variables:
double time(time) ;
double slopex(time, lat, lon) ;
}
netcdf slopey {
dimensions:
time = UNLIMITED ; // (1 currently)
lon = 41 ;
lat = 41 ;
variables:
double time(time) ;
double slopey(time, lat, lon) ;
}
```

The two NetCDF files can be merged into one single file and can be used with tcl flags. The variable names should be exactly as mentioned above. Please refer to "slopes.nc" under Little Washita test case. *Node level collective I/O is currently not implemented for setting initial conditions.*

`string TopoSlopesX.Type` [no default]

This key sets flag for slopes in x direction to be read from a NetCDF file.

Example Usage:

```
pfset TopoSlopesX.Type NCFFile
pfset TopoSlopesX.FileName "slopex.nc"
```


string **TopoSlopesY.Type** [no default]

This key sets flag for slopes in y direction to be read from a NetCDF file.

Example Usage:

```
pfset TopoSlopesY.Type    NCFFile
pfset TopoSlopesY.FileName    "slopey.nc"
```

6.2.6 NetCDF4 Transient EvapTrans Forcing

Following keys can be used for NetCDF4 based transient evaptrans forcing. The file should contain forcing for all time steps. For a given time step, if the forcing is null, zero values could be filled for the given time step in the ".nc" file. The format of the sample file looks as follows. The names of the dimensions are not important. The order of dimensions is important e.g. *(time, lev, lat, lon)* or *(time,z, y, x)*

```
netcdf evap_trans {
dimensions:
time = UNLIMITED ; // (1000 currently)
x = 72 ;
y = 72 ;
z = 3 ;
variables:
double evaptrans(time, z, y, x) ;
}
```

Node level collective I/O is currently not implemented for transient evaptrans forcing.

string **NetCDF.EvapTransFileTransient** [False]

This key sets flag for transient evaptrans forcing to be read from a NetCDF file.

Example Usage:

```
pfset NetCDF.EvapTransFileTransient    True
```

string **NetCDF.EvapTrans.FileName** [no default]

This key sets the name of the NetCDF transient evaptrans forcing file.

Example Usage:

```
pfset NetCDF.EvapTrans.FileName    "evap_trans.nc"
```

6.2.7 NetCDF4 CLM Output

Similar to ParFlow binary and silo, following keys can be used to write output CLM variables in a single NetCDF file containing multiple time steps.

integer **NetCDF.CLMNumStepsPerFile** [None]

This key sets number of time steps to be written to a single NetCDF file.

Example Usage:

```
pfset NetCDF.CLMNumStepsPerFile 24
```

string **NetCDF.WriteCLM** [False]

This key sets CLM variables to be written in a NetCDF file.

Example Usage:

```
pfset NetCDF.WriteCLM    True
```

The output variables are:

eflx_lh_tot for latent heat flux total [W/m^2] using the silo variable *LatentHeat*;

eflx_lwrad_out for outgoing long-wave radiation [W/m^2] using the silo variable *LongWave*;

eflx_sh_tot for sensible heat flux total [W/m^2] using the silo variable *SensibleHeat*;

`eflx_soil_grnd` for ground heat flux [W/m^2] using the silo variable *GroundHeat*;
`qflx_evap_tot` for total evaporation [mm/s] using the silo variable *EvaporationTotal*;
`qflx_evap_grnd` for ground evaporation without condensation [mm/s] using the silo variable *EvaporationGround-NoSublimation*;
`qflx_evap_soi` for soil evaporation [mm/s] using the silo variable *EvaporationGround*;
`qflx_evap_veg` for vegetation evaporation [mm/s] using the silo variable *EvaporationCanopy*;
`qflx_tran_veg` for vegetation transpiration [mm/s] using the silo variable *Transpiration*;
`qflx_infl` for soil infiltration [mm/s] using the silo variable *Infiltration*;
`swe_out` for snow water equivalent [mm] using the silo variable *SWE*;
`t_grnd` for ground surface temperature [K] using the silo variable *TemperatureGround*; and
`t_soil` for soil temperature over all layers [K] using the silo variable *TemperatureSoil*.

6.2.8 NetCDF4 CLM Input/Forcing

NetCDF based meteorological forcing can be used with following TCL keys. It is built similar to 2D forcing case for CLM with parflow binary files. All the required forcing variables must be present in one single NetCDF file spanning entire length of simulation. If the simulation ends before number of time steps in NetCDF forcing file, next cycle of simulation can be restarted with same forcing file provided it covers the time span of this cycle.

e.g. If the NetCDF forcing file contains 100 time steps and simulation CLM-ParFlow simulation runs for 10 cycles containing 10 time steps in each cycle, the same forcing file can be reused. The user has to set correct value for the key `Solver.CLM.IstepStart`

The format of input file looks as follows. The variable names should match exactly as follows. The names of the dimensions are not important. The order of dimensions is important e.g. *(time, lev, lat, lon)* or *(time,z, y, x)*

```
netcdf metForcing {
dimensions:
lon = 41 ;
lat = 41 ;
time = UNLIMITED ; // (72 currently)
variables:
double time(time) ;
double APCP(time, lat, lon) ;
double DLWR(time, lat, lon) ;
double DSWR(time, lat, lon) ;
double Press(time, lat, lon) ;
double SPFH(time, lat, lon) ;
double Temp(time, lat, lon) ;
double UGRD(time, lat, lon) ;
double VGRD(time, lat, lon) ;
```

Note: While using NetCDF based CLM forcing, `Solver.CLM.MetFileNT` should be set to its default value of 1

`string Solver.CLM.MetForcing` [no default]

This key sets meteorological forcing to be read from NetCDF file.

Example Usage:

```
pfset Solver.CLM.MetForcing NC
```

Set the name of the input/forcing file as follows.

```
pfset Solver.CLM.MetFileName "metForcing.nc"
```

This file should be present in experiment directory. User may create soft links in experiment directory in case where data can not be moved.

6.2.9 NetCDF Testing Little Washita Test Case

The basic NetCDF functionality of output (pressure and saturation) and initial conditions (pressure) can be tested with following tcl script. CLM input/output functionality can also be tested with this case.

```
parflow/test/washita/tcl_scripts/LW_NetCDF_Test.tcl
```

This test case will be initialized with following initial condition file, slopes and meteorological forcing.

```
parflow/test/washita/parflow_input/press.init.nc
parflow/test/washita/parflow_input/slopes.nc
parflow/test/washita/clm_input/metForcing.nc
```

6.3 ParFlow Binary Files (.pfb)

The .pfb file format is a binary file format which is used to store PARFLOW grid data. It is written as BIG ENDIAN binary bit ordering [141]. The format for the file is:

```
<double : X>    <double : Y>    <double : Z>
<integer : NX>  <integer : NY>  <integer : NZ>
<double : DX>   <double : DY>   <double : DZ>

<integer : num_subgrids>
FOR subgrid = 0 TO <num_subgrids> - 1
BEGIN
  <integer : ix>  <integer : iy>  <integer : iz>
  <integer : nx>  <integer : ny>  <integer : nz>
  <integer : rx>  <integer : ry>  <integer : rz>
  FOR k = iz TO iz + <nz> - 1
  BEGIN
    FOR j = iy TO iy + <ny> - 1
    BEGIN
      FOR i = ix TO ix + <nx> - 1
      BEGIN
        <double : data_ijk>
      END
    END
  END
END
END
```

6.4 ParFlow CLM Single Output Binary Files (.c.pfb)

The .pfb file format is a binary file format which is used to store CLM output data in a single file. It is written as BIG ENDIAN binary bit ordering [141]. Each field is written as a contiguous 2D array; one can think of the Z axis as representing field. The number of fields depends on CLM options used. The format for the file is:

```
<double : X>    <double : Y>    <double : Z>
<integer : NX>  <integer : NY>  <integer : NZ>
<double : DX>   <double : DY>   <double : DZ>

<integer : num_subgrids>
FOR subgrid = 0 TO <num_subgrids> - 1
BEGIN
  <integer : ix>  <integer : iy>  <integer : iz>
```

```

<integer : nx> <integer : ny> <integer : nz>
<integer : rx> <integer : ry> <integer : rz>

fields = [ eflx_lh_tot
           eflx_lwrad_out
           eflx_sh_tot
           eflx_soil_grnd
           qflx_evap_tot
           qflx_evap_grnd
           qflx_evap_soil
           qflx_evap_veg
           qflx_tran_veg
           qflx_infl
           swe_out
           t_grnd
           IF (clm_irr_type == 1) qflx_qirr
           ELSE IF (clm_irr_type == 3) qflx_qirr_inst
           ELSE NULL
           FOR k = 1 TO clm_nz
             tsoilk
           END
         ]
FOREACH f in fields
  FOR j = iy TO iy + <ny> - 1
    BEGIN
      FOR i = ix TO ix + <nx> - 1
        BEGIN
          <f>_ij
        END
      END
    END
  END_FOREACH
END

```

6.5 ParFlow Scattered Binary Files (.pfsb)

The **.pfsb** file format is a binary file format which is used to store PARFLOW grid data. This format is used when the grid data is “scattered”, that is, when most of the data is 0. For data of this type, the **.pfsb** file format can reduce storage requirements considerably. The format for the file is:

```

<double : X> <double : Y> <double : Z>
<integer : NX> <integer : NY> <integer : NZ>
<double : DX> <double : DY> <double : DZ>

<integer : num_subgrids>
FOR subgrid = 0 TO <num_subgrids> - 1
  BEGIN
    <integer : ix> <integer : iy> <integer : iz>
    <integer : nx> <integer : ny> <integer : nz>
    <integer : rx> <integer : ry> <integer : rz>
    <integer : num_nonzero_data>
    FOR k = iz TO iz + <nz> - 1
      BEGIN

```

```

    FOR j = iy TO iy + <ny> - 1
    BEGIN
        FOR i = ix TO ix + <nx> - 1
        BEGIN
            IF (<data_ijk> > tolerance)
            BEGIN
                <integer : i> <integer : j> <integer : k>
                <double : data_ijk>
            END
        END
    END
END
END
END

```

6.6 ParFlow Solid Files (.pfsol)

The `.pfsol` file format is an ASCII file format which is used to define 3D solids. The solids are represented by closed triangulated surfaces, and surface “patches” may be associated with each solid.

Note that unlike the user input files, the solid file cannot contain comment lines.

The format for the file is:

```

<integer : file_version_number>

<integer : num_vertices>
# Vertices
FOR vertex = 0 TO <num_vertices> - 1
BEGIN
    <real : x> <real : y> <real : z>
END

# Solids
<integer : num_solids>
FOR solid = 0 TO <num_solids> - 1
BEGIN
    #Triangles
    <integer : num_triangles>
    FOR triangle = 0 TO <num_triangles> - 1
    BEGIN
        <integer : v0> <integer : v1> <integer : v2>
    END

    # Patches
    <integer : num_patches>
    FOR patch = 0 TO <num_patches> - 1
    BEGIN
        <integer : num_patch_triangles>
        FOR patch_triangle = 0 TO <num_patch_triangles> - 1
        BEGIN
            <integer : t>
        END
    END
END
END

```

The field `<file_version_number>` is used to make file format changes more manageable. The field `<num_vertices>` specifies the number of vertices to follow. The fields `<x>`, `<y>`, and `<z>` define the coordinate of a triangle vertex. The field `<num_solids>` specifies the number of solids to follow. The field `<num_triangles>` specifies the number of triangles to follow. The fields `<v0>`, `<v1>`, and `<v2>` are vertex indexes that specify the 3 vertices of a triangle. Note that the vertices for each triangle MUST be specified in an order that makes the normal vector point outward from the domain. The field `<num_patches>` specifies the number of surface patches to follow. The field `num_patch_triangles` specifies the number of triangles indices to follow (these triangles make up the surface patch). The field `<t>` is an index of a triangle on the solid `solid`.

PARFLOW `.pfsol` files can be created from GMS `.sol` files using the utility `gmssol2pfsol` located in the `$PARFLOW_DIR/bin` directory. This conversion routine takes any number of GMS `.sol` files, concatenates the vertices of the solids defined in the files, throws away duplicate vertices, then prints out the `.pfsol` file. Information relating the solid index in the resulting `.pfsol` file with the GMS names and material IDs are printed to stdout.

6.7 ParFlow Well Output File (.wells)

A well output file is produced by PARFLOW when wells are defined. The well output file contains information about the well data being used in the internal computations and accumulated statistics about the functioning of the wells. The header section has the following format:

```

LINE
BEGIN
    <real : BackgroundX>
    <real : BackgroundY>
    <real : BackgroundZ>
    <integer : BackgroundNX>
    <integer : BackgroundNY>
    <integer : BackgroundNZ>
    <real : BackgroundDX>
    <real : BackgroundDY>
    <real : BackgroundDZ>
END

LINE
BEGIN
    <integer : number_of_phases>
    <integer : number_of_components>
    <integer : number_of_wells>
END

FOR well = 0 TO <number_of_wells> - 1
BEGIN
    LINE
    BEGIN
        <integer : sequence_number>
    END

    LINE
    BEGIN
        <string : well_name>
    END

    LINE

```

```

BEGIN
  <real : well_x_lower>
  <real : well_y_lower>
  <real : well_z_lower>
  <real : well_x_upper>
  <real : well_y_upper>
  <real : well_z_upper>
  <real : well_diameter>
END

LINE
BEGIN
  <integer : well_type>
  <integer : well_action>
END
END

```

The data section has the following format:

```

FOR time = 1 TO <number_of_time_intervals>
BEGIN
  LINE
  BEGIN
    <real : time>
  END

  FOR well = 0 TO <number_of_wells> - 1
  BEGIN
    LINE
    BEGIN
      <integer : sequence_number>
    END

    LINE
    BEGIN
      <integer : SubgridIX>
      <integer : SubgridIY>
      <integer : SubgridIZ>
      <integer : SubgridNX>
      <integer : SubgridNY>
      <integer : SubgridNZ>
      <integer : SubgridRX>
      <integer : SubgridRY>
      <integer : SubgridRZ>
    END

    FOR well = 0 TO <number_of_wells> - 1
    BEGIN
      LINE
      BEGIN
        FOR phase = 0 TO <number_of_phases> - 1
        BEGIN
          <real : phase_value>
        END
      END
    END
  END
END

```

```

END

IF injection well
BEGIN
  LINE
  BEGIN
    FOR phase = 0 TO <number_of_phases> - 1
    BEGIN
      <real : saturation_value>
    END
  END

  LINE
  BEGIN
    FOR phase = 0 TO <number_of_phases> - 1
    BEGIN
      FOR component = 0 TO <number_of_components> - 1
      BEGIN
        <real : component_value>
      END
    END
  END
END

LINE
BEGIN
  FOR phase = 0 TO <number_of_phases> - 1
  BEGIN
    FOR component = 0 TO <number_of_components> - 1
    BEGIN
      <real : component_fraction>
    END
  END
END

LINE
BEGIN
  FOR phase = 0 TO <number_of_phases> - 1
  BEGIN
    <real : phase_statistic>
  END
END

LINE
BEGIN
  FOR phase = 0 TO <number_of_phases> - 1
  BEGIN
    <real : saturation_statistic>
  END
END

LINE

```



```

BEGIN
  FOR phase = 0 TO <number_of_phases> - 1
  BEGIN
    FOR component = 0 TO <number_of_components> - 1
    BEGIN
      <real : component_statistic>
    END
  END
END

LINE
BEGIN
  FOR phase = 0 TO <number_of_phases> - 1
  BEGIN
    FOR component = 0 TO <number_of_components> - 1
    BEGIN
      <real : concentration_data>
    END
  END
END
END
END
END

```

6.8 ParFlow Simple ASCII and Simple Binary Files (.sa and .sb)

The simple binary, **.sa**, file format is an ASCII file format which is used by **pftools** to write out PARFLOW grid data. The simple binary, **.sb**, file format is exactly the same, just written as BIG ENDIAN binary bit ordering [141]. The format for the file is:

```

<integer : NX> <integer : NY> <integer : NZ>

FOR k = 0 TO <nz> - 1
BEGIN
  FOR j = 0 TO <ny> - 1
  BEGIN
    FOR i = 0 TO <nz> - 1
    BEGIN
      <double : data_ijk>
    END
  END
END
END

```

Chapter 7

GNU Free Documentation License

Version 1.3, 3 November 2008
Copyright © 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc.

<<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The purpose of this License is to make a manual, textbook, or other functional and useful document “free” in the sense of freedom: to assure everyone the effective freedom to copy and redistribute it, with or without modifying it, either commercially or noncommercially. Secondly, this License preserves for the author and publisher a way to get credit for their work, while not being considered responsible for modifications made by others.

This License is a kind of “copyleft”, which means that derivative works of the document must themselves be free in the same sense. It complements the GNU General Public License, which is a copyleft license designed for free software.

We have designed this License in order to use it for manuals for free software, because free software needs free documentation: a free program should come with manuals providing the same freedoms that the software does. But this License is not limited to software manuals; it can be used for any textual work, regardless of subject matter or whether it is published as a printed book. We recommend this License principally for works whose purpose is instruction or reference.

1. APPLICABILITY AND DEFINITIONS

This License applies to any manual or other work, in any medium, that contains a notice placed by the copyright holder saying it can be distributed under the terms of this License. Such a notice grants a world-wide, royalty-free license, unlimited in duration, to use that work under the conditions stated herein. The “**Document**”, below, refers to any such manual or work. Any member of the public is a licensee, and is addressed as “**you**”. You accept the license if you copy, modify or distribute the work in a way requiring permission under copyright law.

A “**Modified Version**” of the Document means any work containing the Document or a portion of it, either copied verbatim, or with modifications and/or translated into another language.

A “**Secondary Section**” is a named appendix or a front-matter section of the Document that deals exclusively with the relationship of the publishers or authors of the Document to the Document’s overall subject (or to related matters) and contains nothing that could fall directly within that overall subject. (Thus, if the Document is in part a textbook of mathematics, a Secondary Section may not explain any mathematics.) The relationship could be a

matter of historical connection with the subject or with related matters, or of legal, commercial, philosophical, ethical or political position regarding them.

The “**Invariant Sections**” are certain Secondary Sections whose titles are designated, as being those of Invariant Sections, in the notice that says that the Document is released under this License. If a section does not fit the above definition of Secondary then it is not allowed to be designated as Invariant. The Document may contain zero Invariant Sections. If the Document does not identify any Invariant Sections then there are none.

The “**Cover Texts**” are certain short passages of text that are listed, as Front-Cover Texts or Back-Cover Texts, in the notice that says that the Document is released under this License. A Front-Cover Text may be at most 5 words, and a Back-Cover Text may be at most 25 words.

A “**Transparent**” copy of the Document means a machine-readable copy, represented in a format whose specification is available to the general public, that is suitable for revising the document straightforwardly with generic text editors or (for images composed of pixels) generic paint programs or (for drawings) some widely available drawing editor, and that is suitable for input to text formatters or for automatic translation to a variety of formats suitable for input to text formatters. A copy made in an otherwise Transparent file format whose markup, or absence of markup, has been arranged to thwart or discourage subsequent modification by readers is not Transparent. An image format is not Transparent if used for any substantial amount of text. A copy that is not “Transparent” is called “**Opaque**”.

Examples of suitable formats for Transparent copies include plain ASCII without markup, Texinfo input format, LaTeX input format, SGML or XML using a publicly available DTD, and standard-conforming simple HTML, PostScript or PDF designed for human modification. Examples of transparent image formats include PNG, XCF and JPG. Opaque formats include proprietary formats that can be read and edited only by proprietary word processors, SGML or XML for which the DTD and/or processing tools are not generally available, and the machine-generated HTML, PostScript or PDF produced by some word processors for output purposes only.

The “**Title Page**” means, for a printed book, the title page itself, plus such following pages as are needed to hold, legibly, the material this License requires to appear in the title page. For works in formats which do not have any title page as such, “Title Page” means the text near the most prominent appearance of the work’s title, preceding the beginning of the body of the text.

The “**publisher**” means any person or entity that distributes copies of the Document to the public.

A section “**Entitled XYZ**” means a named subunit of the Document whose title either is precisely XYZ or contains XYZ in parentheses following text that translates XYZ in another language. (Here XYZ stands for a specific section name mentioned below, such as “**Acknowledgements**”, “**Dedications**”, “**Endorsements**”, or “**History**”.) To “**Preserve the Title**” of such a section when you modify the Document means that it remains a section “Entitled XYZ” according to this definition.

The Document may include Warranty Disclaimers next to the notice which states that this License applies to the Document. These Warranty Disclaimers are considered to be included by reference in this License, but only as regards disclaiming warranties: any other implication that these Warranty Disclaimers may have is void and has no effect on the meaning of this License.

2. VERBATIM COPYING

You may copy and distribute the Document in any medium, either commercially or noncommercially, provided that this License, the copyright notices, and the license notice saying this License applies to the Document are reproduced in all copies, and that you add no other conditions whatsoever to those of this License. You may not use technical measures to obstruct or control the reading or further copying of the copies you make or distribute. However, you may accept compensation in exchange for copies. If you distribute a large enough number of copies you must also follow the conditions in section 3.

You may also lend copies, under the same conditions stated above, and you may publicly display copies.

3. COPYING IN QUANTITY

If you publish printed copies (or copies in media that commonly have printed covers) of the Document, numbering more than 100, and the Document’s license notice requires Cover Texts, you must enclose the copies in covers that carry, clearly and legibly, all these Cover Texts: Front-Cover Texts on the front cover, and Back-Cover Texts on the

back cover. Both covers must also clearly and legibly identify you as the publisher of these copies. The front cover must present the full title with all words of the title equally prominent and visible. You may add other material on the covers in addition. Copying with changes limited to the covers, as long as they preserve the title of the Document and satisfy these conditions, can be treated as verbatim copying in other respects.

If the required texts for either cover are too voluminous to fit legibly, you should put the first ones listed (as many as fit reasonably) on the actual cover, and continue the rest onto adjacent pages.

If you publish or distribute Opaque copies of the Document numbering more than 100, you must either include a machine-readable Transparent copy along with each Opaque copy, or state in or with each Opaque copy a computer-network location from which the general network-using public has access to download using public-standard network protocols a complete Transparent copy of the Document, free of added material. If you use the latter option, you must take reasonably prudent steps, when you begin distribution of Opaque copies in quantity, to ensure that this Transparent copy will remain thus accessible at the stated location until at least one year after the last time you distribute an Opaque copy (directly or through your agents or retailers) of that edition to the public.

It is requested, but not required, that you contact the authors of the Document well before redistributing any large number of copies, to give them a chance to provide you with an updated version of the Document.

4. MODIFICATIONS

You may copy and distribute a Modified Version of the Document under the conditions of sections 2 and 3 above, provided that you release the Modified Version under precisely this License, with the Modified Version filling the role of the Document, thus licensing distribution and modification of the Modified Version to whoever possesses a copy of it. In addition, you must do these things in the Modified Version:

- A. Use in the Title Page (and on the covers, if any) a title distinct from that of the Document, and from those of previous versions (which should, if there were any, be listed in the History section of the Document). You may use the same title as a previous version if the original publisher of that version gives permission.
- B. List on the Title Page, as authors, one or more persons or entities responsible for authorship of the modifications in the Modified Version, together with at least five of the principal authors of the Document (all of its principal authors, if it has fewer than five), unless they release you from this requirement.
- C. State on the Title page the name of the publisher of the Modified Version, as the publisher.
- D. Preserve all the copyright notices of the Document.
- E. Add an appropriate copyright notice for your modifications adjacent to the other copyright notices.
- F. Include, immediately after the copyright notices, a license notice giving the public permission to use the Modified Version under the terms of this License, in the form shown in the Addendum below.
- G. Preserve in that license notice the full lists of Invariant Sections and required Cover Texts given in the Document's license notice.
- H. Include an unaltered copy of this License.
- I. Preserve the section Entitled "History", Preserve its Title, and add to it an item stating at least the title, year, new authors, and publisher of the Modified Version as given on the Title Page. If there is no section Entitled "History" in the Document, create one stating the title, year, authors, and publisher of the Document as given on its Title Page, then add an item describing the Modified Version as stated in the previous sentence.
- J. Preserve the network location, if any, given in the Document for public access to a Transparent copy of the Document, and likewise the network locations given in the Document for previous versions it was based on. These may be placed in the "History" section. You may omit a network location for a work that was published at least four years before the Document itself, or if the original publisher of the version it refers to gives permission.
- K. For any section Entitled "Acknowledgements" or "Dedications", Preserve the Title of the section, and preserve in the section all the substance and tone of each of the contributor acknowledgements and/or dedications given therein.

- L. Preserve all the Invariant Sections of the Document, unaltered in their text and in their titles. Section numbers or the equivalent are not considered part of the section titles.
- M. Delete any section Entitled “Endorsements”. Such a section may not be included in the Modified Version.
- N. Do not retitle any existing section to be Entitled “Endorsements” or to conflict in title with any Invariant Section.
- O. Preserve any Warranty Disclaimers.

If the Modified Version includes new front-matter sections or appendices that qualify as Secondary Sections and contain no material copied from the Document, you may at your option designate some or all of these sections as invariant. To do this, add their titles to the list of Invariant Sections in the Modified Version’s license notice. These titles must be distinct from any other section titles.

You may add a section Entitled “Endorsements”, provided it contains nothing but endorsements of your Modified Version by various parties—for example, statements of peer review or that the text has been approved by an organization as the authoritative definition of a standard.

You may add a passage of up to five words as a Front-Cover Text, and a passage of up to 25 words as a Back-Cover Text, to the end of the list of Cover Texts in the Modified Version. Only one passage of Front-Cover Text and one of Back-Cover Text may be added by (or through arrangements made by) any one entity. If the Document already includes a cover text for the same cover, previously added by you or by arrangement made by the same entity you are acting on behalf of, you may not add another; but you may replace the old one, on explicit permission from the previous publisher that added the old one.

The author(s) and publisher(s) of the Document do not by this License give permission to use their names for publicity for or to assert or imply endorsement of any Modified Version.

5. COMBINING DOCUMENTS

You may combine the Document with other documents released under this License, under the terms defined in section 4 above for modified versions, provided that you include in the combination all of the Invariant Sections of all of the original documents, unmodified, and list them all as Invariant Sections of your combined work in its license notice, and that you preserve all their Warranty Disclaimers.

The combined work need only contain one copy of this License, and multiple identical Invariant Sections may be replaced with a single copy. If there are multiple Invariant Sections with the same name but different contents, make the title of each such section unique by adding at the end of it, in parentheses, the name of the original author or publisher of that section if known, or else a unique number. Make the same adjustment to the section titles in the list of Invariant Sections in the license notice of the combined work.

In the combination, you must combine any sections Entitled “History” in the various original documents, forming one section Entitled “History”; likewise combine any sections Entitled “Acknowledgements”, and any sections Entitled “Dedications”. You must delete all sections Entitled “Endorsements”.

6. COLLECTIONS OF DOCUMENTS

You may make a collection consisting of the Document and other documents released under this License, and replace the individual copies of this License in the various documents with a single copy that is included in the collection, provided that you follow the rules of this License for verbatim copying of each of the documents in all other respects.

You may extract a single document from such a collection, and distribute it individually under this License, provided you insert a copy of this License into the extracted document, and follow this License in all other respects regarding verbatim copying of that document.

7. AGGREGATION WITH INDEPENDENT WORKS

A compilation of the Document or its derivatives with other separate and independent documents or works, in or on a volume of a storage or distribution medium, is called an “aggregate” if the copyright resulting from the compilation is not used to limit the legal rights of the compilation’s users beyond what the individual works permit. When the Document is included in an aggregate, this License does not apply to the other works in the aggregate which are not themselves derivative works of the Document.

If the Cover Text requirement of section 3 is applicable to these copies of the Document, then if the Document is less than one half of the entire aggregate, the Document’s Cover Texts may be placed on covers that bracket the Document within the aggregate, or the electronic equivalent of covers if the Document is in electronic form. Otherwise they must appear on printed covers that bracket the whole aggregate.

8. TRANSLATION

Translation is considered a kind of modification, so you may distribute translations of the Document under the terms of section 4. Replacing Invariant Sections with translations requires special permission from their copyright holders, but you may include translations of some or all Invariant Sections in addition to the original versions of these Invariant Sections. You may include a translation of this License, and all the license notices in the Document, and any Warranty Disclaimers, provided that you also include the original English version of this License and the original versions of those notices and disclaimers. In case of a disagreement between the translation and the original version of this License or a notice or disclaimer, the original version will prevail.

If a section in the Document is Entitled “Acknowledgements”, “Dedications”, or “History”, the requirement (section 4) to Preserve its Title (section 1) will typically require changing the actual title.

9. TERMINATION

You may not copy, modify, sublicense, or distribute the Document except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, or distribute it is void, and will automatically terminate your rights under this License.

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, receipt of a copy of some or all of the same material does not give you any rights to use it.

10. FUTURE REVISIONS OF THIS LICENSE

The Free Software Foundation may publish new, revised versions of the GNU Free Documentation License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. See <http://www.gnu.org/copyleft/>.

Each version of the License is given a distinguishing version number. If the Document specifies that a particular numbered version of this License “or any later version” applies to it, you have the option of following the terms and conditions either of that specified version or of any later version that has been published (not as a draft) by the Free Software Foundation. If the Document does not specify a version number of this License, you may choose any version ever published (not as a draft) by the Free Software Foundation. If the Document specifies that a proxy can decide which future versions of this License can be used, that proxy’s public statement of acceptance of a version permanently authorizes you to choose that version for the Document.

11. RELICENSING

“Massive Multiauthor Collaboration Site” (or “MMC Site”) means any World Wide Web server that publishes copyrightable works and also provides prominent facilities for anybody to edit those works. A public wiki that anybody can edit is an example of such a server. A “Massive Multiauthor Collaboration” (or “MMC”) contained in the site means any set of copyrightable works thus published on the MMC site.

“CC-BY-SA” means the Creative Commons Attribution-Share Alike 3.0 license published by Creative Commons Corporation, a not-for-profit corporation with a principal place of business in San Francisco, California, as well as future copyleft versions of that license published by that same organization.

“Incorporate” means to publish or republish a Document, in whole or in part, as part of another Document.

An MMC is “eligible for relicensing” if it is licensed under this License, and if all works that were first published under this License somewhere other than this MMC, and subsequently incorporated in whole or in part into the MMC, (1) had no cover texts or invariant sections, and (2) were thus incorporated prior to November 1, 2008.

The operator of an MMC Site may republish an MMC contained in the site under CC-BY-SA on the same site at any time before August 1, 2009, provided the MMC is eligible for relicensing.

Bibliography

- [1] Ajami, H., McCabe, M.F., Evans, J.P. and Stisen, S. (2014). Assessing the impact of model spin-up on surface water-groundwater interactions using an integrated hydrologic model. *Water Resources Research* **50** 2636–2656, doi:10.1002/2013WR014258.
- [2] Ajami,H., M.F. McCabe, and J.P. Evans (2015). Impacts of model initialization on an integrated surface water-groundwater model. *Hydrological Processes*, 29(17):3790–3801.
- [3] Ajami, H.; Sharma, A. (2018). Disaggregating Soil Moisture to Finer Spatial Resolutions: A Comparison of Alternatives. *Water Resour. Res.* , **54** (11), 9456–9483. <https://doi.org/10.1029/2018WR022575>.
- [4] Ashby, S.F. and Falgout,R. D. (1996). A parallel multigrid preconditioned conjugate gradient algorithm for groundwater flow simulations. *Nuclear Science and Engineering*, **124**:145–159.
- [5] Atchley, A. and Maxwell, R.M. (2011). Influences of subsurface heterogeneity and vegetation cover on soil moisture, surface temperature, and evapotranspiration at hillslope scales. *Hydrogeology Journal* doi:10.1007/s10040-010-0690-1.
- [6] Atchley, A.L., Maxwell, R.M. and Navarre-Sitchler, A.K. (2013). Human Health Risk Assessment of CO₂ Leakage into Overlying Aquifers Using a Stochastic, Geochemical Reactive Transport Approach. *Environmental Science and Technology* **47** 5954–5962, doi:10.1021/es400316c.
- [7] Atchley, A.L., Maxwell, R.M. and Navarre-Sitchler, A.K. (2013). Using streamlines to simulate stochastic reactive transport in heterogeneous aquifers: Kinetic metal release and transport in CO₂ impacted drinking water aquifers. *Advances in Water Resources* **52** 93–106, doi:10.1016/j.advwatres.2012.09.005.
- [8] Atchley, A. L.; Kinoshita, A. M.; Lopez, S. R.; Trader, L.; Middleton, R. (2018). Simulating Surface and Subsurface Water Balance Changes Due to Burn Severity. *Vadose Zo. J.* **17** (1). <https://doi.org/10.2136/vzj2018.05.0099>.
- [9] Bhaskar,A.S., C. Welty, R.M. Maxwell, and A.J. Miller (2015). Untangling the effects of urban development on subsurface storage in baltimore. *Water Resources Research*, 51(2):1158–1181.
- [10] Baatz, D.; Kurtz, W.; Hendricks Franssen, H. J.; Vereecken, H.; Kollet, S. J. (2017). Catchment Tomography - An Approach for Spatial Parameter Estimation. *Adv. Water Resour.* **107**, 147–159. <https://doi.org/10.1016/j.advwatres.2017.06.006>.
- [11] Barnes,M. C. Welty, and A. Miller (2015). Global topographic slope enforcement to ensure connectivity and drainage in an urban terrain. *Journal of Hydrologic Engineering*, 0(0):06015017.
- [12] Barnes, M. L.; Welty, C.; Miller, A. J. (2018). Impacts of Development Pattern on Urban Groundwater Flow Regime. *Water Resour. Res.* **54** (8), 5198–5212. <https://doi.org/10.1029/2017WR022146>.
- [13] Baroni, G.; Schalge, B.; Rakovec, O.; Kumar, R.; SchÄijler, L.; Samaniego, L.; Simmer, C.; Attinger, S. A (2019). Comprehensive Distributed Hydrological Modeling Intercomparison to Support Process Representation and Data Collection Strategies. *Water Resour. Res.* **990**–**1010**. <https://doi.org/10.1029/2018WR023941>.
- [14] Bearup,L.A. R.M. Maxwell and J.E. McCray (2016). Hillslope response to insect-induced land-cover change: an integrated model of end-member mixing. *Ecohydrology*, ECO-15-0202.R1.

- [15] Beisman, J.J., R. M. Maxwell, A. K. Navarre-Sitchler, C. I. Steefel, and S. Molins (2015). Parcrunchflow: an efficient, parallel reactive transport simulation tool for physically and chemically heterogeneous saturated subsurface environments. *Computational Geosciences*, 19(2):403–422.
- [16] Bürger, C.M., Kollet, S., Schumacher, J. and BÄusel, D. (2012). Introduction of a web service for cloud computing with the integrated hydrologic simulation platform ParFlow. *Computers and Geosciences* **48** 334–336, doi:10.1016/j.cageo.2012.01.007.
- [17] Condon, L.E. and Maxwell, R.M. (2013). Implementation of a linear optimization water allocation algorithm into a fully integrated physical hydrology model. *Advances in Water Resources* **60** 135–147, doi:10.1016/j.advwatres.2013.07.012.
- [18] Condon, L.E., Maxwell, R.M. and Gangopadhyay, S. (2013). The impact of subsurface conceptualization on land energy fluxes. *Advances in Water Resources* **60** 188–203, doi:10.1016/j.advwatres.2013.08.001.
- [19] Condon, L.E. and Maxwell, R.M. (2014). Feedbacks between managed irrigation and water availability: Diagnosing temporal and spatial patterns using an integrated hydrologic model. *Water Resources Research* **50** 2600–2616, doi:10.1002/2013WR014868.
- [20] Condon, L.E. and Maxwell, R.M. (2014). Groundwater-fed irrigation impacts spatially distributed temporal scaling behavior of the natural system: a spatio-temporal framework for understanding water management impacts. *Environmental Research Letters* **9** 1–9, doi:10.1088/1748-9326/9/3/034009.
- [21] Condon, L.E., A. S. Hering, and R. M. Maxwell (2015). Quantitative assessment of groundwater controls across major {US} river basins using a multi-model regression algorithm. *Advances in Water Resources*, 82:106 – 123.
- [22] Condon, L.E., and R. M. Maxwell (2015). Evaluating the relationship between topography and groundwater using outputs from a continental-scale integrated hydrology model. *Water Resources Research*, 51(8):6602–6621.
- [23] Condon, L. E.; Maxwell, R. M. (2017). Systematic Shifts in Budyko Relationships Caused by Groundwater Storage Changes. *Hydrol. Earth Syst. Sci.* **21** (2), 1117–1135. <https://doi.org/10.5194/hess-21-1117-2017>.
- [24] Condon, L. E.; Maxwell, R. M. (2019). Simulating the Sensitivity of Evapotranspiration and Streamflow to Large-Scale Groundwater Depletion. *Sci. Adv.* **5** (6). <https://doi.org/10.1126/sciadv.aav4574>.
- [25] Condon, L. E.; Maxwell, R. M. (2019). Modified priority flood and global slope enforcement algorithm for topographic processing in physically based hydrologic modeling applications. *Computers and Geosciences*, **126**(February), 73–83. <https://doi.org/10.1016/j.cageo.2019.01.020>.
- [26] Cui, Z., Welty, C. and Maxwell, R.M. (2014). Modeling nitrogen transport and transformation in aquifers using a particle-tracking approach. *Computers and Geosciences* **70** 1–14, doi:10.1016/j.cageo.2014.05.005.
- [27] Dai, Y., X. Zeng, R.E. Dickinson, I. Baker, G.B. Bonan, M.G. Bosilovich, A.S. Denning, P.A. Dirmeyer, P.R., G. Niu, K.W. Oleson, C.A. Schlosser and Z.L. Yang (2003). The common land model. *The Bulletin of the American Meteorological Society* **84**(8):1013–1023.
- [28] Danesh-Yazdi, M.; Klaus, J.; Condon, L. E.; Maxwell, R. M. (2018). Bridging the Gap between Numerical Solutions of Travel Time Distributions and Analytical Storage Selection Functions. *Hydrol. Process.* **32** (8), 1063–1076. <https://doi.org/10.1002/hyp.11481>.
- [29] Daniels, M.H., Maxwell, R.M., Chow, F.K. (2010). An algorithm for flow direction enforcement using subgrid-scale stream location data, *Journal of Hydrologic Engineering* **16** 677–683, doi:10.1061/(ASCE)HE.1943-5584.0000340.
- [30] de Barros, F.P.J., Rubin, Y. and Maxwell, R.M. (2009). The concept of comparative information yield curves and their application to risk-based site characterization. *Water Resources Research* **45**, W06401, doi:10.1029/2008WR007324.
- [31] de Rooij, R., Graham, W. and Maxwell, R.M. (2013). A particle-tracking scheme for simulating pathlines in coupled surface-subsurface flows. *Advances in Water Resources* **52** 7–18, doi:10.1016/j.advwatres.2012.07.022.
- [32] Eisenstat, S.C. and Walker, H.F. (1996). Choosing the forcing terms in an inexact newton method. *SIAM J. Sci. Comput.*, **17**(1):16–32.

- [33] Nicholas B. Engdahl and Reed M. Maxwell (2015). Quantifying changes in age distributions and the hydrologic balance of a high-mountain watershed from climate induced variations in recharge. *Journal of Hydrology*, 522:152 – 162.
- [34] Zhufeng Fang, Heye Bogen, Stefan Kollet, Julian Koch, and Harry Vereecken (2015). Spatio-temporal validation of long-term 3d hydrological simulations of a forested catchment using empirical orthogonal functions and wavelet coherence analysis. *Journal of Hydrology*, 529, Part 3:1754 – 1767.
- [35] Fang, Y., L. R. Leung, Z. Duan, M. S. Wigmosta, R. M. Maxwell, J. Q. Chambers, and J. Tomasella (2016). Influence of landscape heterogeneity on water available to tropical forests in an Amazonian catchment and implications for modeling drought response, *J. Geophys. Res. Atmos.*, **122**, 8410–8426, doi:10.1002/2017JD027066.
- [36] Fang, Yilin; Leung, L. Ruby; Duan, Zhuoran; Wigmosta, Mark S.; Maxwell, Reed M.; Chambers, Jeffrey Q.; Tomasella, J. (2017). Journal of Geophysical Research: Atmospheres. *J. Geophys. Res. Atmos.* /bf 122, 3672–3685. <https://doi.org/10.1002/2016JD025676>.
- [37] Ferguson, I.M. and Maxwell, R.M. (2010). Role of groundwater in watershed response and land surface feedbacks under climate change. *Water Resources Research* 46, W00F02, doi:10.1029/2009WR008616.
- [38] Ferguson, I.M. and Maxwell, R.M. (2011). Hydrologic and land–energy feedbacks of agricultural water management practices. *Environmental Research Letters* **6** 1–7, doi:10.1088/1748-9326/6/1/014006.
- [39] Ferguson, I.M. and Maxwell, R.M. (2012). Human impacts on terrestrial hydrology: climate change versus pumping and irrigation. *Environmental Research Letters* **7** 1–8, doi:10.1088/1748-9326/7/4/044022.
- [40] Ferguson, I. M.; Jefferson, J. L.; Maxwell, R. M.; Kollet, S. J. (2016). Effects of Root Water Uptake Formulation on Simulated Water and Energy Budgets at Local and Basin Scales. *Environ. Earth Sci.* **75** (4), 1–15. <https://doi.org/10.1007/s12665-015-5041-z>.
- [41] Forrester, M. M.; Maxwell, R. M.; Bearup, L. A.; Gochis, D. J. (2018). Forest Disturbance Feedbacks From Bedrock to Atmosphere Using Coupled Hydrometeorological Simulations Over the Rocky Mountain Headwaters. *J. Geophys. Res. Atmos.* **123** (17), 9026–9046. <https://doi.org/10.1029/2018JD028380>.
- [42] Forsyth, P.A., Wu, Y.S. and Pruess, K. (1995). Robust Numerical Methods for Saturated-Unsaturated Flow with Dry Initial Conditions. *Advances in Water Resources*, **17**:25–38.
- [43] Foster, L. M.; Bearup, L. A.; Molotch, N. P.; Brooks, P. D.; Maxwell, R. M. (2016). Energy Budget Increases Reduce Mean Streamflow More than Snow-Rain Transitions: Using Integrated Modeling to Isolate Climate Change Impacts on Rocky Mountain Hydrology. *Environ. Res. Lett.* **11** (4). <https://doi.org/10.1088/1748-9326/11/4/044015>.
- [44] Foster, L. M.; Maxwell, R. M. (2019). Sensitivity Analysis of Hydraulic Conductivity and Manning’s n Parameters Lead to New Method to Scale Effective Hydraulic Conductivity across Model Resolutions. *Hydrol. Process.* **33** (3), 332–349. <https://doi.org/10.1002/hyp.13327>.
- [45] Frei, S., Fleckenstein, J.H., Kollet, S.J. and Maxwell, R.M. (2009). Patterns and dynamics of river-aquifer exchange with variably-saturated flow using a fully-coupled model. *Journal of Hydrology* 375(3-4), 383–393, doi:10.1016/j.jhydrol.2009.06.038.
- [46] Gebler, S.; Hendricks Franssen, H. J.; Kollet, S. J.; Qu, W.; Vereecken, H. (2017). High Resolution Modelling of Soil Moisture Patterns with TerrSysMP: A Comparison with Sensor Network Data. *J. Hydrol.* **547**, 309–331. <https://doi.org/10.1016/j.jhydrol.2017.01.048>.
- [47] Gilbert, J. M.; Jefferson, J. L.; Constantine, P. G.; Maxwell, R. M. (2016). Global Spatial Sensitivity of Runoff to Subsurface Permeability Using the Active Subspace Method. *Adv. Water Resour.* **92**, 30–42. <https://doi.org/10.1016/j.advwatres.2016.03.020>.
- [48] Gilbert, J. M.; Maxwell, R. M. (2017). Examining Regional Groundwater-Surface Water Dynamics Using an Integrated Hydrologic Model of the San Joaquin River Basin. *Hydrol. Earth Syst. Sci.* **21** (2), 923–947. <https://doi.org/10.5194/hess-21-923-2017>.
- [49] Gilbert, J. M.; Maxwell, R. M.; Gochis, D. J. (2017). Effects of Water-Table Configuration on the Planetary Boundary Layer over the San Joaquin River Watershed, California. *J. Hydrometeorol.* **18** (5), 1471–1488. <https://doi.org/10.1175/JHM-D-16-0134.1>.

- [50] Gilbert, J. M.; Maxwell, R. M. (2018). Contrasting Warming and Drought in Snowmelt-Dominated Agricultural Basins: Revealing the Role of Elevation Gradients in Regional Response to Temperature Change. *Environ. Res. Lett.* **13** (7). <https://doi.org/10.1088/1748-9326/aacb38>.
- [51] Gou, S.; Miller, G. R.; Saville, C.; Maxwell, R. M.; Ferguson, I. M. (2018). Simulating Groundwater Uptake and Hydraulic Redistribution by Phreatophytes in a High-Resolution, Coupled Subsurface-Land Surface Model. *Adv. Water Resour.* **121** (August 2017), 245–262. <https://doi.org/10.1016/j.advwatres.2018.08.008>.
- [52] Haverkamp, R. and Vauclin, M. (1981). A comparative study of three forms of the Richard equation used for predicting one-dimensional infiltration in unsaturated soil. *Soil Sci. Soc. of Am. J.*, **45**:13–20.
- [53] Hein, A.; Condon, L.; Maxwell, R. (2019). Unravelling the Impacts of Precipitation, Temperature and Land-Cover Change for Extreme Drought over the North American High Plains. *Hydrol. Earth Syst. Sci. Discuss.* **11**:30. <https://doi.org/10.5194/hess-2018-485>.
- [54] Jennifer L. Jefferson and Reed M. Maxwell (2015). Evaluation of simple to complex parameterizations of bare ground evaporation. *Journal of Advances in Modeling Earth Systems*, **7**(3):1075–1092.
- [55] Jennifer L. Jefferson, James M. Gilbert, Paul G. Constantine, and Reed M. Maxwell (2015). Active subspaces for sensitivity analysis and dimension reduction of an integrated hydrologic model. *Computers & Geosciences*, **83**:127 – 138.
- [56] Jefferson, J. L.; Maxwell, R. M.; Constantine, P. G. (2017). Exploring the Sensitivity of Photosynthesis and Stomatal Resistance Parameters in a Land Surface Model. *J. Hydrometeorol.* **18** (3), 897–915. <https://doi.org/10.1175/jhm-d-16-0053.1>.
- [57] Jones, J.E. and Woodward, C.S. (2001). Newton-krylov-multigrid solvers for large-scale, highly heterogeneous, variably saturated flow problems. *Advances in Water Resources*, **24**:763–774.
- [58] Keune, J.; Gasper, F.; Goergen, K.; Hense, A.; Shrestha, P.; Sulis, M.; Kollet, S. (2016). Studying the Influence of Groundwater Representations on Land Surface-Atmosphere Feedbacks during the European Heat Wave in 2003. *J. Geophys. Res.* **121** (22), 13,301–13,325. <https://doi.org/10.1002/2016JD025426>.
- [59] Keune, J.; Sulis, M.; Kollet, S.; Siebert, S.; Wada, Y. Human Water Use Impacts on the Strength of the Continental Sink for Atmospheric Water. *Geophys. Res. Lett.* **2018**, **45** (9), 4068–4076. <https://doi.org/10.1029/2018GL077621>.
- [60] Keyes, D.E., McInnes, L.C., Woodward, C., Gropp, W., Myra, E., Pernice, M., Bell, J., Brown, J., Clo, A., Connors, J., Constantinescu, E., Estep, D., Evans, K., Farhat, C., Hakim, A., Hammond, G., Hansen, G., Hill, J., Isaac, T., et al. (2013). Multiphysics simulations: Challenges and opportunities. *International Journal of High Performance Computing Applications* **27** 4–83, doi:10.1177/1094342012468181.
- [61] J. Koch, T. Cornelissen, Z. Fang, H. Bogen, B. H. Diekkrüger, S. Kollet, and S. Stisen (2016). Inter-comparison of three distributed hydrological models with respect to seasonal variability of soil moisture patterns at a small forested catchment. *J. of Hydrology*, (533):234–246. <https://doi.org/10.1016/j.jhydrol.2015.12.002>.
- [62] Kollat, J.B., Reed, P.M. and Maxwell, R.M. (2011). Many-objective groundwater monitoring network design using bias-aware ensemble Kalman filtering, evolutionary optimization, and visual analytics. *Water Resources Research*, doi:10.1029/2010WR009194.
- [63] Kollet, S.J. (2009). Influence of soil heterogeneity on evapotranspiration under shallow water table conditions: transient, stochastic simulations. *Environmental Research Letters* **4** 1–9, doi:10.1088/1748-9326/4/3/035007.
- [64] Kollet, S.J., Cvijanovic, I., Schüttemeyer, D., Maxwell, R.M., Moene, A.F. and Bayer P (2009). The influence of rain sensible heat, subsurface heat convection and the lower temperature boundary condition on the energy balance at the land surface. *Vadose Zone Journal*, doi:10.2136/vzj2009.0005.
- [65] Kollet, S. J. and Maxwell, R. M. (2006). Integrated surface-groundwater flow modeling: A free-surface overland flow boundary condition in a parallel groundwater flow model. *Advances in Water Resources*, **29**:945–958 .
- [66] Kollet, S.J. and Maxwell, R.M. (2008). Capturing the influence of groundwater dynamics on land surface processes using an integrated, distributed watershed model, *Water Resources Research*, **44**: W02402.

- [67] Kollet, S.J. and Maxwell, R.M. (2008). Demonstrating fractal scaling of baseflow residence time distributions using a fully-coupled groundwater and land surface model. *Geophysical Research Letters*, **35**, L07402.
- [68] Kollet, S.J., Maxwell, R.M., Woodward, C.S., Smith, S.G., Vanderborght, J., Vereecken, H., and Simmer, C. (2010). Proof-of-concept of regional scale hydrologic simulations at hydrologic resolution utilizing massively parallel computer resources. *Water Resources Research*, 46, W04201, doi:10.1029/2009WR008730.
- [69] S.J. Kollet (2015). Optimality and inference in hydrology from entropy production considerations: synthetic hillslope numerical experiments. *Hydrol. Earth Syst. Sci. Discuss.*, (12):5123–5149.
- [70] Kollet, S. J. (2016). Technical Note: Inference in Hydrology from Entropy Balance Considerations. *Hydrol. Earth Syst. Sci.* **20** (7), 2801–2809. <https://doi.org/10.5194/hess-20-2801-2016>.
- [71] Kollet, S. J., Sulis, M., Maxwell, R. M., Paniconi, C., Putti, M., Bertoldi, G., & Sudicky, E. (2017). The integrated hydrologic model intercomparison project, IH-MIP2: A second set of benchmark results to diagnose integrated hydrology and feedbacks. *Water Resources Research*. <https://doi.org/10.1002/2016WR019191>.
- [72] Kollet, S., Gasper, F., Brdar, S., Goergen, K., Hendricks-Franssen, H. J., Keune, J., & Sulis, M. (2018). Introduction of an experimental terrestrial forecasting/monitoring system at regional to continental scales based on the terrestrial systems modeling platform (v1.1.0). *Water (Switzerland)*, **10**(11). <https://doi.org/10.3390/w10111697>.
- [73] Kuffour, B. N. O. ., Engdahl, N. B. ., Woodward, C. S. ., Condon, L. E. ., Kollet, S., & Maxwell, R. M. (2019). Simulating Coupled Surface-Subsurface Flows with ParFlow v3.5.0: Capabilities, applications, and ongoing development of an open-source, massively parallel, integrated hydrologic model. *Geoscientific Model Development*, (August). <https://doi.org/10.5194/gmd-2019-190>.
- [74] Kurtz, W., He, G., Kollet, S. J., Maxwell, R. M., Vereecken, H., & Franssen, H. J. H. (2016). TerrSysMP-PDAF (version 1.0): A modular high-performance data assimilation framework for an integrated land surface-subsurface model. *Geoscientific Model Development*. <https://doi.org/10.5194/gmd-9-1341-2016>.
- [75] Lim, T. C., & Welty, C. (2017). Effects of spatial configuration of imperviousness and green infrastructure networks on hydrologic response in a residential sewershed. *Water Resources Research*, **53**(9), 8084–8104. <https://doi.org/10.1002/2017WR020631>.
- [76] Lim, T. C., & Welty, C. (2018). Assessing variability and uncertainty in green infrastructure planning using a high-resolution surface-subsurface hydrological model and site-monitored flow data. *Frontiers in Built Environment*, **4** (December), 1–15. <https://doi.org/10.3389/fbuil.2018.00071>.
- [77] Lopez, S. R., & Maxwell, R. M. (2016). Identifying Urban Features from LiDAR for a High-Resolution Urban Hydrologic Model. *Journal of the American Water Resources Association*, **52**(3), 756–768. <https://doi.org/10.1111/1752-1688.12425>.
- [78] Maina, F. Z., & Siirila-Woodburn, E. R. (2019). Watersheds dynamics following wildfires: Non-linear feedbacks and implications on hydrologic responses. *Hydrological Processes*, (August), 1–18. <https://doi.org/10.1002/hyp.13568>.
- [79] Major, E., Benson, D.A., Revieille, J., Ibrahim, H., Dean, A., Maxwell, R.M., Poeter, E. and Dogan, M. (2011). Comparison of Fickian and temporally nonlocal transport theories over many scales in an exhaustively sampled sandstone slab. *Water Resources Research* **47** 1-14, doi:10.1029/2011WR010857.
- [80] Markovich, K. H., Maxwell, R. M., & Fogg, G. E. (2016). Hydrogeological response to climate change in alpine hillslopes. *Hydrological Processes*, **30**(18), 3126–3138. <https://doi.org/10.1002/hyp.10851>.
- [81] Maxwell, R.M., Carle, S.F and Tompson, A.F.B. (2000). Risk-Based Management of Contaminated Groundwater: The Role of Geologic Heterogeneity, Exposure and Cancer Risk in Determining the Performance of Aquifer Remediation, In *Proceedings of Computational Methods in Water Resources XII*, Balkema, 533–539.
- [82] Maxwell, R.M., Welty, C. and Tompson, A.F.B. (2003). Streamline-based simulation of virus transport resulting from long term artificial recharge in a heterogeneous aquifer *Advances in Water Resources*, **22**(3):203–221.
- [83] Maxwell, R.M. and Miller, N.L. (2005). Development of a coupled land surface and groundwater model. *Journal of Hydrometeorology*, **6**(3):233–247.

- [84] Maxwell, R.M., Chow, F.K. and Kollet, S.J. (2007). The groundwater-land-surface-atmosphere connection: soil moisture effects on the atmospheric boundary layer in fully-coupled simulations. *Advances in Water Resources*, **30**(12):2447–2466.
- [85] Maxwell, R.M., Welty, C. and Harvey, R.W. (2007). Revisiting the Cape Cod Bacteria Injection Experiment Using a Stochastic Modeling Approach, *Environmental Science and Technology*, **41**(15):5548–5558.
- [86] Maxwell, R.M., Carle, S.F. and Tompson, A.F.B. (2008). Contamination, risk, and heterogeneity: on the effectiveness of aquifer remediation. *Environmental Geology*, **54**:1771–1786.
- [87] Maxwell, R.M. and Kollet, S.J. (2008). Quantifying the effects of three-dimensional subsurface heterogeneity on Hortonian runoff processes using a coupled numerical, stochastic approach. *Advances in Water Resources* **31**(5): 807–817.
- [88] Maxwell, R.M. and Kollet, S.J. (2008) Interdependence of groundwater dynamics and land-energy feedbacks under climate change. *Nature Geoscience* **1**(10): 665–669.
- [89] Maxwell, R.M., Tompson, A.F.B. and Kollet, S.J. (2009) A serendipitous, long-term infiltration experiment: Water and tritium circulation beneath the CAMBRIC trench at the Nevada Test Site. *Journal of Contaminant Hydrology* 108(1-2) 12-28, doi:10.1016/j.jconhyd.2009.05.002.
- [90] Maxwell, R.M. (2010). Infiltration in arid environments: Spatial patterns between subsurface heterogeneity and water-energy balances, *Vadose Zone Journal* 9, 970–983, doi:10.2136/vzj2010.0014.
- [91] Maxwell, R.M., Lundquist, J.K., Mirocha, J.D., Smith, S.G., Woodward, C.S. and Tompson, A.F.B. (2011). Development of a coupled groundwater-atmospheric model. *Monthly Weather Review* doi:10.1175/2010MWR3392.
- [92] Maxwell, R.M. (2013). A terrain-following grid transform and preconditioner for parallel, large-scale, integrated hydrologic modeling. *Advances in Water Resources* **53** 109–117, doi:10.1016/j.advwatres.2012.10.001.
- [93] Maxwell, R.M., Putti, M., Meyerhoff, S., Delfs, J.-O., Ferguson, I.M., Ivanov, V., Kim, J., Kolditz, O., Kollet, S.J., Kumar, M., Lopez, S., Niu, J., Paniconi, C., Park, Y.-J., Phanikumar, M.S., Shen, C., Sudicky, E. a. and Sulis, M. (2014). Surface-subsurface model intercomparison: A first set of benchmark results to diagnose integrated hydrology and feedbacks. *Water Resources Research* **50** 1531–1549, doi:10.1002/2013WR013725.
- [94] Maxwell, R.M., L. E. Condon, and S. J. Kollet (2015). A high-resolution simulation of groundwater and surface water over most of the continental us with the integrated hydrologic model parflow v3. *Geoscientific Model Development*, 8(3):923–937.
- [95] Maxwell, R.M., L. E. Condon, S. J. Kollet, K. Maher, R. Haggerty, and M. M. Forrester (2016). The imprint of climate and geology on the residence times of groundwater. *Geophysical Research Letters*, 43(2):701–708. 2015GL066916.
- [96] Maxwell, R. M., & Condon, L. E. (2016). Connections between groundwater flow and transpiration partitioning. *Science*, **353**(6297), 377–380. <https://doi.org/10.1126/science.aaf7891>.
- [97] Maxwell, R. M., Condon, L. E., Danesh-Yazdi, M., & Bearup, L. A. (2019). Exploring source water mixing and transient residence time distributions of outflow and evapotranspiration with an integrated hydrologic model and Lagrangian particle tracking approach. *Ecohydrology*, **12**(1), 1–10. <https://doi.org/10.1002/eco.2042>.
- [98] Meyerhoff, S.B. and Maxwell, R.M. (2011). Quantifying the effects of subsurface heterogeneity on hillslope runoff using a stochastic approach. *Hydrogeology Journal* **19** 1515–1530, doi:10.1007/s10040-011-0753-y.
- [99] Meyerhoff, S.B., Maxwell, R.M., Graham, W.D. and Williams, J.L. (2014). Improved hydrograph prediction through subsurface characterization: conditional stochastic hillslope simulations. *Hydrogeology Journal* doi:10.1007/s10040-014-1112-6.
- [100] Meyerhoff, S.B., Maxwell, R.M., Revil, A., Martin, J.B., Karaoulis, M. and Graham, W.D. (2014). Characterization of groundwater and surface water mixing in a semiconfined karst aquifer using time-lapse electrical resistivity tomography. *Water Resources Research* **50** 2566–2585, doi:10.1002/2013WR013991.
- [101] Mikkelsen, K.M., Maxwell, R.M., Ferguson, I., Stednick, J.D., McCray, J.E. and Sharp, J.O. (2013). Mountain pine beetle infestation impacts: modeling water and energy budgets at the hill-slope scale. *Ecohydrology* **6** doi:10.1002/eco.278.

- [102] Moqbel, S.; Abu-El-Shaar, W. (2018). Modeling Groundwater Flow and Solute Transport at Azraq Basin Using Parflow and Slim-Fast. *Jordan J. Civ. Eng.* **12** (2), 263–278.
- [103] Penn, C. A., Bearup, L. A., Maxwell, R. M., & Clow, D. W. (2016). Numerical experiments to explain multiscale hydrological responses to mountain pine beetle tree mortality in a headwater watershed. *Water Resources Research*, **52**, 3143–3161. doi:10.1002/2015WR018300.
- [104] Pribulick, C. E., Foster, L. M., Bearup, L. A., Navarre-Sitchler, A. K., Williams, K. H., Carroll, R. W. H., & Maxwell, R. M. (2016). Contrasting the hydrologic response due to land cover and climate change in a mountain headwaters system. *Ecohydrology*, **9**(8), 1431–1438. <https://doi.org/10.1002/eco.1779>.
- [105] Rahman, M., M. Sulis, and S.J. Kollet (2015). Evaluating the dual-boundary forcing concept in subsurface-land surface interactions of the hydrological cycle. *Hydrological Processes*.
- [106] Rahman, M. M. Sulis, and S.J. Kollet (2015). The subsurface-land surface-atmosphere connection under convective conditions. *Advances in Water Resour.*, (83):240–249.
- [107] Rahman, M., Sulis, M., & Kollet, S. J. (2016). Evaluating the dual-boundary forcing concept in subsurface-land surface interactions of the hydrological cycle. *Hydrological Processes*, **30**(10), 1563–1573. <https://doi.org/10.1002/hyp.10702>.
- [108] Rahman, M., Rosolem, R., Kollet, S. J., & Wagener, T. (2018). Towards a computationally efficient free-surface groundwater flow boundary condition for large-scale hydrological modelling. *Advances in Water Resources*, **123** (December 2018), 225–233. <https://doi.org/10.1016/j.advwatres.2018.11.015>.
- [109] Reyes, R., R.M. Maxwell, and T. S. Hogue (2015). Impact of lateral flow and spatial scaling on the simulation of semi-arid urban land surfaces in an integrated hydrologic and land surface model. *Hydrological Processes*.
- [110] Reyes, B., Hogue, T., & Maxwell, R. (2018). Urban irrigation suppresses land surface temperature and changes the hydrologic regime in semi-arid regions. *Water (Switzerland)*, **10**(11). <https://doi.org/10.3390/w10111563>.
- [111] Rihani, J., Maxwell, R.M., Chow, F.K. (2010). Coupling groundwater and land-surface processes: Idealized simulations to identify effects of terrain and subsurface heterogeneity on land surface energy fluxes. *Water Resources Research* 46, W12523, doi:10.1029/2010WR009111.
- [112] Rihani, J.F., F. K. Chow, and R. M. Maxwell (2015). Isolating effects of terrain and soil moisture heterogeneity on the atmospheric boundary layer: Idealized simulations to diagnose land-atmosphere feedbacks. *Journal of Advances in Modeling Earth Systems*, 7(2):915–937.
- [113] Schalge, B., Haefliger, V., Kollet, S., & Simmer, C. (2019). Improvement of surface run-off in the hydrological model ParFlow by a scale-consistent river parameterization. *Hydrological Processes*, (October 2017), 2006–2019. <https://doi.org/10.1002/hyp.13448>.
- [114] Seck, A. C. Welty, and R. M. Maxwell (2015). Spin-up behavior and effects of initial conditions for an integrated hydrologic model. *Water Resources Research*, 51(4):2188–2210.
- [115] Shrestha, P., Sulis, M., Masbou, M., Kollet, S. and Simmer, C. (2014). A scale-consistent Terrestrial Systems Modeling Platform based on COSMO, CLM and ParFlow. *Monthly Weather Review* doi:10.1175/MWR-D-14-00029.1.
- [116] Shrestha, P., M. Sulis, C. Simmer, and S. Kollet (2015). Impacts of grid resolution on surface energy fluxes simulated with an integrated surface-groundwater flow model. *Hydrol. Earth Syst. Sci.*, 19:4317–4326.
- [117] Shrestha, P., Sulis, M., Simmer, C., & Kollet, S. (2018). Effects of horizontal grid resolution on evapotranspiration partitioning using TerrSysMP. *Journal of Hydrology*, **557**, 910–915. <https://doi.org/10.1016/j.jhydrol.2018.01.024>.
- [118] Siirila, E.R., Navarre-Sitchler, A.K., Maxwell, R.M. and McCray, J.E. (2012). A quantitative methodology to assess the risks to human health from CO₂ leakage into groundwater. *Advances in Water Resources*, **36**, 146–164, doi:10.1016/j.advwatres.2010.11.005.
- [119] Siirila, E.R. and Maxwell, R.M. (2012). A new perspective on human health risk assessment: Development of a time dependent methodology and the effect of varying exposure durations. *Science of The Total Environment* **431** 221–232, doi:10.1016/j.scitotenv.2012.05.030.

- [120] Siirila, E.R. and Maxwell, R.M. (2012). Evaluating effective reaction rates of kinetically driven solutes in large-scale, statistically anisotropic media: Human health risk implications. *Water Resources Research* **48** 1-23, doi:10.1029/2011WR011516.
- [121] Siirila-Woodburn, E. R., Steefel, C. I., Williams, K. H., & Birkholzer, J. T. (2018). Predicting the impact of land management decisions on overland flow generation: Implications for cesium migration in forested Fukushima watersheds. *Advances in Water Resources*, **113** (January), 42–54. <https://doi.org/10.1016/j.advwatres.2018.01.008>.
- [122] Srivastava, V., W. Graham, R. Mušoz-Carpena, and R. M. Maxwell (2014). Insights on geologic and vegetative controls over hydrologic behavior of a large complex basin—global sensitivity analysis of an integrated parallel hydrologic model. *Journal of Hydrology*, 519, Part B:2238 – 2257.
- [123] Sulis, M., Meyerhoff, S., Paniconi, C., Maxwell, R.M., Putti, M. and Kollet, S.J. (2010). A comparison of two physics-based numerical models for simulating surface water-groundwater interactions. *Advances in Water Resources*, 33(4), 456-467, doi:10.1016/j.advwatres.2010.01.010.
- [124] Sulis, M., Williams, J. L., Shrestha, P., Diederich, M., Simmer, C., Kollet, S. J., & Maxwell, R. M. (2017). Coupling Groundwater, Vegetation, and Atmospheric Processes: A Comparison of Two Integrated Models. *Journal of Hydrometeorology*. <https://doi.org/10.1175/JHM-D-16-0159.1>.
- [125] Sulis, M., Keune, J., Shrestha, P., Simmer, C., & Kollet, S. J. (2018). Quantifying the Impact of Subsurface-Land Surface Physical Processes on the Predictive Skill of Subseasonal Mesoscale Atmospheric Simulations. *Journal of Geophysical Research: Atmospheres*, **123**(17), 9131–9151. <https://doi.org/10.1029/2017JD028187>.
- [126] Sweetenham, M. G., Maxwell, R. M., & Santi, P. M. (2017). Assessing the timing and magnitude of precipitation-induced seepage into tunnels bored through fractured rock. *Tunnelling and Underground Space Technology*, **65**, 62–75. <http://dx.doi.org/10.1016/j.tust.2017.02.003>.
- [127] Tompson, A.F.B., Ababou, R. and Gelhar, L.W. (1989). Implementation of the three-dimensional turning bands random field generator. *Water Resources Research*, **25**(10):2227–2243.
- [128] Tompson, A.F.B., Falgout, R.D., Smith, S.G., Bosl, W.J. and Ashby, S.F. (1998). Analysis of subsurface contaminant migration and remediation using high performance computing. *Advances in Water Resources*, **22**(3):203–221.
- [129] Tompson, A. F. B., Bruton, C. J. and Pawloski, G. A. eds. (1999b). *Evaluation of the hydrologic source term from underground nuclear tests in Frenchman Flat at the Nevada Test Site: The CAMBRIC test*, Lawrence Livermore National Laboratory, Livermore, CA (UCRL-ID-132300), 360pp.
- [130] Tompson, A.F.B., Carle, S.F., Rosenberg, N.D. and Maxwell, R.M. (1999). Analysis of groundwater migration from artificial recharge in a large urban aquifer: A simulation perspective, *Water Resources Research*, **35**(10):2981–2998.
- [131] Tompson AFB., Bruton, C.J., Pawloski, G.A., Smith, D.K., Bourcier, W.L., Shumaker, D.E., Kersting, A.B., Carle, S.F. and Maxwell, R.M. (2002). On the evaluation of groundwater contamination from underground nuclear tests. *Environmental Geology*, **42**(2-3):235–247.
- [132] Tompson, A. F. B., Maxwell, R. M., Carle, S. F., Zavarin, M., Pawloski, G. A. and Shumaker, D. E. (2005). *Evaluation of the Non-Transient Hydrologic Source Term from the CAMBRIC Underground Nuclear Test in Frenchman Flat, Nevada Test Site*, Lawrence Livermore National Laboratory, Livermore, CA, UCRL-TR-217191.
- [133] van Genuchten, M.Th.(1980). A closed form equation for predicting the hydraulic conductivity of unsaturated soils. *Soil Sci. Soc. Am. J.*, **44**:892–898.
- [134] Welch, B. (1995) *Practical Programming in TCL and TK*. Prentice Hall.
- [135] Woodward, C.S. (1998), A Newton-Krylov-Multigrid solver for variably saturated flow problems. In *Proceedings of the XIIth International Conference on Computational Methods in Water Resources*, June.
- [136] Woodward, C.S., Grant, K.E., and Maxwell, R.M. (2002). Applications of Sensitivity Analysis to Uncertainty Quantification for Variably Saturated Flow. In *Proceedings of the XIVth International Conference on Computational Methods in Water Resources*, Amsterdam, The Netherlands, June.

- [137] Williams, J.L. and Maxwell, R.M. (2011). Propagating Subsurface Uncertainty to the Atmosphere Using Fully Coupled Stochastic Simulations. *Journal of Hydrometeorology* **12** 690-701, doi:10.1175/2011JHM1363.1.
- [138] Williams, J.L., Maxwell, R.M. and Monache, L.D. (2013). Development and verification of a new wind speed forecasting system using an ensemble Kalman filter data assimilation technique in a fully coupled hydrologic and atmospheric model. *Journal of Advances in Modeling Earth Systems* **5** 785-800, doi:10.1002/jame.20051.
- [139] Zhang, H., Kurtz, W., Kollet, S., Vereecken, H., & Franssen, H. J. H. (2018). Comparison of different assimilation methodologies of groundwater levels to improve predictions of root zone soil moisture with an integrated terrestrial system model. *Advances in Water Resources*, **111**(May), 224–238. <https://doi.org/10.1016/j.advwatres.2017.11.003>.
- [140] Zipper, S. C., Keune, J., & Kollet, S. J. (2019). Land use change impacts on European heat and drought: Remote land-atmosphere feedbacks mitigated locally by shallow groundwater. *Environmental Research Letters*, **14**(4). <https://doi.org/10.1088/1748-9326/ab0db3>.
- [141] *Endianness*, Wikipedia Entry: <http://en.wikipedia.org/wiki/Endianness>