

# GSFLOW Input Instructions: A Supplement to Appendix 1 of the GSFLOW manual (USGS TM 6-D1)

Version 2.2.0 GSFLOW release, February 18, 2021

## Introduction

Instructions for preparing input files for GSFLOW were provided with the first release of GSFLOW as Appendix 1 in Markstrom and others (2008). Since that time, new functionality has been added to the software; some of the original functionality has been removed; and individual parameters and variables have been added, modified, and deleted. As a result, it has been necessary to update the original input instructions with each new release of GSFLOW. Input instructions for preparing a GSFLOW input dataset are now provided in three formats: This file provides updated information for a few of the tables in Appendix 1 that relate directly to the GSFLOW software. This file is a supplement to Appendix 1 in Markstrom and others (2008; TM 6-D1), which provides a general discussion of the terminology, styles, and formats of GSFLOW inputs and the definitions of each of the GSFLOW input files. This file also replaces the ‘Appendix1\_Tables.pdf’ file that was distributed with previous versions of the software.

Input instructions for the several PRMS modules and MODFLOW packages that are part of the GSFLOW software can be found in separate resources:

### **PRMS Data and Parameter Files:**

PRMS is documented in:

Markstrom, S.L., Regan, R.S., Hay, L.E., Viger, R.J., Webb, R.M.T., Payn, R.A., and LaFontaine, J.H., 2015, PRMS-IV, the Precipitation-Runoff Modeling System, version 4: U.S. Geological Survey Techniques and Methods book 6, chap. B7, 158 p.

See the file ‘tm6b8\_PRMS\_enhancements.pdf (Regan and LaFontaine, 2017) in the ‘doc\Related reports’ subdirectory for documentation on the dynamic parameters, water-use, lake simulation, and summary output options.

Up-to-date specifications for PRMS dimensions, parameters, and input and output variables are provided in several tables in file PRMS\_tables\_5.2.0.pdf in the ‘doc\Related reports’ subdirectory of the GSFLOW distribution.

**MODFLOW Input Files:** Up-to-date descriptions of the input requirements for all MODFLOW-2005 and MODFLOW-NWT Packages and Processes are provided in the *Online Guide to MODFLOW-2005* (<http://water.usgs.gov/ogw/modflow/MODFLOW-2005-Guide/>, accessed September 25, 2020) and *Online Guide to MODFLOW-NWT* (<http://water.usgs.gov/ogw/modflow-nwt/MODFLOW-NWT-Guide/>, accessed September 25, 2020). These guides supersede information given on pages 176-226 in TM 6-D1.

## Information Related to GSFLOW Input Tables

**Tables 1 and 2: Descriptions of PRMS and GSFLOW modules and MODFLOW packages supported in GSFLOW version 2.2.0**

Brief descriptions of the modules and packages that are supported in GSFLOW version 2.2.0 are given in table 1. This release includes all PRMS version 5.2.0 and MODFLOW-NWT version 1.2 Packages, thus table 2 is no longer needed.

### **Table A1-1: Parameters specified in the GSFLOW Control File**

This table supersedes table A1-1 on pages 135-136 of the GSFLOW manual (TM 6-D1) and Table 1-2 in TM6-B7. The GSFLOW Control File is described in detail on pages 134-139 of TM 6-D1. Additional notes follow:

1. Previous versions of GSFLOW required that a PRMS Parameter File be specified in the Control File for a MODFLOW-only simulation. The code has been updated, and the user no longer needs to specify a PRMS Parameter File for a MODFLOW-only simulation. Thus, for a MODFLOW-only simulation, the Control File could be as short as the following example for the Sagehen Creek GSFLOW model distributed with the software:

```
Control File for a MODFLOW-only simulation, Sagehen Creek Watershed
####
model_mode
1
4
MODFLOW
####
modflow_name
1
4
../input/modflow/sagehen.mf.nam
```

Note, however, that for restart simulations, the user also will need to specify control parameters **modflow\_time\_zero**, **init\_vars\_from\_file**, **save\_vars\_to\_file**, **start\_time**, and **end\_time**.

2. If a default value as given in Table A1-1 for any input parameter is acceptable, the user does not need to enter a parameter block.

3. Up-to-date specifications for PRMS Control File parameters is provided in table 1-2 in file PRMS\_tables\_5.2.0.pdf in the ‘doc\Related reports’ subdirectory of the GSFLOW distribution.

### **Table A1-3: Time-series data that can be specified in the PRMS Data File (supersedes table A1-3 in TM 6-D1, page 141)**

1. Up-to-date specifications for PRMS Data File is provided in table 1-4 in file PRMS\_tables\_5.2.0.pdf in the ‘doc\Related reports’ subdirectory of the GSFLOW distribution.

2. Though all types of time-series data are optional, the Data File must have at least one column of input values (“data”) in addition to the 6 values that specify the date and time for the time series.

### **Table A1-4: Dimensions defined in PRMS Parameter Files (supersedes table A1-4 in TM 6-D1, page 145 and table 1-1 in TM 6-B7)**

1. Dimensions defined in this table only are needed for the GSFLOW and PRMS-only simulation modes. Parameter Files are not needed for MODFLOW-only simulations.

**Tables A1-5 and A1-6 through A1-22: Parameters in the PRMS Parameter File and input parameters for each of the PRMS modules (pages 147-172 in TM 6-D1)**

1. These tables have been superseded and are provided in table 1-3 in file PRMS\_tables\_5.2.0.pdf in the 'doc\Related reports' subdirectory of the GSFLOW distribution. Parameters are listed by module or process usage within the PRMS. Note that not all of the parameters listed in this table are used in the GSFLOW simulation mode.

**Table A1-23: Parameters specified for GSFLOW modules (supersedes tables 3 and 4, page 27, and tables A1-23 through A1-27, pages 173-175 in TM 6-D1)**

1. This table replaces the seven tables previously used to define input parameters for each of the GSFLOW modules. In keeping with the new structure of the table used to define PRMS input parameters, the parameters for all of the GSFLOW modules are now combined into a single table.

**Table 1-5: Selected GSFLOW output variables for which values can be written to the PRMS Statistic Variables File and PRMS Animation Variables File(s) (supersedes Table A1-2, p. 138-139 in TM 6-D1).**

1. The variables shown in this table relate to GSFLOW simulation mode only; additional variables can be written depending on values in the Data File and active modules. Tables 1-4 and 1-5 in file PRMS\_tables\_5.2.0.pdf in the 'doc\Related reports' subdirectory of the GSFLOW distribution describe variables that can be specified in the Data File and that are available for output from the PRMS.

**Table 1-6: GSFLOW output variables written to the GSFLOW Comma-Separated Values File (supersedes Table 12, p. 88-89 in TM 6-D1).**

1. The variables shown in this table have been substantially revised from previous versions of the software.

**Table 1.** Description of PRMS and GSFLOW modules and MODFLOW packages implemented in GSFLOW version 2.2.0. **[Module or package name:** Users select only one of the modules or packages in each group indicated by a number from 1 to 8. **Fortran or C programming language file:** C programming language file designated with a “.c” at end of file name. **Version:** Shows the GSFLOW release version number when the module or package was first added to GSFLOW. **Model mode:** G is GSFLOW coupled simulation, P is PRMS-only simulation, M is MODFLOW-only simulation; HRU: hydrologic response unit]

Process	Fortran or C programming language file	Description	Version	Model mode
<b>PRMS Modules</b>				
Basin Definition	basin	Defines shared watershed-wide and hydrologic response unit (HRU) physical parameters and variables	1.0.00	G,P
Cascading Flow	cascade	Determines computational order of the HRUs and groundwater reservoirs for routing flow downslope	1.0.00	G,P
Climate and Flow Parameter and Variable Definition	climateflow	Defines shared watershed-wide and hydrologic response unit (HRU) climate and flow parameters and variables	1.1.5	G,P
Potential Solar Radiation	soltab	Computes potential solar radiation and sunlight hours for each HRU for each day of year	1.0.00	G,P
Daily Time Step Definition	prms_time	Computes time related variables within the daily time step	1.2.0	G,P
Observed Data	obs	Reads and stores observed data from all specified measurement stations	1.0.00	G,P
Dynamic Parameter Input	dynamic_param_read	Provides the capability of varying several parameters that define landscape, soil, and climate characteristics for each Hydrologic Response Unit on any simulation time step by reading parameter values for each HRU from pre-processed files	2.0.0	G,P
Water Use Input	water_use_read	Provides the capability to specify the connectivity and flow rates of water transfers from water-supply sources to destination storage locations as a time series of values by reading water-use data values from pre-processed files	2.0.0	G,P
Temperature Distribution (1)	temp_1sta	Distributes maximum and minimum temperatures to each HRU by using temperature data measured at one station and specified monthly lapse rates (note, each HRU uses data from a single station, but, multiple stations can be used in a model with each HRU assigned data from one of those stations)	1.0.00	G,P
	temp_laps	Distributes maximum and minimum temperatures to each HRU by computing a daily lapse rate with temperature data measured at a base station and a lapse station with differing altitudes	1.0.00	G,P
	xyz_dist	Determines the form of precipitation and distributes precipitation and temperatures to each HRU by using a multiple linear regression of measured data from a group of measurement stations or from atmospheric model simulation; selection requires this module also be selected for precipitation	1.0.00	G,P
	temp_dist2	Distributes maximum and minimum temperatures to each HRU by using a basin-wide lapse rate applied to the temperature data, adjusted for	1.0.00	G,P

		distance, measured at each station		
	climate_hru	Reads distributed minimum and maximum air temperature values for each HRU directly from pre-processed files	1.1.5	G,P
	ide_dist	Determines the form of precipitation and distributes precipitation and temperatures to each HRU on the basis of measurements at stations with closest elevation or shortest distance to the respective HRU; selection requires this module also be selected for precipitation	1.2.0	G,P
	temp_sta	Distributes maximum and minimum temperatures to each HRU by using temperature data measured at one station, similar to temp_1sta except there is no lapse rate (note, each HRU uses data from a single station, but, multiple stations can be used in a model with each HRU assigned data from one of those stations)	2.0.0	G,P
	temp_map	Distributes maximum and minimum temperatures to each HRU by using daily time-series maximum and minimum temperature data as input from files, such as gridded data, on the basis of mapping and adjustment parameters.	2.2	G,P
Precipitation Distribution (2)	precip_1sta	Determines the form of precipitation and distributes it to each HRU by using monthly correction factors to account for differences in altitude, spatial variation, topography, and measurement gage efficiency and observed data from one station (note, each HRU uses data from a single station, but, multiple stations can be used in a model with each HRU assigned data from one of those stations)	1.0.00	G,P
	precip_laps	Determines the form of precipitation and distributes it to each HRU by using monthly lapse rates	1.0.00	G,P
	xyz_dist	Distributes precipitation and maximum and minimum temperatures to each HRU using a multiple linear regression of measured data from a group of measurement stations or from atmospheric model results; selection requires this module also be selected for temperature	1.0.00	G,P
	precip_dist2	Determines the form of precipitation and distributes it to each HRU by using an inverse distance weighting scheme	1.0.00	G,P
	climate_hru	Reads distributed precipitation values for each HRU directly from pre-processed files	1.1.5	G,P
	ide_dist	Determines the form of precipitation and distributes precipitation and temperatures to each HRU on the basis of measurements at stations with closest elevation or shortest distance to the respective HRU; selection requires this module also be selected for temperature	1.2.0	G,P
	precip_map	Determines the form of precipitation and distributes precipitation to each HRU by using daily time-series data as input from a file, such as gridded data, on the basis of mapping and adjustment parameters.	2.2	G,P
Solar Radiation (3)	ddsolrad	Distributes solar radiation to each HRU and estimates missing solar radiation data using a maximum temperature per degree-day relation	1.0.00	G,P

	ccsolrad	Distributes solar radiation to each HRU and estimates missing solar radiation data using a relation between solar radiation and cloud cover	1.0.00	G,P
	climate_hru	Reads distributed solar radiation values for each HRU directly from pre-processed files	1.1.5	G,P
Potential Evapotranspiration (4)	potet_jh	Computes the potential evapotranspiration by using the Jensen-Haise formulation (Jensen and Haise, 1963)	1.0.00	G,P
	potet_hamon	Computes the potential evapotranspiration by using the Hamon formulation (Hamon, 1961)	1.0.00	G,P
	potet_pan	Computes the potential evapotranspiration for each HRU by using pan-evaporation data	1.0.00	G,P
	potet_hs	Computes the potential evapotranspiration by using the Hargreaves-Samani formulation (Hargreaves and Samani, 1982)	1.2.0	G,P
	potet_pm	Computes the potential evapotranspiration by using the Penman-Monteith formulation (Penman, 1948; Monteith, 1965) using specified windspeed and humidity in CBH files	1.2.0	G,P
	potet_pm_sta	Computes the potential evapotranspiration by using the Penman-Monteith formulation (Penman, 1948; Monteith, 1965) using specified windspeed and humidity in the PRMS Data File	1.2.1	G,P
	potet_pt	Computes the potential evapotranspiration by using the Priestley-Taylor formulation (Priestley and Taylor, 1972)	1.2.0	G,P
	climate_hru	Reads distributed potential evapotranspiration values for each HRU directly from pre-processed files	1.1.5	G,P
Transpiration Period (8)	transp_frost	Determines whether the current time step is in a period of active transpiration by the killing frost method	1.2.0	G,P
	transp_tindex	Determines whether the current time step is in a period of active transpiration by the temperature index method	1.0.00	G,P
	climate_hru	Reads distributed transpiration values for each HRU directly from pre-processed files	1.1.5	G,P
Interception	intcp	Computes volume of intercepted precipitation, evaporation from intercepted precipitation, and throughfall that reaches the soil or snowpack	1.0.00	G,P
Snow Dynamics	snowcomp	Initiates development of a snowpack and simulates snow accumulation and depletion processes by using an energy-budget approach	1.0.00	G,P
Glacier Dynamics	glacr_melt	Simulates glacier dynamics of growth, retreat, and melt on the basis of three water-holding reservoirs (firn, snow, and ice) as driven by precipitation, maximum and minimum air temperature, and solar radiation.	2.2	G,P
Surface Runoff (5)	srunoff_smidx	Computes surface runoff and infiltration for each HRU by using a nonlinear variable-source-area method allowing for cascading flow	1.0.00	G,P
	srunoff_carea	Computes surface runoff and infiltration for each HRU by using a linear variable-source-area method allowing for cascading flow	1.0.00	G,P
Soil Zone	soilzone	Computes inflows to and outflows from soil zone of	1.0.00	G,P

		each HRU and includes inflows from infiltration, groundwater, and upslope HRUs, and outflows to gravity drainage, interflow, and surface runoff to down-slope HRUs		
Groundwater	gwflow	Sums inflow to and outflow from PRMS groundwater reservoirs; outflow can be routed to downslope groundwater reservoirs and stream segments	1.0.00	P
Streamflow	strmflow	Computes daily streamflow as the sum of surface runoff, shallow-subsurface flow (interflow), detention reservoir flow, and groundwater flow	1.0.00	P
	routing	Computes common segment routing flows for modules <code>strmflow_in_out</code> and <code>muskingum</code>	1.2.0	P
	strmflow_in_out	Routes water between segments in the stream network by setting the outflow to the inflow	1.2.0	P
	muskingum	Computes flow in the stream network using the Muskingum routing method (Linsley and others, 1982)	1.2.0	P
	muskingum_lake	Computes flow in the stream network using the Muskingum routing method and flow and storage in on-channel lake using several methods	2.0.0	P
	muskingum_mann	Computes flow in the stream network using the Muskingum routing method with routing coefficients based on Manning's N equation	2.1.0	P
Stream Temperature	stream_temp	Computes daily mean stream temperature for each stream segment in the stream network, module based on the Stream Network Temperature Model (SNTMP, Theurer and others, 1984)	2.1.0	P
Summary	basin_sum	Sums values for daily, monthly, yearly, and total flow summaries of volumes and flows for all HRUs	1.0.00	P
	map_results	Writes HRU summaries to a user specified target map at weekly, monthly, yearly, and total time steps (initially named <code>grid_report</code> )	1.1.3	G,P
	subbasin	Computes streamflow at internal basin nodes and variables by subbasin	1.1.00	G,P
	nhru_summary	Writes user-selected results dimensioned by the value of dimension <b>nhru</b> as daily, monthly, mean-monthly, mean yearly, and yearly total time-series as Comma-Separated-Values (CSV) files	1.2.0	G,P
	nsegment_summary	Writes user-selected results dimensioned by the value of dimension <b>nsegment</b> as daily, monthly, mean-monthly, mean yearly, and yearly total time-series as Comma-Separated-Values (CSV) files	1.2.2	G,P
	nsub_summary	Writes selected user-selected results dimensioned by the value of dimension <b>nsub</b> or <b>nhru</b> as daily, monthly, mean-monthly, mean yearly, and yearly total time-series as Comma-Separated-Values (CSV) files	1.2.2	G,P
	basin_summary	Writes user-selected results dimensioned by the value of dimension <b>one</b> as daily, monthly, mean-monthly, mean yearly, and yearly total time-series as Comma-Separated-Values (CSV) files	1.2.2	G,P
	water_balance	Computes daily HRU and basin-wide water balances for selected hydrologic processes when control parameter <b>print_debug</b> is specified equal to 1	1.2.0	P

	write_climate_hru	Writes climate-by-HRU Files of user-selected climate variables on the basis of distributed climate; land, subsurface, and stream processes are not computed	1.1.6	G,P
	frost_date	Writes a parameter file of the last spring frost and first fall frost for each HRU based on the simulation time period and distributed temperature as required by the transp_frost module; land, subsurface, and stream processes are not computed	1.2.0	P
	convert_params	Writes values for new PRMS-V parameters to a file based on a PRMS-IV Parameter File when control parameter <b>model_mode</b> is specified equal to CONVERT. Writes values for old PRMS-IV parameters to a file based on a PRMS-V Parameter File when control parameter <b>model_mode</b> is specified equal to CONVERT4	2.0.0	P
	prms_summary	Computes select basin-wide variables to a Comma-Separated Values (CSV) file	2.0.0	P
<b>MODFLOW Packages</b>				
Basic	gwf2bas7_NWT	BAS: Handles a number of basic administrative tasks; modification of gwf2bas7	1.0.00	G,M
Block Centered Flow (6)	gwf2bcf7	BCF: Calculates conductance coefficients for groundwater-flow equations using a block-centered flow package	1.0.00	G,M
Layer Property Flow (6)	gwf2lpf7	LPF: Calculates conductance coefficients for groundwater-flow equations using a layer-property flow package	1.0.00	G,M
Hydrogeologic-Unit Flow (6)	gwf2huf7	HUF: Calculates effective hydraulic properties for model layers using hydrostratigraphic units	1.0.00	G,M
Upstream-Weighting Package (6)	gwf2upw1	UPW: Calculates conductance coefficients for groundwater-flow equations using an upstream-weighting package. The package is used with the NWT solver	1.1.5	G,M
Recharge	gwf2rch7	RCH: Adds terms to groundwater flow equation to represent areal recharge to groundwater system	2.0.0	M
Evapotranspiration	gwf2evt7	EVT: Adds terms to groundwater flow equation to represent head-dependent evapotranspiration from groundwater system	2.0.0	M
Segmented Evapotranspiration	gwf2ets7	ETS: Adds terms to groundwater flow equation to represent segmented head-dependent evapotranspiration from groundwater system	2.0.0	M
Interbed Storage	gwf2ibs7	IBS: Adds terms to groundwater flow equation to represent inelastic compaction of fine-grained sediments	2.0.0	M
Subsidence	gwf2sub7_NWT	SUB: Simulates aquifer-system compaction and land subsidence	2.0.0	M
Tile Drain	gwf2drt7	DRT: Adds terms to groundwater flow equation to represent groundwater discharge to drains while accounting for irrigation return flows	2.0.0	M
River	gwf2riv7_NWT	RIV: Adds terms to groundwater flow equation to represent rivers to represent head-dependent flow between a surface water body and a groundwater system	2.0.0	M
Drain	gwf2drn7_NWT	DRN: Adds terms to groundwater flow equation to	2.0.0	M



		represent groundwater discharge to drains		
Reservoir	gwf2res7	RES: Adds terms to groundwater flow equation to represent leakage from reservoirs	2.0.0	M
Stream	gwf2str7	STR: Adds terms to flow equation to represent groundwater and stream interactions; predecessor to SFR2 Package	2.0.0	M
Surface-Water Routing	gwf2swr7_NWT	SWR: Surface-water routing process is designed to simulated surface-water routing in one- and two-dimensional surface-water features and surface-water/groundwater interactions	2.0.0	M
Hydrograph capability	gwf2hydmod7.f	HYDMOD: Records time-series data for selected data types	2.0.0	M
Horizontal Flow Barrier	gwf2hfb7_NWT	HFB: Simulates flow barriers by reducing horizontal conductance	1.0.00	G,M
Well	gwf2wel7_NWT	WEL: Adds terms to flow equation to represent wells	1.0.00	G,M
Multi-Node Well	gwf2mnw17_NWT	MNW, version 1: Adds terms to flow equation for wells that extract or inject water in more than one cell	1.0.00	G,M
	gwf2mnw27_NWT	MNW, version 2: Adds terms to flow equation for wells that extract or inject water in more than one cell	1.1.1	G,M
General Head Boundary	gwf2ghb7_NWT	GHB: Adds terms to flow equation to represent general head-dependent boundaries	1.0.00	G,M
Constant Head Boundary	gwf2chd7	CHD: Adds terms to flow equation to represent constant-head boundaries	1.0.00	G,M
Flow and Head Boundary	gwf2fhb7	FHB: Adds terms to flow equation to represent flow and head boundaries	1.0.00	G,M
Sea Water Intrusion	gwf2swi27	SWI: Allows three-dimensional vertically integrated variable-density groundwater flow and seawater intrusion in coastal multiaquifer systems to be simulated	1.2.2	M
Subsidence and Aquifer-System Compaction for Water-Table Aquifers	gwf2swt7	SWT: Simulates vertical compaction in models of regional groundwater flow. The program simulates groundwater storage changes and compaction in discontinuous interbeds or in extensive confining units, accounting for stress-dependent changes in storage properties.	1.2.2	M
Streamflow Routing	gwf2sfr7_NWT	SFR: Adds terms to flow equation to represent groundwater and stream interactions; modification of gwf2sfr1	1.0.00	G,M
Lake	gwf2lak7	LAK: Adds terms to flow equation to represent groundwater and lake interactions; modification of gwf2lak3	1.0.00	G,M
Unsaturated Zone Flow	gwf2uzf1_NWT	UZF: Adds terms to flow equation to represent recharge from the unsaturated zone, evapotranspiration, and groundwater discharge to land surface	1.0.00	G,M
Gage	gwf2gag7	GAG: Prints time series gage output for selected stream reaches and lakes; modification of gwf2gag5	1.0.00	G,M
Agriculture	gwf2ag1_NWT	AG: apply agricultural demands to fields from stream segments and wells	2.1.0	G,M
Link to the MT3DMS	lmt8_NWT	LMT: Records flow information from MODFLOW for use by MT3DMS or MT3D-USGS	1.2.2	M

contaminant-transport model				
Observation	obs2bas7, obs2chd7, obs2ghb7	OBS: Compares model-generated values of heads and flows to observed values for the BAS, CHD, and GHB Packages	1.0.00	G,M
	obs2drn7, obs2riv7, obs2str7	OBS: Compares model-generated values of heads and flows to observed values for the DRN, RIV, and STR Packages	2.0.0	M
Solver (7)	sip7_NWT	SIP: Solves simultaneous equations resulting from finite-difference approximations using the strongly implicit procedure	1.0.00	G,M
	pcg7_NWT	PCG: Solves simultaneous equations resulting from finite-difference approximations using a preconditioned conjugate-gradient procedure	1.0.00	G,M
	de47_NWT	DE4: Solves simultaneous equations resulting from finite-difference approximations using a direct solution procedure	1.0.00	G,M
	NWT1 (various files)	NWT: Solves simultaneous equations resulting from finite-difference approximations using a Newton formulation	1.1.5	G,M
<b>GSFLOW modules</b>				
Computation Order	gsflow_prms	Controls model mode, the GSFLOW and PRMS daily time-step loop, and computational sequence order of GSFLOW and PRMS modules—PRMS equivalent file call_modules.f90	1.0.00	G,P,M
	gsflow_modflow	Controls sequence order for reading MODFLOW time-dependent input data and controls the computational sequence of calculations in the time-step and iteration loops for MODFLOW packages and defines variables used for converting between PRMS and MODFLOW units—MODFLOW equivalent to MF_NWT.f	1.0.00	G,M
Integration	gsflow_prms2mf	Distributes the PRMS soilzone module computed gravity drainage and unsatisfied potential evaporation from HRUs to MODFLOW cells for input to the UZF Package; computes PRMS surface-runoff and soilzone Hortonian and Dunnian surface runoff and interflow from HRUs to stream segments and lakes, and precipitation and evaporation to lakes for input to the SFR and LAK Packages at the end of each time step	1.0.00	G
	gsflow_mf2prms	Distributes computed groundwater discharge from MODFLOW cells to HRUs for input to the PRMS soilzone module at the end of each time step	1.0.00	G
Summary	gsflow_budget	Computes watershed budget for GSFLOW and adjusts PRMS gravity reservoir storage using the flows to and from MODFLOW cells after the MODFLOW budget procedure and writes to the GSFLOW output file at the end of each timestep	1.0.00	G
	gsflow_sum	Computes detailed watershed water budgets for flow and storage components and writes these to the GSFLOW CSV file at the end of each timestep	1.0.00	G

**Table A1-1.** Parameters specified in the GSFLOW Control File.

[Pathnames for all files can have a maximum of 256 characters, variable names a maximum of 32 characters; Data Type: 1=integer, 2=single precision floating point (real), 3=double precision floating point (double); 4=character string; HRU, hydrologic response unit; GWR, groundwater reservoir; CBH, climate-by-HRU; ET, evapotranspiration; PET, potential evapotranspiration;; >, greater than; dimensions **ncascade**, **ncascdgw**, and **nsub** defined in table A1-4 of this document; the first two blocks of control parameters listed in the table are recommended for every simulation, although all parameters are optional depending on the appropriateness of the default values]

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>Simulation execution and input and output files</b>					
<b>csv_output_file</b>	Pathname of GSFLOW or PRMS Comma-Separated-Values (CSV) output file for selected GSFLOW basin-area weighted flows and storages for each time step	<b>model_mode</b> = GSFLOW or GSFLOW5 with <b>gsf_rpt</b> = 1 or <b>model_mode</b> = PRMS or PRMS5 with <b>csvON_OFF</b> = 1	1	4	prms_summary.csv
<b>csvON_OFF</b>	Switch to specify whether or not the PRMS Comma-Separated-Values (CSV) output file is generated (0=no; 1=yes; 2=only output pairs of simulated and measured flows)	<b>model_mode</b> = PRMS or PRMS5	1	1	1
<b>data_file</b>	Pathname(s) for measured input Data File(s), typically a single Data File is specified	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5	number of Data Files	4	prms.data
<b>end_time</b>	Simulation end date and time as: year, month, day, hour, minute, second	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5	6	1	2001, 9, 30, 0, 0, 0
<b>gsflow_output_file</b> <sup>2</sup>	Pathname for GSFLOW Water-Budget File for writing summaries of each component of the GSFLOW water budget	<b>model_mode</b> = GSFLOW or GSFLOW5	1	4	gsflow.out
<b>gsf_rpt</b> <sup>2</sup>	Switch to specify whether or not the GSFLOW Comma-Separated-Values (CSV) output file is generated (0=no; 1=yes)	<b>model_mode</b> = GSFLOW or GSFLOW5	1	1	1
<b>model_mode</b>	Flag to indicate the simulation mode (GSFLOW=GSFLOW coupled model, version IV parameters; GSFLOW5=GSFLOW coupled model, version V parameters; GSFLOW=GSFLOW coupled model, version IV parameters; GSFLOW=GSFLOW coupled model, version IV parameters; PRMS=PRMS-only, version IV parameters; PRMS5=PRMS-only, version V parameters; MODFLOW=MODFLOW-only; FROST=growing season for each HRU; WRITE_CLIMATE=write CBH files of minimum and maximum air temperature (variables <i>tminf</i> and <i>tmaxf</i> -Fahrenheit), precipitation (variable <i>hru_ppt</i> -inches), solar radiation (variable <i>swrad</i> -Langleys), potential ET (variable <i>potet</i> -inches), and/or transpiration flag (variable <i>transp_on</i> -dimensionless) ); POTET=simulate to potential ET; TRANSPIRE=simulate to determine transpiration period; DOCUMENTATION=write files of all declared parameters and variables in the executable)	required	1	4	GSFLOW

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>model_output_file</b>	Pathname for Water-Budget File for results module <b>basin_sum</b>	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5	1	4	<b>prms.out</b>
<b>modflow_name</b> <sup>2</sup>	Path and file name for MODFLOW Name File	<b>model_mode</b> = GSFLOW, GSFLOW5, or MODFLOW	1	4	<b>modflow.nam</b>
<b>modflow_time_zero</b> <sup>2</sup>	Date and time for the first MODFLOW stress period as: year, month, day, hour, minute, second; stress periods are skipped to model <b>start_time</b> if later than <b>modflow_time_zero</b>	<b>model_mode</b> = GSFLOW, GSFLOW5, or MODFLOW and <b>init_vars_from_file</b> = 1 or <b>save_vars_to_file</b> = 1	6	1	<b>start_time</b>
<b>param_file</b>	Pathname(s) for PRMS Parameter File(s)	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5	number of Parameter Files	4	<b>prms.params</b>
<b>prms_warmup</b>	Number of years to simulate before writing mapped results, Basin, <b>nhru</b> , <b>nsub</b> , or <b>nsegment</b> Summary Output Files	<b>map_resultsON_OFF</b> = 1, <b>basinOutON_OFF</b> = 1, <b>nsubOutON_OFF</b> = 1, <b>nsegmentOutON_OFF</b> = 1 or 2, or <b>nhruOutON_OFF</b> = 1 or 2	1	1	1
<b>rpt_days</b> <sup>2</sup>	Frequency with which summary tables are written to the GSFLOW Water-Budget File (0=none; >0=frequency in days, e.g., 1=daily, 7=every 7 <sup>th</sup> day)	<b>model_mode</b> = GSFLOW or GSFLOW5	1	1	7
<b>start_time</b>	Simulation start date and time specified in the control item as: year, month, day, hour, minute, second	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5	6	1	2000, 10, 1, 0, 0, 0
<b>Module selection and simulation options (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>cascade_flag</b>	Flag to indicate if HRU cascades are computed (0=no; 1=yes; 2=simple cascades defined by <b>hru_segment</b> )	<b>ncascade</b> > 0	1	1	1
<b>cascadegw_flag</b>	Flag to indicate if GWR cascades are computed (0=no; 1 or 2=yes). If <b>cascadegw_flag</b> = 2, the GWR cascades are set equal to the HRU cascades, so <b>gw_up_id</b> , <b>gw_strmseg_down_id</b> , <b>gw_down_id</b> , and <b>gw_pct_up</b> do not need to be specified, which decreases the size of the parameter files	<b>ncascdgw</b> > 0	1	1	1
<b>dprst_flag</b>	Flag to indicate if depression-storage simulation is computed (0=no; 1=yes)	optional	1	1	0
<b>et_module</b>	Module name for potential-evapotranspiration method ( <b>climate_hru</b> , <b>potet_jh</b> , <b>potet_hamon</b> , <b>potet_hs</b> , <b>potet_pt</b> , <b>potet_pm</b> , <b>potet_pm_sta</b> , or <b>potet_pan</b> )	required	1	4	<b>potet_jh</b>
<b>frozen_flag</b>	Flag to indicate if continuous frozen ground index simulation is computed (0=no; 1=yes)	frozen ground	1	1	0
<b>glacier_flag</b>	Flag to indicate if glacier simulation is computed (0=no;	glacier	1	1	0

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>gwr_swale_flag</b>	1=yes) Flag to indicate if GWR swales are allowed (0=no; 1=groundwater flow goes to groundwater sink; 3=groundwater flow goes to stream segment specified using parameter <b>hru_segment</b> )	optional	1	1	0
<b>mbInit_flag</b>	Flag to indicate initial mass balance of glaciers (0=no optimization; 1=use first year of climate data; 2=constant mass balance gradient above and below equilibrium line altitude (ELA))	<b>glacier_flag</b> = 1	1	1	0
<b>precip_module</b>	Module name for precipitation-distribution method (climate_hru, ide_dist, precip_1sta, precip_dist2, precip_laps, precip_map, or xyz_dist)	required	1	4	precip_1sta
<b>PRMS_iteration_flag</b>	Flag to indicate if interception, snow dynamics, surface runoff, and depression storage computations, in addition to soilzone processes, in the MODFLOW iteration loop of an integrated GSFLOW simulation (0=no, only soilzone computations in the MODFLOW iteration loop)	optional	1	1	0
<b>snarea_curve_flag</b>	Flag to specify whether to specify or compute snow depletion curves. (0=specify snow depletion curves with parameter <b>hru_deplcrv</b> and <b>snarea_curve</b> ; 1=compute using parameters <b>snarea_a</b> , <b>snarea_b</b> , <b>snarea_c</b> , and <b>snarea_d</b> )	required	1	1	0
<b>soilzone_aet_flag</b>	Flag to specify soil-water evapotranspiration (ET) compute method. Either it's based on unsatisfied potential ET (PET) and for GSFLOW or GSFLOW5 modes, replenishes the upper zone of capillary reservoir using the fraction of the upper zone of the capillary reservoir (as was done in previous versions) or it's based on PET when specified equal to 1 and replenishes by first filling the lower zone and then the upper zone to their maximum water-holding capacities (0=compute soil-water ET based on unsatisfied ET and old upper zone replenishment method; 1=based on PET and new replenishment method); set to 0 for downward compatibility of old models, though it is recommended setting to 1 for new models	required	1	1	0
<b>solrad_module</b>	Module name for solar-radiation-distribution method (ccsolrad or ddsolrad)	required	1	4	ddsolrad
<b>srunoff_module</b>	Module name for surface-runoff/infiltration computation method (srunoff_carea or srunoff_smidx)	required	1	4	srunoff_smidx
<b>stream_temp_flag</b>	Flag to specify whether to simulate stream temperature; <b>strmflow_module</b> must be set to muskingum, muskingum_mann, strmflow_in_out, or muskingum_lake	<b>model_mode</b> = PRMS or PRMS5 stream temperature	1	1	0
<b>stream_temp_shade_flag</b>	Flag to indicate how shade is used in the stream_temp module (0 = compute shade; 1 = specified constant)	stream temperature	1	1	0

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>strmflow_module</b>	Module name for streamflow routing simulation method (strmflow, muskingum, muskingum_mann, or strmflow_in_out, muskingum_lake)	<b>model_mode</b> = PRMS or PRMS5	1	4	strmflow
<b>strmtemp_humidity_flag</b>	Flag to specify where humidity information is read for use by the stream_temp module (0=CBH File specified by control parameter <b>humidity_day</b> ; 1=parameter <b>seg_humidity</b> ; 2=Data File with values assigned based on parameter <b>seg_humidity_sta</b> ), <b>strmflow_module</b> must be set to muskingum, muskingum_mann, strmflow_in_out, or muskingum_lake	<b>model_mode</b> = PRMS or PRMS5 stream temperature	1	1	0
<b>subbasin_flag</b>	Flag to indicate if internal subbasins are computed (0=no; 1=yes)	<b>nsub</b> > 0	1	1	1
<b>temp_module</b>	Module name for temperature-distribution method (climate_hru, temp_1sta, temp_dist2, temp_laps, temp_sta, temp_map, ide_dist, or xyz_dist)	required	1	4	temp_1sta
<b>transp_module</b>	Module name for transpiration simulation method (climate_hru, transp_frost, or transp_tindex)	required	1	4	transp_tindex
Dynamic Parameter Input ( <b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5)					
<b>covden_sum_dynamic</b>	Pathname of the time series of pre-processed values for summer plant-cover density used to set values of <b>covden_sum</b> for each HRU	<b>dyn_covden_flag</b> = 1 or 3	1	4	dyncovsum
<b>covden_win_dynamic</b>	Pathname of the time series of pre-processed values for winter plant-cover density used to set values of <b>covden_win</b> for each HRU	<b>dyn_covden_flag</b> = 2 or 3	1	4	dyncovwin
<b>covtype_dynamic</b>	Pathname of the time series of pre-processed values used to set values of <b>cov_type</b> for each HRU	<b>dyn_covtype_flag</b> = 1	1	4	dyncovtype
<b>dprst_depth_dynamic</b>	Pathname of the time series of pre-processed values used to set values of <b>dprst_depth_avg</b>	<b>dyn_dprst_flag</b> = 2 or 3	1	4	dyndprst_depth
<b>dprst_frac_dynamic</b>	Pathname of the time series of pre-processed values used to set values of <b>dprst_frac</b>	<b>dyn_dprst_flag</b> = 1 or 3	1	4	dyndprst_frac
<b>dyn_covden_flag</b>	Flag to indicate if a time series of plant-canopy density values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>covden_sum_dynamic</b> ; 2=file <b>covden_win_dynamic</b> ; 3=both)	dynamic canopy cover density	1	1	0
<b>dyn_covtype_flag</b>	Flag to indicate if a time series of plant-canopy type values are input in a Dynamic Parameter File with pathname specified by <b>covtype_dynamic</b> (0=no; 1=yes)	dynamic canopy cover type	1	1	0
<b>dyn_dprst_flag</b>	Flag to indicate if a time series of surface-depression values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>dprst_frac_dynamic</b> ; 2=file <b>dprst_depth_dynamic</b> ; 3=both)	dynamic surface depression	1	1	0
<b>dyn_fallfrost_flag</b>	Flag to indicate if a time series of transpiration-start Julian day values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>fallfrost_dynamic</b> )	dynamic transpiration and transp_module = transp_frost	1	1	0

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>dyn_imperv_flag</b>	Flag to indicate if a time series of impervious values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>imperv_frac_dynamic</b> ; 2=file <b>imperv_stor_dynamic</b> ; 3=both)	dynamic impervious	1	1	0
<b>dyn_intcp_flag</b>	Flag to indicate if a time series of plant canopy interception values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>wrain_intcp_dynamic</b> ; 2=file <b>srain_intcp_dynamic</b> ; 4=file <b>snow_intcp_dynamic</b> ; additive combinations, such as 3=file <b>wrain_intcp_dynamic</b> and <b>srain_intcp_dynamic</b> , but not <b>snow_intcp_dynamic</b> )	dynamic interception	1	1	0
<b>dyn_potet_flag</b>	Flag to indicate if a time series of potential ET coefficient values are input in a Dynamic Parameter File with pathname specified by <b>potet_coef_dynamic</b> to update coefficients for the specified month for the selected potential ET module specified by control parameter <b>et_module</b> (0=no; 1=parameter <b>jh_coef</b> , <b>pt_alpha</b> , <b>hs_krs</b> , <b>hamon_coef</b> , <b>epan_coef</b> , <b>potet_cbh_adj</b> , and <b>pm_n_coef</b> used in <b>potet_jh</b> , <b>potet_pt</b> , <b>potet_hs</b> , <b>potet_hamon</b> , <b>potet_pan</b> , <b>climate_hru</b> , <b>potet_pm</b> , and <b>potet_pm_sta</b> modules, respectively; 2=parameter <b>jh_coef_hru</b> , <b>pm_d_coef</b> used in <b>potet_jh</b> , <b>potet_pm</b> , and <b>potet_pm_sta</b> modules, respectively)	dynamic potential ET	1	1	0
<b>dyn_radtrncf_flag</b>	Flag to indicate if a time series of solar radiation values are input in a Dynamic Parameter File with pathname specified by <b>radtrncf_dynamic</b> (0=no; 1=yes)	dynamic solar radiation transmission	1	1	0
<b>dyn_soil_flag</b>	Flag to indicate if a time series of soil-water capacity values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>soilmoist_dynamic</b> only, 2=file <b>soilrechr_dynamic</b> only; 3=both)	dynamic soil moisture	1	1	0
<b>dyn_springfrost_flag</b>	Flag to indicate if a time series of transpiration-start Julian day values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>springfrost_dynamic</b> )	dynamic transpiration and transp_module = transp_frost	1	1	0
<b>dyn_sro2dprst_perv_flag</b>	Flag to indicate if a time series of fraction of surface runoff from the pervious portion of an HRU are input in Dynamic Parameter File <b>sro2dprst_perv_dyn</b> (0=no; 1=yes)	dynamic surface depression	1	1	0
<b>dyn_sro2dprst_imperv_flag</b>	Flag to indicate if a time series of fraction of surface runoff from the impervious portion of an HRU are input in Dynamic Parameter File <b>sro2dprst_imperv_dynamic</b> (0=no; 1=yes)	dynamic surface depression	1	1	0
<b>dyn_transp_flag</b>	Flag to indicate if a time series of transpiration month values are input in a Dynamic Parameter File(s) (0=no; 1=file <b>transpbeg_dynamic</b> ; 2=file <b>transpend_dynamic</b> only, 3=both)	dynamic transpiration and transp_module = transp_tindex	1	1	0
<b>dynamic_param_log_file</b>	Pathname of the log file that summarizes dynamic parameter changes	for all dynamic parameter input	1	4	dynamic_parameter.out

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>fallfrost_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>fall_frost</b>	<b>dyn_fallfrost_flag</b> = 1 and transp_module = transp_frost	1	4	dynfallfrost
<b>imperv_frac_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>hru_percent_imperv</b>	<b>dyn_imperv_flag</b> = 1 or 3	1	4	dynimperv
<b>imperv_stor_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>imperv_stor_max</b>	<b>dyn_imperv_flag</b> = 2 or 3	1	4	dynimperv
<b>potet_coef_dynamic</b>	Pathname of the time series of pre-processed potential evapotranspiration coefficient values where the parameter is dependent on the value of <b>et_module</b>	<b>dyn_potet_flag</b> = 1 or 2	1	4	dynpotetcoef
<b>radtrncf_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>rad_trncf</b>	<b>dyn_radtrncf_flag</b> = 1	1	4	dynradtrncf
<b>snow_intcp_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>snow_intcp</b>	<b>dyn_intcp_flag</b> = 4, 5, 6, or 7	1	4	dynsnowintcp
<b>soilmoist_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>soil_moist_max</b>	<b>dyn_soil_flag</b> = 1 or 3	1	4	dynsoilmoist
<b>soilrechr_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>soil_rechr_max_frac</b>	<b>dyn_soil_flag</b> = 2 or 3	1	4	dynsoilrechr
<b>springfrost_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>spring_frost</b>	<b>dyn_springfrost_flag</b> = 1 and transp_module = transp_frost	1	4	dynspringfrost
<b>srain_intcp_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>srain_intcp</b>	<b>dyn_intcp_flag</b> = 2, 3, 6, or 7	1	4	dynsrainintcp
<b>sro2dprst_perv_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>sro_to_dprst_perv</b>	<b>dyn_sro2dprst_perv_flag</b> = 1	1	4	dynsrotodprst_perv
<b>sro2dprst_imperv_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>sro_to_dprst_imperv</b>	<b>dyn_sro2dprst_imperv_flag</b> = 1	1	4	dynsrotodprst_imperv
<b>transpbeg_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>transp_beg</b>	<b>dyn_transp_flag</b> = 1 or 3 and transp_module = transp_tindex	1	4	dyntranspbeg
<b>transpend_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>transp_end</b>	<b>dyn_transp_flag</b> = 2 or 3 and transp_module = transp_tindex	1	4	dyntranspend
<b>wrain_intcp_dynamic</b>	Pathname of the time series of pre-processed values for dynamic parameter <b>wrain_intcp</b>	<b>dyn_intcp_flag</b> = 1, 3, 5, or 7	1	4	dynwrainintcp
Water Use Input ( <b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5)					
<b>dprst_transfer_file</b>	Pathname of the time series of pre-processed flow rates for transfers from surface-depression storage	<b>dprst_transferON_OFF</b> = 1 and <b>dprst_flag</b> = 1	1	4	dprst.transfer
<b>dprst_transferON_OFF</b>	Flag to indicate to use time series of surface-depression transfer	surface depression transfer	1	1	0



Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>external_transfer_file</b>	flow rates from the <b>dprst_transfer_file</b> (0=no; 1=yes) Pathname of the time series of pre-processed flow rates for transfers from external sources	and <b>dprst_flag</b> = 1 <b>external_transferON_OFF</b> = 1	1	4	<code>ext.transfer</code>
<b>external_transferON_OFF</b>	Flag to indicate to use external transfer flow rates from the <b>external_transfer_file</b> (0=no; 1=yes)	external transfer	1	1	0
<b>gwr_transfer_file</b>	Pathname of the time series of pre-processed flow rates for transfers from groundwater reservoir storage	<b>gwr_transferON_OFF</b> = 1	1	4	<code>gwr.transfer</code>
<b>gwr_transferON_OFF</b>	Flag to indicate to use groundwater transfer flow rates from the <b>gwr_transfer_file</b> (0=no; 1=yes)	groundwater transfer	1	1	0
<b>lake_transfer_file</b>	Pathname of the time series of pre-processed flow rates for transfers from lake HRUs	<b>lake_transferON_OFF</b> = 1	1	4	<code>lake.transfer</code>
<b>lake_transferON_OFF</b>	Flag to indicate to use lake HRU transfer flow rates from the <b>lake_transfer_file</b> (0=no; 1=yes)	lake water transfer	1	1	0
<b>segment_transfer_file</b>	Pathname of the time series of pre-processed flow rates for transfers from stream segments	<b>segment_transferON_OFF</b> = 1	1	4	<code>seg.transfer</code>
<b>segment_transferON_OFF</b>	Flag to indicate to use stream segment transfer flow rates from the <b>segment_transfer_file</b> (0=no; 1=yes)	stream water transfer	1	1	0
<b>Climate-by-HRU Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>cbh_binary_flag</b>	Flag to specify whether to input CBH files in a binary format using the same order of values as the text file version (0=no; 1=yes)	<b>et_module</b> , <b>precip_module</b> , <b>temp_module</b> , <b>solrad_module</b> , or <b>transp_module</b> = <code>climate_hru</code>	1	1	0
<b>humidity_cbh_flag</b>	Flag to specify whether to read a CBH file with humidity data (0=no; 1=yes)	<b>et_module</b> = <code>potet_pm</code> or <code>potet_pt</code>	1	1	0
<b>humidity_day</b>	Pathname of the CBH file of pre-processed humidity input data for each HRU to specify variable <i>humidity_hru</i> (units: percentage)	<b>et_module</b> = <code>potet_pm</code> , <code>potet_pm_sta</code> , or <code>potet_pt</code>	1	4	<code>humidity.day</code>
<b>orad_flag</b>	Flag to specify whether or not the variable <i>orad</i> is specified as the last column of the <b>swrad_day</b> CBH file (0=no; 1=yes)	<b>solrad_module</b> = <code>climate_hru</code>	1	1	0
<b>potet_day</b>	Pathname of the CBH file of pre-processed potential-ET input data for each HRU to specify variable <i>potet</i> (units: inches/day)	<b>et_module</b> = <code>climate_hru</code>	1	4	<code>potet.day</code>
<b>precip_day</b>	Pathname of the CBH file of pre-processed precipitation input data for each HRU to specify variable <i>precip</i> (units based on value specified for parameter <b>precip_units</b> )	<b>precip_module</b> = <code>climate_hru</code>	1	4	<code>precip.day</code>
<b>swrad_day</b>	Pathname of the CBH file of pre-processed solar-radiation input data for each HRU to specify variable <i>swrad</i> (units: Langleys/day)	<b>solrad_module</b> = <code>climate_hru</code>	1	4	<code>swrad.day</code>
<b>tmax_day</b>	Pathname of the CBH file of pre-processed maximum air temperature input data for each HRU to specify variable <i>tmaxf</i> (units: degrees Fahrenheit)	<b>temp_module</b> = <code>climate_hru</code>	1	4	<code>tmax.day</code>

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>tmin_day</b>	Pathname of the CBH file of pre-processed minimum air temperature input data for each HRU to specify variable <i>tminf</i> (units: degrees Fahrenheit)	<b>temp_module</b> = climate_hru	1	4	tmin.day
<b>transp_day</b>	Pathname of the CBH file of pre-processed transpiration on or off flag for each HRU file to specify variable <i>transp_on</i> (units: none)	<b>transp_module</b> = climate_hru	1	4	transp.day
<b>windspeed_cbh_flag</b>	Flag to specify whether to read a CBH file with wind speed data (0=no; 1=yes)	<b>et_module</b> = potet_pm	1	1	0
<b>windspeed_day</b>	Pathname of the CBH file of pre-processed wind speed input data for each HRU to specify variable <i>windspeed_hru</i> (units: meters/second)	<b>et_module</b> = potet_pm	1	4	windspeed.day
<b>Debug options (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>cbh_check_flag</b>	Flag to indicate if CBH values are validated each time step (0=no; 1=yes)	optional	1	1	1
<b>parameter_check_flag</b>	Flag to indicate if selected parameter-values validation checks are treated as warnings or errors (0=warning; 1=errors; 2=check parameters and then stop execution)	optional	1	1	1
<b>print_debug<sup>1</sup></b>	Flag to indicate type of debug output (-2=minimal output to screen and no <b>model_output_file</b> or <i>gsflow.log</i> file; -1 =minimize screen output; 0=none; 1=water balances; 2=basin module; 4=basin_sum module; 5=soltab module; 7=soilzone module; 9=snowcomp module; 13=cascade module; 14=subbasin module)	optional	1	1	0
<b>Statistic Variables (statvar) Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>nstatVars</b>	Number of variables to include in Statistics Variables File and names specified in <b>statVar_names</b>	<b>statsON_OFF</b> = 1	1	1	0
<b>stat_var_file</b>	Pathname for Statistics Variables File	<b>statsON_OFF</b> = 1	1	4	statvar.out
<b>statsON_OFF</b>	Switch to specify whether or not the Statistics Variables File is generated (0=no; 1=statvar text format; 2=CSV format)	<b>statsON_OFF</b> = 1	1	1	0
<b>statVar_element</b>	List of identification numbers corresponding to variables specified in <b>statVar_names</b> list (1 to variable's dimension size)	<b>statsON_OFF</b> = 1	<b>nstatVars</b>	4	none
<b>statVar_names</b>	List of variable names for which output is written to Statistics Variables File	<b>statsON_OFF</b> = 1	<b>nstatVars</b>	4	none
<b>Initial Condition Files</b>					
<b>init_vars_from_file</b>	Flag to specify whether or not the Initial Conditions File is specified as an input file (0=no; 1=yes; 2=yes and use parameters <b>dprst_frac_init</b> , <b>snowpack_init</b> , <b>segment_flow_init</b> , <b>elevlake_init</b> , <b>gwstor_init</b> , ( <b>soil_rechr_init</b> , <b>soil_moist_init</b> , <b>ssstor_init</b> for <b>model_mode</b> =PRMS or GSFLOW) or ( <b>soil_rechr_init_frac</b> , <b>soil_moist_init_frac</b> , <b>ssstor_init_frac</b> for	optional (available for all model modes)	1	1	0

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
	<b>model_mode</b> =PRMS5 or GSFLOW5), and <b>stream_tave_init</b> ; 3=yes and use parameter <b>snowpack_init</b> ; 4=yes and use parameter <b>elevlake_init</b> ; 5=yes and use parameters ( <b>soil_rechr_init</b> , <b>soil_moist_init</b> , <b>ssstor_init</b> for <b>model_mode</b> =PRMS or GSFLOW) or ( <b>soil_rechr_init_frac</b> , <b>soil_moist_init_frac</b> , <b>ssstor_init_frac</b> for <b>model_mode</b> =PRMS5 or GSFLOW5); 6=yes and use parameter <b>gwstor_init</b> ; 7=yes and use parameter <b>dprst_frac_init</b> ; 8=yes and use parameter <b>stream_tave_init</b> ). Note, <b>segment_flow_init</b> , <b>elevlake_init</b> , <b>gwstor_init</b> , and <b>stream_tave_init</b> are not used for GSFLOW or GSFLOW5 simulation modes				
<b>save_vars_to_file</b>	Flag to determine if an Initial Conditions File will be generated at the end of simulation (0=no; 1=yes)	optional (available for all model modes)	1	1	0
<b>var_init_file</b>	Pathname for Initial Conditions input file	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5 and <b>init_vars_from_file</b> = 1	1	4	prms_ic.in
<b>var_save_file</b>	Pathname for the Initial Conditions File to be generated at end of simulation	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5 and <b>save_vars_to_file</b> = 1	1	4	prms_ic.out
<b>Animation Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>ani_output_file</b>	Pathname for Animation Files(s) to which a filename suffix based on dimension name associated with selected variables is appended	<b>aniOutON_OFF</b> = 1	1	4	animation.out
<b>aniOutON_OFF</b>	Switch to specify whether or not Animation File(s) are generated (0=no; 1=yes)	animation output	1	1	0
<b>aniOutVar_names</b>	List of variable names for which all values of the variable (that is, the entire dimension size) for each time step are written to Animation Files(s)	<b>aniOutON_OFF</b> = 1	<b>naniOutVars</b>	4	none
<b>naniOutVars</b>	Number of output variables specified in the <b>aniOutVar_names</b> list	<b>aniOutON_OFF</b> = 1	1	1	0
<b>Mapped Results Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>mapOutON_OFF</b>	Switch to specify whether or not Mapped Output file(s) by a specified number of columns (parameter <b>ncol</b> ) of daily, monthly, yearly, or total simulation results is generated (0=no; 1=yes)	optional	1	1	0
<b>mapOutVar_names</b>	List of variable names for which output is written to mapped output files(s)	<b>map_resultsON_OFF</b> = 1	<b>nmapOutVars</b>	4	none
<b>nmapOutVars</b>	Number of variables to include in mapped output file(s)	<b>map_resultsON_OFF</b> = 1	1	1	0
<b>Nhru Summary Results Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>nhruOutBaseFileName</b>	Base pathname for each Nhru Summary Output File	<b>nhruOutON_OFF</b> =1 or 2	1	4	nhruout_path
<b>nhruOutNcol</b>	Number of columns written per line, which can be used to generate gridded output (0=all values for each timestep are written on a	<b>nhruOutON_OFF</b> =1 or 2	1	1	0

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>nhruOutON_OFF</b>	single line as in previous versions; >0 number of columns) Switch to specify whether or not Nhru Summary Output File(s) are generated (0=no; 1=yes)	<b>nhru</b> summary results	1	1	0
<b>nhruOutVar_names</b>	List of variable names for which output is written to <b>nhru</b> Summary Comma Separated Values (CSV) Output Files(s). Each variable is written to a separate file with the prefix of each file equal to the value of <b>nhruOutBaseFileName</b> ; variables must be of type real or double. Each variable is written to a separate file with the prefix of each file equal to the value of <b>nhruOutBaseFileName</b> . The suffix of the files is based on the value of <b>nhruOut_freq</b> and will be .csv; _meanyearly.csv; _yearly.csv; _meanmonthly.csv; or _monthly.csv. Variables must be of type real or double	<b>nhruOutON_OFF</b> = 1 or 2	<b>nhruOutVars</b>	4	none
<b>nhruOutVars</b>	Number of variables to include in Nhru Summary Output File(s)	<b>nhruOutON_OFF</b> = 1 or 2	1	1	0
<b>outputSelectDatesON_OFF</b>	Switch to indicate if <b>nhru_summary</b> output files are generated for a specified set of dates (0=no, output time series on basis of <b>nhruOut_freq</b> ; 1=yes, specify dates in file specified by <b>selectDatesFileName</b> )	<b>nhru</b> summary results and <b>nhruOut_freq</b> = 1 or 3	1	1	0
<b>selectDatesFileName<sup>2</sup></b>	String to define the filename of the set of dates to output values of <b>nhru_summary</b> output files in chronological order with dates specified as YEAR MONTH DAY with a space(s) and/or comma separating YEAR and MONTH and MONTH and DAY (e.g. 1959 09 01)	<b>outputSelectDatesON_OFF</b> = 1	1	4	<code>selectDates.in</code>
<b>nhruOut_format</b>	Format of values (1=scientific notation with 4 significant digits (default); 2=2 decimal places; 3=3 decimal places; 4=4 decimal places; 5=5 decimal places)	<b>nhruOutON_OFF</b> = 1 or 2	1	1	1
<b>nhruOut_freq</b>	Output frequency and type (1=daily; 2=monthly; 3=both; 4=mean monthly; 5=mean yearly; 6=yearly)	<b>nhruOutON_OFF</b> = 1 or 2	1	1	1
<b>nsegment Summary Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>nsegmentOutBaseFileName</b>	String to define the prefix for each <b>nsegment</b> summary output file.	<b>nsegmentOutON_OFF</b> = 1 or 2	1	4	<code>nsegmentout_path</code>
<b>nsegmentOutON_OFF</b>	Switch to specify whether <b>nsegment</b> summary output files are generated (0=no; 1=yes; 2=yes and use values of <b>nhm_seg</b> as column heading)	<b>nsegment</b> summary results	1	1	0
<b>nsegmentOutVar_names</b>	List of variable names for which output is written to <b>nsegment</b> summary Comma Separated Values (CSV) output files(s). Each variable is written to a separate file with the prefix of each file equal to the value of <b>nsegmentOutBaseFileName</b> ; variables must be of type real or double; the suffix of the files is based on the value of <b>nsegmentOut_freq</b> and will be .csv; _meanyearly.csv; _yearly.csv; _meanmonthly.csv; or _monthly.csv	<b>nsegmentOutON_OFF</b> = 1 or 2	<b>nsegmentOutVars</b>	4	none

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
<b>nsegmentOutVars</b>	Number of variables to include in <b>nsegment</b> summary output file(s)	<b>nsegmentOutON_OFF</b> = 1 or 2	1	1	0
<b>nsegmentOut_format</b>	Format of values (1=scientific notation with 4 significant digits (default); 2=2 decimal places; 3=3 decimal places; 4=4 decimal places; 5=5 decimal places)	<b>nsegmentOutON_OFF</b> = 1 or 2	1	1	1
<b>nsegmentOut_freq</b>	Output frequency and type (1=daily; 2=monthly; 3=both; 4=mean monthly; 5=mean yearly; 6=yearly)	<b>nsegmentOutON_OFF</b> = 1 or 2	1	1	1
<b>nsub Summary Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>nsubOutBaseFileName</b>	String to define the prefix for each <b>nsub</b> summary output file.	<b>nsubOutON_OFF</b> = 1	1	4	nsubout_path
<b>nsubOutON_OFF</b>	Switch to specify whether <b>nsub</b> summary output files are generated (0=no; 1=yes)	<b>nsub</b> summary results	1	1	0
<b>nsubOutVar_names</b>	List of variable names for which output is written to <b>nsub</b> summary Comma Separated Values (CSV) output files(s). Each variable is written to a separate file with the prefix of each file equal to the value of <b>nsubOutBaseFileName</b> ; variables must be of type real or double. The suffix of the files is based on the value of <b>nsubOut_freq</b> and will be .csv; _meanyearly.csv; _yearly.csv; _meanmonthly.csv; or _monthly.csv.	<b>nsubOutON_OFF</b> = 1	<b>nsubOutVars</b>	4	none
<b>nsubOutVars</b>	Number of variables to include in <b>nsub</b> summary output file(s)	<b>nsubOutON_OFF</b> = 1	1	1	0
<b>nsubOut_format</b>	Format of values (1=scientific notation with 4 significant digits (default); 2=2 decimal places; 3=3 decimal places; 4=4 decimal places; 5=5 decimal places)	<b>nsubOutON_OFF</b> = 1	1	1	1
<b>nsubOut_freq</b>	Output frequency and type (1=daily; 2=monthly; 3=both; 4=mean monthly; 5=mean yearly; 6=yearly)	<b>nsubOutON_OFF</b> = 1	1	1	1
<b>Basin Summary Results Files (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>					
<b>basinOutBaseFileName</b>	String to define the prefix for each Basin Summary Output File.	<b>basinOutON_OFF</b> = 1	1	4	basinout_path
<b>basinOutON_OFF</b>	Switch to specify whether or not basin Summary Output Files are generated (0=no; 1=yes)	Basin summary results	1	1	0
<b>basinOutVar_names</b>	List of variable names for which output is written to Basin Summary Comma Separated Values (CSV) Output Files(s). Each variable is written to a separate file with the prefix of each file equal to the value of <b>basinOutBaseFileName</b> ; variables must be of type real or double. Each variable is written to a separate file with the prefix of each file equal to the value of <b>basinOutBaseFileName</b> . The suffix of the files is based on the value of <b>basinOut_freq</b> and will be .csv; _meanyearly.csv; _yearly.csv; _meanmonthly.csv; or _monthly.csv. Variables must be of type real or double	<b>basinOutON_OFF</b> = 1	<b>basinOutVars</b>	4	none
<b>basinOutVars</b>	Number of variables to include in Basin Summary Output File(s)	<b>basinOutON_OFF</b> = 1	1	1	0
<b>basinOut_freq</b>	Output frequency and type (1=daily; 2=monthly; 3=both; 4=mean	<b>basinOutON_OFF</b> = 1	1	1	1

Parameter name	Description	Required/Simulation condition(s)	Number of Values	Data type	Default value
----------------	-------------	----------------------------------	------------------	-----------	---------------

monthly; 5=mean yearly; 6=yearly)

<sup>1</sup>File and screen output options: 1=water balance output files written in current directory, for `intcp` module file `intcp.wbal`; for `snowcomp` module `snowcomp.wbal`; for `srunoff` module `srunoff_smidx.wbal` or `srunoff_carea.wbal`; for `soilzone` module `soilzone.wbal`; for `gwflow` module `gwflow.wbal`; 2=basin module output written to screen; 4=basin\_sum debug information written to file `basin_sum.dbg` in current directory; 5=soltab module output written to the file `soltab_debug` in current directory; 7=soilzone debug information concerning input parameter consistency written to file `soilzone.dbg` in current directory; 9=arrays of *net\_rain*, *net\_snow*, and *snowmelt* written to screen; 13=subbasin error and warning messages and cascade paths are written to the file `cascade.msgs` in current directory; 14=subbasin computation order written to file `tree_structure` in current directory.

<sup>2</sup>Parameter not needed for a PRMS-only simulation.

**Table A1-4.** Dimensions defined in the PRMS Parameter File.

[Dimensions only need to be defined for GSFLOW and PRMS-only simulation modes and are not needed for MODFLOW-only mode; HRU, hydrologic response unit; GWR, groundwater reservoir; >, greater than; control parameters **temp\_module**, **precip\_module**, **solrad\_module**, **et\_module**, **strmflow\_module**, **subbasin\_flag**, **cascade\_flag**, **cascadegw\_flag**, and **mapOutON\_OFF** are defined in table A1-1 of this document; parameter **hru\_solsta** defined in table 1-3 of online PRMS-IV documents; note a Dimension is optional if there is no associated parameter specified in the Parameter File(s) or variable specified in the Data File]

Dimension	Description	Default	Required/Simulated Condition(s)
<b>Spatial dimensions</b>			
<b>ngw</b> <sup>1</sup>	Number of GWRs (used in PRMS-only simulations)	1	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5
<b>ngwcell</b>	Number of cells in the MODFLOW grid (includes active and inactive cells)	0	<b>model_mode</b> = GSFLOW or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5
<b>nhru</b> <sup>1</sup>	Number of hydrologic response units	1	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5
<b>nhrucell</b>	Number of unique intersections between HRUs and spatial units of a target map for mapped results	0	<b>model_mode</b> = GSFLOW or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5
<b>nlake</b>	Number of lakes	0	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5 when any HRU has <b>hru_type</b> specified equal to 2
<b>nreach</b>	Number of reaches on all stream-channel segments	0	<b>model_mode</b> = GSFLOW or GSFLOW5
<b>nsegment</b>	Number of stream-channel segments	0	<b>model_mode</b> = GSFLOW, GSFLOW5 or when HRU or GWR cascading flow is active or <b>strmflow_module</b> = <b>strmflow_in_out</b> , <b>muskingum</b> , <b>muskingum_mann</b> , or <b>muskingum_lake</b> when <b>model_mode</b> = PRMS or <b>cascade_flag</b> = 1 or 2 or <b>cascadegw_flag</b> = 1 or 2
<b>nssr</b> <sup>1</sup>	Number of subsurface reservoirs	1	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5
<b>nsub</b>	Number of internal subbasins	0	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5 and <b>subbasin_flag</b> = 1 or parameter <b>subbasin_down</b> is specified
<b>Time-series input data dimensions (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)<sup>2</sup></b>			
<b>nconsumed</b>	Number of consumptive water-use destinations	0	optional
<b>nevap</b>	Number of pan-evaporation data sets	0	<b>et_module</b> = <b>potet_pan</b> or when any HRU has <b>hru_pansta</b> specified > 0
<b>nexternal</b>	Number of external water-use sources or destinations	0	optional
<b>nhumid</b>	Number of relative-humidity measurement stations	0	required if <b>et_module</b> = <b>potet_pm_sta</b>
<b>nlakeelev</b>	Maximum number of lake elevations for any rating table data set	0	<b>strmflow_module</b> = <b>muskingum_lake</b>
<b>nmap</b>	Number of spatial units in mapped climate	0	<b>temp_module</b> = <b>temp_map</b> or <b>precip_module</b> = <b>precip_map</b>
<b>nmap2hru</b>	Number of intersections between HRUs and spatial units in mapped climate	0	<b>temp_module</b> = <b>temp_map</b> or <b>precip_module</b> = <b>precip_map</b>
<b>nobs</b>	Number of streamflow-measurement stations	0	optional in general and required when using the replacement flow option when <b>strmflow_module</b> = <b>strmflow_in_out</b> , <b>muskingum</b> , <b>muskingum_mann</b> , or <b>muskingum_lake</b> and <b>model_mode</b> = PRMS or PRMS5

Dimension	Description	Default	Required/Simulated Condition(s)
<b>npoigages</b>	Number of points-of-interest streamflow gages	0	Optional
<b>nrain</b>	Number of precipitation-measurement stations	0	<b>precip_module</b> = precip_1sta, precip_laps, precip_dist2, ide_dist, or xyz_dist
<b>nratetbl</b>	Number of rating-table data sets for lake elevations	0	<b>strmflow_module</b> = muskingum_lake
<b>nsnow</b>	Number of snow-depth measurement stations	0	Optional
<b>nsol</b>	Number of solar-radiation measurement stations	0	<b>solrad_module</b> = ddsolrad or ccsolrad and when any HRU has <b>hru_solsta</b> specified > 0
<b>ntemp</b>	Number of air-temperature-measurement stations	0	<b>temp_module</b> = temp_1sta, temp_laps, temp_dist2, temp_sta, ide_dist, or xyz_dist
<b>nwind</b>	Number of wind-speed measurement stations	0	required if <b>et_module</b> = potet_pm_sta
<b>Computation dimensions (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>			
<b>ncascade</b>	Number of HRU links for cascading flow	0	<b>cascade_flag</b> = 1 or 2
<b>ncascdgw</b>	Number of GWR links for cascading flow	0	<b>cascadegw_flag</b> = 1 or 2
<b>ndepl</b>	Number of snow-depletion curves	1	Required
<b>ndeplval</b>	Number of values in all snow-depletion curves (set to <b>ndepl</b> *11)	11	Required
<b>Lake computation dimensions (model_mode = PRMS or PRMS5)</b>			
<b>mxnsos</b>	Maximum number of storage/outflow table values for lakes routed using the Puls method	0	<b>strmflow_module</b> = muskingum_lake
<b>ngate</b>	Maximum number of reservoir gate-opening values (columns) for lake rating table 1	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 0
<b>ngate2</b>	Maximum number of reservoir gate-opening values (columns) for lake rating table 2	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 1
<b>ngate3</b>	Maximum number of reservoir gate-opening values (columns) for lake rating table 3	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 2
<b>ngate4</b>	Maximum number of reservoir gate-opening values (columns) for lake rating table 4	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 3
<b>nstage</b>	Maximum number of lake elevations values (rows) for lake rating table 1	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 0
<b>nstage2</b>	Maximum number of lake elevations values (rows) for lake rating table 2	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 1
<b>nstage3</b>	Maximum number of lake elevations values (rows) for lake rating table 3	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 2
<b>nstage4</b>	Maximum number of lake elevations values (rows) for lake rating table 4	0	<b>strmflow_module</b> = muskingum_lake and <b>nratetbl</b> > 3
<b>Fixed dimensions (model_mode = GSFLOW, GSFLOW5, PRMS, or PRMS5)</b>			
<b>four</b>	Number of glacier variables in integer array	4	<b>glacier_flag</b> = 1
<b>ndays</b>	Maximum number of days in a year	366	Optional
<b>nglres</b>	Number of reservoirs in a glacier	3	<b>glacier_flag</b> = 1
<b>nlapse</b>	Number of lapse rates in X, Y, and Z directions	3	<b>precip_module</b> = xyz_dist
<b>nmonths</b>	Number of months in a year	12	Optional
<b>one</b>	Dimension of scalar parameters and variables	1	Optional
<b>seven</b>	Number of glacier variables in real array	7	<b>glacier_flag</b> = 1

<sup>1</sup>Dimensions **ngw**, **nhru**, and **nssr** must be equal.

<sup>2</sup>All associated data specified in Data File can be used for calibration purposes. While the default value for these dimensions is 0, there must be at least one column of measured data in the Data File, which could be a column of zeros.



**Table A1-23.** Input parameters specified for GSFLOW modules in the PRMS Parameter File(s).  
[HRU, hydrologic response unit; Dimensions are defined in table A1-4 of this document]

Parameter name	Description	Dimension	Type	Units	Range	Default	Required/Simulated condition(s)
<b>gvr_cell_id</b>	Index of the grid cell associated with each gravity reservoir	<b>nhrucell</b>	integer	none	0 to <b>ngwcell</b>	0	<b>model_mode</b> = GSFLOW or GSFLOW5 or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5
<b>gvr_cell_pct</b>	Proportion of the grid-cell area associated with each gravity reservoir	<b>nhrucell</b>	real	decimal fraction	0.0 to 1.0	0.0	<b>model_mode</b> = GSFLOW or GSFLOW5 or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5 and <b>nhru</b> not equal to <b>nhrucell</b>
<b>gvr_hru_id</b>	Index of the HRU associated with each gravity reservoir	<b>nhrucell</b>	integer	none	1 to <b>nhru</b>	1	<b>model_mode</b> = GSFLOW or GSFLOW5 or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5 and <b>nhru</b> not equal to <b>nhrucell</b>
<b>gvr_hru_pct</b>	Proportion of the HRU area associated with each gravity reservoir	<b>nhrucell</b>	real	decimal fraction	0.0 to 1.0	0.0	<b>model_mode</b> = GSFLOW or GSFLOW5 or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5 and <b>nhru</b> not equal to <b>nhrucell</b>
<b>id_obsrunoff</b>	Index of measured streamflow station corresponding to the basin outlet	<b>one</b>	integer	none	1 to <b>nobs</b>	0	<b>model_mode</b> = GSFLOW or GSFLOW5 or when <b>mapOutON_OFF</b> = 1 and <b>model_mode</b> = PRMS or PRMS5 and <b>nhru</b> not equal to <b>nhrucell</b>
<b>lake_hru_id</b>	Identification number of the lake associated with an HRU; more than one HRU can be associated with each lake	<b>nhru</b>	integer	none	0 to <b>nhru</b>	0	<b>model_mode</b> = GSFLOW, GSFLOW5, PRMS, or PRMS5 and <b>nlake</b> is greater than 0
<b>mxsziter</b> <sup>1</sup>	Maximum number of iterations for which soil-zone states are computed	<b>one</b>	integer	none	0 to 5,000	MODFLOW maximum number of outer iterations <sup>2</sup>	<b>model_mode</b> = GSFLOW or GSFLOW5

<sup>1</sup>Parameter is not required in MODFLOW-only simulations.

<sup>2</sup>MXITER, ITMX, or MAXITEROUT

**Table 1-5. Selected GSFLOW output variables for which values can be written to the PRMS Statistic Variables File and PRMS Animation Variables File(s)**  
(supersedes Table A1-2 in Markstrom and others, 2008; TM 6D1). [HRU, hydrologic response unit; ET, evapotranspiration; cfs: cubic feet per second; L3, cubic length units of MODFLOW; L3/T, cubic length units of MODFLOW per MODFLOW timestep; >, greater than; <, less than]

Variable name	Description	Dimension <sup>1</sup>	Units	Data type	Original Variable Name
<i>actet_gw</i>	Actual ET from each GW cell	<b>one</b>	inches	real	
<i>actet_tot_gwsz</i>	Total actual ET from PRMS soil zone, and deeper unsaturated and saturated zones	<b>one</b>	inches	real	
<i>ActualET_Q</i>	Volumetric flow rate of actual evapotranspiration from HRUs	<b>one</b>	L3/T	double	<i>basinactet</i>
<i>Ave_SoilDrainage2Unsat_Q</i>	Running average gravity drainage to the unsaturated and saturated zones	<b>one</b>	L3	double	<i>ave_uzf_infil</i>
<i>basin_gw2sm</i>	Basin average water exfiltrated from unsaturated and saturated zones and added to soil zone	<b>one</b>	inches	double	
<i>basin_reach_latflow</i>	Lateral flow into all reaches in basin	<b>one</b>	cfs	double	
<i>basingvr2sm</i>	Volumetric flow rate of flow from gravity reservoirs to capillary reservoirs	<b>one</b>	L3/T	double	
<i>basinrain</i>	Volumetric flow rate of rain	<b>one</b>	L3/T	double	
<i>basinseepout</i>	Volumetric flow rate of groundwater discharge from the saturated zone to the soil zone	<b>one</b>	L3/T	double	
<i>basinsm2gvr</i>	Volumetric flow rate of flow from capillary reservoirs to gravity reservoirs	<b>one</b>	L3/T	double	
<i>basinsnow</i>	Volumetric flow rate of precipitation falling as snow	<b>one</b>	L3/T	double	
<i>basinsoilstor</i>	Volume of soil moisture storage	<b>one</b>	L3	double	
<i>basin_szreject</i>	Basin average recharge from SZ and rejected by UZF	<b>one</b>	inches	double	
<i>BoundaryStreamFlow_Q</i>	Volumetric flow rate of streamflow entering the model domain to SFR	<b>one</b>	L3/T	double	new
<i>Canopy_S</i>	Volume of intercepted precipitation in plant-canopy reservoirs	<b>one</b>	L3	double	<i>basinintcpstor</i>
<i>CanopyEvap_Q</i>	Volumetric flow rate of evaporation of intercepted precipitation	<b>one</b>	L3/T	double	<i>basinintcpevap</i>
<i>Cap_S</i>	Volume of water in capillary reservoirs of the soil zone	<b>one</b>	L3	double	<i>basinsoilmoist</i>
<i>CapDrainage2Sat_Q</i>	Volumetric flow rate of direct drainage from excess capillary water to the unsaturated zone	<b>one</b>	L3/T	double	<i>basinsoiltogw</i>
<i>CapET_Q</i>	Volumetric flow rate of evapotranspiration from pervious areas	<b>one</b>	L3/T	double	<i>basinpervet</i>
<i>cell_drain_rate</i>	Recharge rate for each cell	<b>ngwcell</b>	L/T	real	
<i>cum_pweqv</i>	Cumulative change in snowpack storage	<b>one</b>	L3	double	
<i>cum_satstor</i>	Cumulative change in saturated storage	<b>one</b>	L3	double	
<i>cum_soilstor</i>	Cumulative change in soil storage	<b>one</b>	L3	double	
<i>cum_uzstor</i>	Cumulative change in unsaturated storage	<b>one</b>	L3	double	
<i>Dprst_S</i>	Volume of water in surface-depression storage	<b>one</b>	L3	double	new

<i>DprstEvap_Q</i>	Volumetric flow rate of evaporation from surface depressions	<b>one</b>	L3/T	double	new
<i>DunnInterflow2Cap_Q</i>	Volumetric flow rate of cascading Dunnian runoff and interflow to HRUs	<b>one</b>	L3/T	double	<i>basindnflow</i>
<i>DunnInterflow2Lake_Q</i>	Volumetric flow rate of Dunnian runoff and interflow to lakes	<b>one</b>	L3/T	double	<i>basinlakeinsz</i>
<i>DunnSroff2Stream_Q</i>	Volumetric flow rate of Dunnian runoff to streams	<b>one</b>	L3/T	double	<i>basin_dunnian</i>
<i>Grav_S</i>	Volume of water in gravity reservoirs of the soil zone	<b>one</b>	L3	double	<i>basingravstor</i>
<i>gw_rejected</i>	HRU average recharge rejected by UZF	<b>nhru</b>	inches	real	
<i>gw_rejected_grav</i>	Recharge rejected by UZF for each gravity-flow reservoir	<b>nhrucell</b>	inches	real	
<i>gw2sm</i>	HRU average groundwater flow to soil zone	<b>nhru</b>	inches	real	
<i>HortSroff2Lake_Q</i>	Volumetric flow rate of Hortonian surface runoff to lakes	<b>one</b>	L3/T	double	<i>basinhortonianlakes</i>
<i>HortSroff2Stream_Q</i>	Volumetric flow rate of Hortonian runoff to streams	<b>one</b>	L3/T	double	<i>basinhortonian</i>
<i>hru_ag_irr</i>	Depth per unit area of irrigation added to soil-zone capillary reservoir from MODFLOW	<b>nhru</b>	inches	real	new
<i>Imperv_S</i>	Volume of water in impervious reservoirs	<b>one</b>	L3	double	<i>basinimpervstor</i>
<i>ImpervEvap_Q</i>	Volumetric flow rate of evaporation from impervious areas	<b>one</b>	L3/T	double	<i>basinimpervevap</i>
<i>Infil2CapTotal_Q</i>	Volumetric flow rate of soil infiltration into capillary reservoirs (including precipitation, snowmelt, and cascading Hortonian and Dunnian runoff and interflow minus infiltration to preferential-flow reservoirs)	<b>one</b>	L3/T	double	<i>basininfil_tot</i>
<i>Infil2Pref_Q</i>	Volumetric flow rate of soil infiltration into preferential-flow reservoirs (including precipitation, snowmelt, and cascading surface runoff)	<b>one</b>	L3/T	double	<i>basininfil2pref</i>
<i>Infil2Soil_Q</i>	Volumetric flow rate of soil infiltration (including precipitation, snowmelt, and cascading Hortonian flow)	<b>one</b>	L3/T	double	<i>basininfil</i>
<i>Interflow2Stream_Q</i>	Volumetric flow rate of slow and fast interflow to streams	<b>one</b>	L3/T	double	<i>basininterflow</i>
<i>KKITER</i>	Current iteration in GSFLOW simulation	<b>one</b>	none	integer	<i>KKITER</i>
<i>Lake_dS</i>	Change in lake storage	<b>one</b>	L3	double	<i>lake_change_stor</i>
<i>Lake_S</i>	Volume of water in lakes	<b>one</b>	L3	double	<i>lake_stor</i>
<i>Lake2Sat_Q</i>	Volumetric flow rate of lake leakage to the saturated zones	<b>one</b>	L3/T	double	<i>lakebed_loss</i>
<i>Lake2Unsat_Q</i>	Volumetric flow rate of lake leakage to the unsaturated zones	<b>one</b>	L3/T	double	<i>lakebed_loss</i>
<i>LakeEvap_Q</i>	Volumetric flow rate of evaporation from lakes	<b>one</b>	L3/T	double	<i>basinlakeevap</i>
<i>LakeExchng2Sat_Q</i>	Volumetric flow rate of exchange between lakes and the saturated zone (value is equal to <i>Lake2Sat_Q</i> minus <i>SatDisch2Lake_Q</i> , where a negative value indicates a net loss from lakes)	<b>one</b>	L3/T	double	new
<i>LakePrecip_Q</i>	Volumetric flow rate of precipitation on lakes	<b>one</b>	L3/T	double	<i>basinlakeprecip</i>
<i>net_sz2gw</i>	Net volumetric flow rate of gravity drainage from the soil zone to the unsaturated and saturated zones	<b>one</b>	L3/T	double	
<i>NetBoundaryFlow2Sat_Q</i>	Volumetric flow rate to the saturated zone along the external boundary (negative value is flow out of model domain)	<b>one</b>	L3/T	double	<i>gw_inout</i>
<i>NetWellFlow_Q</i>	Net volumetric flow rate of groundwater injection or removal from wells	<b>one</b>	L3/T	double	<i>basinnetgwwell</i>

<i>obs_strmflow</i>	Volumetric flow rate of streamflow measured at a gaging station	<b>one</b>	L3/T	double	
<i>PotGravDrn2Unsat</i>	Potential volumetric flow rate of gravity drainage from the soil zone to the unsaturated zone (before conditions of the unsaturated and saturated zones are applied)	<b>one</b>	L3/T	double	<i>basinsz2gw</i>
<i>Precip_Q</i>	Volumetric flow rate of precipitation	<b>one</b>	L3/T	double	<i>basinppt</i>
<i>Pref_S</i>	Volume of water stored in preferential-flow reservoirs of the soil zone	<b>one</b>	L3	double	<i>basinprefstor</i>
<i>rate_pweqv</i>	Change in snow pack storage	<b>one</b>	L3	double	
<i>rate_satstor</i>	Change in saturated storage	<b>one</b>	L3	double	
<i>rate_soilstor</i>	Change in soil storage	<b>one</b>	L3	double	
<i>rate_uzstor</i>	Change in unsaturated storage	<b>one</b>	L3	double	
<i>reach_cfs</i>	Stream flow leaving each stream reach	<b>nreach</b>	cfs	real	
<i>reach_wse</i>	Water surface elevation in each stream reach	<b>nreach</b>	L	real	
<i>RechargeUnsat2Sat_Q</i>	Volumetric flow rate of recharge from the unsaturated zone to the saturated zone	<b>one</b>	L3/T	double	<i>uzf_recharge</i>
<i>Sat_dS</i>	Change in saturated-zone storage	<b>one</b>	L3	double	<i>sat_change_stor</i>
<i>Sat_S</i>	Volume of water in the saturated zone	<b>one</b>	L3	double	<i>sat_stor</i>
<i>Sat2Grav_Q</i>	Volumetric flow rate of groundwater discharge from the saturated zone to the soil zone	<b>one</b>	L3/T	double	<i>basingw2sz</i>
<i>SatDisch2Lake_Q</i>	Volumetric flow rate of groundwater discharge to lakes	<b>one</b>	L3/T	double	<i>gwwflow2lakes</i>
<i>SatDisch2Stream_Q</i>	Volumetric flow rate of groundwater discharge to streams	<b>one</b>	L3/T	double	<i>gwwflow2strms</i>
<i>SatET_Q</i>	Volumetric flow rate of evapotranspiration from the saturated zone	<b>one</b>	L3/T	double	<i>sat_et</i>
<i>SnowEvap_Q</i>	Volumetric flow rate of snowpack sublimation	<b>one</b>	L3/T	double	<i>basinsnowevap</i>
<i>SnowMelt_Q</i>	Volumetric flow rate of snowmelt	<b>one</b>	L3/T	double	<i>basinsnowmelt</i>
<i>SnowPweqv_S</i>	Volume of water in snowpack storage	<b>one</b>	L3	double	<i>basinpweqv</i>
<i>SoilDrainage2Unsat_Q</i>	Volumetric flow rate of gravity drainage to the unsaturated and saturated zones	<b>one</b>	L3/T	double	<i>uzf_infil</i>
<i>Sroff2Stream_Q</i>	Volumetric flow rate of surface runoff to streams	<b>one</b>	L3/T	double	<i>basinsroff</i>
<i>stream_inflow</i>	Specified volumetric stream inflow into model	<b>one</b>	L3/T	double	
<i>Stream_S</i>	Volume of water stored in streams (non-zero only when transient routing option is used in SFR2)	<b>one</b>	L3	double	<i>strm_stor</i>
<i>Stream2Sat_Q</i>	Volumetric flow rate of stream leakage to saturated zones	<b>one</b>	L3/T	double	<i>streambed_loss</i>
<i>Stream2Unsat_Q</i>	Volumetric flow rate of stream leakage to unsaturated zones	<b>one</b>	L3/T	double	
<i>StreamExchnng2Sat_Q</i>	Volumetric flow rate of exchange between streams and the unsaturated and saturated zones (value is equal to <i>Stream2Sat_Q</i> minus <i>SatDisch2Stream_Q</i> , where a negative value indicates a net loss from streams)	<b>one</b>	L3/T	double	<i>stream_leakage</i>
<i>streamflow_sfr</i>	Volumetric flow rate of streamflow computed by SFR for each segment	<b>nsegment</b>	cfs	real	
<i>StreamOut_Q</i>	Volumetric flow rate of streamflow leaving the model domain	<b>one</b>	L3/T	double	<i>basinstrmflow</i>

<i>SwaleEvap_Q</i>	Volumetric flow rate of evaporation from swale HRUs	<b>one</b>	L3/T	double	<i>basinswaleet</i>
<i>total_pump</i>	Total pumpage from all cells	<b>one</b>	L3	double	
<i>total_pump_cfs</i>	Total pumpage from all cells	<b>one</b>	cfs	double	
<i>Unsat_dS</i>	Change in unsaturated-zone storage	<b>one</b>	L3	double	<i>uzf_del_stor</i>
<i>Unsat_S</i>	Volume of water in the unsaturated zone	<b>one</b>	L3	double	<i>unsat_stor</i>
<i>UnsatDrainageExcess_Q</i>	Volumetric flow rate of gravity drainage from the soil zone not accepted due to conditions in the unsaturated and saturated zones	<b>one</b>	L3/T	double	<i>basinszreject</i>
<i>UnsatET_Q</i>	Volumetric flow rate of evapotranspiration from the unsaturated zone	<b>one</b>	L3/T	double	<i>uzf_et</i>
<i>UnsatStream_dS</i>	Change in unsaturated-zone storage under streams	<b>one</b>	L3	double	<i>sfruz_change_stor</i>
<i>UnsatStream_S</i>	Volume of water in the unsaturated zone under streams	<b>one</b>	L3	double	<i>sfruz_tot_stor</i>
<i>uzf_et</i>	Volumetric flow rate of evapotranspiration from the unsaturated and saturated zones	<b>one</b>	L3/T	double	

---

<sup>1</sup>Dimension variables defined in table 1-1.

**Table 1-6.** GSFLOW output variables written to the GSFLOW Comma-Separated-Values File (supercedes Table 12 in Markstrom and others, 2008; TM 6-D1).  
[HRU, hydrologic response unit; ET, evapotranspiration; cfs: cubic feet per second; L3, cubic length units of MODFLOW; L3/T, cubic length units of MODFLOW per MODFLOW timestep; >, greater than; <, less than]

Variable name	Description	Dimension <sup>1</sup>	Units	Data type	Original Variable Name
<i>BoundaryStreamFlow_Q</i>	Volumetric flowrate of streamflow entering the model domain to SFR	<b>one</b>	L3/T	double	new
<i>Canopy_S</i>	Volume of intercepted precipitation in plant-canopy reservoirs	<b>one</b>	L3	double	<i>basinintcpstor</i>
<i>CanopyEvap_Q</i>	Volumetric flow rate of evaporation of intercepted precipitation	<b>one</b>	L3/T	double	<i>basinintcpevap</i>
<i>Cap_S</i>	Volume of water in capillary reservoirs of the soil zone	<b>one</b>	L3	double	<i>basinsoilmoist</i>
<i>CapET_Q</i>	Volumetric flow rate of evapotranspiration from pervious areas	<b>one</b>	L3/T	double	<i>basinpervet</i>
<i>Dprst_S</i>	Volume of water in surface dpressions	<b>one</b>	L3	double	new
<i>DprstEvap_Q</i>	Volumetric flow rate of evaporation from surface depressions	<b>one</b>	L3/T	double	new
<i>DunnInterflow2Lake_Q</i>	Volumetric flow rate of Dunnian runoff and interflow to lakes	<b>one</b>	L3/T	double	<i>basinlakeinsz</i>
<i>DunnSroff2Stream_Q</i>	Volumetric flow rate of Dunnian runoff to streams	<b>one</b>	L3/T	double	<i>basin_dunnian</i>
<i>Grav_S</i>	Volume of water in gravity reservoirs of the soil zone .	<b>one</b>	L3	double	<i>basingravstor</i>
<i>HortSroff2Lake_Q</i>	Volumetric flow rate of Hortonian runoff to lakes	<b>one</b>	L3/T	double	<i>basinhortonianlakes</i>
<i>HortSroff2Stream_Q</i>	Volumetric flow rate of Hortonian runoff to streams	<b>one</b>	L3/T	double	<i>basinhortonian</i>
<i>Imperv_S</i>	Volume of water in impervious reservoirs	<b>one</b>	L3	double	<i>basinimpervstor</i>
<i>ImpervEvap_Q</i>	Volumetric flow rate of evaporation from impervious areas	<b>one</b>	L3/T	double	<i>basinimpervevap</i>
<i>Infil2Soil_Q</i>	Volumetric flow rate of soil infiltration (including precipitation, snowmelt, and cascading Hortonian flow)	<b>one</b>	L3/T	double	<i>basininfil</i>
<i>Interflow2Stream_Q</i>	Volumetric flow rate of slow plus fast interflow to streams	<b>one</b>	L3/T	double	<i>basininterflow</i>
<i>KKITER</i>	Current iteration in GSFLOW simulation	<b>one</b>	none	integer	<i>KKITER</i>
<i>Lake_S</i>	Volume of water in lakes	<b>one</b>	L3	double	<i>lake_stor</i>
<i>Lake2Unsat_Q</i>	Volumetric flow rate of lake leakage to the unsaturated zones	<b>one</b>	L3/T	double	new
<i>LakeEvap_Q</i>	Volumetric flow rate of evaporation from lakes	<b>one</b>	L3/T	double	<i>basinlakeevap</i>
<i>LakeExchng2Sat_Q</i>	Volumetric flow rate of exchange between lakes and the saturated zone (value is equal to <i>Lake2Sat_Q</i> minus <i>SatDisch2Lake_Q</i> , where a negative value indicates a net loss from lakes)	<b>one</b>	L3/T	double	new
<i>NetBoundaryFlow2Sat_Q</i>	Volumetric flow rate to the saturated zone along the external boundary (negative value is flow out of model domain)	<b>one</b>	L3/T	double	<i>gw_inout</i>
<i>NetWellFlow_Q</i>	Net volumetric flow rate of groundwater injection or removal from wells	<b>one</b>	L3/T	double	<i>basinnetgwwel</i>

<i>Precip_Q</i>	Volumetric flow rate of precipitation	<b>one</b>	L3/T	double	<i>basinppt</i>
<i>RechargeUnsat2Sat_Q</i>	Volumetric flow rate of recharge from the unsaturated zone to the saturated zone	<b>one</b>	L3/T	double	<i>uzf_recharge</i>
<i>Sat_S</i>	Volume of water in the saturated zone	<b>one</b>	L3	double	<i>sat_stor</i>
<i>Sat2Grav_Q</i>	Volumetric flow rate of groundwater discharge from the saturated zone to the soil zone	<b>one</b>	L3/T	double	<i>basingw2sz</i>
<i>SatET_Q</i>	Volumetric flow rate of evapotranspiration from the saturated zone	<b>one</b>	L3/T	double	<i>sat_et</i>
<i>SnowEvap_Q</i>	Volumetric flow rate of snowpack sublimation	<b>one</b>	L3/T	double	<i>basinsnowevap</i>
<i>SnowPweqv_S</i>	Volume of water in snowpack storage	<b>one</b>	L3	double	<i>basinpweqv</i>
<i>SoilDrainage2Unsat_Q</i>	Volumetric flow rate of gravity drainage to the unsaturated and saturated zones	<b>one</b>	L3/T	double	<i>uzf_infil</i>
<i>Stream_S</i>	Volume of water in streams (non-zero only when transient routing option is used in SFR2)	<b>one</b>	L3	double	<i>strm_stor</i>
<i>Stream2Unsat_Q</i>	Volumetric flow rate of stream leakage to the unsaturated zones	<b>one</b>	L3/T	double	<i>new</i>
<i>StreamExchn2Sat_Q</i>	Volumetric flow rate of exchange between streams and the unsaturated and saturated zones (value is equal to <i>Stream2Sat_Q</i> minus <i>SatDisch2Stream_Q</i> , where a negative value indicates a net loss from streams)	<b>one</b>	L3/T	double	<i>stream_leakage</i>
<i>StreamOut_Q</i>	Volumetric flow rate of streamflow leaving the model domain	<b>one</b>	L3/T	double	<i>basinstrmflow</i>
<i>SwaleEvap_Q</i>	Volumetric flow rate of evaporation from swale HRUs	<b>one</b>	L3/T	double	<i>basinswaleet</i>
<i>Unsat_S</i>	Volume of water in the unsaturated zone	<b>one</b>	L3	double	<i>unsat_stor</i>
<i>UnsatET_Q</i>	Volumetric flow rate of evapotranspiration from the unsaturated zone	<b>one</b>	L3/T	double	<i>uzf_et</i>
<i>UnsatStream_S</i>	Volume of water in the unsaturated zone under streams	<b>one</b>	L3	double	<i>sfruz_tot_stor</i>

---

<sup>1</sup>Dimension variables defined in table 1-1