



## **Get started**

### **Install and maintain**

NetApp  
May 19, 2024

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems/get-up-and-run.html> on May 19, 2024. Always check docs.netapp.com for the latest.

# Table of Contents

Get up and running with AFF, ASA and FAS storage systems . . . . . 1

# Get up and running with AFF, ASA and FAS storage systems

To get up and running with AFF, ASA and FAS systems, you install hardware components, cable your hardware, and configure your storage in ONTAP.

If your system is in a MetroCluster configuration, go to the [MetroCluster doc site](#) and follow the install instructions applicable to your MetroCluster configuration type.

Use the following workflow to deploy your storage system when it is not set up in a MetroCluster configuration.

1

## Install switches

Install your switches in the rack or cabinet. Access the following instructions for your switch model.

### Cluster switches

- [Install BES-53248 switch](#)
- [Install Cisco Nexus 9336C-FX2 switch](#)
- [Install NVIDIA SN2100 switch](#)

### Storage switches

- [Install Cisco Nexus 9336C-FX2 switch](#)
- [Install NVIDIA SN2100 switch](#)

### Shared switches

- [Install Cisco Nexus 9336C-FX2 switch](#)

2

## Install platform and shelves

Install your platform and shelves in the cabinet or rack. Access the install and setup instructions for your platform model.

### AFF A-Series systems

- [AFF A150](#)
- [AFF A250](#)
- [AFF A400](#)
- [AFF A800](#)
- [AFF A900](#)

### AFF C-Series systems

- [AFF C190](#)
- [AFF C250](#)

- [AFF C400](#)
- [AFF C800](#)

### **ASA A-Series systems**

- [ASAA150](#)
- [ASAA250](#)
- [ASAA400](#)
- [ASAA800](#)
- [ASAA900](#)

### **ASA C-Series systems**

- [ASA C250](#)
- [ASA C400](#)
- [ASA C800](#)

### **FAS systems**

- [FAS2700](#)
- [FAS2800](#)
- [FAS8300](#)
- [FAS8700](#)
- [FAS9500](#)

**3**

### **Connect cables**

Cable the controllers to your network and then cable the controllers to your shelves. The install and setup instructions for your platform model include instructions for cabling the controller ports to your network and to your switches.

**6**

### **Complete ONTAP configuration**

After you have installed and set up your controllers and switches, you must complete configuring your storage in ONTAP. Access the following instructions according to your deployment configuration.

- For ONTAP deployments, see [Configure ONTAP](#).
- For ONTAP with MetroCluster deployments, see [Configure Metrocluster with ONTAP](#).

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.