

cocotbext FIFO



April 4, 2025

Jay Convertino

Contents

1 Usage	2
1.1 Introduction	2
1.2 Dependencies	2
1.3 In a Simulation	2
2 Architecture	2
2.1 Directory Guide	3
3 Simulation	4
3.1 cocotb	4
4 Code Documentation	5
4.1 init	6
4.2 monitor	7
4.3 driver	9
4.4 absbus	13
4.5 test extension python	15
4.6 test extension verilog	16

1 Usage

1.1 Introduction

Cocotb extension to test FIFO based devices.

1.2 Dependencies

The following are the dependencies of the cores.

- iverilog (simulation)
- cocotb (simulation)
- cocotb-bus (simulation)
- cocotbext-busbase (simulation)

1.3 In a Simulation

Below is a simple example for reading and writing data from register zero in the cocotb extension.

```
source = xilinxFIFOsource(dut, "wr", dut.wr_clk, dut.  
    ↪ wr_rstn, dut.FWFT.value != 0)  
sink = xilinxFIFOsink(dut, "rd", dut.rd_clk, dut.rd_rstn,   
    ↪ dut.FWFT.value != 0)  
  
await source.write(0, 0xAAAAAAAA)  
  
rx_data = await sink.read(0)  
  
assert 0xAAAAAAAA == rx_data, "RECEIVED_DATA_DOES_NOT_  
    ↪ MATCH"
```

2 Architecture

Please see 4 for more information.

xilinxFIFOsource write to Xilinx FIFOs.

xilinxFIFOsink read from Xilinx FIFOs.

xilinxFIFOmonitor tests to make sure signals are proper. N/A

2.1 Directory Guide

Below highlights important folders from the root of the directory.

1. **docs** Contains all documentation related to this project.
 - **manual** Contains user manual and github page that are generated from the latex sources.
2. **cocotbext** Contains source files for the extension
 - **fifo.xilinx** Contains source files for the Xilinx FIFO.
3. **tests** Contains test files for cocotb

3 Simulation

A simulation for testing the cores can be run to verify operation.

3.1 cocotb

To use the cocotb tests you must install the following python libraries.

```
$ pip install cocotb  
$ pip install -e .
```

Then you must enter the tests folder and enter the tests folder. From there you may execute the following command which will kick off the test.

```
$ make
```

4 Code Documentation

Natural docs is used to generate documentation for this project. The next lists the following sections.

- **init** Python init code.
- **monitor** Contains bus monitor code.
- **driver** Contains bus driver code.
- **absbus** Contains bus abstraction for monitor, and driver code.
- **busbase** Contains bus base for threads and read/write methods.
- **cocotb test** Python TestFactory code.
- **cocotb verilog test wrapper** Verilog wrapper module.

__init__.py

AUTHORS

JAY CONVERTINO

DATES

2025/03/27

INFORMATION

Brief

xilinx fifo define for packages

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright (c) 2020 Alex Forencich

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

monitor.py

AUTHORS

JAY CONVERTINO

DATES

2025/03/11

INFORMATION

Brief

Monitor for APB3

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

apb3Monitor

apb3Base

apb3Monitor

Check signals to make sure they are applied properly.

FUNCTIONS

init

```
def __init__(
    self,
    entity,
    name,
    clock,
    resetn,

    args,

    kwargs
)
```

*

**

Setup defaults and call base class constructor.

_check_type

```
def _check_type(
    self,
    trans
)
```

Check and make sure we are only sending apb3trans, this is only here to satisfy the need to have it.

_run

```
async def _run(
    self
)
```

_run thread that deals with checking signals, simple check for now.

driver.py

AUTHORS

JAY CONVERTINO

DATES

2025/03/27

INFORMATION

Brief

Bus Driver for Xilinx FIFO

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

xilinxFIFOsource

xilinxFIFObase

xilinxFIFOsource

Drive xilinx FIFO write interfaces

VARIABLES

signals

```
_signals
```

List of signals that are required

_optional_signals

```
_optional_signals
```

List of optional signals, these will never be required but will be used if found.

FUNCTIONS

__init__

```
def __init__(
    self,
    entity,
    name,
    clock,
    resetn,
    fwft
    =
    False,
    ack
    =
    False,
    args,
    kwargs
)
```

*

**

Setup defaults and call base class constructor.

write

```
async def write(
    self,
    data
)
```

Write to a address some data

_check_type

```
def _check_type(
    self,
    trans
)
```

Check and make sure we are only sending xilinxFIFOtrans

_run

```
async def _run(  
    self  
)
```

_run thread that deals with read and write queues.

xilinxFIFOsink

xilinxFIFObase

xilinxFIFOsink

Drive xilinx FIFO read interfaces

VARIABLES

_signals

_signals

List of signals that are required

_optional_signals

_optional_signals

List of optional signals, these will never be required but will be used if found.

FUNCTIONS

__init__

```
def __init__(  
    self,  
    entity,  
    name,  
    clock,  
    resetn,  
    fwft  
    =  
    False,  
    args,  
    kwargs  
)
```

Setup defaults and call base class constructor.

write

```
async def write(  
    self,  
    data  
)
```

Write to a address some data

read

```
async def read(  
    self,  
    data  
)
```

Read from a address and return data

check_type

```
def _check_type(  
    self,  
    trans  
)
```

Check and make sure we are only sending xilinxFIFOtrans

_run

```
async def _run(  
    self  
)
```

_run thread that deals with read and write queues.

absbus.py

AUTHORS

JAY CONVERTINO

DATES

2025/03/27

INFORMATION

Brief

abstraction of the xilinx fifo bus

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

xilinxFIFOtrans

transaction

xilinxFIFOtrans

create an object that associates a data member and ? for operation.

xilinxFIFOsourceState

enum.IntEnum

xilinxFIFOsourceState

An enum class that provides the current state and will change states per spec.

xilinxFIFOsinkState

enum.IntEnum

xilinxFIFOsinkState

An enum class that provides the current state and will change states per spec.

xilinxFIFObase

busbase

xilinxFIFObase

xilinxFIFOsink

xilinxFIFOsource

abstract base class that defines Xilinx FIFO signals

FUNCTIONS

__init__

```
def __init__(
    self,
    entity,
    name,
    clock,
    resetn,
    fwft
    =
    False,
    ack
    =
    False,
    args,
    kwargs
)
```

Setup defaults and call base class constructor.

TB

TB

Create the device under test which is the master/slave.

FUNCTIONS

run_test

```
async def run_test(  
    dut,  
    payload_data  
    =  
    None  
)
```

Tests the source/sink for valid transmission of data.

incrementing_payload

```
def incrementing_payload()
```

Generate a list of ints that increment from 0 to 2^8

test

```
def test(  
    request  
)
```

Main cocotb function that specifies how to put the test together.

test.v

AUTHORS

JAY CONVERTINO

DATES

2025/03/17

INFORMATION

Brief

Test bench for xilinx fifo using cocotb

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

test

```
module test #(
  parameter
    FIFO_DEPTH
    =
    8,
  parameter
    BYTE_WIDTH
    =
    4,
  parameter
    FWFT
    =
    1
) ( input rd_clk, input rd_rstn, inout rd_en, inout rd_valid, inout [(BYTE_V
```

Test bench loop for xilinx fifo

Parameters

FIFO_DEPTH parameter	Depth of the fifo, must be a power of two number(divisable aka $256 = 2^8$). Any non-power of two will be rounded up to the next closest.
BYTE_WIDTH parameter	How many bytes wide the data in/out will be.
FWFT parameter	1 for first word fall through mode. 0 for normal.

Ports

rd_clk	Clock for read data
rd_rstn	Negative edge reset for read.
rd_en	Active high enable of read interface.
rd_valid	Active high output that the data is valid.
rd_data	Output data
rd_empty	Active high output when read is empty.
wr_clk	Clock for write data
wr_rstn	Negative edge reset for write
wr_en	Active high enable of write interface.
wr_ack	Active high when enabled, that data write has been done.
wr_data	Input data
wr_full	Active high output that the FIFO is full.