

BSA - SECTION C)

D14/4 CARBURETTER C1

INDEX

Page

| | |
|---|----|
| DESCRIPTION | C3 |
| DISMANTLING AND REBUILDING (Concentric Float Chamber) | C3 |
| HINTS AND TIPS | C4 |
| INSPECTING THE CARBURETTER COMPONENTS | C4 |
| TRACING FAULTS | C5 |
| TUNING THE CARBURETTER | C7 |
| VARIABLE SETTINGS AND PARTS | C6 |

D14/4 CARBURETTER C2

FIG. C.1. Concentric carburetter exploded

D14/4 CARBURETTER C3

DESCRIPTION

All the D14 Bantam models are fitted with an Amal carburetter having a concentric float chamber and a cable operated air valve. The only variation between the models is in the lengths of the control cables.

The carburetter, because of the sizes of its jets and choke bore, proportions and atomises just the right amount of petrol and air, to provide the mixture for combustion and give adequate lubrication.

The float chamber maintains a constant level of fuel at the jets and incorporates a valve to cut off the fuel supply when the engine is stopped.

The throttle, opened from the handlebar twist grip, controls the volume of mixture and therefore the power.

At tick-over the mixture is controlled by the pilot jet. As the throttle is opened this is added to by a supply from the main jet, controlled by the needle in the needle jet until, at three-quarter throttle, the main jet takes over.

The pilot supply is controlled by a small jet, situated in the base of the mixing chamber within the float chamber.

The main jet does not spray directly into the mixing chamber, but discharges through the needle jet into the primary air chamber, and goes from there as a rich petrol/air mixture through the primary air choke, into the main air choke. This primary air choke has a compressing action in conjunction with bleed holes in the needle jet, which serves the double purpose of

compensating the mixture from the needle jet and allowing the fuel to provide a well outside and around the needle jet, available for snap acceleration.

The carburettor also has an independently operated mixture control known as an air slide, for use when starting from cold. This slide partially blocks the passage of air through the main choke, enrichening the mixture.

DISMANTLING AND REBUILDING

(Concentric Float Chamber)

Unscrew the two fixing nuts and withdraw the carburettor from its mounting studs; it will not be necessary to detach the cables from the handlebar controls.

Take out the two Phillips-head fixing screws and remove the carburettor top cover complete with throttle valve and air slide assembly. Compress the throttle spring and remove the needle clip to release the needle. Whilst still compressing the spring, push the cable downwards to release the nipple from its location in the valve. Take care not to lose the needle clip when taking off the spring.

To release the air slide, compress the spring and slip the nipple out of the base of the slide.

Unscrew the "banjo" bolt which secures the fuel pipe "banjo" connector to the float needle seating block and withdraw the nylon filter.

The float chamber is secured to the base of the mixing chamber by two screws with spring washers. On removal, it will be noted that the float spindle is a press-fit into the chamber body and that the needle is retained in position by the rear forked end of the float.

The pilot jet, needle jet and main jet (with holder) can now be unscrewed from the mixing chamber base.

Take out the throttle stop adjusting and pilot air adjusting screws and ensure that the small rubber "O"-ring on each screw is in good condition before replacing. These "O"-rings are necessary to retain any adjustments made with the screws.

The float chamber tickler (or primer) consists of a spring and plunger, splayed at one end to retain it in the mixing chamber. This item should not be subjected to a great deal of wear and is therefore unlikely to require replacement.

D14/4 CARBURETTOR C4

Having dismantled the carburettor, carefully clean all parts in petrol (gasoline). Hard deposits on the carburettor body are best removed with a light-grade

wire brush. After washing the parts in clean petrol, allow to dry and ensure that all holes or small drillings are free from dirt. A hand pump is ideal for "blowing through" and blockages in the drillings. Inspect the component parts for wear and check that the jets are in accordance with the recommended sizes in General Data.

Reassembly is simply a reversal of the above instructions but remember to replace any gaskets or "O"-rings that appear unserviceable. Refer to fig. C1 for guidance.

INSPECTING THE CARBURETTER COMPONENTS

The parts most liable to show wear after considerable mileage are the throttle valve slide and the mixing chamber.

(1) Inspect the throttle valve for excessive scoring of the front area and check the extent of wear on the rear slide face. If wear is apparent, the slide should be renewed; be sure to fit valve with correct degree of cut-away (see General Data).

(2) See that the air slide has not been subjected to excessive wear and that it is a good fit in the jet block. Ensure also that the valve return spring is serviceable.

(3) Check the throttle return spring for efficiency. Check also that it has not lost its compressive strength by measuring the free length and comparing it with the figure given on page GD3.

(4) Examine the needle jet for wear or possible scoring and check the tapered end of the needle for similar signs.

(5) Check the float needle for efficiency by inserting it into the float needle seating block, pouring a small amount of petrol (gasoline) into the aperture surrounding the needle and checking it for leakage.

(6) Ensure that the float is not punctured by shaking it to see if it contains any fuel. Do not attempt to repair a damaged float. A new one can be purchased at a small cost.

(7) Check the fuel filter that fits over the needle seating block, for any possible damage to the mesh. If the filter has parted from its supporting structure it will allow the petrol mixture to pass through unfiltered.

HINTS AND TIPS

Throttle Cable

See that there is a minimum of backlash when the twist grip is turned back and that any movement of the handlebar does not cause the throttle to open.

Use the adjuster on the cable to obtain the correct setting and ensure that the throttle valve shuts down freely.

Fuel Feed

Unscrew the float chamber "banjo" bolt, remove the "banjo" and take off the filter gauze from the needle seating.

Ensure that the filter gauze is undamaged and free from all foreign matter. To check fuel flow before replacing the "banjo", turn on fuel tap momentarily and see that the fuel gushes out.

Flooding

This may be due to a worn needle or a punctured float, but is more likely due to impurities (grit, fluff etc.) in the tank. This trouble can sometimes be cleared by periodically cleaning out the float chamber. If, however the trouble persists, the fuel tank must be drained and swilled out.

Carburettor Air Leaks

Erratic slow-running is often caused by air leaks between the joints at the carburettor flange and the cylinder and can be detected by applying oil around the joints.

D14/4 CARBURETTER C5

Eliminate by fitting new joint washers and tightening the flange nuts evenly to a torque wrench setting of 1012 lb./ft.

Also check that the rubber sealing ring in the carburettor flange is undamaged and located correctly.

On much used or old machines look for air leaks caused by a worn throttle.

Banging in Exhaust

This may be caused by too weak a pilot mixture when the throttle is closed or nearly closed. It may also be caused by too rich a pilot mixture and an air leak in the exhaust system. The reason in either case is that

the mixture has not fired in the cylinder but has fired in the hot silencer.

If the banging occurs when the throttle is fairly wide open, the trouble will be traced to ignition, not carburation.

Excessive Fuel Consumption

If this cannot be corrected by normal adjustments, it may be due to flooding caused by impurities from the fuel tank lodging on the float needle seat, so preventing its valve from closing. The float needle should also be checked for wear or damage.

High consumption can also be caused by a worn needle jet and may be remedied or improved by lowering the needle in the throttle. If this method is unsatisfactory, then a new needle and needle jet will have to be fitted.

There are many other causes of high fuel consumption and it should not be assumed that the fault lies in the carburettor alone.

Air Filters

If a carburettor is first set with an air filter and then the engine is run without, the jet setting may be affected and care must be taken to avoid overheating the engine due to a weak mixture. Testing with the air control will indicate if a larger main jet and higher needle position are required.

Air Control

The air control should at all times be kept open except when starting from cold. When the engine fires, the control must be opened.

Repeated operation of the kickstart pedal with the air valve closed results in an accumulation of liquid petrol in the crankcase and until this has been drained away, it will be quite impossible to start. The crankcase drain plug is the smaller of the two plugs under the crankcase. If poor starting re-occurs, then the fault will most likely be found in the ignition system.

Effect of Altitude on a Carburettor

Increased altitude tends to produce a rich mixture; the greater the altitude, the smaller the main jet required.

Carburettors ex-works are suitably set for use in altitudes up of to approximately 3,000 feet.

Carburettors used constantly in altitudes of between 3,000 to 6,000 feet should have a reduction in main jet size of 5 per cent. A further reduction of 4 per cent should be made for every 3,000 feet in excess of 6,000 feet altitude.

No adjustment can be made to compensate