



WisePad™ Q

mPOS Solution Combining Swipe, EMV Contactless, EMV Chip and Pin Card Reading Functions




Support Operating System:
iOS, Android, Windows Phone 8, MS Windows




www.bbpos.com

Index & Accessories (Fig.1)




Index & Accessories (Fig.2)



Package Contents

Device	x 1	Quick start guide (QR code)	x 1
Micro-USB cable	x 1		

Status LED Indicators in Transaction



Product Specifications

Features & Functions	• EMV/PBOC Chip card reader (ISO 7816 Compliant Class A, B, C card) • NFC Reader (EMV contactless, ISO 14443A/B) • Secure PIN pad • Dual Track Magnetic Stripe Card Reader
Display	1.8" LCD, 128x40 dot pixel with backlight
Status Indicator	4 LEDs
Communication Interface	mPOS mode - Bluetooth® BLE 4.2, Micro-USB
Power & Battery	Li-polymer battery, 3.7V, 520mAh
Charging	Via Micro-USB
Support Operating Systems	Android 4.2 or above, iOS 6.0 or above, Windows Phone 8 or above, MS Windows
Operating Temperature	0°C - 45°C (32°F - 113°F)
Operating Humidity	Maximum 95%
Storage Temperature	-20°C - 55°C (-4°F - 131°F)
Storage Humidity	Maximum 95%
Dimensions	94 x 63 x 15.5 mm / 3.7 x 2.48 x 0.61 inch (approx.)
Weight	105 g / 3.7 oz (approx.)

Troubleshooting

Problems	Recommendations
Device cannot be paired	• Please press & hold the power on/off button to restart your device. • Please check if you can find the device's "Serial Number" (Shown on the back of device) in the "Scanned Device List" of your smartphone or tablet.
Display turned off automatically	• The display may turn off after enter the "SLEEP MODE" to save power. Please press and hold the power on/off button to restart it. • The device may be out of power, please use the USB cable to recharge it, then retry.
Device lost the connection with your smartphone or tablet when the device is auto-off.	• Please press and hold the power on/off button to turn on the device again. The device will automatically connect with your smartphone or tablet again. • The device may be at lower battery level, please use the USB cable to recharge it, then retry. • Please ensure the device or smartphone/tablet is within the reception range.
Device cannot read your card successfully through NFC reading	• Please check if your card supports NFC payment. • Please ensure if your card is placed within 4cm range on top of the NFC marking.
Device cannot read your card successfully through NFC reading	• Please check if your card supports NFC payment. • Please ensure if your card is placed within 4cm range on top of the NFC marking. • Please take out your NFC payment card from wallet or purse for payment to avoid any interference.

Troubleshooting

Problems	Recommendations
Device cannot read your card successfully	• Please check if the device has power when operating and ensure devices are connected. • Please ensure that there is no obstacle in the card slots. • Please check if the chip of the card is facing the right direction when inserting card. • Please ensure your phone/tablet is supported model for this device's operation. • Please insert card with a more constant speed.
Device has no response	• Please use a paper clip to press the reset button at the back for reboot.

CAUTION & IMPORTANT NOTES

- Ensure to turn on the *Bluetooth®* function of your smartphone or tablet before use.
- Please fully charge your **WisePad™ Q** before use.
- Please ensure that you have chosen the desired "Pairing" method of **WisePad™ Q** before to start the connection process.
- Please ensure EMV chip of the card is facing the right direction when inserting card.
- Don't drop, disassemble, tear, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign object into the device. Doing any of which will void the Warranty.
- Don't immerse the device into water and place near washbasins or any wet locations. Don't spill any food or liquid on the device. Don't attempt to dry the device with external heat sources, such as microwave or hair dryer.
- Don't use any corrosive solvent or water to clean the device. Recommend using dry cloth to clean the surface only.
- Don't use any sharp tools to point the internal components or connectors, doing which may lead to malfunction and void the Warranty.
- Don't try to disassemble the device to repair. Please contact your dealer for repair and maintenance.
- Please be aware the correct direction of IC card insert. Chips should be facing up and on the left before entering the card slot.




Fig 3 - The correct direction of inserting IC card.

FCC Caution Statements:

FCC Supplier's Declaration of Conformity:

BBPOS / WPC40, WPC41

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

BBPOS Corp.
970 Reserve Drive, Suite 132 Roseville, CA 95678
www.bbpos.com

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.



Need Help?
E: sales@bbpos.com | T: +852 3158 2585



Room 1903-04, 19/F, Tower 2, Nina Tower, No. 8 Yeung Uk Road, Tsuen Wan, Hong Kong
www.bbpos.com

©2017 BBPOS Limited. All rights reserved. BBPOS and WisePad™ are either trademark or registered trademarks of BBPOS Limited. iOS is the trademark of Apple Inc. Android™ is a trademark of Google Inc. Windows® is registered trademark of Microsoft Corporation in the United States and/or other countries. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BBPOS Limited is under license. Other trademarks and trade names are those of their respective owners. All details are subject to change without prior notice.