

UWB Qplatform API

Qorvo

Release R12.7.0-288-gb8203d55886

Contents

1 Overview	3
1.1 Porting guide	3
2 Qplatform API	4
2.1 qplatform_init	4
2.2 qplatform_deinit	5
2.3 qplatform_uwb_interrupt_enable	5
2.4 qplatform_uwb_interrupt_disable	5
2.5 qplatform_uwb_spi_set_fast_rate_freq	6
2.6 qplatform_uwb_spi_set_slow_rate_freq	6
Index	7

1 Overview

Qplatform is the set of platform specific services and drivers offered by a given Hardware platform.

Eventually, Qplatform will replace qhal, and aims at being the sum of different parts:

- UWB-Support Package: The fixed/known support layer for the UWB.
- BLE-Support Package : The fixed/known support layer for BLE/Matter.
- System Support Package : The fixed/known support layer the system (UWB, BLE or UWB + BLE).
- Drivers: Set of drivers offered by the platform. These drivers are not necessarily using a completely fixed API but they should offer at least a common minimal API (see work done on the QHAL front from BLE/Matter) and optionally some custom enhanced APIS. The drivers can be identified as being mostly generic or being completely platform specific. NB: The generic driver can be built on top of the specific ones to offer a simplified API.

On top of Qplatform, qosal offers OS level services (threads, mutexes, etc.).

To port the UWB stack on a given platform, the integrator must provide the UWB-Support package and System Support package.

The drivers are used:

- By the support package to fulfill the services;
- By the application itself when it makes sense.

1.1 Porting guide

1.1.1 Initialization

API `qplatform_init()` allows to initialize the platform system.

It aims at configuring everything which is specific to the platform. For example, it can include (but is not restricted to):

- GPIO configuration
- Powering up/down some peripherals, and initializing them

- Uploading some firmwares
- Etc.

1.1.1.1 QM33 requirements

QM33/DW3000 is a UWB transceiver-only chip. The UWB stack always run on an external MCU, and uses `dwt_uwb_driver` to communicate with the transceiver, using a SPI bus. The platform initialization requires to **configure the SPI driver**. Besides, multiple components (`qhal_qotp`, `l1`) of the UWB stack requires the `dwt_uwb_driver` **driver to be probed**.

`qplatform_init()` is responsible of both SPI and `dwt_uwb_driver` initializations.

Two Qplatform implementations are provided for QM33:

- The first implementation aims at being used with **Zephyr OS**. It can be built by enabling `CONFIG_QPLATFORM_IMPL_QM33_QHAL_ZEPHYR` and relies on Zephyr device tree.
- The second implementation aims at being used for non-zephyr nRFx platforms. It can be built by enabling `CONFIG_QPLATFORM_IMPL_QM33_QHAL_NON_ZEPHYR` and relies on Kconfig parameters to define the platform GPIOs and SPI instance:
 - `CONFIG_DWT_RSTN_GPIO_PORT` and `CONFIG_DWT_RSTN_GPIO_PIN` for **RSTn** GPIO;
 - `CONFIG_DWT_IRQ_GPIO_PORT` and `CONFIG_DWT_IRQ_GPIO_PIN` for **IRQ** GPIO;
 - `CONFIG_SPI_UWB_SCK_GPIO_PORT` and `CONFIG_SPI_UWB_SCK_GPIO_PIN` for **SPI CLK** GPIO;
 - `CONFIG_SPI_UWB_MOSI_GPIO_PORT` and `CONFIG_SPI_UWB_MOSI_GPIO_PIN` for **SPI MOSI** GPIO;
 - `CONFIG_SPI_UWB_MISO_GPIO_PORT` and `CONFIG_SPI_UWB_MISO_GPIO_PIN` for **SPI MISO** GPIO;
 - `CONFIG_SPI_UWB_CS_GPIO_PORT` and `CONFIG_SPI_UWB_CS_GPIO_PIN` for **SPI CS** GPIO;
 - `CONFIG_UWB_SPI_INSTANCE` for the **SPI instance** to use.

Important: Both implementation relies on `qhal_qspi` from `qhal`, and requires that module to be ported on the platform.

Note: `qspi` is planned to be moved from `qhal` to Qplatform in the future.

2 Qplatform API

2.1 `qplatform_init`

enum qerr `qplatform_init`(void)

Initialize the platform.

Parameters

- **void** – no arguments

2.1.1 Description

Initialize what is platform specific in the system. It should be called prior to any other init of the UWB stack.

2.1.2 Return

QERR_SUCCESS or error.

2.2 qplatform_deinit

enum qerr **qplatform_deinit**(void)

Denitalize the platform.

Parameters

- **void** – no arguments

2.2.1 Description

Deinitialize what is platform specific in the system.

2.2.2 Return

QERR_SUCCESS or error.

2.3 qplatform_uwb_interrupt_enable

enum qerr **qplatform_uwb_interrupt_enable**(void)

Enable interrupts for the UWB subsystem.

Parameters

- **void** – no arguments

2.3.1 Return

QERR_SUCCESS or error.

2.4 qplatform_uwb_interrupt_disable

enum qerr **qplatform_uwb_interrupt_disable**(void)

Disable interrupts for the UWB subsystem.

Parameters

- **void** – no arguments

2.4.1 Return

QERR_SUCCESS or error.

2.5 qplatform_uwb_spi_set_fast_rate_freq

void `qplatform_uwb_spi_set_fast_rate_freq`(void)

Configure fast rate frequency for SPI used for the UWB communication, if applicable.

Parameters

- `void` – no arguments

2.6 qplatform_uwb_spi_set_slow_rate_freq

void `qplatform_uwb_spi_set_slow_rate_freq`(void)

Configure slow rate frequency for SPI used for the UWB communication, if applicable.

Parameters

- `void` – no arguments

Index

Q

`qplatform_deinit` (*C function*), [5](#)
`qplatform_init` (*C function*), [4](#)
`qplatform_uwb_interrupt_disable` (*C function*), [5](#)
`qplatform_uwb_interrupt_enable` (*C function*), [5](#)
`qplatform_uwb_spi_set_fast_rate_freq` (*C function*),
[6](#)
`qplatform_uwb_spi_set_slow_rate_freq` (*C function*),
[6](#)