



File System Analytics with System Manager

ONTAP 9

NetApp
December 01, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap/concept_nas_file_system_analytics_overview.html on December 01, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- File System Analytics with System Manager 1
 - File System Analytics overview 1
 - Enable File System Analytics 2
 - View file system activity 2
 - Take corrective action based on analytics 4

File System Analytics with System Manager

File System Analytics overview

File System Analytics is a framework for collecting and displaying data about the contents of a FlexGroup or FlexVol volume.

File System Analytics presents detailed information at each level of the volume's file system hierarchy, allowing you to:

- Assess capacity usage and trends
- Monitor file and directory counts
- Evaluate file activity and history
- Capture information on inactive data
- Take corrective action based on displays (beginning with ONTAP 9.9.1)
- Analyze and download information on high traffic and high throughput activity (beginning with ONTAP 9.10.1)

In ONTAP 9.8 and later, File System Analytics data can be displayed using ONTAP System Manager. You can also use ONTAP REST APIs to access the data programmatically.

NOTES:

- Enabling File System Analytics is expected to have a performance impact. Do not enable analytics if maximal performance is required in your environment. You can also disable analytics if your testing shows that the performance impact is unacceptable. When you disable analytics, previously collected data is no longer displayed for that volume.
- If you have enabled File System Analytics on volumes whose containing SVM is in a protection relationship, the analytics data is not replicated to the destination SVM. If the source SVM must be resynchronized in a recovery operation, you must manually reenables analytics on desired volumes after recovery.
- Beginning with ONTAP 9.9.1, File System Analytics is available for volumes transitioned from 7-mode systems. Nonetheless, because File System Analytics can consume storage space, it should not be run on transitioned volumes that are close to maximum capacity.

File System Analytics is not available for the following volume types:

- SnapMirror destination volumes
- SnapLock volumes
- Volumes containing LUNs
- Volumes used only to hold SMB audit logs (MDV volumes)
- Node root volumes (/mroot)

Feature availability by release

	ONTAP 9.8	ONTAP 9.9.1	ONTAP 9.10.1
Visualization in System Manager	X	X	X

Capacity analytics	X	X	X
Inactive Data information	X	X	X
Availability for volumes transitioned from 7-mode systems		X	X
Option to change Inactive period in System Manager		X	X
Activity Tracking			X
Download to CSV (Activity Tracking)			X

Enable File System Analytics

To collect and display usage data, you must enable File System Analytics. You can do so using System Manager, the ONTAP CLI, or REST APIs.

You can enable File System Analytics when you create a new volume, or when you upgrade a system with volumes to ONTAP 9.8 or later. After upgrading, be sure that all upgrade processes have completed before enabling analytics. Beginning with ONTAP 9.10.1, you can also view the most active files, directories, clients, and users for a selected FlexGroup or FlexVol volume with the Activity Tracking feature.

Depending on the size and contents of the volume, enabling analytics might take some time while ONTAP processes existing data in the volume. System Manager displays progress and presents analytics data when complete. If you need more precise information about initialization progress, you can use the ONTAP CLI command `volume analytics show`.

Procedure to enable File System Analytics

1. Click **Storage > Volumes**, then select the desired volume.
2. Click **Explorer**, then click **Enable Analytics** or **Disable Analytics**.

View file system activity

After File System Analytics is enabled, by default you can view the root directory contents of a selected volume sorted by the spaced used in each subtree.

Clicking on any file system object allows you to browse the file system and to display detailed information about each object in a directory. Information about directories can also be displayed graphically. Over time, historical data is displayed for each subtree. Space used is not sorted if there are more than 3000 directories. Beginning with ONTAP 9.10.1, you can display the hot files, directories, clients, and users in a specified volume for real time performance troubleshooting with [Activity Tracking](#).

Explorer

The File System Analytics **Explorer** screen consists of three areas:

- Tree view of directories and subdirectories; expandable list showing name, size, modify history, and access history.
- Files; showing name, size, and accessed time for the object selected in the directory list.
- Active and inactive data comparison for the object selected in the directory list.

Beginning with ONTAP 9.9.1, you can customize the range to be reported. The default is one year. Based on these customizations, you can take corrective actions, such as moving volumes and modifying the tiering policy.

Accessed time is shown by default. However, if the volume default has been altered from the CLI, by setting the `-atime-update` option to `false` with the `volume modify` command, only last modified time is shown. For example:

- The tree view will not display the **access history**.
- The files view will be altered.
- The active/inactive data view will be based on modified time (`mtime`).

Using these displays, you can examine the following:

- File system locations consuming the most space
- Detailed information about a directory tree, including file and subdirectory count within directories and subdirectories
- File system locations that contain old data (for example, scratch, temp, or log trees)

Keep the following points in mind when interpreting file system analytics output:

- File system analytics show where and when your data is in use, not how much data is being processed. For example, large space consumption by recently accessed or modified files does not necessarily indicate high system processing loads.
- The way that the **Volume Explorer** tab calculates space consumption for file system analytics might differ from other tools. In particular, there could be significant differences compared to the consumption reported in the **Volume Overview** if the volume has storage efficiency features enabled. This is because the **Volume Explorer** tab does not include efficiency savings.
- Due to space limitations in the directory display, it is not possible to view a directory depth greater than 8 levels in the *List View*. To view directories more than 8 levels deep, you must switch to *Graphical View*, locate the desired directory, then switch back to *List View*. This will allow additional screen space in the display.

Procedure

In ONTAP 9.8 and 9.9	Beginning in ONTAP 9.10.1
Click Storage > Volumes , select the desired volume, then click Explorer .	Select Storage > Volumes , select the desired volume. From the individual volume menu, select File System > Explorer .

Activity Tracking

Beginning with ONTAP 9.10.1, you can identify hot objects with Activity Tracking. Activity Tracking enables monitoring in four categories:

- Directories
- Files
- Clients
- Users

For each category monitored, Activity Tracking will display Read IOPs, Write IOPs, Read Throughputs, and Write Throughputs. Queries on Activity Tracking refresh every 10 to 15 seconds pertaining to hot spots seen in the system over the previous five-second interval.

Activity tracking information is approximate, and the accuracy of the data depends on the distribution of the incoming I/O traffic.

When viewing Activity Tracking in System Manager, only the menu of the expanded volume will actively refresh. If the view of any volumes are collapsed, they will not refresh until the volume display is expanded. You can stop the refreshes with the **Pause Refresh** button. Activity data can be downloaded in a CSV format that will display all the point in time data captured for the selected volume.

Steps

1. Select **Storage > Volumes**. Select the desired volume. From the individual volume menu, select File System and then select the Activity tab.
2. Ensure **Activity Tracking** is on to view individual reports on top directories, files, clients, and users.
3. To analyze data in greater depth without refreshes, select **Pause Refresh**. You can download the data to have a CSV record of the report as well.

Take corrective action based on analytics

Beginning with ONTAP 9.9.1, you can take corrective actions directly from File System Analytics displays based on current data and desired outcomes.

When analytics are enabled, you can take the following actions:

- delete directories and files

In the Explorer display, you can select directories or individual files to delete. Directories are deleted with low-latency fast directory delete functionality. (Fast directory delete is also available beginning in ONTAP 9.9.1 without analytics enabled.)

- assign media cost in storage tiers to compare costs of inactive data storage locations

Media cost is a value that you assign based on your evaluation of storage costs, represented as your choice of currency per GB. When set, ONTAP System Manager uses the assigned media cost to project estimated savings when you move volumes.


The media cost you set is not persistent; it can only be set for a single browser session.

- move volumes to reduce storage costs

Based on analytics displays and media cost comparisons, you can move volumes to less expensive storage in local tiers.

Only one volume at a time can be compared and moved.

Table 1. Steps

To perform this action...	Take these steps...
Delete directories or files	<ol style="list-style-type: none"> 1. Click Storage > Volumes, then click Explorer. When you hover over a file or folder, the option to delete appears. You can only delete one object at a time. <p>Note When directories and files are deleted, the new storage capacity values are not displayed immediately.</p>
Enable media cost comparison	<ol style="list-style-type: none"> 1. Click Storage > Tiers, then click Set Media Cost in the desired local tier (aggregate) tiles. Be sure to select active and inactive tiers to enable comparison. 2. Enter a currency type and amount. When you enter or change the media cost, the change is made in all media types.
Move volumes to a less expensive tier	<ol style="list-style-type: none"> 1. After enabling media cost display, click Storage > Tiers, then click Volumes. 2. To compare destination options for a volume, click  for the volume, then click Move. 3. In the Select Destination Local Tier display, select destination tiers to display the estimated cost difference. 4. After comparing options, select the desired tier and click Move.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.