




Quark

VoiceMail Configuration Setup on Cisco 7941 Phones



Press the “Messages” button on Cisco phone, an automated prompt system will guide through the self-enrolment -

(Initial default PIN : 160059)

After entering PIN, Use “Setup options” by pressing 4 to configure or change **greeting , message settings, preferences, transfer settings.**

At any time during above setup –


Use ‘0’ for “Help” and ‘*’ to ‘Cancel or back up’

0 Help

***** Cancel or back up

Refer to next page for detailed Voice Mail flow options.

Retrieve Messages



During Message

- | | |
|-------------------|------------------------------|
| 1 Restart message | 7 Rewind message |
| 2 Save | 8 Pause/Resume |
| 3 Delete | 9 Fast-forward |
| 4 Slow playback | # Fast-forward to end |
| 5 Change volume* | # # Skip message, save as is |
| 6 Fast playback | |

After Message


- | | |
|--------------------------|-------------------------------|
| 1 Replay message | 5 Forward message |
| 2 Save/Restore as saved* | 6 Save as new/Restore as new* |
| 3 Delete | 7 Rewind message |
| 4 Reply | 9 Play message properties |
| 4 2 Reply to all | # Save as is |
| 4 4 Call the user* | |

Find Voice Messages


5 Find messages*

- 1 From another user
- 2 From all outside callers
- 3 From a specific outside caller

Send a Message



Change Preferences



Use These Keys Anytime

- 0 Help * Cancel or back up

*Not available on some systems.