

Q 1.

# Stress When depth is constant

Q = float (input ("Enter the value of Load in kN: "))

N= int (input ("Number of data values of radial distance: "))

pi = 3.14159265359

Z = float (input ("Depth: "))

r = []

for i in range (1, N+1):

print ("Enter radial distance in m".format (i))

Value\_r = float(input () )

r.append (Value\_r)

Stress = ((3\*Q)/(2\*pi\*Z\*Z))\*(((1 / (1+((Value\_r/Z)\*\*2))))\*\*2.5)

print("Stress:" , Stress, "kN/m^2")

```

Enter the value of Load in kN: 2500
Number of data values of radial distance: 5
Depth: 6
Enter radial distance in m
1
Stress: 30.962130445358056 kN/m^2
Enter radial distance in m
2
Stress: 25.479163627894877 kN/m^2
Enter radial distance in m
3
Stress: 18.98033449112347 kN/m^2
Enter radial distance in m
4
Stress: 13.22290223969301 kN/m^2
Enter radial distance in m
5
Stress: 8.871775810212231 kN/m^2

```

Q 2.

# Stress when Radius is Constant

Q = float (input("Enter the value of Load in kN: "))

M= int (input ("Number of data values of depth: "))

pi = 3.14159265359

r = float (input("Radial Distance: "))

Z = []

for j in range (1, M+1):

print ("Enter depth in Z".format(j))

Value\_Z = float(input())

Z.append (Value\_Z)

Stress = ((3\*Q)/(2\*pi\*Value\_Z\*Value\_Z))\*(((1 / (1+((r/Value\_Z)\*\*2))))\*\*2.5)

print("Stress:" , Stress, "kN/m^2")

```

Enter the value of Load in kN: 2500
Number of data values of depth: 6
Radial Distance: 5
Enter depth in Z
1
Stress: 0.34629643854273023 kN/m^2
Enter depth in Z
2
Stress: 2.1085135063018074 kN/m^2
Enter depth in Z
3
Stress: 4.781320614736756 kN/m^2
Enter depth in Z
4
Stress: 7.0974399578803125 kN/m^2
Enter depth in Z
5
Stress: 8.440465463972316 kN/m^2
Enter depth in Z
6
Stress: 8.871775810212231 kN/m^2

```

```
Q 3.  
#Calculating the stress by Boussineq's Theory  
Q=int(input("Enter the value of given load :"))  
z=int(input("Enter the distance of vertical stress :"))  
r = int(input("Enter the distance of horizontal stress:"))  
stress = (3*Q*((1/(1+(r/z)**2))**2.5))/(2*3.14*(z**2))  
print("The value of stress is",stress)
```

```
Enter the value of given load :2500  
Enter the distance of vertical stress :6  
Enter the distance of horizontal stress:5  
The value of stress is 8.876275703713446
```

Kaushal Shinde