

Section 2.3 — Load and Store Instructions in ARM (Mazidi)

2025-09-01

Chapter 2 • Section 2.3 — Exercises (Mazidi)

Problems are paraphrased to respect copyright. For theory and examples, see **Mazidi, Ch. 2 §2.3**.

25) Show a simple code to store values 0x30 and 0x97 into locations 0x20000015 and 0x20000016, respectively.

Approach: Use **byte stores** (STRB) because the addresses are **unaligned**. Load the base address with LDR r0,=imm.

```

AREA    |.text|, CODE, READONLY
EXPORT  _start
THUMB
_start:
    LDR    r0, =0x20000015    ; first byte address
    MOVS   r1, #0x30
    STRB   r1, [r0]           ; [0x20000015] = 0x30

    ADDS   r0, r0, #1         ; next byte address 0x20000016
    MOVS   r1, #0x97
    STRB   r1, [r0]           ; [0x20000016] = 0x97

    B      .
    END

```

Explanation: STRB writes a single byte; no alignment issues.

26) Show a simple code to load the value 0x55 into locations 0x20000030–0x20000038.

Approach: Fill a **range of 9 bytes** starting at 0x20000030 with 0x55 via a loop.

```

AREA    |.text|, CODE, READONLY
EXPORT  _start
THUMB
_start:
    LDR    r0, =0x20000030    ; start address
    MOVS   r1, #0x55          ; byte to store
    MOVS   r2, #9             ; count: 0x30..0x38 inclusive

fill15:
    STRB   r1, [r0]           ; *r0 = 0x55
    ADDS   r0, r0, #1         ; next byte
    SUBS   r2, r2, #1
    BNE    fill15

    B      .
    END

```

Explanation: Because the range is byte-wise and inclusive, $\text{count} = \text{last} - \text{first} + 1 = 0x38 - 0x30 + 1 = 9$.

27) True or False. We cannot load immediate values into the data SRAM directly.

Answer: True (in the strict instruction sense).

Why: There is **no store-immediate** form. You first load the immediate into a **register** (e.g., `MOVS r1, #imm`) and then **store** it with `STR/STRB` to SRAM.

28) Show a simple code to load the value 0x11 into locations 0x20000010–0x20000015.

Approach: Fill a **range of 6 bytes** with 0x11 using `STRB` and a counter.

```

        AREA    |.text|, CODE, READONLY
        EXPORT  _start
        THUMB

_start:
    LDR    r0, =0x20000010    ; start address
    MOVS    r1, #0x11          ; byte to store
    MOVS    r2, #6              ; 0x10..0x15 inclusive

fill11:
    STRB    r1, [r0]
    ADDS    r0, r0, #1
    SUBS    r2, r2, #1
    BNE     fill11

    B       .
    END

```

Explanation: $\text{count} = 0x15 - 0x10 + 1 = 6$.

29) Repeat Problem 28, except load the value into locations 0x20000034–0x2000003C.

Approach: Same loop; **9 bytes** from 0x34 to 0x3C inclusive.

```

        AREA    |.text|, CODE, READONLY
        EXPORT  _start
        THUMB

_start:
    LDR    r0, =0x20000034
    MOVS    r1, #0x11          ; requested value
    MOVS    r2, #9              ; 0x34..0x3C inclusive

fill_more:
    STRB    r1, [r0]
    ADDS    r0, r0, #1
    SUBS    r2, r2, #1
    BNE     fill_more

    B       .
    END

```

Explanation: $\text{count} = 0x3C - 0x34 + 1 = 9$.

Notes for learners

- Use `STRB` for byte writes; `STR` for word (aligned) writes.
- The pseudo-instruction `LDR Rd, =imm` loads 32-bit addresses/constants via a literal pool—handy for SRAM addresses like **0x2000_XXXX**.
- For inclusive ranges: **count = last – first + 1**.