

CPU09MM3 - GAL Selection Table.

Type	I/O	G1	G2	G3	Programmer
GAL16V8A-15LP	2	x	x	x	1, 2
GAL16V8B-15LP	1	x	x	x	1, 2
GAL16V8D-15LP	1	x	x	x	1, 2
GAL16V8D-25LP	1	x	x	x	1, 2
GAL22V10B-15LP	3	CPU_1	CPU_2	CPU_3	1, 2
GAL22V10D-15LP	3	CPU_1	CPU_2	CPU_3	1, 2
ATF16V8B-15PC	1	x	x	x	2, 3, 1
ATF16V8B-25PC	1	x	x	x	2, 3, 1
ATF22V10B-15PC	1	ATF-CPU_1	ATF-CPU_2	ATF-CPU_3	2, 3, 1
ATF22V10C-15PC	5	ATF-CPU_1	ATF-CPU_2	ATF-CPU_3	2, 3, 1
PALCE16V8-15PC	1	x	x	x	2
PALCE16V8-25PC	1	x	x	x	2
PALCE16V8H-15PC/4	4	x	x	x	2, 3
PALCE16V8H-25PC	4	x	x	x	2, 3
PALCE22V10H-15PC	4				2
PALCE22V10H-25PC	4				2
PALCE22V10Q-25PC	4	CPU_1	CPU_2	CPU_3	2

Tested

Any open field means not used/tested

First nr preferred

Also tested a mix ATF / GAL / PALCE and -15 / -25

I/O: 1 = I/O 50K pull up 2 = I/O No pull up 3 = I/O Active pull up 4 = 100K 50K No pull up 5 = I/O Pin keeper	Programmer: 1 = Xgpro TL866II Plus, software version 12.67 2 = GALEP-4, software Galep32 Version 1.20.4 3 = TOP2013, software Ver. 8.92
---	--

Remarks: I/O type 4 depending on device suffix /4 = 100K, /5 = 50K, otherwise NO pull-up
I/O type 2,4 and 5 may need a pull-up on floating input pins.
Some ATF16V8B had errors on the TL866II Plus but not on the GALEP-4.
Do select the full name in the programmer A, B, C, D, H or Q version !
Otherwise you will get programming errors !
TOP2013 also select the correct speed -10, -15 or -25 !