




Kellfri[®]

27-V18ATV ATV ROAD DRAG



**CAREFULLY READ THE OPERATING INSTRUCTIONS BEFORE USING THE PRODUCT!!
TRANSLATED FROM THE ORIGINAL**

INTRODUCTION

Thank you for choosing a product from Kellfri AB. By following the general safety information and the instruction manual and by using common sense, you will have a great and safety use of your Kellfri product for many years. Kellfris tools and products aimed at the self operateing farmer with high demands on functionality.

PRODUCT INFORMATION

Grader with rotatable edge steel for ATV or small tractor, angled steel and individually adjustable wheels for grading road angles. Powerful wheels, stable fully galvanised frame for half pallet, 50 mm rotatable ball coupling, working width 180 cm, blade length 193 cm. Wheels adjustable 15 cm individually, making it easy to retract gravel verges into the road, scrape and level roads, courtyards and paddocks, etc.

ART. NO	27-V18ATV
Length	1950 mm
Working width	1800 mm
Height	Adjustable up to 150 mm
Weight	85 kg
Wheels	4.80/4.00-8
Wheel width	1600 mm
Ball coupling	50 mm

INTENDED USE

Intended to scrape gravel paths, horse riding tracks and bridleways.

SAFETY INSTRUCTIONS

Before using the equipment or product, and for the safety of yourself and others, you must read the safety instructions and the instruction manual and understand its contents. Always keep the safety instructions and instruction manual handy for users of the equipment or product. For the safety of both yourself and others, it may be a good idea to read through the safety instructions every now and then. If the safety instructions or instruction manual gets damaged or in any other way cannot be used, new copies may be ordered from:

Kellfri AB, Munkatorpsgatan 6, 532 37 SKARA

Sweden. Tel.: +46 (0)511 242 50 (Pls. contact the retailer) <https://www.kellfri.co.uk/>

Do not use the equipment or product if you feel ill, tired or are under the influence of alcohol.

Do not use the equipment or product if you are taking prescribed medication or drugs. Always comply with general rules of the road and applicable rules stipulated by the Protection of Animals Act. People under the age of 15 are not allowed to use the equipment.










PRODUCT SAFETY INSTRUCTIONS

- It is the user's responsibility to read through the instructions and comply with them. Read the ATV manual before connecting the implement.
- Always check that the performance of the machine combination to be used with to guarantee safety and functionality.
- Never leave the driver's seat until the brakes on the towing vehicle have been applied.
- The risk area is 5 metres. Only the operator is allowed to be within the risk area while the trailer is in use.
- When unhitching the implement, it must be empty and on a level surface with the trailer wheels secured using suitable brake blocks.
- To stop the implements movements in the event of emergency, stop the ATV.
- The implement is not equipped with lights and is only intended to be used during the day. If necessary, the implement can be fitted with a magnetic rear light.
- An SMV sign must be attached when travelling on public roads.
- The road drag is fitted with a 50 mm ball coupling. Regularly check the coupling for wear and tear. EU has regulations on how fast a tractor with a non-brake trailer is allowed to go. Comply with these regulations.
- Make sure that ATV'n has enough weight in the front for safe driving. Avoid fast movements.
- When servicing the equipment, put the implement on level ground.

WARNING DECALS

Make sure that the warning decals are always visible, clean the warning labels if necessary. Do not wash with high pressure washer directly on the warning label. If any part of the decal is worn or label becomes frayed or otherwise unreadable, order new decals.

When traveling on public roads, SMV plate must be fixed,visibly and clearly.

SYMBOL	EXPLANATION
	<p>Read the operating manual! Stop the engine for repairs</p>
	<p>Risk zone 5 m</p>
 <p>Smörjning efter 10 tim. i drift</p>  <p>Efterdrag samtliga skruvar och kopplingar</p>	<p>Greasing after 10 hours of operation Retighten all bolts and connections</p>
 	<p>Warning! Accident risk for children! Children are not allowed in the vicinity of the machine Prohibition to stay on the machine</p>
	<p>The product is CE marked</p>

INCASE OF EMERGENCIES

In case of an emergency please dial 112.

Keep cell phone or emergency phone available specially when working alone. First aid kit and fire extinguishers must be kept easily accesable during all work, maintenance and service.

PERSONAL PROTECTIVE EQUIPMENT

Wear suitable clothing and footwear. Do not wear loose clothing or jewelry when working with the equipment. Remember to put up long hair when working with equipment that rotates. Wear protective gloves during maintenance.

SURROUNDINGS

Check and make sure that the area is clear of people, children and objects before switching on or using the equipment. Risk of serious personal injury. Be especially careful if children are in the area where the equipment is being use or stored. Check that there are no low-hanging power lines within the work area. Be careful when working on slopes and near ditches.

Always work alone with equipment designed for single - purpose tools/products. Never have junk/debris lying in your work area. Have workspaces clean. Always respect the risk zone.



BEFORE USING


Read the instruction manual carefully. Be sure that you understand the safety information, instruction manual and warning labels. Use common sense when using and use the appropriate personal protective equipment. Always check the performance of the machine combination to be used. Importantly, these harmonize and match in a satisfactory manner. This is to ensure the implement function and your and others' safety.

Visually inspect the gear or the product before use. Fix or replace damaged and worn parts immediately to reduce the risk of injury. Lubricate moving parts and check that all screw-nuts and bolts are tightened. Clearing when necessary.

Learn and remember the correct working methods. Beginners should always keep a low speed, use extreme caution before routine and product knowledge is achieved. The user/customer is responsible to handle the situation correctly. The product should not be taken into use unless it can be done in a safe way for the user.

USE / OPERATION

Only people who understand the safety information and instructions in this manual may operate the equipment. Be alert and careful when working with the machine and only use the tool or product in the manner described in this manual. When working with equipment that has moving parts, there is always the risk of injury. Be careful when working with equipment equipped with hydraulic hoses ,oil under pressure can penetrate the skin. Seek medical attention immediately if this occurs. Always work alone with the tools that are defined as single purpose tools. Respect the equipment's danger zone.



IMPLEMENT CONNECTIVITY

- Check that the equipment is not damaged before connecting it to the vehicle.
- Mount the implement to the towing vehicle. Secure the ball-coupling
- Set the desired height of the blade.
- Drive and control the implement.

USE

- Check the surface before driving
- Reduce speed when working on slopes and uneven terrain.
- Practice the movement pattern calmly and methodically.
- Maximum speed when driving 10 km / h.
- If the ground need more weight during processing, the frame is made to carry a half pallet to use as ballast.



TRANSPORT AND STORING

Make sure there are no people, children and foreign objects around the area before transporting the machine. Always take an extra caution during the transport. Ensure that the product is well secured and that transport brackets are mounted. Always place the load as low as possible. Respect the danger zone even during transport. When lifting the equipment, never go underneath suspended loads. Trailer used for transport should have working brakes.

Always store the machine in a dry place preferably underneath a cover when not in use. Ensure that the product is stable and not likely to tip over. Never let children play where the machine is being stored. Always keep in mind the risk of tipping!

STORAGE

To extend the life of the product,keep it under cover when not in use.

MAINTENANCE AND SERVICE

Ensure that the unit is stable and cannot tip over during maintenance and service. Replace damaged or worn parts immediately to reduce the risk of abrasion. Always perform maintenance, service and inspection, as recommended. Use only original replacement parts or spare parts with equivalent performance to reduce the risk of damage.

Check all nuts and bolts are tightened after performing maintenance and service.Never weld towing eye as it alters the strength!Contact Kelfri for spare parts.

ART. NO.	SPARE PARTS LIST V18 ATV
R27-V18ATV.001	Blade
R27-V18ATV.002	Wheel incl. height adjustment

INSTALLATION INSTRUCTIONS

Check so that all parts are included, the mounting bolts are mounted on the frame.



1 x Frame



1 x Tow bar




2 x Wheels - left and right wheel




1 x Grader blade


INSTALLATION INSTRUCTIONS




1. Attach the wheels to the frame, note: right and left wheels



2. Flip the frame and then mount the blade, be careful and ensure that the frame assembly can not overturn.



3. Mount the drawbar, then place the trailer gently on the ground. Check and tighten all bolts.



We are grateful for your help pointing out any inaccuracies in the Kellfri product delivered to you. Before making a complaint read Kellfris general warranty and sales conditions in our catalog as well as the enclosed User's manual that comes with the product.

Please fill in the details below and attach photo and other information in order to process your request.

Buyer:	Customer number:
Adress:	Invoice number:
E-mail:	Phone nr:

When was the product delivered?	When was the product taken into operation?	Did the product functioned as it should upon the first operation?
--	---	--

Defect product / part:

.....

Problem description:

.....

.....

Describe the sequence of events:

.....

.....

.....

.....

.....

.....

Other:

.....

.....

Submit Complaint form and photo to:

Kellfri AB

Division of service: (Contact Kellfri retailer)

Munkatorpsgratan 6

532 37 Skara

Or e-mail service.

info@kellfri.se

Signature:	Date:
-------------------	--------------

KELLFRI AB

Munkatorpsgratan 6

SE-532 37 SKARA

Phone: +46 (0)511-242 50

Fax: +46 (0)511-168 33

Web

www.kellfri.se

E-mail

info@kellfri.se

Issue: 2014-01-01

WARRANTY TERMS AND CONDITIONS

- | | |
|-----------------------------|--|
| Validity of the warranty | - Kellfri's Warranty is valid 12 months from the date of purchase |
| This warranty replaces | - Compensation for spare parts after acknowledgment that the fault lies on the material or manufacturing defects. |
| This guarantee do not cover | <ul style="list-style-type: none">• Labour costs• Travel expenses• Any modification that the buyer himself has/had made.• Any consequential damages that occurred out of damage to the machine.• Damage due to normal deterioration of the machine, inadequate: service, user inexperience or use of spare parts which are not original.• Wear parts such as hoses, seals, oils, and mechanical belts |

EG-FÖRSÄKRAN OM MASKINENS ÖVERENSTÄMMELSE, ORIGINAL

EC-DECLARATION OF CONFORMITY

According to 2006/42/EC, Annex 2A

Kellfri AB

Munkatorpsgratan 6

532 37 Skara, Sweden

Declares that the machine

Name: 27-V18ATV

Type: ATV Road Drag

Complies with all applicable provisions of the Machinery Directive 2006/42/EC.

Other equipment must meet the hardware requirements of the Directive



Tina Baudtler, VD

Kellfri AB is constantly working on further developing their products and therefore reserves the right to modify, among other things the design and appearance without notice

CUSTOMER SERVICE

You are always welcome to give your feedbacks, reviews or ask us about our tools and products.

Kellfri AB

Telefon: 0046 (0)511 - 242 50

Fax: 0046 (0)511 - 168 33

E-post: info@kellfri.se

