


PiTalk

Instruction Manual



1. Home Screen and Menu

This section helps you navigate through your home screen and Menu pages

1. Home screen



2. Menu Screen



Prev
Page

Home
button


Next
Page

The Prev and next button helps in navigating between the different menu screens. The home button takes back to the home screen.

In the following sections we'll go through the different buttons in the menu screen in the order of their arrangement

3. Call Screen

Pressing the call Icon on either home screen on the menu screen takes you to this window.




Dial Number: Dialed Number appears here.

Call Button: Pressing the Call button makes a call to the dialed number

Delete Button: Delete a single number at a time from Dial Number

Dialpad: Standard Dialpad used to dial numbers

Pressing the call button takes you to the next screen.



The dialed number is displayed above, the three buttons accompanying it are as follows.

Disconnect: Disconnects the outgoing call and takes you back to the home screen


Headphone Mode: Routes the audio to the Headphone Jack

NOTE: After this selection, the default audio for all functions is routed to the headphone jack

Speaker Mode: Routes the audio to the connected external speaker


NOTE: After this selection, the default audio for all functions is routed to the external speaker. The Label displays the current audio mode.

During an incoming call, the screen switches to the following screen:



4. SMS Screen

Pressing the SMS button in the menu screen brings you to this screen



Description of each button in this screen is as follows


1. Create New: This screen lets you send a regular SMS to the recipient number. Carrier charges apply.

Recipient


Text Body

A screenshot of the 'Create New' SMS screen. The status bar at the top shows 'Vodafone' in green, the time '07:39:50' in orange, and a signal strength indicator. The screen has a white background. At the top, there is a 'To:' label followed by a text input field containing the number '12345678'. To the right of this field is a green button with the word 'SEND' in white. Below the 'To:' field is a large text input area containing the text 'Hello world !!'. At the bottom of the screen is a virtual keyboard with a grid of buttons. The buttons are labeled with letters, numbers, and symbols. The bottom row of the keyboard includes a 'HOME' button, an 'UP' button, a 'space' button, a 'SYM' button, and a 'DEL' button.

2. Inbox: This screen lets you view incoming SMS sent to your SIM Card




3. Selecting a message from the list above brings you to the following screen, which has the body of the SMS along with the option to reply.




The New SMS indicator is visible across all screens and only goes away if the user has read his unread messages. The unread SMS turns white from yellow in the message list. The scrollbar on the right helps navigate the list of received SMS.

4. Delete: Tapping on this button lets you delete all your received SMS from the MODULE or the memory in which the user is storing his SMS while maintaining their copies in Inbox and SMS log. It asks the user for a confirmation before deleting all SMS.



5. Camera Screen

Tapping the camera Icon on either the home screen or the menu screen brings you to this screen.




The different buttons and labels with their functions are described as follows:

1. Photo Button: This button lets you click photos from your camera attached with the raspberry pi.
2. Error Label: This error label pops up on the screen whenever the following scenario happens
 - a. Camera is not enabled in the Raspberry Pi
 - b. Camera is enabled but not connected to the Raspberry Pi
 - c. Camera is connected but the connection is not proper
3. Back Button: This button lets you go back to the menu screen. It remains disabled unless the camera is connected.
4. Home Button: This button sends the user back to the home screen.

NOTE: To use the camera, you need to connect a Pi compatible camera (sold separately) and attach it to the raspberry pi via SUNNY connector

6. Internet Screen



Pressing this icon brings you to the following screen

The description of the labeled buttons and entries are as follows:

APN: This entry takes in the APN of your Network Carrier

Port: This entry takes in the Comm Port assigned to it by the raspberry Pi. The format is `ttyxxx` where x is the port assigned to it by the Raspberry Pi.

NOTE: It is recommended that the user connects the shield to the Pi along with mounting it over via GPIO pins and writing the port as `'ttyUSBx'` where x is usually 3. This helps in uninterrupted AT communication of the shield with the GSM module via UART1 and internet is routed via UART2


Connect Button: This button connects the phone to the internet by taking the values from APN and Port. On successful connection it will pop a label with the text 'Connected' when the user presses the Status button.

Disconnect Button: This button allows the user to disconnect from the internet (if connected previously).

Status Button: This button checks the status of the internet connection. It pops a green 'connected' or a red 'disconnected' depending on the connection.

7. Gallery Screen

Tapping on the gallery icon in the menu brings you to this screen.




The function of the buttons and labels are as follows:

1. Photo Button: Views the photos stored in the memory. The photos are stored in “./Gallery/Images” where “.” Represents the directory in which PiTalk folder is located. It gets disabled when pressed and the error label shows “No Image” if the image folder is empty.
2. Photo Navigation Buttons: The navigation buttons help navigating between different photos, and the photos are shown one at a time. They remain disabled until the user press the Photo Button AND there are images to be displayed.
3. Error Label/ Image counter: The error label shows the error mentioned above in case of no photo/video and shows the total Images in the photo section when viewing the photos.
4. Home Button: This button takes the user back to the home screen


8. Settings Screen

Tapping this icon in the menu screen lets you access the general settings of the PiTalk




The description of the various settings are as follows:

1. Screen Orientation



The buttons are as follows:

1. Rotate 0°: Rotates the display output to the default position i.e., landscape mode.
2. Rotate 90°: Rotates the display output by 90 degrees. (Portrait Mode)
3. Rotate 180°: Rotates the display output by 180 degrees. (Landscape Mode)
4. Rotate 270°: Rotates the display output by 270 degrees.
5. NOTE: While the display output will still show on HDMI, it is recommended to view the rotated outputs on the respective LCD as the HDMI output will be zoomed in which might decrease the viewing aesthetics of the GUI




2. Call Settings


The description of the various buttons and labels are as follows:

1. Ring Counter: This counter goes from 0 to 10 and allows the user to set a fixed number of rings before automatically picking up an incoming call
2. Call Forward Number: User can type a number here with the help of the dialpad on which he needs his calls to be forwarded. The call forwarding is unconditional i.e., it will forward all calls until disabled. Carrier charges may apply.
3. Set Button: This button sets the number of rings displayed on the ring counter as the number of rings after which an incoming call is automatically connected
4. Enable Button: This button enables call forwarding and sets the number displayed on the entry as the default call forwarding destination. Invalid number or incorrect format (as shown) will result in a warning label popping up saying "Incorrect Format"
5. Check Button: This button checks the state of call forwarding and it returns the following
 - a. The number to which calls are being forwarded, displayed in the entry box
 - b. N/A if no number is set or if call forwarding is disabled
6. Disable Button: This button deletes the stored number for call forwarding and disables call forwarding. To enable call forwarding again, user needs to type in a number and press the enable button.

7. Back, Delete, Home Buttons: These buttons work the same as described on various occasions above.
3. HDMI Mode
- As described in the picture above, pressing OK will reboot the raspberry Pi and PiTalk and changes the default output to HDMI




4. Logs
- Logs of all the user's calls and SMS are stored in "./Logs" where "." Represents the current directory in which PiTalk folders are located. User can enable/disable or delete his logs with the help of the buttons displayed above




5. Shutdown

As written in the screenshot, pressing OK will shut down your GUI and PiTalk, taking the user back to raspberry Pi's desktop



9. Stopwatch Screen

Tapping on this icon in the menu screen will open up this screen




The functionality of the various buttons are as follows:

1. Play Button: This button starts the stopwatch counter
2. Stop Button: This button pauses the stopwatch counter when pressed.
3. Reset Button: This button resets the stopwatch counter back to 00:00:00.

Back and Home buttons work the same way as described above

10. Location Screen


Tapping on this icon in the menu screen brings this screen forward.



Pressing the “Get Position” button on this screen will display the current latitude and longitude of the shield.

11. Calculator Screen


Pressing the calculator Icon brings the user to the following screen



It functions as a regular calculator with symbols representing their usual meaning. The back and home buttons take the user back to menu screen and back to home screen respectively.

12. Audio Screen

Pressing this icon on the second page of the menu screen brings up this screen



The description of various buttons with their functionalities are as follows:


1. Headphone Mode: This Button routes the audio of the phone towards the headphone Jack
2. Speaker Mode: This Button routes the audio of the phone towards speaker Jack
3. Volume slider: This slider lets you set the volume of the speaker output, it goes from 0 to a maximum of 7

NOTE: The volume slider and the set button work for speaker mode only

4. Set Button: This button sets the volume shown on the slider to the speaker output.

13. Sensor Screen

Pressing this icon on the second page of the menu screen brings up this screen




The two buttons “Read ADC0” and “READ ADC1” gives the voltage across the two ADC terminals given on the shield. Sensors can be connected to it.

14. InsidePi Screen

Pressing this icon on the second page of the menu screen brings up this screen


Pressing OK shuts down the GUI.

NOTE: This feature doesn't close Module functionalities such as CALL, SMS or INTERNET



15. Calendar screen


Pressing this icon on the second page of the menu screen brings up this screen



16. SIM Info Screen

Pressing this icon on the second page of the menu screen brings up this screen


Pressing the Read button brings carrier and IMEI info on screen as follows.



17. About Screen

Pressing this icon on the second page of the menu screen brings up this screen


This screen shows the model, company and the developers information.



18. Apps screen


Pressing this icon on the second page of the menu screen brings up this screen

This is a template screen. You can use this screen space to design your app by editing the code. Edit the template code however you want.



19. GPIO Buttons (unique to Waveshare 3.2LCD)

Waveshare 3.2" LCD comes with 3 buttons in the bottom of the LCD as shown. The functioning of each button is as described below.



1. Key1: This button functions as a back button in most cases. It takes the user back to menu screen upon pressing it.
2. Key2: This button takes the user to the home screen from the current screen. In camera frame however, this button enables the user to take a picture.
3. Key3: This button takes the user back to home screen if the user is in camera frame. It mimics the next button when in the menu screen.

All these keys mimic the bottom keys in the menu screen when it is being displayed. The functionality changes in different screens as stated above.