

BRIC4 Bluetooth Protocol

Rev D

Kris Fausnight, Dec 25, 2020

Overview:

This document describes the bluetooth communication protocol for the BRIC4 survey tool. The hardware implemented is a Laird BL652 module which implements Bluetooth Low Energy version 4.2. All communication is performed over BLE GATT/ATT using several standard and custom services:

- **Device Information Service:** Standard service to provide device name, serial number, firmware version, and more.
- **Battery Service:** Standard service to provide BRIC4 battery level.
- **Measurement Sync Service:** Custom service to send measurements and metadata to the client.
- **Device Control Service:** Custom service to allow client to control/adjust the BRIC4 device.

The “Device Information Service” and “Battery Service” will not be discussed in much detail since it is a standard service protocol. All data is transmitted in Little Endian per the BLE protocol standards. Bluetooth info and additional options can be found on the BRIC4, *Main Menu > Bluetooth*.

Pairing:

The BRIC4 will advertise while it is powered up and not connected. The device name advertised is “BRIC4_XXXX” where “XXXX” is the device serial number (example: “BRIC4_0039”). No encryption or pairing PIN numbers are implemented. The BRIC4 will remain connected while powered-down but will not respond or tend to any services. If the BRIC4 is connected, a bluetooth symbol will appear on the bottom right of the screen.

BLE Services

Device Information Service (UUID 0x180A)

The BRIC4 implements the standard “Device Information Service” which provides the following information:

- **Manufacturer Name String:** example: “Team Poseidon LLC”
- **Model Number String:** example: “BRIC4”
- **Serial Number String:** “0039”
- **Hardware Revision String:** “A”
- **Firmware Revision String:** BL652 Module Software, example “BL652:v28.6.2.0”
- **Software Revision String:** BRIC4 Software, example: “4.08”
- **System ID:** Not Implemented
- **IEEE 11073-20601 Regulator Certification Data List:** Not Implemented
- **PnP ID:** Not Implemented

Battery Service (UUID 0x180F)

The BRIC4 implements the standard “Battery Service” which provides the device battery level percentage from 0-100. For example a hex reading of 0x4E is equal to 78%.

Measurement Sync Service (UUID 0x58D0)

The BRIC4 implements the “Measurement Sync Service” which is a custom service designed to send survey measurements from the device to the client. Each measurement is transferred in 3 characteristics due to the 20-byte limit on BLE-Indicated characteristics: “Measurement Primary”, “Measurement MetaData”, and “Measurement Errors”. In addition there is a characteristic of “Last Time” which allow the client to roll back or forward the synchronization point if desired.

A “Sync Tracker” on the BRIC4 is used to track which measurements are in queue to be transmitted to the client. All measurements are stored on the SD card of the device, also accessible through the USB interface.

Measurement Sync Characteristics:

When a measurement is sent to the device, first the “Measurement MetaData” and “Measurement Errors” characteristics are written and BLE-Notified. Then the “Measurement Primary” characteristic is written and BLE-Indicated. This means that when the client receives a “Measurement Primary” characteristic BLE-Indication then the “Measurement MetaData” and “Measurement Errors” can be read.

| Measurement Primary Characteristic | | |
|------------------------------------|-----------|-----------------------------------|
| UUID: | 0x58D1 | Read, Indication |
| Byte | Data Type | Description |
| 1 | uint16_t | Year |
| 2 | | |
| 3 | uint8_t | Month |
| 4 | uint8_t | Day (of month) |
| 5 | uint8_t | Hours |
| 6 | uint8_t | Minutes |
| 7 | uint8_t | Seconds |
| 8 | uint8_t | Centiseconds |
| 9 | float | Distance (meters) |
| 10 | | |
| 11 | | |
| 12 | | |
| 13 | float | Azimuth (degrees, 0 to 360) |
| 14 | | |
| 15 | | |
| 16 | | |
| 17 | float | Inclination (degrees, -90 to +90) |
| 18 | | |
| 19 | | |
| 20 | | |

| Measurement Metadata Characteristic | | |
|-------------------------------------|-----------|---|
| UUID: | 0x58D2 | Read, Notification |
| Byte | Data Type | Description |
| 1 | uint32_t | Reference Index (As shown on BRIC4 Display) |
| 2 | | |
| 3 | | |
| 4 | | |

| | | |
|----|----------|--|
| 5 | float | Dip (Magnetic Dip above/below horizon, -90 to +90) |
| 6 | | |
| 7 | | |
| 8 | | |
| 9 | float | Roll (Roll angle of instrument about laser axis, 0 to 360) |
| 10 | | |
| 11 | | |
| 12 | | |
| 13 | float | Temperature (degrees Celsius) |
| 14 | | |
| 15 | | |
| 16 | | |
| 17 | uint16_t | Samples (Magnetometer and Accelerometer Samples Averaged) |
| 18 | | |
| 19 | uint8_t | Measurement Type (Defined in another section) |
| 20 | | |

| Measurement Errors Characteristic | | |
|-----------------------------------|------------------|--------------------|
| UUID: | 0x58D3 | Read, Notification |
| Byte | Data Type | Description |
| 1 | uint8_t | Error Code 1 |
| 2 | float | Error 1, Data 1 |
| 3 | | |
| 4 | | |
| 5 | | |
| 6 | float | Error 1, Data 2 |
| 7 | | |
| 8 | | |
| 9 | | |
| 10 | uint8_t | Error Code 2 |
| 11 | float | Error 2, Data 1 |
| 12 | | |
| 13 | | |
| 14 | | |
| 15 | float | Error 2, Data 2 |
| 16 | | |
| 17 | | |
| 18 | | |
| 19 | | |
| 20 | | |

Last Time Characteristic

The “Last Time” characteristic provides an optional method for the client to roll back or roll forward the sync point in the measurement service. For example, if a new client is paired with the BRIC4, the “Last Time” can be set to a past date and all measurements after that point will be sent to the device. In another example, if the BRIC4 has a large number of un-sent measurements and a new survey is started, the client can set the “Last Time” to the current date and avoid receiving unnecessary data.

After the BRIC4 has completed measurement synchronization, this characteristic will be updated with the time of the last measurement. If the client writes to this characteristic, the BRIC4 internal “Sync Tracker” will be updated as needed.

| Last Time Characteristic | | |
|--------------------------|------------------|--------------------|
| UUID: | 0x58D4 | Read / Write |
| Byte | Data Type | Description |
| 1 | uint16_t | Year |
| 2 | | |
| 3 | uint8_t | Month |
| 4 | uint8_t | Day (of month) |
| 5 | uint8_t | Hours |
| 6 | uint8_t | Minutes |
| 7 | uint8_t | Seconds |
| 8 | uint8_t | Centiseconds |
| 9 | | |
| 10 | | |
| 11 | | |
| 12 | | |
| 13 | | |
| 14 | | |
| 15 | | |
| 16 | | |
| 17 | | |
| 18 | | |
| 19 | | |
| 20 | | |

Device Control Service (UUID 0x58E0)

The BRIC4 implements the “Device Control Service” which is a custom service that allows the client to control or adjust the device. For example, this service can initiate “Scan Mode”, trigger a measurement, or adjust error sensitivity.

The command is sent as a string up to 20 bytes long.

| Device Control Characteristic | | |
|-------------------------------|------------------|----------------------------------|
| UUID: | 0x58E1 | Read / Write |
| Byte | Data Type | Description |
| 1 | char | Command string, ASCII characters |
| 2 | char | |
| 3 | char | |
| 4 | char | |

| | | |
|----|------|--|
| 5 | char | |
| 6 | char | |
| 7 | char | |
| 8 | char | |
| 9 | char | |
| 10 | char | |
| 11 | char | |
| 12 | char | |
| 13 | char | |
| 14 | char | |
| 15 | char | |
| 16 | char | |
| 17 | char | |
| 18 | char | |
| 19 | char | |
| 20 | char | |

The available commands are shown below. This is expected to change over time with additional capability added. All commands should be in lower-case. The string must contain the command but can contain additional characters. For example, "AscanBCD" will be interpreted as the "scan" command.

| String Command | Hex Command | Description |
|----------------|-------------------------------|---|
| "scan" | 0x 73 63 61 6e | Initiate scan mode where instrument takes continuous readings and streams them over the BLE connection. Typical rates are 1 Hz but can be higher if the distance is relatively stable. Measurement rate is limited by the laser rangefinder. While in scan mode, any other command reverts back to normal operation. |
| "shot" | 0x 73 68 6f 74 | If the laser is not already on, it will be turned on. If the laser is on, this immediately takes a measurement survey shot. |
| "laser" | 0x 6c 61 73 65 72 | Toggles the laser on or off |
| "power off" | 0x 70 6f 77 65 72 20 6f 66 66 | Turns-off the BRIC4 in the same way as holding down the main button. Note, the BRIC4 cannot be turned back on over BLE, yet. |
| | | |
| | | |