




## USER MANUAL: RASPBERRY PI 3



The Pilot® is a WAN communications board which provides an HSPA wireless interface for the Raspberry Pi 2 and 3. Conforming to the HAT specification, the Pilot® also provides location information using an on-board GNSS\* solution.

\*HL8548-G variant only


### Contents

Specification.....	<a href="#">2</a>
Box contents.....	<a href="#">2</a>
Required equipment.....	<a href="#">3</a>
Assembly.....	<a href="#">4</a>
Using the Pilot®.....	<a href="#">9</a>
Related documents.....	<a href="#">13</a>
Acronyms.....	<a href="#">13</a>
Further resources.....	<a href="#">14</a>

**Specification**

<b>EMBEDDED WIRELESS MODULE</b>	Sierra Wireless HL8548-G / HL8518
<b>FREQUENCY BANDS</b>	<b>HSPA —</b> B1 (2100MHz) / B2 (1900MHz) / B5 (850MHz) / B6 (850MHz) / B8 (900MHz) / B19 (800MHz) <b>EDGE/GPRS —</b> 850/900/1800/1900MHz
<b>3G PROTOCOLS</b>	WCDMA (UMTS), HSDPA, HSUPA, HSPA+
<b>GNSS SUPPORT (HL8548-G variant only)</b>	SiRF V GPS + GLONASS
<b>INTERFACES</b>	Serial, USB (CDC-ACM, CDC-ECM)
<b>SIM</b>	3V Micro-SIM
<b>POWER</b>	From Raspberry Pi or direct (can also power Raspberry Pi)
<b>AT COMMAND INTERFACE</b>	3GPP 27.007 standard, plus proprietary extended commands
<b>IP STACK</b>	On-board or Raspberry Pi


**Box contents**



**Required equipment**

**All variants:**

Raspberry Pi 2  
or 3



Pilot® HAT for Raspberry Pi

Right-angled stub antenna



SIM card



USB to Micro USB cable



#1 Pozidriv screwdriver




**HL8548-G variant only:**




GPS/GNSS antenna

Recommended: 2J GNSS patch antenna: <http://linkwave.co.uk/magneticadhesive-patch-antenna>


**Step-by-Step Assembly**



**Step one** – Gently push the 40 way pins all the way through the holes in the socket.





**Step two** – Remove the four screws from the mounting pillars.





**Step three** – Screw the right-angled stub antenna on to the SMA WAN antenna connector located next to the 40 pin header.

**Please note:** when using the GNSS (HL8548-G) variant, you will also need to use a GNSS antenna when using the GNSS function. Please screw this onto the other SMA WAN antenna connector alongside the right-angled stub antenna.




**Step four** – Align the 40 way socket with the 40 way header on the Raspberry Pi. Gently press together.








**Step five** – Ensure the Pilot® is securely mounted on the Raspberry Pi by inserting the four screws (see **step two**) into the holes at the bottom of the Raspberry Pi. Gently tighten using a #1 Pozidriv screwdriver.



**Step six** – Insert the SIM card into the SIM card holder, ensuring the chamfer is located as shown on the photo, and the contact side is face down.



**Step seven** – Insert the USB end of the USB to Micro USB cable into the top centre USB socket.



**Step eight** – Insert the Micro USB side of the USB to Micro USB cable into the Micro USB socket located above the USB socket.



### Using the Pilot®

**Please note: instructions for access to the physical serial port using the Pilot® will be available with the next Pilot® user manual: Raspberry Pi 3 update. This document provides instructions for using the Pilot® over USB on the Raspberry Pi 3.**

The following instructions are based on use of Raspbian Jessie OS.

Firstly, install Minicom using the following code:

```
sudo apt-get install minicom
```

### Pilot® power supply control

The Pilot® power supply is controlled by a Raspberry Pi IO pin. A logic “1” output enables a power supply regulator which supplies the Pilot® with power. Note that the regulator may switch on by default when power is applied to the Raspberry Pi.

### Pilot® HL module ON/OFF control

The Pilot® module ON pin is used to turn on the HL module’s internal power supply.

The Pilot® module ON pin is GPIO21 on the Raspberry Pi.

The HL module will automatically power on when the Pilot® power supply powers on. Once the module is powered off, the ON pin will need to be pulsed to turn the module back on again.

To power on, insert the following commands:

```
gpio -g mode 6 out  
gpio -g write 6 1  
gpio -g mode 21 out  
gpio -g write 21 1  
gpio -g write 21 0
```

### Connecting to the Pilot® via a UART port

To enable handshaking on the serial port, enter the following commands:

```
gpio -g mode 16 ALT3  
gpio -g mode 17 ALT3
```


You are now able to use AT commands to communicate with the HL module on the Pilot®.

### Connecting via USB

The USB interface provides several USB endpoints to the Raspberry Pi. These can be set using the AT+USBCOMP command. Serial endpoints can be seen by typing the following:

```
ls /dev/ttyACM*
```

This should respond as below:



```
pi@raspberrypi: ~  
File Edit Tabs Help  
pi@raspberrypi:~ $ ls /dev/ttyACM*  
/dev/ttyACM0 /dev/ttyACM1 /dev/ttyACM2 /dev/ttyACM3 /dev/ttyACM4  
pi@raspberrypi:~ $
```

A serial session can be instigated using the command below:

```
minicom -D /dev/ttyACM0
```

### Using IP

Using Minicom, enter the following command to ensure you are registered on the network.

```
AT+KSYNC=2,7
```

The LEDs on the PiloT should flash to confirm you are registered on the network.

Remaining in Minicom, enter the following command, which changes the USB end points to provide a CDC ECM interface:

```
AT+KUSBCOMP=2
```

Close Minicom (**Ctrl A then X** > enter), then power cycle the Raspberry Pi by removing and reinserting the power cable.

In a Raspberry Pi shell session, type:

```
ifconfig
```

A new Ethernet device should appear in the reported list. On a Raspberry Pi 2, this should be **'eth1'**.

Edit the interface configuration file:

```
sudo nano /etc/network/interfaces
```

Change or add the entry for eth1 as follows:

```
#auto eth1
#allow-hotplug eth1
iface eth1 inet dhcp
pre-up ifconfig $IFACE down
dns-nameservers 8.8.8.8 8.8.4.4
```

Save the file by holding **Ctrl A + X**  
Press **'Y'**  
Then **'enter'**.

Configure the HL8 bearer APN by opening a Minicom session to **/dev/ttyACM0**, then entering the following command using the appropriate APN according to your selected network:

```
AT+CGDCONT=1,"IP","Access Point Name"
```

Configure the APN username and password:

```
AT+WPPP=1,1,"username","password"
```

Configure dynamic DNS request:

```
AT+XDNS=1,1
```

To start an IP session:

```
AT+XCEDATA=1,0
```

To stop an IP session:

```
AT+CGACT=0,1
```

**Power off**

To power off the Pilot®, open a Minicom session with **/dev/ttyAMA0** or **/dev/ttyACM0**.  
Power off by entering the following command:

```
at+cpof
```

**Using GPS**

**Please note: the optional GPS function is only available for the HL8548-G variant of the Pilot®.**  
**Please see specification and/or related documents for more information.**

The following instructions set up an NMEA feed over the **Raspberry Pi 3** USB port.

Ensure the Pilot® is powered on by following the instructions on [page 9](#).

Connect to the Pilot® using Minicom:

```
minicom -D /dev/ttyACM0
```

Open a second terminal, then, within the second terminal, open a Minicom session with **/dev/ttyACM3**:  
Connect to the Pilot® using Minicom:

```
minicom -D /dev/ttyACM3
```

In terminal one, enter:

```
AT+GPSNMEA=1,1,FFFF,FF
```

This will direct the NMEA output to the USB serial port.

Start GPS output on the USB port by entering:

```
AT+GPSSTART=2
```

NMEA sentences should now stream from /dev/ttyACM3. You will see this occurring in the second terminal. **(See HL8548 AT Command Guide for more details of GPS commands)**

To stop running GPS, open a Minicom session on /dev/ttyACM0 and enter:

```
AT+GPSSTOP
```

Close Minicom (**Ctrl + A**, then **X** > enter).

### Related documents

Access further data about the HL modules at the Sierra Wireless technical information site (the Source) using the following links:

<http://source.sierrawireless.com/devices/hl-series/hl8548/>

<http://source.sierrawireless.com/devices/hl-series/hl8518/>

### Acronyms

Acronym or term	Definition
APN	An Access Point Name (APN) is the name of a gateway between a GSM, GPRS, 3G or 4G mobile network and another computer network.
AT Command	A set of device commands used to control modems, preceded by "AT" (meaning ATtention).
CDC ECM	Communications Device Class (CDC) and Ethernet Control Model (ECM) are protocols for Ethernet-style networking over USB.
DNS	The Domain Name System (DNS) is a hierarchical decentralized naming system for computers, services, or any resource connected to the Internet or a private network.
EDGE	Enhanced Data rates for GSM Evolution  (EDGE) is a digital mobile phone technology that allows improved data transmission rates as a backward-compatible extension of GSM. EDGE is considered a pre-3G radio technology and is part of ITU's 3G definition.
GLONASS	GLONASS or GLObal Navigation Satellite System is a space-based satellite navigation system operating in the radio navigation-satellite service. It provides an alternative to GPS and is the second alternative navigational system in operation with global coverage and of comparable precision.
GNSS	A satellite navigation system with global coverage may be termed a global navigation satellite system (GNSS).
GPRS	General Packet Radio Service is a packet-oriented mobile data service on 2G and 3G cellular communication systems.
GPS	Global Positioning System is a system that uses a series of 24+ satellites to provide navigational data.



<b>HAT</b>	A HAT (Hardware Attached on Top) is an add-on board for the Raspberry Pi that conforms to a specific set of rules which enhance usability.
<b>HSPA</b>	High Speed Packet Access (HSPA) is an amalgamation of two mobile telephony protocols: High Speed Downlink Packet Access (HSDPA) and High Speed Uplink Packet Access (HSUPA).
<b>IO</b>	Input/output is the communication between an information processing system. Inputs are the signals or data received by the system and outputs are the signals or data sent from it.
<b>IP</b>	The Internet Protocol (IP) is the protocol by which one computer communicates with another on the Internet. Each device is identified on the internet by a uniquely assigned IP address.
<b>Minicom</b>	Minicom is a text-based modem control and terminal emulation program for Unix-like operating systems. It is a menu-driven communications program.
<b>SIM</b>	A subscriber identity module or subscriber identification module (SIM) is an integrated circuit that securely stores the international mobile subscriber identity (IMSI) and the related key used to identify and authenticate subscribers on mobile telephony devices.
<b>SMA</b>	SMA (SubMiniature version A) connectors are semi-precision coaxial RF connectors developed as a minimal connector interface for coaxial cable with a screw type coupling mechanism.
<b>USB</b>	A Universal Serial Bus is an industry standard developed that defines the cables, connectors and communications protocols used in a bus for connection, communication, and power supply between computers and electronic devices.
<b>WAN</b>	A wide area network (WAN) is a telecommunications network or computer network that extends over a large geographical distance.

**Further resources**

[https://doc.airvantage.net/av/howto/hardware/3rdparty\\_getting\\_started/](https://doc.airvantage.net/av/howto/hardware/3rdparty_getting_started/)

<https://doc.airvantage.net/av/howto/hardware/samples/raspberry-hl-mqtt/>