

can4linux — CAN driver for passive CAN interface boards with SJA1000 controller

1. Installation

Download can4linux, create a can4linux directory, e.g. *can4linux* and unpack the archive:

```
$ mkdir can4linux
$ cd can4linux
$ tar zxvf ../can4linux*.tgz
```

The driver has to be compiled for each supported hardware. A list of supported boards can be found in the Makefile. It is displayed by typing

```
$ make help
```

Compile the driver with specifying the hardware target:

```
$ make TARGET=ATCANMINI_PELICAN
```

The driver object file *Can.o* is created in the actual working directory.

Now create the necessary device entries by using make again:

```
$ make inodes
```

The default value for a CAN drivers major number is 91. Please check before using it if the major number is already used. (major 91 is a registered number for CAN drivers.)

```
$ cat /proc/devices
```

lists all devices major numbers in use.

Next go into *etc*. Look for a configuration that fits to your hardware.

In the most cases you can use one of the available: *2-at_can_mini.conf* or *1-cpcpci.conf*.

If you don't see any pre-configured settings that match your hardware read your hardware manuals carefully and add a new entry.

Create a configuration file named according to the name of your computer. Your computers name is returned:

```
$ uname -n
uschi
$ cp 1-cpcpci.conf uschi.conf
```

Some entries are hardware dependant. Be careful when using your own hardware.

The content in the configuration file is used to overwrite the appropriate entries in the */proc* file system.

```
/proc/sys/Can/*
```

Now you can do a

```
$ make load
```

The driver **Can.o** is loaded using `insmod(1)` and entries in */proc/sys/Can/** are overwritten with the config file contents.

ATTENTION! When using PCI boards, the driver is using values obtained from the BIOS for addresses, access type and IRQ numbers. In this case these values are read-only and can not be overwritten. Ignore the warnings given while loading a configuration.

2. Test

Change into the directory *examples*. and compile the applications there

```

$ cd examples
$ make
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o ctest.o ctest.c
gcc ctest.o -o ctest
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o baud.o baud.c
gcc baud.o -o baud
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o can_send.o can_send.c
gcc can_send.o -o can_send
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o acceptance.o acceptance.c
gcc acceptance.o -o acceptance
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o noiser.o noiser.c
gcc noiser.o -o noiser
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o receive.o receive.c
gcc receive.o -o receive
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o transmit.o transmit.c
gcc transmit.o -o transmit
gcc -Wall -I../src -DUSE_RT_SCHEDULING -c -o can_verify.o can_verify.c
gcc can_verify.o -o can_verify

```

Before calling `ctest` watch the message log of the driver in the file `/var/log/messages`. Open a separate window **xterm**

```
$ tail -f /var/log/messages
```

(super user access rights are needed on most systems)

In order to see more messages increase the debug level by writing to the `/proc` filesystem

```
echo 7 > /proc/sys/Can/dbgMask
```

(super user access rights are needed on most systems)

or use the shell script

```
./debug 7
```

After the start of `ctest` you will see the following in the message log

```

Sep 17 13:13:31 uschi kernel: Can: - :in  can_open
Sep 17 13:13:31 uschi kernel: Can: - :in  CAN_VendorInit
Sep 17 13:13:31 uschi kernel: Can: - :in  Can_RequestIrq
Sep 17 13:13:31 uschi kernel: Can: - :Requested IRQ: 5 @ 0xce2e28c0
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :in  Can_WaitInit
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :in  Can_FifoInit
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :in  CAN_ChipReset
Sep 17 13:13:31 uschi kernel: Can: - : INT 0x0
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :status=0x3c mode=0x1
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x1
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x9
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x9
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :in  CAN_SetTiming
Sep 17 13:13:31 uschi kernel: Can: - :baud[0]=125
Sep 17 13:13:31 uschi kernel: Can: - :tim0=0x3 tim1=0x1c
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x9
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :in  CAN_SetMask
Sep 17 13:13:31 uschi kernel: Can: - :[0] acc=0xffffffff mask=0xffffffff
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x9
Sep 17 13:13:31 uschi kernel:
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel: Can: - :in  CAN_StartChip
Sep 17 13:13:31 uschi kernel: Can: - :[0] CAN_mode 0x9
Sep 17 13:13:31 uschi kernel:

```

```
Sep 17 13:13:31 uschi kernel: Can: - :start mode=0x8
Sep 17 13:13:31 uschi kernel: Can: - :out
Sep 17 13:13:31 uschi kernel:  MODE 0x8, STAT 0x3c, IRQE 0xf,
Sep 17 13:13:31 uschi kernel: Can: - :out
```

Other messages denote a corrupt or wrong *.conf configuration or using a not supported hardware.

Please start `can_send` to send a CAN message with 8 data byte with the contents of 0x55:

```
$ can_send -D can0 0x555 0x55 0x55 0x55 0x55 0x55 0x55 0x55 0x55
```

After execution of `can_send` there should be a CAN message on the bus. When the bus is not connected with a receiving device the CAN controller will continue to send the message because it doesn't receive an acknowledge. This behaviour is easy to trace with an oscilloscope. The chosen CAN identifier and the pattern of the data is quite easy to recognise and to measure. With a baud rate of 125 kBit/s the measurement of the shortest signal change should be 8 µs.

Reset the debug level of the driver:

```
./debug 0
```

3. Entries in /proc/sys/Can

Please see also the example in the configuration files *etc/*.conf*.

Entry	per channel	meaning
AccCode	*	CAN Controller Acceptance Code Register
AccMask	*	CAN Controller Acceptance Maske
Base	*	CAN Controller Address
IOModel		One letter per channel for the IO-Model
IRQ	*	IRQ Number
Outc	*	Output Control Register
Overrun	*	Overrun Flag of the channel
RxErr	*	number of Rx errors
Timeout	*	Timeout value
TxErr	*	Number of TX errors
dbgMask		global debug level
version		versions string
Chipset		CAN controller supported by the driver

The values for the bit timing registers of the CAN controller for the bit-rates 10,20,40,50,125,250,500,800 and 1000 kBit/s are taken from internal tables. These tables are only valid if the clock cycle of the CAN controller is 8 MHz (external 16 MHz quartz). When using a different clock cycle the bit timing registers are calculated as follows:

```
BTR0 = (Baud >> 8) && 0xFF
BTR1 = Baud      && 0xFF
```

Example for setting the bit rate to 125 kBit/s for a SJA1000 with a clock cycle of 10 MHz (20MHz), 16 time quanta and the sampling point at 87.5%

Calculated values for the bit timing register:

```
BTR0 = 0x04
BTR1 = 0x1c
```

From this it follows that:

```
Baud = (0x04 << 8) + 0x1c = 0x041c = 1052
```

The site http://www.port.de/deutsch/canprod/sv_req_form.html provides a input form for bit timing calculation of the bit timing register.

dbgMask

global debug level

default 0 - no debug messages

every bit of this mask has a specified meaning.

Bit	meaning
0	Flag for setting all options=on
1	log function entries
2	log function exits
3	log branches
4	log data given to functions
5	log interrupts
6	log register info
7	reserved

Outc The output control register of the Philips 82C200/SJA1000

4. DIL-NET-PC TRM/816 Hardware by SSV embedded Systems

The code was provided by [Sven Geggus](mailto:geggus@iitb.fraunhofer.de) <geggus@iitb.fraunhofer.de>. Please read his *README.trm816* and the *trm816/README*.

5. PC104 board PC104-200 from EDS

modified [can4linux](http://www.esd-electronics.com/) was and extended to support the [esd electronic system design gmbh](http://www.esd-electronics.com/) PC/104-CAN Card by [Jean-Jacques Tchouto](mailto:tchouto@fokus.fraunhofer.de) <tchouto@fokus.fraunhofer.de>.

6. In the case of ...

In the case of any malfunction of the driver, e.g. **open()** returns EINVAL - invalid argument -, set the debugmask **dbgMask** to a higher level, and watch the system log at */var/log/messages*