

(BAFT BALOCH)  
(AC 2,3)

IO LIST  
SYSTEM CONFIG  
PARAMETER SETTING

INPUT			SLOT
AC_CONTROL		0	1
FDBK_SUPPLY_1		1	
FDBK_SUPPLY_2		2	
FDBK_RETURN_1		3	
FDBK_RETURN_2		4	
FDBK_RETURN_3		5	
FDBK_PUMP_RUN		6	
FDBK_DUST_FAN_1		7	
FDBK_DUST_FAN_2		8	
FDBK_DUST_FAN_3		9	
FDBK_DUST_FAN_4		10	
FDBK_ROTARY_1		11	
FDBK_ROTARY_2		12	
FDBK_JAROOB_1		13	2
FDBK_JAROOB_2		14	
FDBK_POWER_DAMPER		15	
FAULT_DRIVE		16	
FAULT_DRIVE_MPCB		17	
FAULT_FAN_SUPPLY_1		18	
FAULT_FAN_SUPPLY_2		19	
FAULT_FAN_RETURN_1		20	
FAULT_FAN_RETURN_2		21	
FAULT_FAN_RETURN_3		22	
FAULT_DUST_FAN_1		23	
FAULT_DUST_FAN_2		24	
FAULT_DUST_FAN_3		25	3
FAULT_DUST_FAN_4		26	
FAULT_ROTARY_1		27	
FAULT_ROTARY_2		28	
FAULT_JAROOB_1		29	
FAULT_JAROOB_2		30	
TERMOSTAT_ALARM		31	
FIRE_ALARM		32	
DOOR1		33	
DOOR2		34	
		35	
		36	
		37	
OUTPUT			SLOT
FAN_SUPPLY_1_k1		0	1
FAN_SUPPLY_1_kB1		1	
FAN_SUPPLY_2_K2		2	
FAN_SUPPLY_2_kB2		3	
FAN_RETURN_1_K3		4	
FAN_RETURN_1_Kb3		5	
FAN_RETURN_2_K4		6	
FAN_RETURN_2_kB4		7	
FAN_RETURN_3_K5		8	
FAN_RETURN_3_Kb5		9	2
DRIVE_RUN		10	
PUMP_RUN		11	
DUST_FAN_1		12	
DUST_FAN_2		13	
DUST_FAN_3		14	
DUST_FAN_4		15	
ROTARY1		16	
JAROOB1		17	
ROTARY2		18	
JAROOB2		19	
DAMPER_POWER		20	
STEAM_VALVE_POWER		21	
		22	
		23	
		24	
		25	

SLOT 1	SLOT 2	SLOT 3	SLOT 4	SLOT 5
CPU 1215C AC/DC/Rly	SM 1223 DI16/DQ16 x relay	SM 1221 DI8 x 24VDC	SM 1231 AI4	SM 1232 AQ4
			CH 0 :TEMP IN	CH 0 :FREQ REF
			CH 1 :HUMID IN	CH 1 :FRESH DAMPER
			CH 2 :TEMP OUT	CH 2 :STEAM VALVE
			CH 3 :HUMID OUT	CH 3 :

LS H100 PARAMETER		
DRV-06	Command source	1
DRV-07	Frequency reference source	2
DRV-03	Acceleration time	15 S
DRV-04	Deceleration time	2 S
ADV-07	Start Mode	1
ADV-08	Stop Mode	1
ADV-12	DC braking time at startup	3S
OUT-32	RELAY 2	14