

# VCF Control Descriptions

## A Frequency Control

Changes the Cutoff Frequency of the filter.

## B Resonance Control

With no signal present at the Resonance Modulation input, **F**, the knob adjusts the amount of feedback applied to the input of the filter. Self-oscillation will occur at or near the maximum setting.

## C Filter Input 1 Level

Adjusts the level of the audio applied to the IN 1 jack. Normalized to VCO Output.

## D Filter Input 2 Level

Adjusts the level of the audio applied to the IN 2 jack. Normalized to VCO Sub Oscillator Output.

## E Filter Input 1

Audio input to filter. Attenuated by **C**.

## F Resonance Modulation

Input for resonance modulation signal. When a signal is present, the Resonance Control knob, **B**, adjusts the modulation depth of the input signal.

## G Filter Input 2

Audio input to filter. Attenuated by **D**.

## H Frequency Mod Input 1

Input for positive Frequency Modulation signal with attenuation. Normalized to VCO KYBD input. Set attenuator knob fully CW for 1 V/octave tracking during self-oscillation.

## I VCF Output

## J Frequency Mod Input 2

Input for bipolar Frequency Modulation signal with attenuation. Maximum attenuation at centre position.

## K Filter Mode Switch

Sets the slope of the cutoff response between 12 dB and 24 dB per octave.

