



OpenLCB Standard	
Memory Access Configuration Protocol	
Dec 8, 2013	Preliminary

1 Introduction (Informative)

This document defines a protocol for configuring OpenLCB nodes by directly accessing their configuration memory.

2 Intended Use (Informative)

5 Intended to be used to configure self-contained nodes over their OpenLCB links.

See also the separate note on a [Configuration Description Information](#).

3 References and Context (Normative)

This specification is in the context of the following OpenLCB-CAN Standards:

- 10 • OpenLCB Datagram Protocol, which defines the protocol for transporting 0-72 byte datagrams from node to node.
- OpenLCB Message Network, which defines message interchange for OpenLCB, specifically how this protocol appears in the Protocol Support Reply message.

4 Protocol (Normative)

15 4.1 Address Space Size

Configuration memory addresses are 32 bits. The addressable quantity is the byte.

4.2 Address Space Selection

20 Required space definitions (these may or may not have content on a particular node); these address space numbers can only be used for this, and if the information is available, it must be accessible by these numbers (in addition to any others the designer might provide):

- (0xFF, flag=11) Configuration definition – reading this is how you get the configuration definition
- 25 • (0xFE, flag=10) All memory – provides access to “all” memory in the device, where “all” is defined by the designer. Single, flat address space for access. Can be used for e.g. dynamic access to RAM for monitoring & debugging.

- (0xFD, flag=01) Configuration - basic configuration space, with the structure of the 32-bit space defined by the designer.

These three spaces, inclusive, can be addressed without an extra byte in the datagram using control bits in the flag byte. All others need to be specified as a byte value. The high addresses (0xFD through 0xFF) were chosen for the dedicated spaces so that space numbers 00, 01, 02 could be used as a 5th bytes in a contiguous address if desired.

4.3 Message Formats

The following table shows available configuration operation formats. All others reserved. They must not be skipped during identification. Items in {} are optional.

4.3.1 Read Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Byte 7/6
0x20	0x40 Space in byte 6 0x41 Space 0xFD 0x42 Space 0xFE 0x43 Space 0xFF	Starting Address				Address Space	Read Count (1-64) Upper bit reserved, must be ignored

4.3.2 Read Reply

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Byte 7/6
0x20	OK status: 0x50 Space in byte 6 0x51 Space 0xFD 0x52 Space 0xFE 0x53 Space 0xFF	Starting Address				Address Space	Data (1-64)
	Failure status: 0x58 Space in byte 6 0x59 Space 0xFD 0x5A Space 0xFE 0x5B Space 0xFF	Starting Address				Address Space	Error Code (two bytes), followed by optional zero-terminated message string

4.3.3 Read Stream Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remaining Bytes
0x20	0x60 Space in byte 6 0x61 Space 0xFD 0x62 Space 0xFE 0x63 Space 0xFF	Starting Address				Address Space	Read Count (4 bytes), followed by stream definition information

4.3.4 Read Stream Reply

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Byte 7/6
0x20	OK status: 0x70 Space in byte 6 0x71 Space 0xFD 0x72 Space 0xFE 0x73 Space 0xFF	Starting Address				Address Space	Read Count (4 bytes), followed by stream definition information
	Failure status: 0x78 Space in byte 6 0x79 Space 0xFD 0x7A Space 0xFE 0x7B Space 0xFF	Starting Address				Address Space	Error Code (two bytes), followed by optional zero-terminated message string

4.3.5 Write Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remaining Bytes
0x20	0x00 Space in byte 6 0x01 Space 0xFD 0x02 Space 0xFE 0x03 Space 0xFF	Starting Address				Address Space	Data (1-64 bytes)

45 **4.3.6 Write Reply**

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remaining Bytes
0x20	OK status: 0x10 Space in byte 6 0x11 Space 0xFD 0x12 Space 0xFE 0x13 Space 0xFF	Starting Address				Address Space	(None)
	Failure status: 0x18 Space in byte 6 0x19 Space 0xFD 0x1A Space 0xFE 0x1B Space 0xFF	Starting Address				Address Space	Error Code (two bytes), followed by optional zero-terminated message string

4.3.7 Write Under Mask Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remainder
0x20	0x08 Space in byte 6 0x09 Space 0xFD 0x0A Space 0xFE 0x0B Space 0xFF	Starting Address				Address Space	Data pairs (2-64 bytes)

50 The data pairs are (Mask, Data) where each of Mask and Data are single bytes. Bits in Data where the corresponding bit in Mask is a 1 will be written to the memory location. Bits in memory where the corresponding bit in Mask is a 0 will be left unchanged. The first data pair refers to memory at the Starting Address. Each following data pair refers to a successive byte in memory.

4.3.8 Write Stream Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remainder
0x20	0x20 Space in byte 6 0x21 Space 0xFD 0x22 Space 0xFE 0x23 Space 0xFF	Starting Address				Address Space	Stream Definition Info

4.3.9 Write Stream Reply

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (optional)	Remaining Bytes
0x20	OK status: 0x30 Space in byte 6 0x31 Space 0xFD 0x32 Space 0xFE 0x33 Space 0xFF	Starting Address				Address Space	(None)
	Failure status: 0x38 Space in byte 6 0x39 Space 0xFD 0x3A Space 0xFE 0x3B Space 0xFF	Starting Address				Address Space	Error Code (two bytes), followed by optional zero-terminated message string

4.3.10 Get Configuration Options Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (Optional)	Remainder (Optional)
0x20	0x80						

55

4.3.11 Get Configuration Reply

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6 (Optional)	Remainder (Optional)
0x20	0x82	Available Commands		Write Lengths	Highest Address Space	Lowest Address Space	Name String

60 **4.3.12 Get Address Space Information Command**

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Remainder
0x20	0x84	Address Space					

4.3.13 Get Address Space Information Reply

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12
0x20	0x86	Address Space	Highest Address			Flags	Lowest Address				Description	

4.3.14 Freeze Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Remainder
0x20	0xA1	Address Space					

65

4.3.15 Unfreeze Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Remainder
0x20	0xA0	Address Space					

4.3.16 Lock/Reserve Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0x20	0x88	Reserving Node ID					

70 **4.3.17 Lock/Reserve Reply**

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0x20	0x8A	Reserved Node ID					

4.3.18 Get Unique ID Command

Byte 0	Byte 1	Byte 2
0x20	0x8C	Number requested (1-8, 3 bits); upper bits reserved and must be ignored

4.3.19 Get Unique ID Reply

Byte 0	Byte 1	Remainder
0x20	0x8D	1-8 requested EventIDs, a total of 8-64 bytes

75

4.3.20 Indicate Command

Byte 0	Byte 1
0x20	0xA3 on 0xA2 off

4.3.21 Update Complete Command

Byte 0	Byte 1
0x20	0xA8

80

4.3.22 Reset/Reboot Command

Byte 0	Byte 1
0x20	0xA9

4.3.23 Reinitialize/Factory Reset Command

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0x20	0xAA	Node ID					

4.4 Operations

85

4.4.1 Read, Read-Reply

In reply to the datagram containing a Read command, the receiving node shall set the Reply Pending bit in the Datagram Received OK message. The receiving node may, but is not required to, include a specific timeout interval in the Datagram Received OK message.

90

If the interval is provided and has elapsed without a Read Reply message being returned, the node requesting the Read operation may, but is not required to, repeat the request.

Attempts to read from an invalid location, either outside the available address range in a valid address space, or from an invalid address space, still require a returning a Read Reply datagram with a data length of zero.

95 In general, a read reply may provide less than the requested data, but always at least one byte if it's a valid read. The maximum read request is 64 bytes when reading via datagrams. When reading via streams, any length up to 0xFF,FF,FF,FF (4GB-1) can be requested; a length of 0x0 means “read forever” or until the end of the address space.

Reading at least one byte, but less than the requested amount, due to the length of the address space is not considered an error.

100 If the full number of bytes cannot be read for any reason other than the size of the address space, or if no bytes can be read, the Read Reply shall have the Fail bit set and include an error code instead of the requested data.

4.4.2 Read Stream, Read Stream Reply

105 Very similar to Read, except that a stream is created to carry the read information back to the requesting node. The stream must be established before the Read Reply datagram is sent, so that error codes can be returned via the Read Reply in the stream initialization fails.

4.4.3 Write, Write Reply

If the write operation can be done immediately and succeeds, only the Datagram Received OK message reply to the Write Command datagram is returned. The Reply Pending bit is not set in that reply.

110 If the write operation takes time, or fails immediately, the Datagram Received OK message reply to the Write Command datagram shall carry the Reply Pending bit set. The receiving node may, but is not required to, include a specific timeout interval in the Datagram Received OK message. This is followed later by the receiving node sending a Write Reply datagram with either OK or Fail set. If Fail is set, the error code shall be included. The optional message string may be, but is not required to be, included.

115 If a timeout interval was provided and has elapsed without a Write Reply message being returned, the node requesting the Write operation may, but is not required to, repeat the request.

4.4.4 Write Stream, Write Stream Reply

120 Write Stream is followed by a stream initialization using the specified Stream ID. Once that completes, the Write Reply can be returned. (Needs careful consideration of whether delayed reply should be used here, and how, exactly)

4.4.5 Get Configuration Options Reply

To make it possible to make simple/cheap nodes, not every configuration operation & option needs to be provided. The reply to “Get Configuration Options” provides information that a configuring device can use to control how it communicates with the node so that it only uses available modes.

- 125
- Available operations mask (2 bytes, bit coded): Indicate which operations are available so the using software can know whether convenience operations (which are not possible on some hardware) are available.
 - 0x8000 Write under mask supported
 - 0x4000 Unaligned reads supported. If not set, reads have to start on an address with the low bits, as given by the data size, all zero. For example a 4-byte write must have the low two address bits zero.
- 130

- 0x2000 Unaligned writes supported. If not set, reads have to start on an address with the low bits, as given by the data size, all zero. For example a 4-byte write must have the low two address bits zero.
- 135 • 0x0800 Read from address space 0xFC available (this is the manufacturer part of Abbreviated CDI)
- 0x0400 Read from address space 0xFB available (this is the user-entered part of Abbreviated CDI)
- 140 • 0x0200 Write to address space 0xFB available (this is the user-entered part of Abbreviated CDI)
- Others reserved, must be ignored on receipt and sent as zero.
- Write lengths supported (One byte, bit coded): (provided for devices that can only write certain sizes to memory) (at least one bit must be set)
 - 0x80 1 byte write
 - 145 • 0x40 2 byte write
 - 0x20 4 byte writes
 - 0x10 64 byte writes (full datagram, but not 63 bytes or arbitrary length, just exactly 64)
 - 0x02 arbitrary writes of any length OK
 - 0x01 stream writes supported (stream support will identify buffer size)
 - 150 • Others reserved, must be ignored on receipt and sent as zero.
- Highest Address Space (byte): Highest number space available. Not all up to that need be available, but sparse allocation will slow down the process as “Get Address Space Information” is needed to determine whether they are present.
- 155 • Lowest Address spaces (byte): Lowest number space available. Note that spaces 0xFD, 0xFE and 0xFF are assumed to be included even if the low space ↔ high space range doesn't include them. (also 0xFC, 0xFB of Abbreviated Default CDI if bits indicate they're available)

A node that only has the high spaces could have Highest Address Space = 255, Lowest Address Space = 253 or 251.

- 160 A node that has additional low address spaces, e.g. to make more memory available with a 28-bit address, could have Highest Address Space = 127, Lowest Address Space = 0 and leave the top spaces assumed.

4.4.6 Get Address Space Information Reply

To ease automated access, a configuring node can enquire about the address spaces in the being-configured node. Whether or not the address space is present, a reply is required.

- 165 • Present: This is carried in the lowest bit of the command byte, just below the reply bit

- 0x01 == 1: Present. == 0 not present.

- Space ID – provided to identify request this reply is in response to
- Highest Address (4 bytes)
- Flags (byte) – (Alignment and size were going to be here but were made global above); Read-Only is LSB, can write if 0, can only read if 1; Non-zero lowest address is 2nd-lowest bit, low address is zero if 0, is non-zero and specified in next four bytes if 1
- Lowest Address (4 bytes) – optional, omit if zero, as that will let reply fit in single CAN frame; if present, “non-zero lowest address” bit in prior byte must be 1.
- Description (variable length) – optional null-terminated string giving the user-readable name of this space

4.4.7 Lock/Reserve and Freeze/Unfreeze

An OpenLCB node can, in general, be configured while the network and even the node itself is operating.

Code can be simplified by disabling operation of a node while it's being configured, so that there's no concern about it trying to react to transient incomplete information. The Freeze/Unfreeze command, if supported, can be used to tell a node that it should “freeze” operation, ignoring inputs, while the configuration is being updated. A reset of the node releases the freeze option, if set.

Although nodes can be configured by multiple other nodes, this can also lead to inconsistencies. The optional Lock/Release command can be used to avoid this. At the start of configuration, a configuring node sends a Lock message with its NodeID. If no node has locked this node, indicated by zero content in the lock memory, the incoming NodeID is placed in the lock memory. If a node has locked this node, the non-zero NodeID in the lock memory is not changed. In either case, the content of the lock memory is returned in the reply. This acts as a test&set operation, and informs the requesting node whether it successfully reserved the node. To release the node, repeat the lock operation with a zero NodeID. The lock memory is set to zero when the node is reset. Note that this is a voluntary protocol in the configuring nodes only; the node being configured does not change it's response to configuration operations when locked or unlocked.

4.4.8 Get Unique EventID

Nodes maintain a list of unique EventIDs for use in configuration. These are allocated based on the node's unique NodeID. This command allows a configuration tool to get new unique EventIDs from the node's pool, for example to interact with the Blue/Gold configuration process. Each request must provide a different EventID, without repeat, even through node resets and factory resets.

4.4.9 Update Complete/Reset/Reboot/Reinitialize

This is a collection of three operations, distinguished by what are normally the flag bits.

The configuration protocol does not specify the meaning of the transferred data. In particular, it doesn't specify when new configuration information takes effect. Depending on how the node is constructed, this might be immediately upon transfer (although this raises issues of write boundaries), or when an entire sequence of transfers is complete. “Update Complete” is the command that indicates that a series of configuration writes is consistent and complete, and the node can put it into effect. Nodes do not

205 have to require this operation, but receiving it must be permitted. Configuration tools should send it at the end of operations. Nodes may, but are not required to, reset after sending the reply to this message.

The “Reboot/Reset” command is meant to reinitialize a node, equivalent to powering it up. Nodes should finish any pending operations, e.g. non-volatile memory writes, before doing the initialization. It's expected that the datagram reply will be sent before the reset, but this might not be entirely reliable.

210 Configuration tools should not count on the reply. The configuring node will receive a “Node Initialization Complete” when the node is back up. This operation must not reset any configuration information to default contents.

“Reinitialize/Factory Reset” is similar, but includes restoring the node's configuration as if factory reset. (This may require creating new unique EventIDs, see other note) This is a heavy-weight operation which may require some form of interlock, e.g. the user pressing a button, to prevent inadvertent data loss. As a small safety precaution, the NodeID of the note being reset is redundantly carried in the data part of the datagram.

215

4.4.10 Indicate

220 (This is likely to move to a separate protocol; note that “indicate” and “ident” are completely different things, with “ident” in a separate protocol already)

This command tells the board to somehow identify itself to the user, for example by flashing a LED or operating it's outputs. This allows the user to be absolutely sure that he's configuring the correct board. “Start” (bit 0 = 1) means that the board should start indicating, and “Stop” (bit 0 = 0) means that the board should stop indicating. The data portion carries information that lets the board know what kind of indication to do. It's not always appropriate to operate outputs if they're e.g. driving large mechanical systems like doors. (This needs to be specified more precisely)

225

Table of Contents

1 Introduction (Informative).....	1
2 Intended Use (Informative).....	1
3 References and Context (Normative).....	1
4 Protocol (Normative).....	1
4.1 Address Space Size.....	1
4.2 Address Space Selection.....	1
4.3 Message Formats.....	2
4.3.1 Read Command.....	2
4.3.2 Read Reply.....	2
4.3.3 Read Stream Command.....	2
4.3.4 Write Command.....	3
4.3.5 Write Reply.....	3
4.3.6 Write Under Mask Command.....	3
4.3.7 Write Stream Command.....	3
4.3.8 Get Configuration Options Command.....	4
4.3.9 Get Configuration Reply.....	4
4.3.10 Get Address Space Information Command.....	4
4.3.11 Get Address Space Information Reply.....	4

4.3.12 Freeze Command.....	4
4.3.13 Unfreeze Command.....	4
4.3.14 Lock/Reserve Command.....	4
4.3.15 Lock/Reserve Reply.....	5
4.3.16 Get Unique ID Command.....	5
4.3.17 Get Unique ID Reply.....	5
4.3.18 Indicate Command.....	5
4.3.19 Update Complete Command.....	5
4.3.20 Reset/Reboot Command.....	5
4.3.21 Reinitialize/Factory Reset Command.....	5
4.4 Operations.....	5
4.4.1 Read, Read-Reply.....	5
4.4.2 Write, Write-Reply.....	6
4.4.3 Get Configuration Options Reply.....	6
4.4.4 Get Address Space Information Reply.....	7
4.4.5 Lock/Reserve and Freeze/Unfreeze.....	8
4.4.6 Get Unique EventID.....	8
4.4.7 Update Complete/Reset/Reboot/Reinitialize.....	8
4.4.8 Indicate.....	9