

TTK4900 Driver documentation

Generated by Doxygen 1.9.1

1 Class Index	1
1.1 Class List	1
2 File Index	3
2.1 File List	3
3 Class Documentation	5
3.1 accelerometer_inData Struct Reference	5
3.1.1 Detailed Description	6
3.1.2 Member Data Documentation	6
3.1.2.1 newXAcc	6
3.1.2.2 newXRot	6
3.1.2.3 newYAcc	6
3.1.2.4 newYRot	6
3.1.2.5 newZAcc	6
3.1.2.6 newZRot	7
3.1.2.7 xAcc	7
3.1.2.8 xRot	7
3.1.2.9 yAcc	7
3.1.2.10 yRot	7
3.1.2.11 zAcc	7
3.1.2.12 zRot	8
3.2 can_mailbox Struct Reference	8
3.2.1 Detailed Description	8
3.2.2 Member Data Documentation	8
3.2.2.1 data	8
3.2.2.2 msgId	8
3.2.2.3 newMsg	9
3.3 controller_descriptor Struct Reference	9
3.3.1 Member Data Documentation	9
3.3.1.1 inputSource	9
3.3.1.2 isMoving	9
3.3.1.3 posCurrent	9
3.3.1.4 posError	10
3.3.1.5 posSetpoint	10
3.4 current_measurement_descriptor Struct Reference	10
3.4.1 Detailed Description	10
3.4.2 Member Data Documentation	10
3.4.2.1 adc	11
3.4.2.2 Aipropi	11
3.4.2.3 conversionConst	11
3.4.2.4 lastMeasurement	11
3.4.2.5 lastReading	11

3.4.2.6 Nadc	11
3.4.2.7 Ripropi	12
3.4.2.8 VrefA	12
3.5 imu_descriptor Struct Reference	12
3.5.1 Detailed Description	12
3.5.2 Member Data Documentation	13
3.5.2.1 i2cHandle	13
3.5.2.2 readAddr	13
3.5.2.3 writeAddr	13
3.5.2.4 xAccAddr	13
3.5.2.5 xRotAddr	13
3.5.2.6 yAccAddr	14
3.5.2.7 yRotAddr	14
3.5.2.8 zAccAddr	14
3.5.2.9 zRotAddr	14
3.6 joint_controller_descriptor Struct Reference	14
3.6.1 Detailed Description	15
3.6.2 Member Data Documentation	15
3.6.2.1 hasAccelerometer	15
3.6.2.2 intError	15
3.6.2.3 isMoving	16
3.6.2.4 jointName	16
3.6.2.5 Kd	16
3.6.2.6 Kp	16
3.6.2.7 KpTi	16
3.6.2.8 motorNum	16
3.6.2.9 posCurrent	17
3.6.2.10 posError	17
3.6.2.11 posSetpoint	17
3.7 motor_descriptor Struct Reference	17
3.7.1 Detailed Description	18
3.7.2 Member Data Documentation	18
3.7.2.1 encoderInitCount	18
3.7.2.2 encoderPreviousCount	18
3.7.2.3 encoderTimer	18
3.7.2.4 encoderTotalCount	19
3.7.2.5 encoderTotalInit	19
3.7.2.6 encoderTotalSetpoint	19
3.7.2.7 isMoving	19
3.7.2.8 mostRecentDelta	19
3.7.2.9 motorId	19
3.7.2.10 motorName	20

3.7.2.11 motorPolarity	20
3.7.2.12 motorTimer	20
3.7.2.13 resolution	20
3.7.2.14 voltageLimit	20
3.7.2.15 voltagePctCap	20
3.8 string_cmd_pair Struct Reference	21
3.8.1 Detailed Description	21
3.8.2 Member Data Documentation	21
3.8.2.1 cmdFuncPointer	21
3.8.2.2 cmdString	21
3.9 string_cmd_processor_args Struct Reference	21
3.9.1 Detailed Description	22
3.9.2 Member Data Documentation	22
3.9.2.1 inputString	22
3.9.2.2 stringLength	22
4 File Documentation	23
4.1 accelerometer_driver.h File Reference	23
4.2 adc_driver.h File Reference	23
4.2.1 Detailed Description	24
4.2.2 Function Documentation	24
4.2.2.1 adc_driver_calculate_current()	24
4.2.2.2 adc_driver_update_measurement()	24
4.2.2.3 adc_driver_update_reading()	25
4.2.2.4 adc_interface_get_current()	25
4.2.2.5 adc_interface_update_current()	25
4.3 can_driver.h File Reference	25
4.3.1 Detailed Description	27
4.3.2 Macro Definition Documentation	28
4.3.2.1 CAN_ACC_CMD_OFFSET	28
4.3.2.2 CAN_MOTOR_CMD_OFFSET	28
4.3.3 Enumeration Type Documentation	28
4.3.3.1 can_message_type	28
4.3.4 Function Documentation	28
4.3.4.1 can_cmd_handle_axisData()	29
4.3.4.2 can_cmd_handle_axisReq()	29
4.3.4.3 can_cmd_handle_motorSp()	29
4.3.4.4 can_cmd_handle_regReq()	29
4.3.4.5 can_cmd_handle_regVal()	30
4.3.4.6 can_cmd_handle_yAcc()	30
4.3.4.7 can_driver_cmd_rx0()	30
4.3.4.8 can_driver_cmd_rx1()	31

4.3.4.9 can_driver_cmd_rx2()	31
4.3.4.10 can_driver_cmd_rx3()	31
4.3.4.11 can_driver_cmd_rx4()	32
4.3.4.12 can_driver_cmd_rx5()	32
4.3.4.13 can_driver_cmd_rx6()	32
4.3.4.14 can_driver_cmd_rx7()	32
4.3.4.15 can_driver_cmd_rx8()	33
4.3.4.16 can_driver_cmd_rx9()	33
4.3.4.17 can_driver_cmd_rxA()	33
4.3.4.18 can_driver_cmd_rxB()	34
4.3.4.19 can_driver_queue_tx()	34
4.3.4.20 can_driver_send_msg()	34
4.3.4.21 can_interface_queue_tx()	35
4.3.4.22 can_mailbox_clear_flag()	35
4.3.4.23 can_mailbox_get_data()	35
4.3.4.24 can_mailbox_get_flag()	36
4.3.4.25 can_mailbox_get_id()	36
4.3.4.26 can_mailbox_set_data()	36
4.3.4.27 can_mailbox_set_flag()	37
4.3.4.28 can_mailbox_set_id()	37
4.3.4.29 can_rx_executive()	37
4.3.4.30 can_tx_executive()	37
4.4 gpio_driver.h File Reference	38
4.4.1 Detailed Description	38
4.4.2 Function Documentation	38
4.4.2.1 gpio_end_switch_handler()	38
4.4.2.2 gpio_twist_switch_handler()	38
4.5 joint_controller.h File Reference	39
4.5.1 Detailed Description	42
4.5.2 Function Documentation	42
4.5.2.1 controller_acc_clear_newX()	42
4.5.2.2 controller_acc_clear_newY()	42
4.5.2.3 controller_acc_clear_newZ()	43
4.5.2.4 controller_acc_get_newX()	43
4.5.2.5 controller_acc_get_newY()	43
4.5.2.6 controller_acc_get_newZ()	43
4.5.2.7 controller_acc_getX()	43
4.5.2.8 controller_acc_getY()	43
4.5.2.9 controller_acc_getZ()	43
4.5.2.10 controller_acc_set_newX()	44
4.5.2.11 controller_acc_set_newY()	44
4.5.2.12 controller_acc_set_newZ()	44

4.5.2.13 controller_acc_setX()	44
4.5.2.14 controller_acc_setY()	44
4.5.2.15 controller_acc_setZ()	44
4.5.2.16 controller_interface_acc_clear_newX()	44
4.5.2.17 controller_interface_acc_clear_newY()	45
4.5.2.18 controller_interface_acc_clear_newZ()	45
4.5.2.19 controller_interface_acc_get_newX()	45
4.5.2.20 controller_interface_acc_get_newY()	46
4.5.2.21 controller_interface_acc_get_newZ()	46
4.5.2.22 controller_interface_acc_getX()	46
4.5.2.23 controller_interface_acc_getY()	47
4.5.2.24 controller_interface_acc_getZ()	47
4.5.2.25 controller_interface_acc_set_newX()	47
4.5.2.26 controller_interface_acc_set_newY()	48
4.5.2.27 controller_interface_acc_set_newZ()	48
4.5.2.28 controller_interface_acc_setX()	48
4.5.2.29 controller_interface_acc_setY()	48
4.5.2.30 controller_interface_acc_setZ()	49
4.5.2.31 controller_interface_clear_acc_poll()	49
4.5.2.32 controller_interface_clear_moving()	49
4.5.2.33 controller_interface_clear_mtr_poll()	49
4.5.2.34 controller_interface_clicks_to_pos()	50
4.5.2.35 controller_interface_get_acc_poll()	50
4.5.2.36 controller_interface_get_error()	50
4.5.2.37 controller_interface_get_moving()	51
4.5.2.38 controller_interface_get_mtr_poll()	51
4.5.2.39 controller_interface_get_position()	51
4.5.2.40 controller_interface_get_setpoint()	52
4.5.2.41 controller_interface_request_acc_axis()	52
4.5.2.42 controller_interface_rot_clear_newX()	52
4.5.2.43 controller_interface_rot_clear_newY()	53
4.5.2.44 controller_interface_rot_clear_newZ()	53
4.5.2.45 controller_interface_rot_get_newX()	53
4.5.2.46 controller_interface_rot_get_newY()	53
4.5.2.47 controller_interface_rot_get_newZ()	54
4.5.2.48 controller_interface_rot_getX()	54
4.5.2.49 controller_interface_rot_getY()	54
4.5.2.50 controller_interface_rot_getZ()	56
4.5.2.51 controller_interface_rot_set_newX()	56
4.5.2.52 controller_interface_rot_set_newY()	56
4.5.2.53 controller_interface_rot_set_newZ()	57
4.5.2.54 controller_interface_rot_setX()	57

4.5.2.55 controller_interface_rot_setY()	57
4.5.2.56 controller_interface_rot_setZ()	58
4.5.2.57 controller_interface_set_acc_poll()	58
4.5.2.58 controller_interface_set_error()	58
4.5.2.59 controller_interface_set_moving()	58
4.5.2.60 controller_interface_set_mtr_poll()	59
4.5.2.61 controller_interface_set_position()	59
4.5.2.62 controller_interface_set_power()	59
4.5.2.63 controller_interface_set_setpoint()	59
4.5.2.64 controller_interface_update_error()	60
4.5.2.65 controller_interface_update_power()	60
4.5.2.66 controller_rot_clear_newX()	60
4.5.2.67 controller_rot_clear_newY()	60
4.5.2.68 controller_rot_clear_newZ()	61
4.5.2.69 controller_rot_get_newX()	61
4.5.2.70 controller_rot_get_newY()	61
4.5.2.71 controller_rot_get_newZ()	61
4.5.2.72 controller_rot_getX()	61
4.5.2.73 controller_rot_getY()	61
4.5.2.74 controller_rot_getZ()	61
4.5.2.75 controller_rot_set_newX()	62
4.5.2.76 controller_rot_set_newY()	62
4.5.2.77 controller_rot_set_newZ()	62
4.5.2.78 controller_rot_setX()	62
4.5.2.79 controller_rot_setY()	62
4.5.2.80 controller_rot_setZ()	62
4.5.2.81 joint_controller_acceleration_to_angle()	63
4.5.2.82 joint_controller_adjust_enc_sp()	63
4.5.2.83 joint_controller_clear_moving()	63
4.5.2.84 joint_controller_clicks_to_pos()	63
4.5.2.85 joint_controller_get_error()	63
4.5.2.86 joint_controller_get_moving()	63
4.5.2.87 joint_controller_get_position()	63
4.5.2.88 joint_controller_get_setpoint()	64
4.5.2.89 joint_controller_request_acc_axis()	64
4.5.2.90 joint_controller_set_error()	64
4.5.2.91 joint_controller_set_moving()	64
4.5.2.92 joint_controller_set_position()	64
4.5.2.93 joint_controller_set_power()	64
4.5.2.94 joint_controller_set_setpoint()	65
4.5.2.95 joint_controller_update_error()	65
4.5.2.96 joint_controller_update_power()	65

4.6 motor_driver.h File Reference	65
4.6.1 Detailed Description	67
4.6.2 Function Documentation	67
4.6.2.1 motor_driver_calc_safe_vlt()	67
4.6.2.2 motor_driver_delta_setpoint()	67
4.6.2.3 motor_driver_get_encoder_cnt()	68
4.6.2.4 motor_driver_get_id()	68
4.6.2.5 motor_driver_get_moving()	68
4.6.2.6 motor_driver_get_resolution()	69
4.6.2.7 motor_driver_get_setpoint()	69
4.6.2.8 motor_driver_get_total_cnt()	69
4.6.2.9 motor_driver_go_backward()	70
4.6.2.10 motor_driver_go_forward()	70
4.6.2.11 motor_driver_init()	70
4.6.2.12 motor_driver_set_power()	70
4.6.2.13 motor_driver_set_pwm_dc()	71
4.6.2.14 motor_driver_set_setpoint()	71
4.6.2.15 motor_driver_update_power()	71
4.6.2.16 motor_driver_update_tot_cnt()	72
4.6.2.17 motor_interface_controller_init()	72
4.6.2.18 motor_interface_delta_setpoint()	72
4.6.2.19 motor_interface_get_encoder_count()	73
4.6.2.20 motor_interface_get_id()	73
4.6.2.21 motor_interface_get_moving()	73
4.6.2.22 motor_interface_get_resolution()	74
4.6.2.23 motor_interface_get_setpoint()	74
4.6.2.24 motor_interface_get_total_count()	74
4.6.2.25 motor_interface_set_power()	75
4.6.2.26 motor_interface_set_setpoint()	75
4.6.2.27 motor_interface_update_power()	75
4.6.2.28 motor_interface_update_tot_cnt()	76
4.7 shoulder_controller.h File Reference	76
4.8 string_cmd_parser.h File Reference	76
4.8.1 Detailed Description	78
4.8.2 Macro Definition Documentation	78
4.8.2.1 NUM_STRING_COMMANDS	78
4.8.2.2 string_cmd_processor	78
4.8.3 Function Documentation	78
4.8.3.1 string_cmd_acc1()	78
4.8.3.2 string_cmd_can()	79
4.8.3.3 string_cmd_category_accelerometer()	79
4.8.3.4 string_cmd_category_adc()	79

4.8.3.5 string_cmd_category_local_motor()	79
4.8.3.6 string_cmd_category_remote_motor()	80
4.8.3.7 string_cmd_elbow()	80
4.8.3.8 string_cmd_pinch()	80
4.8.3.9 string_cmd_processor_base()	80
4.8.3.10 string_cmd_processor_wrp()	81
4.8.3.11 string_cmd_rail()	81
4.8.3.12 string_cmd_rly()	81
4.8.3.13 string_cmd_shoulder()	82
4.8.3.14 string_cmd_stop()	82
4.8.3.15 string_cmd_twist()	82
4.8.3.16 string_cmd_wrist()	82
4.8.4 Variable Documentation	83
4.8.4.1 stringCmdList	83
4.9 uart_driver.h File Reference	83
4.9.1 Detailed Description	84
4.9.2 Function Documentation	84
4.9.2.1 uart_hmi_init()	84
4.9.2.2 uart_hmi_rx_handler()	84
4.9.2.3 uart_parse_input()	84
4.9.2.4 uart_ros_init()	85
4.9.2.5 uart_ros_rx_handler()	85
4.9.2.6 uart_send_string()	85
4.10 unit_config.h File Reference	85
4.10.1 Detailed Description	86
4.10.2 Macro Definition Documentation	86
4.10.2.1 ACTIVE_UNIT	86
4.10.2.2 CAN_FILTER_A	87
4.10.2.3 CAN_FILTER_M	87
4.10.2.4 CAN_FILTERMASK_A	87
4.10.2.5 CAN_FILTERMASK_M	87
4.10.2.6 CMD_MODE_ROS	87
4.10.2.7 CMD_MODE_TERMINAL	87
4.10.2.8 ENC1	87
4.10.2.9 ENC2	87
4.10.2.10 GLOBAL_DEBUG	88
4.10.2.11 HAND	88
4.10.2.12 HW_INTERFACE	88
4.10.2.13 MTR1	88
4.10.2.14 MTR2	88
4.10.2.15 MTR_POL	88
4.10.2.16 PWM_CTR_PRD	88

4.10.2.17 SHOULDER	89
4.10.2.18 SW_INTERFACE	89
4.10.2.19 TORSO	89
4.10.2.20 UART_INPUT	89
4.10.2.21 UART_INTERFACE	89
4.10.2.22 USB_INTERFACE	89
4.10.2.23 VOLTAGE_IN	89
4.10.3 Function Documentation	89
4.10.3.1 activate_peripherals()	89
Index	91

Chapter 1

Class Index

1.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

accelerometer_inData	Holds INCOMING accelerometer data, NOT part of the accelerometer driver	5
can_mailbox	A virtual CAN mailbox for outgoing and incoming messages	8
controller_descriptor	9
current_measurement_descriptor	Database with key information for the motor current sensing ADCs	10
imu_descriptor	Key information about the IMUs	12
joint_controller_descriptor	Joint controller information database	14
motor_descriptor	Contains static and state information relevant to the operation of a motor driver	17
string_cmd_pair	Pairs a command string token with a function pointer	21
string_cmd_processor_args	Wrapper struct to enable a variable number of arguments to the string processor	21

Chapter 2

File Index

2.1 File List

Here is a list of all files with brief descriptions:

accelerometer_driver.h	23
adc_driver.h	
This file contains all the function prototypes and struct definitions for the adc_driver.c file	23
can_driver.h	
This file contains all the function prototypes and struct definitions for the can_driver.c file	25
gpio_driver.h	
This file contains all the function prototypes for the gpio_driver.c file	38
joint_controller.h	
This file contains all the function prototypes and struct definitions for the joint_controller.c file	39
motor_driver.h	
This file contains all the function prototypes and struct definitions for the motor_driver.c file	65
shoulder_controller.h	76
string_cmd_parser.h	
This file contains all the function prototypes and struct definitions for the string_cmd_parser.c file	76
uart_driver.h	
This file contains all the function prototypes for the string_cmd_parser.c file	83
unit_config.h	
This file contains global information relevant to building the project for a specific STM32 in the robotic arm	85

Chapter 3

Class Documentation

3.1 accelerometer_inData Struct Reference

Holds INCOMING accelerometer data, NOT part of the accelerometer driver.

```
#include <joint_controller.h>
```

Public Attributes

- `int16_t xAcc`
X axis acceleration.
- `int16_t xRot`
X axis rotation.
- `int16_t yAcc`
Y axis acceleration.
- `int16_t yRot`
Y axis rotation.
- `int16_t zAcc`
Z axis acceleration.
- `int16_t zRot`
Z axis rotation.
- `uint8_t newXAcc`
Flags new X acceleration data on arrival.
- `uint8_t newYAcc`
Flags new Y acceleration data on arrival.
- `uint8_t newZAcc`
Flags new Z acceleration data on arrival.
- `uint8_t newXRot`
Flags new X rotation data on arrival.
- `uint8_t newYRot`
Flags new Y rotation data on arrival.
- `uint8_t newZRot`
Flags new Z rotation data on arrival.

3.1.1 Detailed Description

Holds INCOMING accelerometer data, NOT part of the accelerometer driver.

3.1.2 Member Data Documentation

3.1.2.1 newXAcc

```
uint8_t accelerometer_inData::newXAcc
```

Flags new X acceleration data on arrival.

3.1.2.2 newXRot

```
uint8_t accelerometer_inData::newXRot
```

Flags new X rotation data on arrival.

3.1.2.3 newYAcc

```
uint8_t accelerometer_inData::newYAcc
```

Flags new Y acceleration data on arrival.

3.1.2.4 newYRot

```
uint8_t accelerometer_inData::newYRot
```

Flags new Y rotation data on arrival.

3.1.2.5 newZAcc

```
uint8_t accelerometer_inData::newZAcc
```

Flags new Z acceleration data on arrival.

3.1.2.6 newZRot

```
uint8_t accelerometer_inData::newZRot
```

Flags new Z rotation data on arrival.

3.1.2.7 xAcc

```
int16_t accelerometer_inData::xAcc
```

X axis acceleration.

3.1.2.8 xRot

```
int16_t accelerometer_inData::xRot
```

X axis rotation.

3.1.2.9 yAcc

```
int16_t accelerometer_inData::yAcc
```

Y axis acceleration.

3.1.2.10 yRot

```
int16_t accelerometer_inData::yRot
```

Y axis rotation.

3.1.2.11 zAcc

```
int16_t accelerometer_inData::zAcc
```

Z axis acceleration.

3.1.2.12 zRot

```
int16_t accelerometer_inData::zRot
```

Z axis rotation.

The documentation for this struct was generated from the following file:

- [joint_controller.h](#)

3.2 can_mailbox Struct Reference

A virtual CAN mailbox for outgoing and incoming messages.

```
#include <can_driver.h>
```

Public Attributes

- uint8_t [newMsg](#)
Flag signifying that the mailbox contains an unhandled message.
- uint32_t [msgId](#)
CAN message ID, 11 bits (standard ID)
- uint8_t [data](#) [8]
CAN message data.

3.2.1 Detailed Description

A virtual CAN mailbox for outgoing and incoming messages.

3.2.2 Member Data Documentation

3.2.2.1 data

```
uint8_t can_mailbox::data[8]
```

CAN message data.

3.2.2.2 msgId

```
uint32_t can_mailbox::msgId
```

CAN message ID, 11 bits (standard ID)

3.2.2.3 newMsg

```
uint8_t can_mailbox::newMsg
```

Flag signifying that the mailbox contains an unhandled message.

The documentation for this struct was generated from the following file:

- [can_driver.h](#)

3.3 controller_descriptor Struct Reference

```
#include <shoulder_controller.h>
```

Public Attributes

- uint8_t [inputSource](#)
- float [posSetpoint](#)
- float [posCurrent](#)
- float [posError](#)
- uint8_t [isMoving](#)

3.3.1 Member Data Documentation

3.3.1.1 inputSource

```
uint8_t controller_descriptor::inputSource
```

3.3.1.2 isMoving

```
uint8_t controller_descriptor::isMoving
```

3.3.1.3 posCurrent

```
float controller_descriptor::posCurrent
```

3.3.1.4 posError

```
float controller_descriptor::posError
```

3.3.1.5 posSetpoint

```
float controller_descriptor::posSetpoint
```

The documentation for this struct was generated from the following file:

- [shoulder_controller.h](#)

3.4 current_measurement_descriptor Struct Reference

Database with key information for the motor current sensing ADCs.

```
#include <adc_driver.h>
```

Public Attributes

- double [VrefA](#)
Analog reference voltage, V.
- double [Ripropi](#)
Current sense resistor, Ohm.
- double [Aipropi](#)
Current sense proportional current, uA/A.
- uint32_t [Nadc](#)
ADC saturation point.
- ADC_HandleTypeDef * [adc](#)
ADC for current measurement.
- double [conversionConst](#)
Constant number for conversion of ADC value to Ampere.
- uint32_t [lastReading](#)
Latest ADC raw value.
- double [lastMeasurement](#)
Latest calculated current.

3.4.1 Detailed Description

Database with key information for the motor current sensing ADCs.

3.4.2 Member Data Documentation

3.4.2.1 adc

ADC_HandleTypeDef* current_measurement_descriptor::adc

ADC for current measurement.

3.4.2.2 Aipropi

double current_measurement_descriptor::Aipropi

Current sense proportional current, uA/A.

3.4.2.3 conversionConst

double current_measurement_descriptor::conversionConst

Constant number for conversion of ADC value to Ampere.

3.4.2.4 lastMeasurement

double current_measurement_descriptor::lastMeasurement

Latest calculated current.

3.4.2.5 lastReading

uint32_t current_measurement_descriptor::lastReading

Latest ADC raw value.

3.4.2.6 Nadc

uint32_t current_measurement_descriptor::Nadc

ADC saturation point.

3.4.2.7 Ripropi

```
double current_measurement_descriptor::Ripropi
```

Current sense resistor, Ohm.

3.4.2.8 VrefA

```
double current_measurement_descriptor::VrefA
```

Analog reference voltage, V.

The documentation for this struct was generated from the following file:

- [adc_driver.h](#)

3.5 imu_descriptor Struct Reference

Key information about the IMUs.

```
#include <accelerometer_driver.h>
```

Public Attributes

- I2C_HandleTypeDef * [i2cHandle](#)
Pointer to the I2C bus peripheral.
- uint16_t [readAddr](#)
Read address of the IMU on the I2C bus.
- uint16_t [writeAddr](#)
Write address of the IMU on the I2C bus.
- uint8_t [xAccAddr](#)
Start address of the IMU's X axis accelerometer register.
- uint8_t [yAccAddr](#)
Start address of the IMU's Y axis accelerometer register.
- uint8_t [zAccAddr](#)
Start address of the IMU's Z axis accelerometer register.
- uint8_t [xRotAddr](#)
Start address of the IMU's X axis rotation rate register.
- uint8_t [yRotAddr](#)
Start address of the IMU's Y axis rotation rate register.
- uint8_t [zRotAddr](#)
Start address of the IMU's Z axis rotation rate register.

3.5.1 Detailed Description

Key information about the IMUs.

3.5.2 Member Data Documentation

3.5.2.1 i2cHandle

```
I2C_HandleTypeDef* imu_descriptor::i2cHandle
```

Pointer to the I2C bus peripheral.

3.5.2.2 readAddr

```
uint16_t imu_descriptor::readAddr
```

Read address of the IMU on the I2C bus.

3.5.2.3 writeAddr

```
uint16_t imu_descriptor::writeAddr
```

Write address of the IMU on the I2C bus.

3.5.2.4 xAccAddr

```
uint8_t imu_descriptor::xAccAddr
```

Start address of the IMU's X axis accelerometer register.

3.5.2.5 xRotAddr

```
uint8_t imu_descriptor::xRotAddr
```

Start address of the IMU's X axis rotation rate register.

3.5.2.6 yAccAddr

```
uint8_t imu_descriptor::yAccAddr
```

Start address of the IMU's Y axis accelerometer register.

3.5.2.7 yRotAddr

```
uint8_t imu_descriptor::yRotAddr
```

Start address of the IMU's Y axis rotation rate register.

3.5.2.8 zAccAddr

```
uint8_t imu_descriptor::zAccAddr
```

Start address of the IMU's Z axis accelerometer register.

3.5.2.9 zRotAddr

```
uint8_t imu_descriptor::zRotAddr
```

Start address of the IMU's Z axis rotation rate register.

The documentation for this struct was generated from the following file:

- [accelerometer_driver.h](#)

3.6 joint_controller_descriptor Struct Reference

Joint controller information database.

```
#include <joint_controller.h>
```

Public Attributes

- `uint8_t hasAccelerometer`
Whether the joint has an accelerometer for position control.
- `float posSetpoint`
The joint's setpoint in radians/mm relative to its zero position.
- `float posCurrent`
The joint's current position in radians/mm relative to its zero position.
- `float posError`
The joint's position error in radians/mm, relative to its setpoint.
- `uint8_t isMoving`
Whether the joint is in a "moving" state.
- `uint8_t motorNum`
Link to the corresponding [motor_descriptor](#).
- `float Kp`
PID controller Kp.
- `float KpTi`
PID controller Kp/Ti.
- `float Kd`
PID controller Kd.
- `float intError`
Positional integral error.
- `uint8_t * jointName`
The joint's human readable name. This field must be last.

3.6.1 Detailed Description

Joint controller information database.

3.6.2 Member Data Documentation

3.6.2.1 hasAccelerometer

```
uint8_t joint_controller_descriptor::hasAccelerometer
```

Whether the joint has an accelerometer for position control.

3.6.2.2 intError

```
float joint_controller_descriptor::intError
```

Positional integral error.

3.6.2.3 isMoving

```
uint8_t joint_controller_descriptor::isMoving
```

Whether the joint is in a "moving" state.

3.6.2.4 jointName

```
uint8_t* joint_controller_descriptor::jointName
```

The joint's human readable name. This field must be last.

3.6.2.5 Kd

```
float joint_controller_descriptor::Kd
```

PID controller Kd.

3.6.2.6 Kp

```
float joint_controller_descriptor::Kp
```

PID controller Kp.

3.6.2.7 KpTi

```
float joint_controller_descriptor::KpTi
```

PID controller Kp/Ti.

3.6.2.8 motorNum

```
uint8_t joint_controller_descriptor::motorNum
```

Link to the corresponding [motor_descriptor](#).

3.6.2.9 posCurrent

```
float joint_controller_descriptor::posCurrent
```

The joint's current position in radians/mm relative to its zero position.

3.6.2.10 posError

```
float joint_controller_descriptor::posError
```

The joint's position error in radians/mm, relative to its setpoint.

3.6.2.11 posSetpoint

```
float joint_controller_descriptor::posSetpoint
```

The joint's setpoint in radians/mm relative to its zero position.

The documentation for this struct was generated from the following file:

- [joint_controller.h](#)

3.7 motor_descriptor Struct Reference

Contains static and state information relevant to the operation of a motor driver.

```
#include <motor_driver.h>
```

Public Attributes

- `uint8_t` [motorId](#)
The motor's unique ID, essential for CAN messaging.
- `uint8_t` [voltageLimit](#)
Safe voltage limit, as stated in the motor's datasheet.
- `uint8_t` [voltagePctCap](#)
Safe voltage percentage cap, given by input voltage and safe limit.
- `int8_t` [motorPolarity](#)
The motor's polarity, which pole is connected to +/- on the driver.
- `TIM_TypeDef *` [motorTimer](#)
The MCU timer peripheral which drives the motor.
- `TIM_TypeDef *` [encoderTimer](#)
The MCU timer peripheral which registers the motor's encoder.
- `int32_t` [resolution](#)
Relation between number of encoder click per mm or rad of movement.

- `uint16_t encoderInitCount`
Number of encoder clicks counted on startup (nominally 0)
- `int32_t encoderTotalInit`
Number of total encoder clicks counted on startup (nominally 0)
- `int32_t encoderTotalSetpoint`
Setpoint for motor encoder count, relevant if circumventing joint controller.
- `int32_t encoderTotalCount`
Total number of encoder clicks registered since startup.
- `int32_t encoderPreviousCount`
The previous total encoder count, used for updating total.
- `int32_t mostRecentDelta`
The most recently registered increment/decrement in encoder count, essentially movement rate.
- `uint8_t isMoving`
Whether the motor is moving, assumed true if `mostRecentDelta > 50`.
- `char * motorName`
Human readable name of the motor.

3.7.1 Detailed Description

Contains static and state information relevant to the operation of a motor driver.

3.7.2 Member Data Documentation

3.7.2.1 encoderInitCount

```
uint16_t motor_descriptor::encoderInitCount
```

Number of encoder clicks counted on startup (nominally 0)

3.7.2.2 encoderPreviousCount

```
int32_t motor_descriptor::encoderPreviousCount
```

The previous total encoder count, used for updating total.

3.7.2.3 encoderTimer

```
TIM_TypeDef* motor_descriptor::encoderTimer
```

The MCU timer peripheral which registers the motor's encoder.

3.7.2.4 encoderTotalCount

```
int32_t motor_descriptor::encoderTotalCount
```

Total number of encoder clicks registered since startup.

3.7.2.5 encoderTotalInit

```
int32_t motor_descriptor::encoderTotalInit
```

Number of total encoder clicks counted on startup (nominally 0)

3.7.2.6 encoderTotalSetpoint

```
int32_t motor_descriptor::encoderTotalSetpoint
```

Setpoint for motor encoder count, relevant if circumventing joint controller.

3.7.2.7 isMoving

```
uint8_t motor_descriptor::isMoving
```

Whether the motor is moving, assumed true if mostRecentDelta>50.

3.7.2.8 mostRecentDelta

```
int32_t motor_descriptor::mostRecentDelta
```

The most recently registered increment/decrement in encoder count, essentially movement rate.

3.7.2.9 motorId

```
uint8_t motor_descriptor::motorId
```

The motor's unique ID, essential for CAN messaging.

3.7.2.10 motorName

```
char* motor_descriptor::motorName
```

Human readable name of the motor.

3.7.2.11 motorPolarity

```
int8_t motor_descriptor::motorPolarity
```

The motor's polarity, which pole is connected to +/- on the driver.

3.7.2.12 motorTimer

```
TIM_TypeDef* motor_descriptor::motorTimer
```

The MCU timer peripheral which drives the motor.

3.7.2.13 resolution

```
int32_t motor_descriptor::resolution
```

Relation between number of encoder click per mm or rad of movement.

3.7.2.14 voltageLimit

```
uint8_t motor_descriptor::voltageLimit
```

Safe voltage limit, as stated in the motor's datasheet.

3.7.2.15 voltagePctCap

```
uint8_t motor_descriptor::voltagePctCap
```

Safe voltage percentage cap, given by input voltage and safe limit.

The documentation for this struct was generated from the following file:

- [motor_driver.h](#)

3.8 string_cmd_pair Struct Reference

Pairs a command string token with a function pointer.

```
#include <string_cmd_parser.h>
```

Public Attributes

- char * [cmdString](#)
String token.
- void(* [cmdFuncPointer](#))()
Corresponding handler function.

3.8.1 Detailed Description

Pairs a command string token with a function pointer.

3.8.2 Member Data Documentation

3.8.2.1 cmdFuncPointer

```
void(* string_cmd_pair::cmdFuncPointer) ()
```

Corresponding handler function.

3.8.2.2 cmdString

```
char* string_cmd_pair::cmdString
```

String token.

The documentation for this struct was generated from the following file:

- [string_cmd_parser.h](#)

3.9 string_cmd_processor_args Struct Reference

Wrapper struct to enable a variable number of arguments to the string processor.

```
#include <string_cmd_parser.h>
```

Public Attributes

- char * [inputString](#) [64]
String to be processed.
- uint8_t [stringLength](#)
Length of the string to be processed.

3.9.1 Detailed Description

Wrapper struct to enable a variable number of arguments to the string processor.

3.9.2 Member Data Documentation

3.9.2.1 [inputString](#)

```
char* string_cmd_processor_args::inputString[64]
```

String to be processed.

3.9.2.2 [stringLength](#)

```
uint8_t string_cmd_processor_args::stringLength
```

Length of the string to be processed.

The documentation for this struct was generated from the following file:

- [string_cmd_parser.h](#)

Chapter 4

File Documentation

4.1 accelerometer_driver.h File Reference

```
#include "uart_driver.h"
#include "unit_config.h"
#include "i2c.h"
#include "stdint.h"
#include "string.h"
Include dependency graph for accelerometer_driver.h:
```

4.2 adc_driver.h File Reference

This file contains all the function prototypes and struct definitions for the adc_driver.c file.

```
#include "stdint.h"
#include "math.h"
#include "adc.h"
#include "unit_config.h"
#include "uart_driver.h"
Include dependency graph for adc_driver.h:
```

Classes

- struct [current_measurement_descriptor](#)
Database with key information for the motor current sensing ADCs.

Functions

- double [adc_interface_get_current](#) (uint8_t sensorSelect)
Module external interface function to read the most recently calculated current.
- void [adc_interface_update_current](#) (uint8_t sensorSelect)
Module external interface function to trigger a current calculation.
- double [adc_driver_calculate_current](#) ([current_measurement_descriptor](#) *sensor)
Calculates current in Ampere based on an ADC raw value.
- void [adc_driver_update_reading](#) ([current_measurement_descriptor](#) *sensor)
Trigger a reading of the relevant ADC, insert into sensor struct.
- void [adc_driver_update_measurement](#) ([current_measurement_descriptor](#) *sensor)
Calculate latest current measurement, insert into struct.

4.2.1 Detailed Description

This file contains all the function prototypes and struct definitions for the `adc_driver.c` file.

Attention

ADC driver for the TTK4900 Master project of Kristian Blom, spring semester of 2024. This driver is tailored for use with the current sense pin of the DRV8251A motor driver

4.2.2 Function Documentation

4.2.2.1 `adc_driver_calculate_current()`

```
double adc_driver_calculate_current (
    current_measurement_descriptor * sensor )
```

Calculates current in Ampere based on an ADC raw value.

Parameters

<i>sensor</i>	Pointer to the relevant sensor struct
---------------	---------------------------------------

Returns

Ampere

4.2.2.2 `adc_driver_update_measurement()`

```
void adc_driver_update_measurement (
    current_measurement_descriptor * sensor )
```

Calculate latest current measurement, insert into struct.

Parameters

<i>sensor</i>	Pointer to the relevant sensor struct
---------------	---------------------------------------

4.2.2.3 adc_driver_update_reading()

```
void adc_driver_update_reading (
    current_measurement_descriptor * sensor )
```

Trigger a reading of the relevant ADC, insert into sensor struct.

Parameters

<i>sensor</i>	Pointer to the relevant sensor struct
---------------	---------------------------------------

4.2.2.4 adc_interface_get_current()

```
double adc_interface_get_current (
    uint8_t sensorSelect )
```

Module external interface function to read the most recently calculated current.

Parameters

<i>sensorSelect</i>	Select from one of two motor current sensor ADCs
---------------------	--

Returns

Latest calculated current measurement

4.2.2.5 adc_interface_update_current()

```
void adc_interface_update_current (
    uint8_t sensorSelect )
```

Module external interface function to trigger a current calculation.

Parameters

<i>sensorSelect</i>	Select from of two motor current sensor ADCs
---------------------	--

4.3 can_driver.h File Reference

This file contains all the function prototypes and struct definitions for the can_driver.c file.

```
#include "stdint.h"
#include "can.h"
```

```
#include "unit_config.h"
#include "motor_driver.h"
#include "accelerometer_driver.h"
#include "joint_controller.h"
```

Include dependency graph for can_driver.h: This graph shows which files directly or indirectly include this file:

Classes

- struct [can_mailbox](#)
A virtual CAN mailbox for outgoing and incoming messages.

Macros

- #define [CAN_MOTOR_CMD_OFFSET](#) 5
- #define [CAN_ACC_CMD_OFFSET](#) 8

Enumerations

- enum [can_message_type](#) {
[ACC_X_TX](#), [ACC_Y_TX](#), [ACC_Z_TX](#), [ACC_REG_RX](#),
[ACC_REG_REQ](#), [JOINT_POS_SP](#), [MOTOR_VLT_SP](#), [JOINT_POS_REQ](#),
[JOINT_POS_TX](#), [ACC_X_REQ](#), [ACC_Y_REQ](#), [ACC_Z_REQ](#),
[num_types](#) }
CAN message types.

Functions

- void [can_interface_queue_tx](#) (uint8_t mailbox, uint8_t *outData, uint32_t id)
Module external function for queueing a CAN message for transmit.
- void [can_rx_executive](#) ()
Looks for new incoming CAN messages and handles them. MAIN LOOP ONLY.
- void [can_tx_executive](#) ()
Looks for new CAN messages to send, sends. MAIN LOOP ONLY.
- void [can_mailbox_set_data](#) ([can_mailbox](#) *mailbox, uint8_t *inData)
Sets the data field of the given mailbox.
- void [can_mailbox_get_data](#) ([can_mailbox](#) *mailbox, uint8_t *target)
Inserts the data field of the given mailbox to target. CAUTION: memcpy 8 bytes.
- void [can_mailbox_set_flag](#) ([can_mailbox](#) *mailbox)
Sets the newmsg flag of the given mailbox.
- uint8_t [can_mailbox_get_flag](#) ([can_mailbox](#) *mailbox)
Gets the newmsg flag of the given mailbox.
- void [can_mailbox_clear_flag](#) ([can_mailbox](#) *mailbox)
Clears the newmsg flag of the given mailbox.
- void [can_mailbox_set_id](#) ([can_mailbox](#) *mailbox, uint32_t id)
Sets the CAN message ID field of the given mailbox.
- uint32_t [can_mailbox_get_id](#) ([can_mailbox](#) *mailbox)
Gets the CAN message ID of the given mailbox.
- void [can_driver_queue_tx](#) ([can_mailbox](#) *mailbox, uint8_t *outData, uint32_t id)
Queues a can message for transmit, driver internal.

- void [can_driver_send_msg](#) (uint8_t *data, uint32_t stdId, int dlc, uint8_t hwMailbox)
Sends a CAN message, is called by can_interface_send_msg.
- void [can_cmd_handle_yAcc](#) (uint32_t id, uint8_t *inData)
- void [can_cmd_handle_regVal](#) (uint32_t id, uint8_t *inData)
Handles an incoming accelerometer register message.
- void [can_cmd_handle_regReq](#) (uint32_t id, uint8_t *inData)
Handles an incoming accelerometer read request.
- void [can_cmd_handle_motorSp](#) (uint32_t id, uint8_t *inData)
Handles an incoming motor setpoint.
- void [can_cmd_handle_axisReq](#) (uint32_t id, uint8_t *inData)
Handles an incoming request for accelerometer axis data.
- void [can_cmd_handle_axisData](#) (uint32_t id, uint8_t *inData)
Handles incoming accelerometer axis data.
- void [can_driver_cmd_rx0](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_X_TX
- void [can_driver_cmd_rx1](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_Y_TX
- void [can_driver_cmd_rx2](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_Z_TX
- void [can_driver_cmd_rx3](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_REG_RX
- void [can_driver_cmd_rx4](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_REG_REQ
- void [can_driver_cmd_rx5](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type JOINT_POS_SP
- void [can_driver_cmd_rx6](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type MOTOR_VLT_SP
- void [can_driver_cmd_rx7](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_X_TX
- void [can_driver_cmd_rx8](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type JOINT_POS_TX
- void [can_driver_cmd_rx9](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_X_REQ
- void [can_driver_cmd_rxA](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_Y_REQ
- void [can_driver_cmd_rxB](#) (uint32_t id, uint8_t *inData)
"Generic" function to handle CAN message type ACC_Z_REQ

4.3.1 Detailed Description

This file contains all the function prototypes and struct definitions for the can_driver.c file.

Attention

CAN driver for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The driver specifies CAN message types relevant to the project, as well as relevant functions for the handling of transmission and reception of messages.

4.3.2 Macro Definition Documentation

4.3.2.1 CAN_ACC_CMD_OFFSET

```
#define CAN_ACC_CMD_OFFSET 8
```

4.3.2.2 CAN_MOTOR_CMD_OFFSET

```
#define CAN_MOTOR_CMD_OFFSET 5
```

4.3.3 Enumeration Type Documentation

4.3.3.1 can_message_type

```
enum can_message_type
```

CAN message types.

Enumerator

ACC_X_TX	A message containing acc/rot X axis.
ACC_Y_TX	A message containing acc/rot Y axis.
ACC_Z_TX	A message containing acc/rot Z axis.
ACC_REG_RX	A message containing an arbitrary accelerometer register value.
ACC_REG_REQ	A message requesting an arbitrary accelerometer register value.
JOINT_POS_SP	A message containing a joint position setpoint.
MOTOR_VLT_SP	A message containing a motor voltage percent setpoint.
JOINT_POS_REQ	A message requesting the position of a joint.
JOINT_POS_TX	A message containing the position of a joint.
ACC_X_REQ	A message requesting acc/rot x axis.
ACC_Y_REQ	A message requesting acc/rot y axis.
ACC_Z_REQ	A message requesting acc/rot z axis.
num_types	Dummy type for counting the number of message types, must always be last.

4.3.4 Function Documentation

4.3.4.1 can_cmd_handle_axisData()

```
void can_cmd_handle_axisData (
    uint32_t id,
    uint8_t * inData )
```

Handles incoming accelerometer axis data.

Parameters

<i>id</i>	Incoming CAN ID
<i>inData</i>	Incoming CAN data

4.3.4.2 can_cmd_handle_axisReq()

```
void can_cmd_handle_axisReq (
    uint32_t id,
    uint8_t * inData )
```

Handles an incoming request for accelerometer axis data.

Parameters

<i>id</i>	Incoming CAN ID
<i>inData</i>	Incoming CAN data

4.3.4.3 can_cmd_handle_motorSp()

```
void can_cmd_handle_motorSp (
    uint32_t id,
    uint8_t * inData )
```

Handles an incoming motor setpoint.

Parameters

<i>id</i>	Incoming CAN ID
<i>inData</i>	Incoming CAN data

4.3.4.4 can_cmd_handle_regReq()

```
void can_cmd_handle_regReq (
```

```
uint32_t id,  
uint8_t * inData )
```

Handles an incoming accelerometer read request.

Parameters

<i>id</i>	Incoming CAN ID
<i>inData</i>	Incoming CAN data

4.3.4.5 can_cmd_handle_regVal()

```
void can_cmd_handle_regVal (  
    uint32_t id,  
    uint8_t * inData )
```

Handles an incoming accelerometer register message.

Parameters

<i>id</i>	Incoming CAN ID
<i>inData</i>	Incoming CAN data

4.3.4.6 can_cmd_handle_yAcc()

```
void can_cmd_handle_yAcc (  
    uint32_t id,  
    uint8_t * inData )
```

4.3.4.7 can_driver_cmd_rx0()

```
void can_driver_cmd_rx0 (  
    uint32_t id,  
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_X_TX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.8 can_driver_cmd_rx1()

```
void can_driver_cmd_rx1 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_Y_TX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.9 can_driver_cmd_rx2()

```
void can_driver_cmd_rx2 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_Z_TX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.10 can_driver_cmd_rx3()

```
void can_driver_cmd_rx3 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_REG_RX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.11 can_driver_cmd_rx4()

```
void can_driver_cmd_rx4 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_REG_REQ

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.12 can_driver_cmd_rx5()

```
void can_driver_cmd_rx5 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type JOINT_POS_SP

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.13 can_driver_cmd_rx6()

```
void can_driver_cmd_rx6 (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type MOTOR_VLT_SP

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.14 can_driver_cmd_rx7()

```
void can_driver_cmd_rx7 (
```

```
uint32_t id,  
uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_X_TX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.15 can_driver_cmd_rx8()

```
void can_driver_cmd_rx8 (  
    uint32_t id,  
    uint8_t * inData )
```

"Generic" function to handle CAN message type JOINT_POS_TX

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.16 can_driver_cmd_rx9()

```
void can_driver_cmd_rx9 (  
    uint32_t id,  
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_X_REQ

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.17 can_driver_cmd_rxA()

```
void can_driver_cmd_rxA (  
    uint32_t id,  
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_Y_REQ

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.18 can_driver_cmd_rxB()

```
void can_driver_cmd_rxB (
    uint32_t id,
    uint8_t * inData )
```

"Generic" function to handle CAN message type ACC_Z_REQ

Parameters

<i>id</i>	CAN message ID
<i>inData</i>	CAN message data field

4.3.4.19 can_driver_queue_tx()

```
void can_driver_queue_tx (
    can_mailbox * mailbox,
    uint8_t * outData,
    uint32_t id )
```

Queues a can message for transmit, driver internal.

Parameters

<i>mailbox</i>	Mailbox struct in which data will be placed
<i>outData</i>	Data to send (8 bytes)
<i>id</i>	CAN transmit ID

4.3.4.20 can_driver_send_msg()

```
void can_driver_send_msg (
    uint8_t * data,
    uint32_t stdId,
    int dlc,
    uint8_t hwMailbox )
```

Sends a CAN message, is called by can_interface_send_msg.

Parameters

<i>data</i>	Data to send, max 8 bytes
<i>stdId</i>	Message ID required for rx handling
<i>dlc</i>	Number of bytes to send
<i>hwMailbox</i>	Hardware(!) mailbox to queue to

4.3.4.21 can_interface_queue_tx()

```
void can_interface_queue_tx (
    uint8_t mailbox,
    uint8_t * outData,
    uint32_t id )
```

Module external function for queueing a CAN message for transmit.

Parameters

<i>mailbox</i>	Mailbox number, must correspond to the correct message type
<i>outData</i>	Data to send
<i>id</i>	CAN transmit ID

4.3.4.22 can_mailbox_clear_flag()

```
void can_mailbox_clear_flag (
    can_mailbox * mailbox )
```

Clears the newmsg flag of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to clear flag from
----------------	----------------------------

4.3.4.23 can_mailbox_get_data()

```
void can_mailbox_get_data (
    can_mailbox * mailbox,
    uint8_t * target )
```

Inserts the data field of the given mailbox to target. CAUTION: memcpy 8 bytes.

Parameters

<i>mailbox</i>	Mailbox to retrieve data from
<i>target</i>	Pointer to data target

4.3.4.24 can_mailbox_get_flag()

```
uint8_t can_mailbox_get_flag (
    can_mailbox * mailbox )
```

Gets the newmsg flag of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to get
----------------	----------------

Returns

Mailbox' newmsg flag

4.3.4.25 can_mailbox_get_id()

```
uint32_t can_mailbox_get_id (
    can_mailbox * mailbox )
```

Gets the CAN message ID of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to get ID from
----------------	------------------------

Returns

CAN message ID

4.3.4.26 can_mailbox_set_data()

```
void can_mailbox_set_data (
    can_mailbox * mailbox,
    uint8_t * inData )
```

Sets the data field of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to insert data into
<i>inData</i>	Data to insert

4.3.4.27 can_mailbox_set_flag()

```
void can_mailbox_set_flag (  
    can_mailbox * mailbox )
```

Sets the newmsg flag of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to set flag
----------------	---------------------

4.3.4.28 can_mailbox_set_id()

```
void can_mailbox_set_id (  
    can_mailbox * mailbox,  
    uint32_t id )
```

Sets the CAN message ID field of the given mailbox.

Parameters

<i>mailbox</i>	Mailbox to insert ID
<i>id</i>	CAN message ID to insert

4.3.4.29 can_rx_executive()

```
void can_rx_executive ( )
```

Looks for new incoming CAN messages and handles them. MAIN LOOP ONLY.

4.3.4.30 can_tx_executive()

```
void can_tx_executive ( )
```

Looks for new CAN messages to send, sends. MAIN LOOP ONLY.

4.4 gpio_driver.h File Reference

This file contains all the function prototypes for the gpio_driver.c file.

```
#include "stdint.h"
#include "gpio.h"
#include "can_driver.h"
#include "joint_controller.h"
#include "unit_config.h"
Include dependency graph for gpio_driver.h:
```

Functions

- void [gpio_end_switch_handler](#) ()
Handler function for the rail end switch.
- void [gpio_twist_switch_handler](#) ()
Handler function for the twist joint end switch.

4.4.1 Detailed Description

This file contains all the function prototypes for the gpio_driver.c file.

Attention

GPIO driver for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The driver handles GPIO interrupts from the end switch and twist joint optical sensors. The functions are called from the HAL_GPIO_EXTI↵_Callback function declared in stm32fxx_hal_gpio.h

4.4.2 Function Documentation

4.4.2.1 gpio_end_switch_handler()

```
void gpio_end_switch_handler ( )
```

Handler function for the rail end switch.

4.4.2.2 gpio_twist_switch_handler()

```
void gpio_twist_switch_handler ( )
```

Handler function for the twist joint end switch.

4.5 joint_controller.h File Reference

This file contains all the function prototypes and struct definitions for the joint_controller.c file.

```
#include "stdint.h"
#include "math.h"
#include "tim.h"
#include "unit_config.h"
#include "uart_driver.h"
#include "motor_driver.h"
#include "can_driver.h"
#include "accelerometer_driver.h"
```

Include dependency graph for joint_controller.h: This graph shows which files directly or indirectly include this file:

Classes

- struct [joint_controller_descriptor](#)
Joint controller information database.
- struct [accelerometer_inData](#)
Holds INCOMING accelerometer data, NOT part of the accelerometer driver.

Functions

- float [controller_interface_get_setpoint](#) (uint8_t controllerSelect)
Public function to get the current positional setpoint of a joint.
- void [controller_interface_set_setpoint](#) (uint8_t controllerSelect, float setPoint)
Public function to get the current positional setpoint of a joint.
- float [controller_interface_get_position](#) (uint8_t controllerSelect)
Public function to set the positional setpoint of a joint.
- void [controller_interface_set_position](#) (uint8_t controllerSelect, float position)
Public function to get the current position of a joint.
- float [controller_interface_get_error](#) (uint8_t controllerSelect)
Public function to get the current positional error of a joint.
- void [controller_interface_update_error](#) (uint8_t controllerSelect)
Public function to trigger a calculation of the joint's positional error.
- void [controller_interface_set_error](#) (uint8_t controllerSelect, float error)
Public function to set the positional error of a joint.
- uint8_t [controller_interface_get_moving](#) (uint8_t controllerSelect)
Public function to get the moving state value of the joint.
- void [controller_interface_set_moving](#) (uint8_t controllerSelect)
Public function to set the moving state flag of the joint.
- void [controller_interface_clear_moving](#) (uint8_t controllerSelect)
Public function to clear the moving state flag of the joint.
- void [controller_interface_set_power](#) (uint8_t controllerSelect, float power)
Public function to set the power of the joint.
- void [controller_interface_update_power](#) (uint8_t controllerSelect)
Public function to trigger an update of the joint's power by PID.
- float [controller_interface_clicks_to_pos](#) (uint8_t controllerSelect)
Public function to convert the joint's associated encoder count to joint position.
- void [controller_interface_request_acc_axis](#) (uint8_t controllerSelect, uint8_t accSelect, char axis)

- Public function to request an update from the joint's accelerometer via CAN bus; acc and rot.*

 - `int16_t controller_interface_acc_getX (uint8_t accSelect)`
Public function to get the accelerometer X axis acceleration.
 - `int16_t controller_interface_acc_getY (uint8_t accSelect)`
Public function to get the accelerometer Y axis acceleration.
 - `int16_t controller_interface_acc_getZ (uint8_t accSelect)`
Public function to get the accelerometer Z axis acceleration.
 - `void controller_interface_acc_setX (uint8_t accSelect, int16_t accVal)`
Public function to set the accelerometer X axis acceleration.
 - `void controller_interface_acc_setY (uint8_t accSelect, int16_t accVal)`
Public function to set the accelerometer Y axis acceleration.
 - `void controller_interface_acc_setZ (uint8_t accSelect, int16_t accVal)`
Public function to set the accelerometer Z axis acceleration.
 - `int16_t controller_interface_rot_getX (uint8_t accSelect)`
Public function to get the accelerometer X axis rotation rate.
 - `int16_t controller_interface_rot_getY (uint8_t accSelect)`
Public function to get the accelerometer Y axis rotation rate.
 - `int16_t controller_interface_rot_getZ (uint8_t accSelect)`
Public function to get the accelerometer Z axis rotation rate.
 - `void controller_interface_rot_setX (uint8_t accSelect, int16_t rotVal)`
Public function to set the accelerometer X axis rotation rate.
 - `void controller_interface_rot_setY (uint8_t accSelect, int16_t rotVal)`
Public function to set the accelerometer Y axis rotation rate.
 - `void controller_interface_rot_setZ (uint8_t accSelect, int16_t rotVal)`
Public function to set the accelerometer Z axis rotation rate.
 - `uint8_t controller_interface_acc_get_newX (uint8_t accSelect)`
Public function to get the new X acceleration data flag.
 - `uint8_t controller_interface_acc_get_newY (uint8_t accSelect)`
Public function to get the new Y acceleration data flag.
 - `uint8_t controller_interface_acc_get_newZ (uint8_t accSelect)`
Public function to get the new Z acceleration data flag.
 - `void controller_interface_acc_set_newX (uint8_t accSelect)`
Public function to set the new X acceleration data flag.
 - `void controller_interface_acc_set_newY (uint8_t accSelect)`
Public function to set the new Y acceleration data flag.
 - `void controller_interface_acc_set_newZ (uint8_t accSelect)`
Public function to set the new Z acceleration data flag.
 - `void controller_interface_acc_clear_newX (uint8_t accSelect)`
Public function to clear the new X acceleration data flag.
 - `void controller_interface_acc_clear_newY (uint8_t accSelect)`
Public function to clear the new Y acceleration data flag.
 - `void controller_interface_acc_clear_newZ (uint8_t accSelect)`
Public function to clear the new Z acceleration data flag.
 - `uint8_t controller_interface_rot_get_newX (uint8_t accSelect)`
Public function to get the new X rotation data flag.
 - `uint8_t controller_interface_rot_get_newY (uint8_t accSelect)`
Public function to get the new Y rotation data flag.
 - `uint8_t controller_interface_rot_get_newZ (uint8_t accSelect)`
Public function to get the new Z rotation data flag.
 - `void controller_interface_rot_set_newX (uint8_t accSelect)`
Public function to set the new X rotation data flag.

- void [controller_interface_rot_set_newY](#) (uint8_t accSelect)
Public function to set the new Y rotation data flag.
- void [controller_interface_rot_set_newZ](#) (uint8_t accSelect)
Public function to set the new Z rotation data flag.
- void [controller_interface_rot_clear_newX](#) (uint8_t accSelect)
Public function to clear the new X rotation data flag.
- void [controller_interface_rot_clear_newY](#) (uint8_t accSelect)
Public function to clear the new Y rotation data flag.
- void [controller_interface_rot_clear_newZ](#) (uint8_t accSelect)
Public function to clear the new Z rotation data flag.
- uint8_t [controller_interface_get_acc_poll](#) ()
Public function to poll the timer driven accelerometer poll flag.
- uint8_t [controller_interface_get_mtr_poll](#) ()
Public function to read the timer driven motor poll flag.
- void [controller_interface_set_acc_poll](#) ()
Public function to set the accelerometer poll flag.
- void [controller_interface_set_mtr_poll](#) ()
Public function to set the motor poll flag.
- void [controller_interface_clear_acc_poll](#) ()
Public function to clear the accelerometer poll flag.
- void [controller_interface_clear_mtr_poll](#) ()
Public function to clear the motor poll flag.
- float [joint_controller_get_setpoint](#) (joint_controller_descriptor *joint)
- void [joint_controller_set_setpoint](#) (joint_controller_descriptor *joint, float setpoint)
- float [joint_controller_get_position](#) (joint_controller_descriptor *joint)
- void [joint_controller_set_position](#) (joint_controller_descriptor *joint, float position)
- float [joint_controller_get_error](#) (joint_controller_descriptor *joint)
- void [joint_controller_update_error](#) (joint_controller_descriptor *joint)
- void [joint_controller_set_error](#) (joint_controller_descriptor *joint, float error)
- uint8_t [joint_controller_get_moving](#) (joint_controller_descriptor *joint)
- void [joint_controller_set_moving](#) (joint_controller_descriptor *joint)
- void [joint_controller_clear_moving](#) (joint_controller_descriptor *joint)
- void [joint_controller_set_power](#) (joint_controller_descriptor *joint, float power)
- void [joint_controller_update_power](#) (joint_controller_descriptor *joint)
- float [joint_controller_clicks_to_pos](#) (joint_controller_descriptor *joint)
- void [joint_controller_adjust_enc_sp](#) (joint_controller_descriptor *joint)
- void [joint_controller_request_acc_axis](#) (joint_controller_descriptor *joint, uint8_t accSelect, char axis)
- float [joint_controller_acceleration_to_angle](#) (joint_controller_descriptor *joint)
- int16_t [controller_acc_getX](#) (accelerometer_inData *accSelect)
- int16_t [controller_acc_getY](#) (accelerometer_inData *accSelect)
- int16_t [controller_acc_getZ](#) (accelerometer_inData *accSelect)
- void [controller_acc_setX](#) (accelerometer_inData *accSelect, int16_t accVal)
- void [controller_acc_setY](#) (accelerometer_inData *accSelect, int16_t accVal)
- void [controller_acc_setZ](#) (accelerometer_inData *accSelect, int16_t accVal)
- int16_t [controller_rot_getX](#) (accelerometer_inData *accSelect)
- int16_t [controller_rot_getY](#) (accelerometer_inData *accSelect)
- int16_t [controller_rot_getZ](#) (accelerometer_inData *accSelect)
- void [controller_rot_setX](#) (accelerometer_inData *accSelect, int16_t rotVal)
- void [controller_rot_setY](#) (accelerometer_inData *accSelect, int16_t rotVal)
- void [controller_rot_setZ](#) (accelerometer_inData *accSelect, int16_t rotVal)
- uint8_t [controller_acc_get_newX](#) (accelerometer_inData *accSelect)
- uint8_t [controller_acc_get_newY](#) (accelerometer_inData *accSelect)
- uint8_t [controller_acc_get_newZ](#) (accelerometer_inData *accSelect)

- void `controller_acc_set_newX` (`accelerometer_inData` *`accSelect`)
- void `controller_acc_set_newY` (`accelerometer_inData` *`accSelect`)
- void `controller_acc_set_newZ` (`accelerometer_inData` *`accSelect`)
- void `controller_acc_clear_newX` (`accelerometer_inData` *`accSelect`)
- void `controller_acc_clear_newY` (`accelerometer_inData` *`accSelect`)
- void `controller_acc_clear_newZ` (`accelerometer_inData` *`accSelect`)
- uint8_t `controller_rot_get_newX` (`accelerometer_inData` *`accSelect`)
- uint8_t `controller_rot_get_newY` (`accelerometer_inData` *`accSelect`)
- uint8_t `controller_rot_get_newZ` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_set_newX` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_set_newY` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_set_newZ` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_clear_newX` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_clear_newY` (`accelerometer_inData` *`accSelect`)
- void `controller_rot_clear_newZ` (`accelerometer_inData` *`accSelect`)

4.5.1 Detailed Description

This file contains all the function prototypes and struct definitions for the `joint_controller.c` file.

Attention

Joint controller for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The controller makes use of the motor driver to implement PID positional control of the two joints for which the relevant MCU is responsible. The accelerometer struct holds data from the joint's accelerometer, where applicable, and is always received via the CAN bus. This makes accelerometer data inherent to joint control, not the accelerometer driver itself.

Private functions are not described individually, but correspond to their public counterparts. They take a joint controller descriptor struct as argument, and are called by the public functions.

4.5.2 Function Documentation

4.5.2.1 `controller_acc_clear_newX()`

```
void controller_acc_clear_newX (
    accelerometer_inData * accSelect )
```

4.5.2.2 `controller_acc_clear_newY()`

```
void controller_acc_clear_newY (
    accelerometer_inData * accSelect )
```

4.5.2.3 controller_acc_clear_newZ()

```
void controller_acc_clear_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.4 controller_acc_get_newX()

```
uint8_t controller_acc_get_newX (
    accelerometer_inData * accSelect )
```

4.5.2.5 controller_acc_get_newY()

```
uint8_t controller_acc_get_newY (
    accelerometer_inData * accSelect )
```

4.5.2.6 controller_acc_get_newZ()

```
uint8_t controller_acc_get_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.7 controller_acc_getX()

```
int16_t controller_acc_getX (
    accelerometer_inData * accSelect )
```

4.5.2.8 controller_acc_getY()

```
int16_t controller_acc_getY (
    accelerometer_inData * accSelect )
```

4.5.2.9 controller_acc_getZ()

```
int16_t controller_acc_getZ (
    accelerometer_inData * accSelect )
```

4.5.2.10 controller_acc_set_newX()

```
void controller_acc_set_newX (
    accelerometer_inData * accSelect )
```

4.5.2.11 controller_acc_set_newY()

```
void controller_acc_set_newY (
    accelerometer_inData * accSelect )
```

4.5.2.12 controller_acc_set_newZ()

```
void controller_acc_set_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.13 controller_acc_setX()

```
void controller_acc_setX (
    accelerometer_inData * accSelect,
    int16_t accVal )
```

4.5.2.14 controller_acc_setY()

```
void controller_acc_setY (
    accelerometer_inData * accSelect,
    int16_t accVal )
```

4.5.2.15 controller_acc_setZ()

```
void controller_acc_setZ (
    accelerometer_inData * accSelect,
    int16_t accVal )
```

4.5.2.16 controller_interface_acc_clear_newX()

```
void controller_interface_acc_clear_newX (
    uint8_t accSelect )
```

Public function to clear the new X acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.17 controller_interface_acc_clear_newY()

```
void controller_interface_acc_clear_newY (  
    uint8_t accSelect )
```

Public function to clear the new Y acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.18 controller_interface_acc_clear_newZ()

```
void controller_interface_acc_clear_newZ (  
    uint8_t accSelect )
```

Public function to clear the new Z acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.19 controller_interface_acc_get_newX()

```
uint8_t controller_interface_acc_get_newX (  
    uint8_t accSelect )
```

Public function to get the new X acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

X axis acceleration new data flag

4.5.2.20 controller_interface_acc_get_newY()

```
uint8_t controller_interface_acc_get_newY (
    uint8_t accSelect )
```

Public function to get the new Y acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Y axis acceleration new data flag

4.5.2.21 controller_interface_acc_get_newZ()

```
uint8_t controller_interface_acc_get_newZ (
    uint8_t accSelect )
```

Public function to get the new Z acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Z axis acceleration new data flag

4.5.2.22 controller_interface_acc_getX()

```
int16_t controller_interface_acc_getX (
    uint8_t accSelect )
```

Public function to get the accelerometer X axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

X axis acceleration raw value

4.5.2.23 controller_interface_acc_getY()

```
int16_t controller_interface_acc_getY (  
    uint8_t accSelect )
```

Public function to get the accelerometer Y axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Y axis acceleration raw value

4.5.2.24 controller_interface_acc_getZ()

```
int16_t controller_interface_acc_getZ (  
    uint8_t accSelect )
```

Public function to get the accelerometer Z axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Z axis acceleration raw value

4.5.2.25 controller_interface_acc_set_newX()

```
void controller_interface_acc_set_newX (  
    uint8_t accSelect )
```

Public function to set the new X acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.26 controller_interface_acc_set_newY()

```
void controller_interface_acc_set_newY (
    uint8_t accSelect )
```

Public function to set the new Y acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.27 controller_interface_acc_set_newZ()

```
void controller_interface_acc_set_newZ (
    uint8_t accSelect )
```

Public function to set the new Z acceleration data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.28 controller_interface_acc_setX()

```
void controller_interface_acc_setX (
    uint8_t accSelect,
    int16_t accVal )
```

Public function to set the accelerometer X axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>accVal</i>	X axis acceleration raw value

4.5.2.29 controller_interface_acc_setY()

```
void controller_interface_acc_setY (
    uint8_t accSelect,
    int16_t accVal )
```

Public function to set the accelerometer Y axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>accVal</i>	Y axis acceleration raw value

4.5.2.30 controller_interface_acc_setZ()

```
void controller_interface_acc_setZ (
    uint8_t accSelect,
    int16_t accVal )
```

Public function to set the accelerometer Z axis acceleration.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>accVal</i>	Z axis acceleration raw value

4.5.2.31 controller_interface_clear_acc_poll()

```
void controller_interface_clear_acc_poll ( )
```

Public function to clear the accelerometer poll flag.

4.5.2.32 controller_interface_clear_moving()

```
void controller_interface_clear_moving (
    uint8_t controllerSelect )
```

Public function to clear the moving state flag of the joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

4.5.2.33 controller_interface_clear_mtr_poll()

```
void controller_interface_clear_mtr_poll ( )
```

Public function to clear the motor poll flag.

4.5.2.34 controller_interface_clicks_to_pos()

```
float controller_interface_clicks_to_pos (
    uint8_t controllerSelect )
```

Public function to convert the joint's associated encoder count to joint position.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

Returns

Joint position in rads

4.5.2.35 controller_interface_get_acc_poll()

```
uint8_t controller_interface_get_acc_poll ( )
```

Public function to poll the timer driven accelerometer poll flag.

Returns

Status of the accelerometer poll flag

4.5.2.36 controller_interface_get_error()

```
float controller_interface_get_error (
    uint8_t controllerSelect )
```

Public function to get the current positional error of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

Returns

Joint positional error in rads relative to its setpoint

4.5.2.37 controller_interface_get_moving()

```
uint8_t controller_interface_get_moving (
    uint8_t controllerSelect )
```

Public function to get the moving state value of the joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

Returns

isMoving flag

4.5.2.38 controller_interface_get_mtr_poll()

```
uint8_t controller_interface_get_mtr_poll ( )
```

Public function to read the timer driven motor poll flag.

Returns

Status of the accelerometer poll flag

4.5.2.39 controller_interface_get_position()

```
float controller_interface_get_position (
    uint8_t controllerSelect )
```

Public function to set the positional setpoint of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

Returns

Joint position in radians relative to its zero position

4.5.2.40 controller_interface_get_setpoint()

```
float controller_interface_get_setpoint (
    uint8_t controllerSelect )
```

Public function to get the current positional setpoint of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

Returns

Joint positional setpoints in radians relative to its zero position

4.5.2.41 controller_interface_request_acc_axis()

```
void controller_interface_request_acc_axis (
    uint8_t controllerSelect,
    uint8_t accSelect,
    char axis )
```

Public function to request an update from the joint's accelerometer via CAN bus; acc and rot.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
<i>accSelect</i>	(One of) the joint's accelerometer(s)
<i>axis</i>	The axis for which information is requested

4.5.2.42 controller_interface_rot_clear_newX()

```
void controller_interface_rot_clear_newX (
    uint8_t accSelect )
```

Public function to clear the new X rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.43 controller_interface_rot_clear_newY()

```
void controller_interface_rot_clear_newY (
    uint8_t accSelect )
```

Public function to clear the new Y rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.44 controller_interface_rot_clear_newZ()

```
void controller_interface_rot_clear_newZ (
    uint8_t accSelect )
```

Public function to clear the new Z rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.45 controller_interface_rot_get_newX()

```
uint8_t controller_interface_rot_get_newX (
    uint8_t accSelect )
```

Public function to get the new X rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Z axis rotation new data flag

4.5.2.46 controller_interface_rot_get_newY()

```
uint8_t controller_interface_rot_get_newY (
    uint8_t accSelect )
```

Public function to get the new Y rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Y axis rotation new data flag

4.5.2.47 controller_interface_rot_get_newZ()

```
uint8_t controller_interface_rot_get_newZ (  
    uint8_t accSelect )
```

Public function to get the new Z rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Z axis rotation new data flag

4.5.2.48 controller_interface_rot_getX()

```
int16_t controller_interface_rot_getX (  
    uint8_t accSelect )
```

Public function to get the accelerometer X axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

X axis rotation rate raw value

4.5.2.49 controller_interface_rot_getY()

```
int16_t controller_interface_rot_getY (  
    uint8_t accSelect )
```

Public function to get the accelerometer Y axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Y axis rotation rate raw value

4.5.2.50 controller_interface_rot_getZ()

```
int16_t controller_interface_rot_getZ (  
    uint8_t accSelect )
```

Public function to get the accelerometer Z axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

Returns

Z axis rotation rate raw value

4.5.2.51 controller_interface_rot_set_newX()

```
void controller_interface_rot_set_newX (  
    uint8_t accSelect )
```

Public function to set the new X rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.52 controller_interface_rot_set_newY()

```
void controller_interface_rot_set_newY (  
    uint8_t accSelect )
```

Public function to set the new Y rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.53 controller_interface_rot_set_newZ()

```
void controller_interface_rot_set_newZ (
    uint8_t accSelect )
```

Public function to set the new Z rotation data flag.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
------------------	--

4.5.2.54 controller_interface_rot_setX()

```
void controller_interface_rot_setX (
    uint8_t accSelect,
    int16_t rotVal )
```

Public function to set the accelerometer X axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>rotVal</i>	X axis rotation rate raw value

4.5.2.55 controller_interface_rot_setY()

```
void controller_interface_rot_setY (
    uint8_t accSelect,
    int16_t rotVal )
```

Public function to set the accelerometer Y axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>rotVal</i>	Y axis rotation rate raw value

4.5.2.56 controller_interface_rot_setZ()

```
void controller_interface_rot_setZ (
    uint8_t accSelect,
    int16_t rotVal )
```

Public function to set the accelerometer Z axis rotation rate.

Parameters

<i>accSelect</i>	The relevant accelerometer inData struct
<i>rotVal</i>	Z axis rotation rate raw value

4.5.2.57 controller_interface_set_acc_poll()

```
void controller_interface_set_acc_poll ( )
```

Public function to set the accelerometer poll flag.

4.5.2.58 controller_interface_set_error()

```
void controller_interface_set_error (
    uint8_t controllerSelect,
    float error )
```

Public function to set the positional error of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
<i>error</i>	Joint positional error in rads

4.5.2.59 controller_interface_set_moving()

```
void controller_interface_set_moving (
    uint8_t controllerSelect )
```

Public function to set the moving state flag of the joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

4.5.2.60 controller_interface_set_mtr_poll()

```
void controller_interface_set_mtr_poll ( )
```

Public function to set the motor poll flag.

4.5.2.61 controller_interface_set_position()

```
void controller_interface_set_position (
    uint8_t controllerSelect,
    float position )
```

Public function to get the current position of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
<i>position</i>	Joint position in rads relative to its zero position

4.5.2.62 controller_interface_set_power()

```
void controller_interface_set_power (
    uint8_t controllerSelect,
    float power )
```

Public function to set the power of the joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
<i>power</i>	Percentage of maximum power

4.5.2.63 controller_interface_set_setpoint()

```
void controller_interface_set_setpoint (
    uint8_t controllerSelect,
    float setPoint )
```

Public function to get the current positional setpoint of a joint.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
<i>setPoint</i>	Joint positional setpoint in rads relative to its zero position

4.5.2.64 controller_interface_update_error()

```
void controller_interface_update_error (
    uint8_t controllerSelect )
```

Public function to trigger a calculation of the joint's positional error.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

4.5.2.65 controller_interface_update_power()

```
void controller_interface_update_power (
    uint8_t controllerSelect )
```

Public function to trigger an update of the joint's power by PID.

Parameters

<i>controllerSelect</i>	One of two joints available to the MCU
-------------------------	--

4.5.2.66 controller_rot_clear_newX()

```
void controller_rot_clear_newX (
    accelerometer_inData * accSelect )
```

4.5.2.67 controller_rot_clear_newY()

```
void controller_rot_clear_newY (
    accelerometer_inData * accSelect )
```


4.5.2.68 controller_rot_clear_newZ()

```
void controller_rot_clear_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.69 controller_rot_get_newX()

```
uint8_t controller_rot_get_newX (
    accelerometer_inData * accSelect )
```

4.5.2.70 controller_rot_get_newY()

```
uint8_t controller_rot_get_newY (
    accelerometer_inData * accSelect )
```

4.5.2.71 controller_rot_get_newZ()

```
uint8_t controller_rot_get_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.72 controller_rot_getX()

```
int16_t controller_rot_getX (
    accelerometer_inData * accSelect )
```

4.5.2.73 controller_rot_getY()

```
int16_t controller_rot_getY (
    accelerometer_inData * accSelect )
```

4.5.2.74 controller_rot_getZ()

```
int16_t controller_rot_getZ (
    accelerometer_inData * accSelect )
```

4.5.2.75 controller_rot_set_newX()

```
void controller_rot_set_newX (
    accelerometer_inData * accSelect )
```

4.5.2.76 controller_rot_set_newY()

```
void controller_rot_set_newY (
    accelerometer_inData * accSelect )
```

4.5.2.77 controller_rot_set_newZ()

```
void controller_rot_set_newZ (
    accelerometer_inData * accSelect )
```

4.5.2.78 controller_rot_setX()

```
void controller_rot_setX (
    accelerometer_inData * accSelect,
    int16_t rotVal )
```

4.5.2.79 controller_rot_setY()

```
void controller_rot_setY (
    accelerometer_inData * accSelect,
    int16_t rotVal )
```

4.5.2.80 controller_rot_setZ()

```
void controller_rot_setZ (
    accelerometer_inData * accSelect,
    int16_t rotVal )
```

4.5.2.81 joint_controller_acceleration_to_angle()

```
float joint_controller_acceleration_to_angle (
    joint_controller_descriptor * joint )
```

4.5.2.82 joint_controller_adjust_enc_sp()

```
void joint_controller_adjust_enc_sp (
    joint_controller_descriptor * joint )
```

4.5.2.83 joint_controller_clear_moving()

```
void joint_controller_clear_moving (
    joint_controller_descriptor * joint )
```

4.5.2.84 joint_controller_clicks_to_pos()

```
float joint_controller_clicks_to_pos (
    joint_controller_descriptor * joint )
```

4.5.2.85 joint_controller_get_error()

```
float joint_controller_get_error (
    joint_controller_descriptor * joint )
```

4.5.2.86 joint_controller_get_moving()

```
uint8_t joint_controller_get_moving (
    joint_controller_descriptor * joint )
```

4.5.2.87 joint_controller_get_position()

```
float joint_controller_get_position (
    joint_controller_descriptor * joint )
```

4.5.2.88 joint_controller_get_setpoint()

```
float joint_controller_get_setpoint (
    joint_controller_descriptor * joint )
```

Private functions are not described individually, but serve the same purpose as their public counterparts. The joint controller descriptors are static structs defined in the .c file and correspond to the unique joints of the robotic arm.

4.5.2.89 joint_controller_request_acc_axis()

```
void joint_controller_request_acc_axis (
    joint_controller_descriptor * joint,
    uint8_t accSelect,
    char axis )
```

4.5.2.90 joint_controller_set_error()

```
void joint_controller_set_error (
    joint_controller_descriptor * joint,
    float error )
```

4.5.2.91 joint_controller_set_moving()

```
void joint_controller_set_moving (
    joint_controller_descriptor * joint )
```

4.5.2.92 joint_controller_set_position()

```
void joint_controller_set_position (
    joint_controller_descriptor * joint,
    float position )
```

4.5.2.93 joint_controller_set_power()

```
void joint_controller_set_power (
    joint_controller_descriptor * joint,
    float power )
```

4.5.2.94 joint_controller_set_setpoint()

```
void joint_controller_set_setpoint (
    joint_controller_descriptor * joint,
    float setpoint )
```

4.5.2.95 joint_controller_update_error()

```
void joint_controller_update_error (
    joint_controller_descriptor * joint )
```

4.5.2.96 joint_controller_update_power()

```
void joint_controller_update_power (
    joint_controller_descriptor * joint )
```

4.6 motor_driver.h File Reference

This file contains all the function prototypes and struct definitions for the motor_driver.c file.

```
#include "stdint.h"
#include "math.h"
#include "tim.h"
#include "unit_config.h"
#include "uart_driver.h"
```

Include dependency graph for motor_driver.h: This graph shows which files directly or indirectly include this file:

Classes

- struct [motor_descriptor](#)

Contains static and state information relevant to the operation of a motor driver.

Functions

- void [motor_interface_controller_init](#) (uint8_t motorSelect)
Initialize the controller interface.
- void [motor_interface_update_power](#) (uint8_t motorSelect)
Update the power setting of the selected motor based on the relevant controller (P/I/D)
- void [motor_interface_update_tot_cnt](#) (uint8_t motorSelect)
Update the total number of registered encoder counts since init.
- int32_t [motor_interface_get_setpoint](#) (uint8_t motorSelect)
Returns the setpoint of the selected motors.
- int32_t [motor_interface_get_total_count](#) (uint8_t motorSelect)
Returns the number of total registered encoder counts since init.
- uint16_t [motor_interface_get_encoder_count](#) (uint8_t motorSelect)
Returns the current encoder hardware count.
- uint8_t [motor_interface_get_id](#) (uint8_t motorSelect)
Returns the numerical ID of the motor.
- int32_t [motor_interface_get_resolution](#) (uint8_t motorSelect)
Returns the resolution of the motor in encoder clicks per rad or mm.
- uint8_t [motor_interface_get_moving](#) (uint8_t motorSelect)
Returns the isMoving flag.
- void [motor_interface_set_power](#) (uint8_t motorSelect, uint8_t direction, double power)
Lets the user set the motor power setting directly.
- void [motor_interface_set_setpoint](#) (uint8_t motorSelect, int32_t setpoint)
Lets the user set the motor setpoint directly.
- void [motor_interface_delta_setpoint](#) (uint8_t motorSelect, int32_t delta)
Lets the user increment or decrement the motor encoder setpoint.
- void [motor_driver_init](#) (motor_descriptor *motor)
Initialise motor controller descriptor.
- void [motor_driver_update_power](#) (motor_descriptor *motor)
Sets the power of the selected motor based on a controller heuristic.
- void [motor_driver_update_tot_cnt](#) (motor_descriptor *motor)
Updates the encoder total count based on the relevant heuristic.
- int32_t [motor_driver_get_setpoint](#) (motor_descriptor *motor)
Gets the total encoder count setpoint of the selected motor.
- int32_t [motor_driver_get_total_cnt](#) (motor_descriptor *motor)
Gets the total encoder count since init.
- uint16_t [motor_driver_get_encoder_cnt](#) (motor_descriptor *motor)
Gets the current hardware encoder count.
- uint8_t [motor_driver_get_id](#) (motor_descriptor *motor)
- int32_t [motor_driver_get_resolution](#) (motor_descriptor *motor)
- uint8_t [motor_driver_get_moving](#) (motor_descriptor *motor)
- void [motor_driver_set_power](#) (motor_descriptor *motor, uint8_t direction, double power)
Set the power of a motor, limited by the motor's safety cap.
- void [motor_driver_set_setpoint](#) (motor_descriptor *motor, int32_t setpoint)
Sets the total encoder count setpoint of the selected motor.
- void [motor_driver_delta_setpoint](#) (motor_descriptor *motor, int32_t delta)
Changes the encoder setpoint of the relevant motor.
- void [motor_driver_set_pwm_dc](#) (uint32_t *timerCounter, double pct)
Sets the duty cycle of the selected PWM timer as a percentage of max.
- void [motor_driver_calc_safe_vlt](#) (motor_descriptor *motor)
Calculates the safe power percentage limit based on the descriptor struct.
- void [motor_driver_go_forward](#) (double pct, TIM_TypeDef *mtr, int8_t polarity)
Forward is the direction of increasing encoder count.
- void [motor_driver_go_backward](#) (double pct, TIM_TypeDef *mtr, int8_t polarity)
Backward is the direction of decreasing encoder count.

4.6.1 Detailed Description

This file contains all the function prototypes and struct definitions for the motor_driver.c file.

Attention

Motor driver for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The driver makes use of the STM32's timer peripheral to generate PWM signals driving the DRV8251A H-bridge motor drivers. The motor descriptor structs hold information relevant to the control of each motor, most importantly the safe voltage limit for each motor embedded in the robotic arm. Additionally, "trip" information such as the total number of encoder counts registered since startup, critical to the state estimation of the arm.

As all STM32s are responsible for the driving of two motors each, the .c file defines two instances of the descriptor struct, motor0 and motor1.

4.6.2 Function Documentation

4.6.2.1 motor_driver_calc_safe_vlt()

```
void motor_driver_calc_safe_vlt (
    motor_descriptor * motor )
```

Calculates the safe power percentage limit based on the descriptor struct.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

4.6.2.2 motor_driver_delta_setpoint()

```
void motor_driver_delta_setpoint (
    motor_descriptor * motor,
    int32_t delta )
```

Changes the encoder setpoint of the relevant motor.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
<i>delta</i>	Change to encoder count setpoint

4.6.2.3 motor_driver_get_encoder_cnt()

```
uint16_t motor_driver_get_encoder_cnt (
    motor_descriptor * motor )
```

Gets the current hardware encoder count.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

Returns

TIMx->CNT

4.6.2.4 motor_driver_get_id()

```
uint8_t motor_driver_get_id (
    motor_descriptor * motor )
```

Parameters

<i>motorSelect</i>	
--------------------	--

Returns

4.6.2.5 motor_driver_get_moving()

```
uint8_t motor_driver_get_moving (
    motor_descriptor * motor )
```

Parameters

<i>motor</i>	
--------------	--

Returns

4.6.2.6 motor_driver_get_resolution()

```
int32_t motor_driver_get_resolution (
    motor_descriptor * motor )
```

Parameters

<i>motor</i>	
--------------	--

Returns

4.6.2.7 motor_driver_get_setpoint()

```
int32_t motor_driver_get_setpoint (
    motor_descriptor * motor )
```

Gets the total encoder count setpoint of the selected motor.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

Returns

encoderTotalSetpoint

4.6.2.8 motor_driver_get_total_cnt()

```
int32_t motor_driver_get_total_cnt (
    motor_descriptor * motor )
```

Gets the total encoder count since init.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

Returns

encoderTotalCount

4.6.2.9 motor_driver_go_backward()

```
void motor_driver_go_backward (
    double pct,
    TIM_TypeDef * mtr,
    int8_t polarity )
```

Backward is the direction of decreasing encoder count.

Parameters

<i>pct</i>	Percentage of input voltage
<i>mtr</i>	Pointer to timer

4.6.2.10 motor_driver_go_forward()

```
void motor_driver_go_forward (
    double pct,
    TIM_TypeDef * mtr,
    int8_t polarity )
```

Forward is the direction of increasing encoder count.

Parameters

<i>pct</i>	Percentage of input voltage
<i>mtr</i>	Pointer to timer

4.6.2.11 motor_driver_init()

```
void motor_driver_init (
    motor_descriptor * motor )
```

Initialise motor controller descriptor.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

4.6.2.12 motor_driver_set_power()

```
void motor_driver_set_power (
    motor_descriptor * motor,
```

```
uint8_t direction,  
double power )
```

Set the power of a motor, limited by the motor's safety cap.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
<i>direction</i>	0 or 1 for forwards or backwards, respectively
<i>power</i>	percentage of input voltage

4.6.2.13 motor_driver_set_pwm_dc()

```
void motor_driver_set_pwm_dc (  
    uint32_t * timerCounter,  
    double pct )
```

Sets the duty cycle of the selected PWM timer as a percentage of max.

Parameters

<i>timerCounter</i>	Pointer to the relevant TIMx->CNT register
<i>pct</i>	Percentage of maximum duty cycle

4.6.2.14 motor_driver_set_setpoint()

```
void motor_driver_set_setpoint (  
    motor_descriptor * motor,  
    int32_t setpoint )
```

Sets the total encoder count setpoint of the selected motor.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
<i>setpoint</i>	Total encoder count

4.6.2.15 motor_driver_update_power()

```
void motor_driver_update_power (  
    motor_descriptor * motor )
```

Sets the power of the selected motor based on a controller heuristic.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

4.6.2.16 motor_driver_update_tot_cnt()

```
void motor_driver_update_tot_cnt (
    motor_descriptor * motor )
```

Updates the encoder total count based on the relevant heuristic.

Parameters

<i>motor</i>	Pointer to the relevant motor struct, motor0 or motor1
--------------	--

4.6.2.17 motor_interface_controller_init()

```
void motor_interface_controller_init (
    uint8_t motorSelect )
```

Initialize the controller interface.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

4.6.2.18 motor_interface_delta_setpoint()

```
void motor_interface_delta_setpoint (
    uint8_t motorSelect,
    int32_t delta )
```

Lets the user increment or decrement the motor encoder setpoint.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
<i>delta</i>	int32_t, number of encoder clicks by which the setpoint is changed

4.6.2.19 motor_interface_get_encoder_count()

```
uint16_t motor_interface_get_encoder_count (
    uint8_t motorSelect )
```

Returns the current encoder hardware count.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

TIMx->CNT

4.6.2.20 motor_interface_get_id()

```
uint8_t motor_interface_get_id (
    uint8_t motorSelect )
```

Returns the numerical ID of the motor.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

motorID

4.6.2.21 motor_interface_get_moving()

```
uint8_t motor_interface_get_moving (
    uint8_t motorSelect )
```

Returns the isMoving flag.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

isMoving

4.6.2.22 motor_interface_get_resolution()

```
int32_t motor_interface_get_resolution (
    uint8_t motorSelect )
```

Returns the resolution of the motor in encoder clicks per rad or mm.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

resolution

4.6.2.23 motor_interface_get_setpoint()

```
int32_t motor_interface_get_setpoint (
    uint8_t motorSelect )
```

Returns the setpoint of the selected motors.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

encoderTotalSetpoint

4.6.2.24 motor_interface_get_total_count()

```
int32_t motor_interface_get_total_count (
    uint8_t motorSelect )
```

Returns the number of total registered encoder counts since init.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

Returns

encoderTotalCount

4.6.2.25 motor_interface_set_power()

```
void motor_interface_set_power (
    uint8_t motorSelect,
    uint8_t direction,
    double power )
```

Lets the user set the motor power setting directly.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
<i>direction</i>	0 or 1 for forwards or backwards, respectively
<i>power</i>	percentage of input voltage

4.6.2.26 motor_interface_set_setpoint()

```
void motor_interface_set_setpoint (
    uint8_t motorSelect,
    int32_t setpoint )
```

Lets the user set the motor setpoint directly.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
<i>setpoint</i>	int32_t

4.6.2.27 motor_interface_update_power()

```
void motor_interface_update_power (
    uint8_t motorSelect )
```

Update the power setting of the selected motor based on the relevant controller (P/I/D)

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

4.6.2.28 motor_interface_update_tot_cnt()

```
void motor_interface_update_tot_cnt (
    uint8_t motorSelect )
```

Update the total number of registered encoder counts since init.

Parameters

<i>motorSelect</i>	0 or 1 for motor0 or motor1 respectively
--------------------	--

4.7 shoulder_controller.h File Reference

```
#include "string.h"
#include <stdio.h>
#include "math.h"
#include "uart_driver.h"
#include "accelerometer_driver.h"
#include "motor_driver.h"
#include "can_driver.h"
Include dependency graph for shoulder_controller.h:
```

Classes

- struct [controller_descriptor](#)

4.8 string_cmd_parser.h File Reference

This file contains all the function prototypes and struct definitions for the string_cmd_parser.c file.

```
#include "string.h"
#include <stdio.h>
#include <stdlib.h>
#include "stdint.h"
#include "unit_config.h"
#include "motor_driver.h"
#include "can_driver.h"
#include "joint_controller.h"
```

Include dependency graph for string_cmd_parser.h: This graph shows which files directly or indirectly include this file:

Classes

- struct [string_cmd_processor_args](#)
Wrapper struct to enable a variable number of arguments to the string processor.
- struct [string_cmd_pair](#)
Pairs a command string token with a function pointer.

Macros

- #define [string_cmd_processor\(...\)](#) [string_cmd_processor_wrp\(\(string_cmd_processor_args*\){__VA_ARGS__}\)](#)
- #define [NUM_STRING_COMMANDS](#) 0xA

Functions

- void [string_cmd_processor_wrp](#) ([string_cmd_processor_args](#) *input)
Wrapper function to enable a variable number of arguments to the string processor.
- void [string_cmd_processor_base](#) (char *inputString, uint8_t stringLength)
Starting point for string processing, splits and incoming string into tokens delimited by " ".
- void [string_cmd_category_local_motor](#) (uint8_t motor, char(*inputTokens)[64])
Handles commands to a motor/joint controller local to the STM32 connected to the serial interface.
- void [string_cmd_category_remote_motor](#) (uint8_t motor, char(*inputTokens)[64])
Handles commands to a motor/joint controller accessible via CAN from the STM32 connected to the serial interface.
- void [string_cmd_category_adc](#) ()
Handles commands to an ADC (NOTE: Not implemented)
- void [string_cmd_category_accelerometer](#) ()
Handles commands to an accelerometer (NOTE: Not implemented)
- void [string_cmd_rail](#) (char(*inputTokens)[64])
Called when "rail" token is registered; concerns the rail linear joint.
- void [string_cmd_shoulder](#) (char(*inputTokens)[64])
Called when "shoulder" token is registered; concerns the shoulder joint.
- void [string_cmd_elbow](#) (char(*inputTokens)[64])
Called when "elbow" token is registered; concerns the elbow joint.
- void [string_cmd_wrist](#) (char(*inputTokens)[64])
Called when "wrist" token is registered; concerns the wrist joint.
- void [string_cmd_twist](#) (char(*inputTokens)[64])
Called when "twist" token is registered; concerns the twist joint.
- void [string_cmd_pinch](#) (char(*inputTokens)[64])
Called when "pinch" token is registered; concerns the pinch joint.
- void [string_cmd_can](#) (char(*inputTokens)[64])
Called when "can" token is registered; concerns the CAN bus.
- void [string_cmd_stop](#) (char(*inputTokens)[64])
Called when "S" token is registered; soft emergency stop for all joints.
- void [string_cmd_acc1](#) (char(*inputTokens)[64])
Called when "acc1" token is registered; concerns the shoulder accelerometer.
- void [string_cmd_rly](#) (char(*inputTokens)[64])
Called when "relay" token is registered; concerns the motor driver enable relays.

Variables

- static `string_cmd_pair stringCmdList [NUM_STRING_COMMANDS]`
Pairing of string commands and handler functions.

4.8.1 Detailed Description

This file contains all the function prototypes and struct definitions for the `string_cmd_parser.c` file.

Attention

Keyboard input string parser for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The parser makes use of the joint controller, motor driver, and the STM32's UART peripheral as well as C string libraries to enable debugging of the arm during development. It lets the user write specified commands to a serial interface such as PuTTY to control joints directly, as well as make sensor readouts on demand.

The `string_cmd_pair` list defines valid commands available to the user, which may be expanded at will. When using the arm with a serial interface, an input string beginning with one of the defined words will be handled by the corresponding function. In the interest of standardisation, all input strings limited to 64 characters.

4.8.2 Macro Definition Documentation

4.8.2.1 NUM_STRING_COMMANDS

```
#define NUM_STRING_COMMANDS 0xA
```

4.8.2.2 string_cmd_processor

```
#define string_cmd_processor(  
    ... ) string_cmd_processor_wrp((string_cmd_processor_args*) {__VA_ARGS__})
```

4.8.3 Function Documentation

4.8.3.1 string_cmd_acc1()

```
void string_cmd_acc1 (  
    char(*) inputTokens[64] )
```

Called when "acc1" token is registered; concerns the shoulder accelerometer.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.2 string_cmd_can()

```
void string_cmd_can (
    char(*) inputTokens[64] )
```

Called when "can" token is registered; concerns the CAN bus.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.3 string_cmd_category_accelerometer()

```
void string_cmd_category_accelerometer ( )
```

Handles commands to an accelerometer (NOTE: Not implemented)

4.8.3.4 string_cmd_category_adc()

```
void string_cmd_category_adc ( )
```

Handles commands to an ADC (NOTE: Not implemented)

4.8.3.5 string_cmd_category_local_motor()

```
void string_cmd_category_local_motor (
    uint8_t motor,
    char(*) inputTokens[64] )
```

Handles commands to a motor/joint controller local to the STM32 connected to the serial interface.

Parameters

<i>motor</i>	One of two motors, 0 or 1
<i>inputTokens</i>	Tokens received from the string processor

4.8.3.6 string_cmd_category_remote_motor()

```
void string_cmd_category_remote_motor (
    uint8_t motor,
    char(*) inputTokens[64] )
```

Handles commands to a motor/joint controller accessible via CAN from the STM32 connected to the serial interface.

Parameters

<i>motor</i>	One of two motors, 0 or 1
<i>inputTokens</i>	Tokens received from the string processor

4.8.3.7 string_cmd_elbow()

```
void string_cmd_elbow (
    char(*) inputTokens[64] )
```

Called when "elbow" token is registered; concerns the elbow joint.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.8 string_cmd_pinch()

```
void string_cmd_pinch (
    char(*) inputTokens[64] )
```

Called when "pinch" token is registered; concerns the pinch joint.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.9 string_cmd_processor_base()

```
void string_cmd_processor_base (
    char * inputString,
    uint8_t stringLength )
```

Starting point for string processing, splits and incoming string into tokens delimited by " ".

Parameters

<i>inputString</i>	The string to be processed
<i>stringLength</i>	Length of the string to be processed

4.8.3.10 string_cmd_processor_wrp()

```
void string_cmd_processor_wrp (
    string_cmd_processor_args * input )
```

Wrapper function to enable a variable number of arguments to the string processor.

Parameters

<i>input</i>	Pointer to arguments
--------------	----------------------

4.8.3.11 string_cmd_rail()

```
void string_cmd_rail (
    char (*) inputTokens[64] )
```

Called when "rail" token is registered; concerns the rail linear joint.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.12 string_cmd_rly()

```
void string_cmd_rly (
    char (*) inputTokens[64] )
```

Called when "relay" token is registered; concerns the motor driver enable relays.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.13 string_cmd_shoulders()

```
void string_cmd_shoulders (
    char(*) inputTokens[64] )
```

Called when "shoulders" token is registered; concerns the shoulders joint.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.14 string_cmd_stop()

```
void string_cmd_stop (
    char(*) inputTokens[64] )
```

Called when "S" token is registered; soft emergency stop for all joints.

Parameters

<i>inputTokens</i>	Arguments to parse (none)
--------------------	---------------------------

4.8.3.15 string_cmd_twist()

```
void string_cmd_twist (
    char(*) inputTokens[64] )
```

Called when "twist" token is registered; concerns the twist joint.

Parameters

<i>inputTokens</i>	Arguments to parse
--------------------	--------------------

4.8.3.16 string_cmd_wrist()

```
void string_cmd_wrist (
    char(*) inputTokens[64] )
```

Called when "wrist" token is registered; concerns the wrist joint.

Parameters

<code>inputTokens</code>	Arguments to parse
--------------------------	--------------------

4.8.4 Variable Documentation

4.8.4.1 stringCmdList

```
string_cmd_pair stringCmdList[NUM\_STRING\_COMMANDS] [static]
```

Initial value:

```
=
{
    {"rail", string\_cmd\_rail},
    {"shoulder", string\_cmd\_should},
    {"elbow", string\_cmd\_elbow},
    {"wrist", string\_cmd\_wrist},
    {"twist", string\_cmd\_twist},
    {"pinch", string\_cmd\_pinch},
    {"can", string\_cmd\_can},
    {"S", string\_cmd\_stop},
    {"accl", string\_cmd\_accl},
    {"relay", string\_cmd\_rly}
}
```

Pairing of string commands and handler functions.

4.9 uart_driver.h File Reference

This file contains all the function prototypes for the `string_cmd_parser.c` file.

```
#include "string.h"
#include <stdio.h>
#include "usart.h"
#include "unit_config.h"
#include "string_cmd_parser.h"
```

Include dependency graph for `uart_driver.h`: This graph shows which files directly or indirectly include this file:

Functions

- void [uart_send_string](#) (char *str)
Sends a string over the UART peripheral interface.
- void [uart_parse_input](#) (char *input, uint8_t *buffer, uint8_t bufferLength, uint8_t *bufferPos)
Reads incoming UART data and enables a keyboard based HMI to the STM32.
- void [uart_hmi_rx_handler](#) ()
Handles incoming UART data when the peripheral is used as HMI.
- void [uart_hmi_init](#) ()
Initializes the UART peripheral as HMI.
- void [uart_ros_rx_handler](#) ()
Handles incoming UART data when the peripheral is used for ROS.
- void [uart_ros_init](#) ()
Initializes the UART peripheral as ROS interface.

4.9.1 Detailed Description

This file contains all the function prototypes for the `string_cmd_parser.c` file.

Attention

UART serial interface driver for the TTK4900 Master project of Kristian Blom, spring semester of 2024. The driver makes use of the STM32's UART peripheral, as well as the string command parser module and C string libraries to do basic processing of incoming and outgoing UART data.

The parser/handler functions are triggered by the `HAL_UART_RxCpltCallback`

4.9.2 Function Documentation

4.9.2.1 `uart_hmi_init()`

```
void uart_hmi_init ( )
```

Initializes the UART peripheral as HMI.

4.9.2.2 `uart_hmi_rx_handler()`

```
void uart_hmi_rx_handler ( )
```

Handles incoming UART data when the peripheral is used as HMI.

4.9.2.3 `uart_parse_input()`

```
void uart_parse_input (
    char * input,
    uint8_t * buffer,
    uint8_t bufferLength,
    uint8_t * bufferPos )
```

Reads incoming UART data and enables a keyboard based HMI to the STM32.

Parameters

<i>input</i>	Last incoming byte
<i>buffer</i>	String buffer holding the currently relevant strings
<i>bufferLength</i>	Length of buffer
<i>bufferPos</i>	Keyboard cursor position in buffer

4.9.2.4 uart_ros_init()

```
void uart_ros_init ( )
```

Initializes the UART peripheral as ROS interface.

4.9.2.5 uart_ros_rx_handler()

```
void uart_ros_rx_handler ( )
```

Handles incoming UART data when the peripheral is used for ROS.

4.9.2.6 uart_send_string()

```
void uart_send_string (
    char * str )
```

Sends a string over the UART peripheral interface.

Parameters

<i>str</i>	string to send
------------	----------------

4.10 unit_config.h File Reference

This file contains global information relevant to building the project for a specific STM32 in the robotic arm.

This graph shows which files directly or indirectly include this file:

Macros

- #define [MTR1](#) TIM15
test
- #define [MTR2](#) TIM1
- #define [ENC1](#) TIM3
- #define [ENC2](#) TIM8
- #define [PWM_CTR_PRD](#) 7200
- #define [GLOBAL_DEBUG](#) 1
- #define [VOLTAGE_IN](#) 20
- #define [TORSO](#) 0

- `#define SHOULDER 1`
- `#define HAND 2`
- `#define ACTIVE_UNIT TORSO`
- `#define UART_INTERFACE 0`
- `#define USB_INTERFACE 1`
- `#define HW_INTERFACE UART_INTERFACE`
- `#define CMD_MODE_TERMINAL 0`
- `#define CMD_MODE_ROS 1`
- `#define SW_INTERFACE CMD_MODE_TERMINAL`
- `#define CAN_FILTER_M 0x000`
- `#define CAN_FILTERMASK_M 0x300`
- `#define CAN_FILTER_A 0x000`
- `#define CAN_FILTERMASK_A 0x0E0`
- `#define MTR_POL -1`
- `#define UART_INPUT 1`

Functions

- `void activate_peripherals ()`

4.10.1 Detailed Description

This file contains global information relevant to building the project for a specific STM32 in the robotic arm.

Attention

STM32 project configuration for the TTK4900 Master project of Kristian Blom, spring semester of 2024. This file specifies information unique to each STM32, i.e. the torso, shoulder and hand unit, respectively, as well as some convenience definitions common to all three.

The most important parameter is `ACTIVE_UNIT`, as this flag specifies which modules will be compiled, CAN message ID filters, and safe power levels for each motor. CAUTION: Flashing an STM32 unit with the wrong `ACTIVE_UNIT` flag may cause harm to the motors, as an inappropriate safe power level may be calculated for that motor.

4.10.2 Macro Definition Documentation

4.10.2.1 ACTIVE_UNIT

```
#define ACTIVE_UNIT TORSO
```

4.10.2.2 CAN_FILTER_A

```
#define CAN_FILTER_A 0x000
```

4.10.2.3 CAN_FILTER_M

```
#define CAN_FILTER_M 0x000
```

4.10.2.4 CAN_FILTERMASK_A

```
#define CAN_FILTERMASK_A 0x0E0
```

4.10.2.5 CAN_FILTERMASK_M

```
#define CAN_FILTERMASK_M 0x300
```

4.10.2.6 CMD_MODE_ROS

```
#define CMD_MODE_ROS 1
```

4.10.2.7 CMD_MODE_TERMINAL

```
#define CMD_MODE_TERMINAL 0
```

4.10.2.8 ENC1

```
#define ENC1 TIM3
```

4.10.2.9 ENC2

```
#define ENC2 TIM8
```

4.10.2.10 GLOBAL_DEBUG

```
#define GLOBAL_DEBUG 1
```

4.10.2.11 HAND

```
#define HAND 2
```

4.10.2.12 HW_INTERFACE

```
#define HW_INTERFACE UART\_INTERFACE
```

4.10.2.13 MTR1

```
#define MTR1 TIM15
```

```
test
```

4.10.2.14 MTR2

```
#define MTR2 TIM1
```

4.10.2.15 MTR_POL

```
#define MTR_POL -1
```

4.10.2.16 PWM_CTR_PRD

```
#define PWM_CTR_PRD 7200
```

4.10.2.17 SHOULDER

```
#define SHOULDER 1
```

4.10.2.18 SW_INTERFACE

```
#define SW_INTERFACE CMD_MODE_TERMINAL
```

4.10.2.19 TORSO

```
#define TORSO 0
```

4.10.2.20 UART_INPUT

```
#define UART_INPUT 1
```

4.10.2.21 UART_INTERFACE

```
#define UART_INTERFACE 0
```

4.10.2.22 USB_INTERFACE

```
#define USB_INTERFACE 1
```

4.10.2.23 VOLTAGE_IN

```
#define VOLTAGE_IN 20
```

4.10.3 Function Documentation

4.10.3.1 activate_peripherals()

```
void activate_peripherals ( )
```


Index

- ACC_REG_REQ
 - [can_driver.h, 28](#)
- ACC_REG_RX
 - [can_driver.h, 28](#)
- ACC_X_REQ
 - [can_driver.h, 28](#)
- ACC_X_TX
 - [can_driver.h, 28](#)
- ACC_Y_REQ
 - [can_driver.h, 28](#)
- ACC_Y_TX
 - [can_driver.h, 28](#)
- ACC_Z_REQ
 - [can_driver.h, 28](#)
- ACC_Z_TX
 - [can_driver.h, 28](#)
- [accelerometer_driver.h, 23](#)
- [accelerometer_inData, 5](#)
 - [newXAcc, 6](#)
 - [newXRot, 6](#)
 - [newYAcc, 6](#)
 - [newYRot, 6](#)
 - [newZAcc, 6](#)
 - [newZRot, 6](#)
 - [xAcc, 7](#)
 - [xRot, 7](#)
 - [yAcc, 7](#)
 - [yRot, 7](#)
 - [zAcc, 7](#)
 - [zRot, 7](#)
- [activate_peripherals](#)
 - [unit_config.h, 89](#)
- ACTIVE_UNIT
 - [unit_config.h, 86](#)
- adc
 - [current_measurement_descriptor, 10](#)
- [adc_driver.h, 23](#)
 - [adc_driver_calculate_current, 24](#)
 - [adc_driver_update_measurement, 24](#)
 - [adc_driver_update_reading, 24](#)
 - [adc_interface_get_current, 25](#)
 - [adc_interface_update_current, 25](#)
- [adc_driver_calculate_current](#)
 - [adc_driver.h, 24](#)
- [adc_driver_update_measurement](#)
 - [adc_driver.h, 24](#)
- [adc_driver_update_reading](#)
 - [adc_driver.h, 24](#)
- [adc_interface_get_current](#)
 - [adc_driver.h, 25](#)
- [adc_interface_update_current](#)
 - [adc_driver.h, 25](#)
- Aipropi
 - [current_measurement_descriptor, 11](#)
- CAN_ACC_CMD_OFFSET
 - [can_driver.h, 28](#)
- [can_cmd_handle_axisData](#)
 - [can_driver.h, 28](#)
- [can_cmd_handle_axisReq](#)
 - [can_driver.h, 29](#)
- [can_cmd_handle_motorSp](#)
 - [can_driver.h, 29](#)
- [can_cmd_handle_regReq](#)
 - [can_driver.h, 29](#)
- [can_cmd_handle_regVal](#)
 - [can_driver.h, 30](#)
- [can_cmd_handle_yAcc](#)
 - [can_driver.h, 30](#)
- [can_driver.h, 25](#)
 - [ACC_REG_REQ, 28](#)
 - [ACC_REG_RX, 28](#)
 - [ACC_X_REQ, 28](#)
 - [ACC_X_TX, 28](#)
 - [ACC_Y_REQ, 28](#)
 - [ACC_Y_TX, 28](#)
 - [ACC_Z_REQ, 28](#)
 - [ACC_Z_TX, 28](#)
 - [CAN_ACC_CMD_OFFSET, 28](#)
 - [can_cmd_handle_axisData, 28](#)
 - [can_cmd_handle_axisReq, 29](#)
 - [can_cmd_handle_motorSp, 29](#)
 - [can_cmd_handle_regReq, 29](#)
 - [can_cmd_handle_regVal, 30](#)
 - [can_cmd_handle_yAcc, 30](#)
 - [can_driver_cmd_rx0, 30](#)
 - [can_driver_cmd_rx1, 31](#)
 - [can_driver_cmd_rx2, 31](#)
 - [can_driver_cmd_rx3, 31](#)
 - [can_driver_cmd_rx4, 31](#)
 - [can_driver_cmd_rx5, 32](#)
 - [can_driver_cmd_rx6, 32](#)
 - [can_driver_cmd_rx7, 32](#)
 - [can_driver_cmd_rx8, 33](#)
 - [can_driver_cmd_rx9, 33](#)
 - [can_driver_cmd_rxA, 33](#)
 - [can_driver_cmd_rxB, 34](#)
 - [can_driver_queue_tx, 34](#)
 - [can_driver_send_msg, 34](#)

- can_interface_queue_tx, 35
- can_mailbox_clear_flag, 35
- can_mailbox_get_data, 35
- can_mailbox_get_flag, 36
- can_mailbox_get_id, 36
- can_mailbox_set_data, 36
- can_mailbox_set_flag, 37
- can_mailbox_set_id, 37
- can_message_type, 28
- CAN_MOTOR_CMD_OFFSET, 28
- can_rx_executive, 37
- can_tx_executive, 37
- JOINT_POS_REQ, 28
- JOINT_POS_SP, 28
- JOINT_POS_TX, 28
- MOTOR_VLT_SP, 28
- num_types, 28
- can_driver_cmd_rx0
 - can_driver.h, 30
- can_driver_cmd_rx1
 - can_driver.h, 31
- can_driver_cmd_rx2
 - can_driver.h, 31
- can_driver_cmd_rx3
 - can_driver.h, 31
- can_driver_cmd_rx4
 - can_driver.h, 31
- can_driver_cmd_rx5
 - can_driver.h, 32
- can_driver_cmd_rx6
 - can_driver.h, 32
- can_driver_cmd_rx7
 - can_driver.h, 32
- can_driver_cmd_rx8
 - can_driver.h, 33
- can_driver_cmd_rx9
 - can_driver.h, 33
- can_driver_cmd_rxA
 - can_driver.h, 33
- can_driver_cmd_rxB
 - can_driver.h, 34
- can_driver_queue_tx
 - can_driver.h, 34
- can_driver_send_msg
 - can_driver.h, 34
- CAN_FILTER_A
 - unit_config.h, 86
- CAN_FILTER_M
 - unit_config.h, 87
- CAN_FILTERMASK_A
 - unit_config.h, 87
- CAN_FILTERMASK_M
 - unit_config.h, 87
- can_interface_queue_tx
 - can_driver.h, 35
- can_mailbox, 8
 - data, 8
 - msgId, 8
 - newMsg, 8
- can_mailbox_clear_flag
 - can_driver.h, 35
- can_mailbox_get_data
 - can_driver.h, 35
- can_mailbox_get_flag
 - can_driver.h, 36
- can_mailbox_get_id
 - can_driver.h, 36
- can_mailbox_set_data
 - can_driver.h, 36
- can_mailbox_set_flag
 - can_driver.h, 37
- can_mailbox_set_id
 - can_driver.h, 37
- can_message_type
 - can_driver.h, 28
- CAN_MOTOR_CMD_OFFSET
 - can_driver.h, 28
- can_rx_executive
 - can_driver.h, 37
- can_tx_executive
 - can_driver.h, 37
- CMD_MODE_ROS
 - unit_config.h, 87
- CMD_MODE_TERMINAL
 - unit_config.h, 87
- cmdFuncPointer
 - string_cmd_pair, 21
- cmdString
 - string_cmd_pair, 21
- controller_acc_clear_newX
 - joint_controller.h, 42
- controller_acc_clear_newY
 - joint_controller.h, 42
- controller_acc_clear_newZ
 - joint_controller.h, 42
- controller_acc_get_newX
 - joint_controller.h, 43
- controller_acc_get_newY
 - joint_controller.h, 43
- controller_acc_get_newZ
 - joint_controller.h, 43
- controller_acc_getX
 - joint_controller.h, 43
- controller_acc_getY
 - joint_controller.h, 43
- controller_acc_getZ
 - joint_controller.h, 43
- controller_acc_set_newX
 - joint_controller.h, 43
- controller_acc_set_newY
 - joint_controller.h, 44
- controller_acc_set_newZ
 - joint_controller.h, 44
- controller_acc_setX
 - joint_controller.h, 44
- controller_acc_setY

joint_controller.h, [44](#)
controller_acc_setZ
 joint_controller.h, [44](#)
controller_descriptor, [9](#)
 inputSource, [9](#)
 isMoving, [9](#)
 posCurrent, [9](#)
 posError, [9](#)
 posSetpoint, [10](#)
controller_interface_acc_clear_newX
 joint_controller.h, [44](#)
controller_interface_acc_clear_newY
 joint_controller.h, [45](#)
controller_interface_acc_clear_newZ
 joint_controller.h, [45](#)
controller_interface_acc_get_newX
 joint_controller.h, [45](#)
controller_interface_acc_get_newY
 joint_controller.h, [45](#)
controller_interface_acc_get_newZ
 joint_controller.h, [46](#)
controller_interface_acc_getX
 joint_controller.h, [46](#)
controller_interface_acc_getY
 joint_controller.h, [47](#)
controller_interface_acc_getZ
 joint_controller.h, [47](#)
controller_interface_acc_set_newX
 joint_controller.h, [47](#)
controller_interface_acc_set_newY
 joint_controller.h, [48](#)
controller_interface_acc_set_newZ
 joint_controller.h, [48](#)
controller_interface_acc_setX
 joint_controller.h, [48](#)
controller_interface_acc_setY
 joint_controller.h, [48](#)
controller_interface_acc_setZ
 joint_controller.h, [49](#)
controller_interface_clear_acc_poll
 joint_controller.h, [49](#)
controller_interface_clear_moving
 joint_controller.h, [49](#)
controller_interface_clear_mtr_poll
 joint_controller.h, [49](#)
controller_interface_clicks_to_pos
 joint_controller.h, [50](#)
controller_interface_get_acc_poll
 joint_controller.h, [50](#)
controller_interface_get_error
 joint_controller.h, [50](#)
controller_interface_get_moving
 joint_controller.h, [50](#)
controller_interface_get_mtr_poll
 joint_controller.h, [51](#)
controller_interface_get_position
 joint_controller.h, [51](#)
controller_interface_get_setpoint
 joint_controller.h, [51](#)
controller_interface_request_acc_axis
 joint_controller.h, [52](#)
controller_interface_rot_clear_newX
 joint_controller.h, [52](#)
controller_interface_rot_clear_newY
 joint_controller.h, [52](#)
controller_interface_rot_clear_newZ
 joint_controller.h, [53](#)
controller_interface_rot_get_newX
 joint_controller.h, [53](#)
controller_interface_rot_get_newY
 joint_controller.h, [53](#)
controller_interface_rot_get_newZ
 joint_controller.h, [54](#)
controller_interface_rot_getX
 joint_controller.h, [54](#)
controller_interface_rot_getY
 joint_controller.h, [54](#)
controller_interface_rot_getZ
 joint_controller.h, [56](#)
controller_interface_rot_set_newX
 joint_controller.h, [56](#)
controller_interface_rot_set_newY
 joint_controller.h, [56](#)
controller_interface_rot_set_newZ
 joint_controller.h, [57](#)
controller_interface_rot_setX
 joint_controller.h, [57](#)
controller_interface_rot_setY
 joint_controller.h, [57](#)
controller_interface_rot_setZ
 joint_controller.h, [57](#)
controller_interface_set_acc_poll
 joint_controller.h, [58](#)
controller_interface_set_error
 joint_controller.h, [58](#)
controller_interface_set_moving
 joint_controller.h, [58](#)
controller_interface_set_mtr_poll
 joint_controller.h, [59](#)
controller_interface_set_position
 joint_controller.h, [59](#)
controller_interface_set_power
 joint_controller.h, [59](#)
controller_interface_set_setpoint
 joint_controller.h, [59](#)
controller_interface_update_error
 joint_controller.h, [60](#)
controller_interface_update_power
 joint_controller.h, [60](#)
controller_rot_clear_newX
 joint_controller.h, [60](#)
controller_rot_clear_newY
 joint_controller.h, [60](#)
controller_rot_clear_newZ
 joint_controller.h, [60](#)
controller_rot_get_newX

- joint_controller.h, 61
- controller_rot_get_newY
 - joint_controller.h, 61
- controller_rot_get_newZ
 - joint_controller.h, 61
- controller_rot_getX
 - joint_controller.h, 61
- controller_rot_getY
 - joint_controller.h, 61
- controller_rot_getZ
 - joint_controller.h, 61
- controller_rot_set_newX
 - joint_controller.h, 61
- controller_rot_set_newY
 - joint_controller.h, 62
- controller_rot_set_newZ
 - joint_controller.h, 62
- controller_rot_setX
 - joint_controller.h, 62
- controller_rot_setY
 - joint_controller.h, 62
- controller_rot_setZ
 - joint_controller.h, 62
- conversionConst
 - current_measurement_descriptor, 11
- current_measurement_descriptor, 10
 - adc, 10
 - Aipropi, 11
 - conversionConst, 11
 - lastMeasurement, 11
 - lastReading, 11
 - Nadc, 11
 - Ripropi, 11
 - VrefA, 12
- data
 - can_mailbox, 8
- ENC1
 - unit_config.h, 87
- ENC2
 - unit_config.h, 87
- encoderInitCount
 - motor_descriptor, 18
- encoderPreviousCount
 - motor_descriptor, 18
- encoderTimer
 - motor_descriptor, 18
- encoderTotalCount
 - motor_descriptor, 18
- encoderTotalInit
 - motor_descriptor, 19
- encoderTotalSetpoint
 - motor_descriptor, 19
- GLOBAL_DEBUG
 - unit_config.h, 87
- gpio_driver.h, 38
 - gpio_end_switch_handler, 38
- gpio_twist_switch_handler, 38
- gpio_end_switch_handler
 - gpio_driver.h, 38
- gpio_twist_switch_handler
 - gpio_driver.h, 38
- HAND
 - unit_config.h, 88
- hasAccelerometer
 - joint_controller_descriptor, 15
- HW_INTERFACE
 - unit_config.h, 88
- i2cHandle
 - imu_descriptor, 13
- imu_descriptor, 12
 - i2cHandle, 13
 - readAddr, 13
 - writeAddr, 13
 - xAccAddr, 13
 - xRotAddr, 13
 - yAccAddr, 13
 - yRotAddr, 14
 - zAccAddr, 14
 - zRotAddr, 14
- inputSource
 - controller_descriptor, 9
- inputString
 - string_cmd_processor_args, 22
- intError
 - joint_controller_descriptor, 15
- isMoving
 - controller_descriptor, 9
 - joint_controller_descriptor, 15
 - motor_descriptor, 19
- joint_controller.h, 39
 - controller_acc_clear_newX, 42
 - controller_acc_clear_newY, 42
 - controller_acc_clear_newZ, 42
 - controller_acc_get_newX, 43
 - controller_acc_get_newY, 43
 - controller_acc_get_newZ, 43
 - controller_acc_getX, 43
 - controller_acc_getY, 43
 - controller_acc_getZ, 43
 - controller_acc_set_newX, 43
 - controller_acc_set_newY, 44
 - controller_acc_set_newZ, 44
 - controller_acc_setX, 44
 - controller_acc_setY, 44
 - controller_acc_setZ, 44
 - controller_interface_acc_clear_newX, 44
 - controller_interface_acc_clear_newY, 45
 - controller_interface_acc_clear_newZ, 45
 - controller_interface_acc_get_newX, 45
 - controller_interface_acc_get_newY, 45
 - controller_interface_acc_get_newZ, 46
 - controller_interface_acc_getX, 46

controller_interface_acc_getY, 47
controller_interface_acc_getZ, 47
controller_interface_acc_set_newX, 47
controller_interface_acc_set_newY, 48
controller_interface_acc_set_newZ, 48
controller_interface_acc_setX, 48
controller_interface_acc_setY, 48
controller_interface_acc_setZ, 49
controller_interface_clear_acc_poll, 49
controller_interface_clear_moving, 49
controller_interface_clear_mtr_poll, 49
controller_interface_clicks_to_pos, 50
controller_interface_get_acc_poll, 50
controller_interface_get_error, 50
controller_interface_get_moving, 50
controller_interface_get_mtr_poll, 51
controller_interface_get_position, 51
controller_interface_get_setpoint, 51
controller_interface_request_acc_axis, 52
controller_interface_rot_clear_newX, 52
controller_interface_rot_clear_newY, 52
controller_interface_rot_clear_newZ, 53
controller_interface_rot_get_newX, 53
controller_interface_rot_get_newY, 53
controller_interface_rot_get_newZ, 54
controller_interface_rot_getX, 54
controller_interface_rot_getY, 54
controller_interface_rot_getZ, 56
controller_interface_rot_set_newX, 56
controller_interface_rot_set_newY, 56
controller_interface_rot_set_newZ, 57
controller_interface_rot_setX, 57
controller_interface_rot_setY, 57
controller_interface_rot_setZ, 57
controller_interface_set_acc_poll, 58
controller_interface_set_error, 58
controller_interface_set_moving, 58
controller_interface_set_mtr_poll, 59
controller_interface_set_position, 59
controller_interface_set_power, 59
controller_interface_set_setpoint, 59
controller_interface_update_error, 60
controller_interface_update_power, 60
controller_rot_clear_newX, 60
controller_rot_clear_newY, 60
controller_rot_clear_newZ, 60
controller_rot_get_newX, 61
controller_rot_get_newY, 61
controller_rot_get_newZ, 61
controller_rot_getX, 61
controller_rot_getY, 61
controller_rot_getZ, 61
controller_rot_set_newX, 61
controller_rot_set_newY, 62
controller_rot_set_newZ, 62
controller_rot_setX, 62
controller_rot_setY, 62
controller_rot_setZ, 62
joint_controller_acceleration_to_angle, 62
joint_controller_adjust_enc_sp, 63
joint_controller_clear_moving, 63
joint_controller_clicks_to_pos, 63
joint_controller_get_error, 63
joint_controller_get_moving, 63
joint_controller_get_position, 63
joint_controller_get_setpoint, 63
joint_controller_request_acc_axis, 64
joint_controller_set_error, 64
joint_controller_set_moving, 64
joint_controller_set_position, 64
joint_controller_set_power, 64
joint_controller_set_setpoint, 64
joint_controller_update_error, 65
joint_controller_update_power, 65
joint_controller_acceleration_to_angle
joint_controller.h, 62
joint_controller_adjust_enc_sp
joint_controller.h, 63
joint_controller_clear_moving
joint_controller.h, 63
joint_controller_clicks_to_pos
joint_controller.h, 63
joint_controller_descriptor, 14
hasAccelerometer, 15
intError, 15
isMoving, 15
jointName, 16
Kd, 16
Kp, 16
KpTi, 16
motorNum, 16
posCurrent, 16
posError, 17
posSetpoint, 17
joint_controller_get_error
joint_controller.h, 63
joint_controller_get_moving
joint_controller.h, 63
joint_controller_get_position
joint_controller.h, 63
joint_controller_get_setpoint
joint_controller.h, 63
joint_controller_request_acc_axis
joint_controller.h, 64
joint_controller_set_error
joint_controller.h, 64
joint_controller_set_moving
joint_controller.h, 64
joint_controller_set_position
joint_controller.h, 64
joint_controller_set_power
joint_controller.h, 64
joint_controller_set_setpoint
joint_controller.h, 64
joint_controller_update_error
joint_controller.h, 65

- joint_controller_update_power
 - joint_controller.h, 65
- JOINT_POS_REQ
 - can_driver.h, 28
- JOINT_POS_SP
 - can_driver.h, 28
- JOINT_POS_TX
 - can_driver.h, 28
- jointName
 - joint_controller_descriptor, 16
- Kd
 - joint_controller_descriptor, 16
- Kp
 - joint_controller_descriptor, 16
- KpTi
 - joint_controller_descriptor, 16
- lastMeasurement
 - current_measurement_descriptor, 11
- lastReading
 - current_measurement_descriptor, 11
- mostRecentDelta
 - motor_descriptor, 19
- motor_descriptor, 17
 - encoderInitCount, 18
 - encoderPreviousCount, 18
 - encoderTimer, 18
 - encoderTotalCount, 18
 - encoderTotalInit, 19
 - encoderTotalSetpoint, 19
 - isMoving, 19
 - mostRecentDelta, 19
 - motorId, 19
 - motorName, 19
 - motorPolarity, 20
 - motorTimer, 20
 - resolution, 20
 - voltageLimit, 20
 - voltagePctCap, 20
- motor_driver.h, 65
 - motor_driver_calc_safe_vlt, 67
 - motor_driver_delta_setpoint, 67
 - motor_driver_get_encoder_cnt, 67
 - motor_driver_get_id, 68
 - motor_driver_get_moving, 68
 - motor_driver_get_resolution, 68
 - motor_driver_get_setpoint, 69
 - motor_driver_get_total_cnt, 69
 - motor_driver_go_backward, 69
 - motor_driver_go_forward, 70
 - motor_driver_init, 70
 - motor_driver_set_power, 70
 - motor_driver_set_pwm_dc, 71
 - motor_driver_set_setpoint, 71
 - motor_driver_update_power, 71
 - motor_driver_update_tot_cnt, 72
 - motor_interface_controller_init, 72
 - motor_interface_delta_setpoint, 72
 - motor_interface_get_encoder_count, 72
 - motor_interface_get_id, 73
 - motor_interface_get_moving, 73
 - motor_interface_get_resolution, 74
 - motor_interface_get_setpoint, 74
 - motor_interface_get_total_count, 74
 - motor_interface_set_power, 75
 - motor_interface_set_setpoint, 75
 - motor_interface_update_power, 75
 - motor_interface_update_tot_cnt, 76
- motor_driver_calc_safe_vlt
 - motor_driver.h, 67
- motor_driver_delta_setpoint
 - motor_driver.h, 67
- motor_driver_get_encoder_cnt
 - motor_driver.h, 67
- motor_driver_get_id
 - motor_driver.h, 68
- motor_driver_get_moving
 - motor_driver.h, 68
- motor_driver_get_resolution
 - motor_driver.h, 68
- motor_driver_get_setpoint
 - motor_driver.h, 69
- motor_driver_get_total_cnt
 - motor_driver.h, 69
- motor_driver_go_backward
 - motor_driver.h, 69
- motor_driver_go_forward
 - motor_driver.h, 70
- motor_driver_init
 - motor_driver.h, 70
- motor_driver_set_power
 - motor_driver.h, 70
- motor_driver_set_pwm_dc
 - motor_driver.h, 71
- motor_driver_set_setpoint
 - motor_driver.h, 71
- motor_driver_update_power
 - motor_driver.h, 71
- motor_driver_update_tot_cnt
 - motor_driver.h, 72
- motor_interface_controller_init
 - motor_driver.h, 72
- motor_interface_delta_setpoint
 - motor_driver.h, 72
- motor_interface_get_encoder_count
 - motor_driver.h, 72
- motor_interface_get_id
 - motor_driver.h, 73
- motor_interface_get_moving
 - motor_driver.h, 73
- motor_interface_get_resolution
 - motor_driver.h, 74
- motor_interface_get_setpoint
 - motor_driver.h, 74
- motor_interface_get_total_count

- motor_driver.h, [74](#)
- motor_interface_set_power
 - motor_driver.h, [75](#)
- motor_interface_set_setpoint
 - motor_driver.h, [75](#)
- motor_interface_update_power
 - motor_driver.h, [75](#)
- motor_interface_update_tot_cnt
 - motor_driver.h, [76](#)
- MOTOR_VLT_SP
 - can_driver.h, [28](#)
- motorId
 - motor_descriptor, [19](#)
- motorName
 - motor_descriptor, [19](#)
- motorNum
 - joint_controller_descriptor, [16](#)
- motorPolarity
 - motor_descriptor, [20](#)
- motorTimer
 - motor_descriptor, [20](#)
- msgId
 - can_mailbox, [8](#)
- MTR1
 - unit_config.h, [88](#)
- MTR2
 - unit_config.h, [88](#)
- MTR_POL
 - unit_config.h, [88](#)
- Nadc
 - current_measurement_descriptor, [11](#)
- newMsg
 - can_mailbox, [8](#)
- newXAcc
 - accelerometer_inData, [6](#)
- newXRot
 - accelerometer_inData, [6](#)
- newYAcc
 - accelerometer_inData, [6](#)
- newYRot
 - accelerometer_inData, [6](#)
- newZAcc
 - accelerometer_inData, [6](#)
- newZRot
 - accelerometer_inData, [6](#)
- NUM_STRING_COMMANDS
 - string_cmd_parser.h, [78](#)
- num_types
 - can_driver.h, [28](#)
- posCurrent
 - controller_descriptor, [9](#)
 - joint_controller_descriptor, [16](#)
- posError
 - controller_descriptor, [9](#)
 - joint_controller_descriptor, [17](#)
- posSetpoint
 - controller_descriptor, [10](#)
- joint_controller_descriptor, [17](#)
- PWM_CTR_PRD
 - unit_config.h, [88](#)
- readAddr
 - imu_descriptor, [13](#)
- resolution
 - motor_descriptor, [20](#)
- Ripropi
 - current_measurement_descriptor, [11](#)
- SHOULDER
 - unit_config.h, [88](#)
- shoulder_controller.h, [76](#)
- string_cmd_acc1
 - string_cmd_parser.h, [78](#)
- string_cmd_can
 - string_cmd_parser.h, [79](#)
- string_cmd_category_accelerometer
 - string_cmd_parser.h, [79](#)
- string_cmd_category_adc
 - string_cmd_parser.h, [79](#)
- string_cmd_category_local_motor
 - string_cmd_parser.h, [79](#)
- string_cmd_category_remote_motor
 - string_cmd_parser.h, [80](#)
- string_cmd_elbow
 - string_cmd_parser.h, [80](#)
- string_cmd_pair, [21](#)
 - cmdFuncPointer, [21](#)
 - cmdString, [21](#)
- string_cmd_parser.h, [76](#)
 - NUM_STRING_COMMANDS, [78](#)
 - string_cmd_acc1, [78](#)
 - string_cmd_can, [79](#)
 - string_cmd_category_accelerometer, [79](#)
 - string_cmd_category_adc, [79](#)
 - string_cmd_category_local_motor, [79](#)
 - string_cmd_category_remote_motor, [80](#)
 - string_cmd_elbow, [80](#)
 - string_cmd_pinch, [80](#)
 - string_cmd_processor, [78](#)
 - string_cmd_processor_base, [80](#)
 - string_cmd_processor_wrp, [81](#)
 - string_cmd_rail, [81](#)
 - string_cmd_rly, [81](#)
 - string_cmd_shoulder, [81](#)
 - string_cmd_stop, [82](#)
 - string_cmd_twist, [82](#)
 - string_cmd_wrist, [82](#)
 - stringCmdList, [83](#)
- string_cmd_pinch
 - string_cmd_parser.h, [80](#)
- string_cmd_processor
 - string_cmd_parser.h, [78](#)
- string_cmd_processor_args, [21](#)
 - inputString, [22](#)
 - stringLength, [22](#)
- string_cmd_processor_base

- string_cmd_parser.h, 80
- string_cmd_processor_wrp
 - string_cmd_parser.h, 81
- string_cmd_rail
 - string_cmd_parser.h, 81
- string_cmd_rly
 - string_cmd_parser.h, 81
- string_cmd_shoulder
 - string_cmd_parser.h, 81
- string_cmd_stop
 - string_cmd_parser.h, 82
- string_cmd_twist
 - string_cmd_parser.h, 82
- string_cmd_wrist
 - string_cmd_parser.h, 82
- stringCmdList
 - string_cmd_parser.h, 83
- stringLength
 - string_cmd_processor_args, 22
- SW_INTERFACE
 - unit_config.h, 89
- TORSO
 - unit_config.h, 89
- uart_driver.h, 83
 - uart_hmi_init, 84
 - uart_hmi_rx_handler, 84
 - uart_parse_input, 84
 - uart_ros_init, 85
 - uart_ros_rx_handler, 85
 - uart_send_string, 85
- uart_hmi_init
 - uart_driver.h, 84
- uart_hmi_rx_handler
 - uart_driver.h, 84
- UART_INPUT
 - unit_config.h, 89
- UART_INTERFACE
 - unit_config.h, 89
- uart_parse_input
 - uart_driver.h, 84
- uart_ros_init
 - uart_driver.h, 85
- uart_ros_rx_handler
 - uart_driver.h, 85
- uart_send_string
 - uart_driver.h, 85
- unit_config.h, 85
 - activate_peripherals, 89
 - ACTIVE_UNIT, 86
 - CAN_FILTER_A, 86
 - CAN_FILTER_M, 87
 - CAN_FILTERMASK_A, 87
 - CAN_FILTERMASK_M, 87
 - CMD_MODE_ROS, 87
 - CMD_MODE_TERMINAL, 87
 - ENC1, 87
 - ENC2, 87
 - GLOBAL_DEBUG, 87
 - HAND, 88
 - HW_INTERFACE, 88
 - MTR1, 88
 - MTR2, 88
 - MTR_POL, 88
 - PWM_CTR_PRD, 88
 - SHOULDER, 88
 - SW_INTERFACE, 89
 - TORSO, 89
 - UART_INPUT, 89
 - UART_INTERFACE, 89
 - USB_INTERFACE, 89
 - VOLTAGE_IN, 89
 - USB_INTERFACE
 - unit_config.h, 89
 - VOLTAGE_IN
 - unit_config.h, 89
 - voltageLimit
 - motor_descriptor, 20
 - voltagePctCap
 - motor_descriptor, 20
 - VrefA
 - current_measurement_descriptor, 12
 - writeAddr
 - imu_descriptor, 13
 - xAcc
 - accelerometer_inData, 7
 - xAccAddr
 - imu_descriptor, 13
 - xRot
 - accelerometer_inData, 7
 - xRotAddr
 - imu_descriptor, 13
 - yAcc
 - accelerometer_inData, 7
 - yAccAddr
 - imu_descriptor, 13
 - yRot
 - accelerometer_inData, 7
 - yRotAddr
 - imu_descriptor, 14
 - zAcc
 - accelerometer_inData, 7
 - zAccAddr
 - imu_descriptor, 14
 - zRot
 - accelerometer_inData, 7
 - zRotAddr
 - imu_descriptor, 14