

## Hail Development Module

Hails come preloaded with a Tock kernel and the hail test app.  
To see the current readings of the sensors, plug in Hail over USB and:

```
$ pip3 install tockloader  
$ tockloader listen
```

The **blue** LED will also blink and pressing the user button turns on the **green** LED. For more detailed instructions and tutorials, please visit:

<https://www.tockos.org/hardware/hail>




## Hail Development Module

Hails come preloaded with a Tock kernel and the hail test app.  
To see the current readings of the sensors, plug in Hail over USB and:

```
$ pip3 install tockloader  
$ tockloader listen
```

The **blue** LED will also blink and pressing the user button turns on the **green** LED. For more detailed instructions and tutorials, please visit:

<https://www.tockos.org/hardware/hail>



## Hail Development Module

Hails come preloaded with a Tock kernel and the hail test app.  
To see the current readings of the sensors, plug in Hail over USB and:

```
$ pip3 install tockloader  
$ tockloader listen
```

The **blue** LED will also blink and pressing the user button turns on the **green** LED. For more detailed instructions and tutorials, please visit:

<https://www.tockos.org/hardware/hail>



## Hail Development Module

Hails come preloaded with a Tock kernel and the hail test app.  
To see the current readings of the sensors, plug in Hail over USB and:

```
$ pip3 install tockloader  
$ tockloader listen
```

The **blue** LED will also blink and pressing the user button turns on the **green** LED. For more detailed instructions and tutorials, please visit:

<https://www.tockos.org/hardware/hail>

