



NVIDIA CUDA GETTING STARTED GUIDE FOR MICROSOFT WINDOWS

DU-05349-001_v5.0 | October 2012

Installation and Verification on Windows



TABLE OF CONTENTS

Chapter 1. Introduction.....	1
1.1 System Requirements.....	1
1.2 About This Document.....	2
Chapter 2. Installing CUDA Development Tools.....	3
2.1 Verify You Have a CUDA-Capable GPU.....	3
2.2 Download the NVIDIA CUDA Toolkit.....	3
2.3 Install the CUDA Software.....	4
2.4 Verify the Installation.....	5
2.4.1 Running the Compiled Examples.....	5
Chapter 3. Compiling CUDA Programs.....	8
3.1 Compiling Sample Projects.....	8
3.2 Sample Projects.....	8
3.3 Build Customizations for Existing Projects.....	9
Chapter 4. Additional Considerations.....	10

LIST OF FIGURES

Figure 1 Valid Results from Sample CUDA Device Query Program.....	6
Figure 2 Valid Results from Sample CUDA Bandwidth Test Program.....	7

Chapter 1.

INTRODUCTION

NVIDIA® CUDA™ is a general purpose parallel computing architecture introduced by NVIDIA. It includes the CUDA Instruction Set Architecture (ISA) and the parallel compute engine in the GPU. To program to the CUDA architecture, developers can use C, one of the most widely used high-level programming languages, which can then be run at great performance on a CUDA-capable processor.

The CUDA architecture and its associated software were developed with several design goals in mind:

- ▶ Provide a small set of extensions to standard programming languages, like C, that enable a straightforward implementation of parallel algorithms. With CUDA C, programmers can focus on the task of parallelization of the algorithms rather than spending time on their implementation.
- ▶ Support heterogeneous computation where applications use both the CPU and GPU. Serial portions of applications are run on the CPU, and parallel portions are offloaded to the GPU. As such, CUDA can be incrementally applied to existing applications. The CPU and GPU are treated as separate devices that have their own memory spaces. This configuration also allows simultaneous computation on both the CPU and GPU without contention for memory resources.

CUDA-capable GPUs have hundreds of cores that can collectively run thousands of computing threads. Each core has shared resources, including registers and memory. The on-chip shared memory allows parallel tasks running on these cores to share data without sending it over the system memory bus.

This guide will show you how to install and check the correct operation of the CUDA Development Tools.

1.1 SYSTEM REQUIREMENTS

To use CUDA on your system, you will need the following:

- ▶ CUDA-capable GPU
- ▶ Microsoft Windows XP, Vista, 7, or 8 or Windows Server 2003 or 2008

- ▶ NVIDIA CUDA Toolkit (available at no cost from <http://www.nvidia.com/content/cuda/cuda-downloads.html>)
- ▶ Microsoft Visual Studio 2008, or 2010, or a corresponding version of Microsoft Visual C++ Express

1.2 ABOUT THIS DOCUMENT

This document is intended for readers familiar with Microsoft Windows XP, Microsoft Windows Vista, or Microsoft Windows 7 operating systems and the Microsoft Visual Studio environment. You do not need previous experience with CUDA or experience with parallel computation.

Chapter 2.

INSTALLING CUDA DEVELOPMENT TOOLS

The installation of CUDA development tools on a system running the appropriate version of Windows consists of a few simple steps:

- ▶ Verify the system has a CUDA-capable GPU.
- ▶ Download the NVIDIA CUDA Toolkit.
- ▶ Install the NVIDIA CUDA Toolkit.
- ▶ Test that the installed software runs correctly and communicated with the hardware.

2.1 VERIFY YOU HAVE A CUDA-CAPABLE GPU

To verify that your GPU is CUDA-capable, open the **Control Panel** (**Start > Control Panel**) and double click on **System**. In the **System Properties** window that opens, click the **Hardware** tab, then **Device Manager**. Expand the **Display adapters** entry. There you will find the vendor name and model of your graphics card. If it is an NVIDIA card that is listed in http://www.nvidia.com/object/cuda_gpus.html, your GPU is CUDA-capable.

The Release Notes for the CUDA Toolkit also contain a list of supported products.

2.2 DOWNLOAD THE NVIDIA CUDA TOOLKIT

The NVIDIA CUDA Toolkit is available at <http://www.nvidia.com/content/cuda/cuda-downloads.html>.

Choose the platform you are using and download the NVIDIA CUDA Toolkit

The NVIDIA CUDA Toolkit contains the driver and tools needed to create, build and run a CUDA application as well as libraries, header files, CUDA samples source code, and other resources.

2.3 INSTALL THE CUDA SOFTWARE

Before installing the toolkit, you should read the *Release Notes*, as they provide details on installation and software functionality.

Install the CUDA Toolkit by executing the Toolkit installer and following the on-screen prompts.



The driver and toolkit must be installed for CUDA to function. If you have not installed a stand-alone driver, install the driver from the NVIDIA CUDA Toolkit.

You can choose what to install from the following packages:

1.



If you want to install the CUDA Driver for new hardware, and have already installed the CUDA Driver before, you can launch the CUDA Driver installer from the Start Menu under:

NVIDIA Corporation\CUDA Toolkit\v5.0, or

NVIDIA Corporation\CUDA Toolkit\v5.0 (64 bit)

CUDA Driver

The CUDA Driver installation can be done silently or by using a GUI. A silent installation of the driver is done by enabling that feature when choosing what to install.

- ▶ Silent: Only the display driver will be installed.
- ▶ GUI: A window will appear after the CUDA Toolkit installation if you allowed it at the last dialog with the full driver installation UI. You can choose which features you wish to install.

2. CUDA Toolkit

The CUDA Toolkit installation defaults to `C:\Program Files\NVIDIA GPU Computing Toolkit\CUDA\v#. #`, where `#. #` is version number 3.2 or higher. This directory contains the following:

Bin

the compiler executables and runtime libraries

Include

the header files needed to compile CUDA programs

Lib

the library files needed to link CUDA programs

Doc

the *CUDA C Programming Guide*, *CUDA C Best Practices Guide*, documentation for the CUDA libraries, and other CUDA Toolkit-related documentation

Note: CUDA Toolkit versions 3.1 and earlier installed into `C:\CUDA` by default, requiring prior CUDA Toolkit versions to be uninstalled before the installation of new

versions. Beginning with CUDA Toolkit 3.2, multiple CUDA Toolkit versions can be installed simultaneously.

3. CUDA Samples

The CUDA Samples contain source code for many example problems and templates with Microsoft Visual Studio 2008 and 2010 projects.

For Windows XP, the samples can be found here:

```
C:\Documents and Settings\All Users\Application Data\NVIDIA Corporation\CUDA Samples\v5.0
```

For Windows Vista, Windows 7, and Windows Server 2008, the samples can be found here:

```
C:\ProgramData\NVIDIA Corporation\CUDA Samples\v5.0
```



The NVIDIA CUDA Toolkit installer only installs Visual Studio project templates for toolkit version 5.0 and higher. Installing NVIDIA® Nsight™, Visual Studio Edition will install Visual Studio project templates for toolkit versions earlier than CUDA 5.0.

2.4 VERIFY THE INSTALLATION

Before continuing, it is important to verify that the CUDA programs can find and communicate correctly with the CUDA-capable hardware. To do this, you need to compile and run some of the included sample programs.

2.4.1 Running the Compiled Examples

The version of the CUDA Toolkit can be checked by running `nvcc -V` in a **Command Prompt** window. You can display a **Command Prompt** window by going to:

Start > All Programs > Accessories > Command Prompt

CUDA Samples include sample programs in both *source* and *compiled* form. To verify a correct configuration of the hardware and software, it is highly recommended that you run the `deviceQuery` program located here:

Windows XP:

```
C:\Documents and Settings\All Users\Application Data\NVIDIA Corporation\CUDA Samples\v5.0\C\bin\win32\Release
```

Windows Vista, Windows 7, Windows Server 2008:

```
C:\ProgramData\NVIDIA Corporation\CUDA Samples\v5.0\C\bin\win32\Release
```

This assumes that you used the default installation directory structure. (On 64-bit versions of Windows, the directory name ends with `\win64\Release`.) If CUDA is installed and configured correctly, the output should look similar to [Figure 1 Valid Results from Sample CUDA Device Query Program](#).

```

Administrator: Command Prompt
deviceQuery Starting...

  CUDA Device Query (Runtime API) version (CUDART static linking)

Found 1 CUDA Capable device(s)

Device 0: "GeForce GTX 670"
  CUDA Driver Version / Runtime Version      5.0 / 5.0
  CUDA Capability Major/Minor version number: 3.0
  Total amount of global memory:             2048 MBytes (2147483648 bytes)
  ( ? ) Multiprocessors x (192) CUDA Cores/MP: 1344 CUDA Cores
  GPU Clock rate:                            1046 MHz (1.05 GHz)
  Memory Clock rate:                         3004 Mhz
  Memory Bus Width:                          256-bit
  L2 Cache Size:                             524288 bytes
  Max Texture Dimension Size (x,y,z)         1D=(65536), 2D=(65536,65536), 3D=(4096,4096,4096)
  Max Layered Texture Size (dim) x layers    1D=(16384) x 2048, 2D=(16384,16384) x 2048
  Total amount of constant memory:           65536 bytes
  Total amount of shared memory per block:   49152 bytes
  Total number of registers available per block: 65536
  Warp size:                                 32
  Maximum number of threads per multiprocessor: 2048
  Maximum number of threads per block:       1024
  Maximum sizes of each dimension of a block: 1024 x 1024 x 64
  Maximum sizes of each dimension of a grid: 2147483647 x 65535 x 65535
  Maximum memory pitch:                     2147483647 bytes
  Texture alignment:                        512 bytes
  Concurrent copy and execution:            Yes with 1 copy engine(s)
  Run time limit on kernels:                 No
  Integrated GPU sharing Host Memory:        No
  Support host page-locked memory mapping:   Yes
  Concurrent kernel execution:               Yes
  Alignment requirement for Surfaces:        Yes
  Device has ECC support enabled:             No
  Device is using TCC driver mode:           No
  Device supports Unified Addressing (UVA):  Yes
  Device PCI Bus ID / PCI location ID:      1 / 0
  Compute Mode:
    < Default (multiple host threads can use ::cudaSetDevice() with device simultaneously) >

deviceQuery, CUDA Driver = CUDART, CUDA Driver Version = 5.0, CUDA Runtime Version = 5.0, NumDe
[deviceQuery] test results...
PASSED

> exiting in 3 seconds: 3...2...1...done!

```

Figure 1 Valid Results from Sample CUDA Device Query Program

The exact appearance and the output lines might be different on your system. The important outcomes are that a device was found, that the device(s) match what is installed in your system, and that the test passed.

If a CUDA-capable device and the CUDA Driver are installed but `deviceQuery` reports that no CUDA-capable devices are present, ensure the device and driver are properly installed.

Running the `bandwidthTest` program, located in the same directory as `deviceQuery` above, ensures that the system and the CUDA-capable device are able to communicate correctly. The output should resemble [Figure 2 Valid Results from Sample CUDA Bandwidth Test Program](#).

```

Administrator: Command Prompt

[bandwidthtest] starting...
bandwidthtest Starting...
Running on...

Device 0: GeForce GTX 670
Quick Mode

Host to Device Bandwidth, 1 Device(s)
PINNED Memory Transfers
Transfer Size (Bytes)      Bandwidth(MB/s)
33554432                  3174.5

Device to Host Bandwidth, 1 Device(s)
PINNED Memory Transfers
Transfer Size (Bytes)      Bandwidth(MB/s)
33554432                  2805.1

Device to Device Bandwidth, 1 Device(s)
PINNED Memory Transfers
Transfer Size (Bytes)      Bandwidth(MB/s)
33554432                  148632.6

[bandwidthtest] test results...
PASSED

> exiting in 3 seconds: 3...2...1...done!

C:\ProgramData\NVIDIA Corporation\CUDA Samples\v5.0\C\bin\win64\Release>

```

Figure 2 Valid Results from Sample CUDA Bandwidth Test Program

The device name (second line) and the bandwidth numbers vary from system to system. The important items are the second line, which confirms a CUDA device was found, and the second-to-last line, which confirms that all necessary tests passed.

If the tests do not pass, make sure you do have a CUDA-capable NVIDIA GPU on your system and make sure it is properly installed.

To see a graphical representation of what CUDA can do, run the sample Particles executable in:

- For Windows XP:

```
c:\Documents and Settings\All Users\Application Data\CUDA Samples\v5.0\C\bin\win32\Release
```

(or ... \win64\Release on 64-bit Windows)

- For Windows Vista and Windows 7:

```
C:\ProgramData\NVIDIA Corporation\CUDA Samples\v5.0\C\bin\win32\Release
```

(or ... \win64\Release on 64-bit Windows)

Chapter 3.

COMPILING CUDA PROGRAMS

The project files in the CUDA Samples have been designed to provide simple, one-click builds of the programs that include all source code. To build the 32-bit or 64-bit Windows projects (for release or debug mode), use the provided *.sln solution files for Microsoft Visual Studio 2008 or 2010 (and likewise for the corresponding versions of Microsoft Visual C++ Express Edition). You can use either the solution files located in each of the examples directories in

```
CUDA Samples\v5.0\C\<category>\<sample_name>
```

or the global solution files Samples*.sln located in

```
CUDA Samples\v5.0\C
```

CUDA Samples are organized according to <category>. Each sample is organized into one of the following folders: (0_Simple, 1_Uutilities, 2_Graphics, 3_Imaging, 4_Finance, 5_Simulations, 6_Advanced, 7_CUDA Libraries).

3.1 COMPILING SAMPLE PROJECTS

The bandwidthTest project is a good sample project to build and run. It is located in the NVIDIA Corporation\CUDA Samples\v5.0\C\1_Uutilities\bandwidthTest directory.

The output is placed in CUDA Samples\C\v5.0\bin\win32\Release. (As mentioned previously, the \win32 segment of this address will be \win64 on 64-bit versions of Windows.) This location presumes that you used the default installation directory structure. Build the program using the appropriate solution file and run the executable. If all works correctly, the output should be similar to [Figure 2 Valid Results from Sample CUDA Bandwidth Test Program](#).

3.2 SAMPLE PROJECTS

The sample projects come in two configurations: debug and release (where release contains no debugging information).

A few of the example projects require some additional setup. The `simpleD3D9` example requires the system to have a Direct3D SDK installed and the Visual C++ directory paths (located in **Tools > Options...**) properly configured. Consult the Direct3D documentation for additional details.

These sample projects also make use of the `$CUDA_PATH` environment variable to locate the CUDA Toolkit and a `.rules` file to locate and configure the `nvcc` compiler. The environment variable is set automatically and the `.rules` file is installed automatically as part of the CUDA Toolkit installation process. The `.rules` file is installed into `$VisualStudioInstallDir\VC\VCProjectDefaults`. You can reference this `.rules` file from your Visual Studio project files when building your own CUDA applications.

3.3 BUILD CUSTOMIZATIONS FOR EXISTING PROJECTS

When adding CUDA acceleration to existing applications, the relevant Visual Studio project file must be updated to include CUDA build customizations. For Visual Studio 2010, this can be done using one of the following two methods:

1. Open the Visual Studio 2010 project, right click on the project name, and select **Build Customizations...**, then select the CUDA Toolkit version you would like to target.
2. Alternatively, you can configure your project always to build with the most recently installed version of the CUDA Toolkit. First add a CUDA build customization to your project as above. Then, right click on the project name and select **Properties**. Under **CUDA C/C++**, select **Common**, and set the **CUDA Toolkit Custom Dir** field to `$(CUDA_PATH)`.

While Option 2 will allow your project to automatically use any new CUDA Toolkit version you may install in the future, selecting the toolkit version explicitly as in Option 1 is often better in practice, because if there are new CUDA configuration options added to the build customization rules accompanying the newer toolkit, you would not see those new options using Option 2.

Note for advanced users: If you wish to try building your project against a newer CUDA Toolkit without making changes to any of your project files, go to the Visual Studio 2010 command prompt, change the current directory to the location of your project, and execute a command such as the following:

```
msbuild <projectname.extension> /t:Rebuild /p:CudaToolkitDir="drive:/path/to/new/toolkit/"
```

Chapter 4.

ADDITIONAL CONSIDERATIONS

Now that you have CUDA-capable hardware and the software installed, you can examine and enjoy the numerous included programs. To begin using CUDA to accelerate the performance of your own applications, consult the *CUDA C Programming Guide*, located in the CUDA Toolkit documentation directory.

For technical support on programming questions, consult and participate in the bulletin board and mailing list at <http://forums.nvidia.com/index.php?showforum=71>.

Notice

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, NVIDIA Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. No license is granted by implication of otherwise under any patent rights of NVIDIA Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all other information previously supplied. NVIDIA Corporation products are not authorized as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2007-2012 NVIDIA Corporation. All rights reserved.