

How to	Configuration – Update thresholds rules
Description	Step by step description of how update the configuration of threshold rules. This does not include changes to the SSD.
Comments	The <i>italic</i> phrases correspond to the red markings in the screenshots. Please be aware that the screenshots may deviate slightly from the application
version	2016-01



This How-To covers the more complex threshold rules used for the Threshold Status Table. The configuration of the more straightforward thresholds is covered in a separate How-To. Please note that this how to does not cover changes to or extensions of the Threshold Status Table (or the svg files of the Schematic Status Display).

1. If a threshold value has changed, update meta data in ROWS\_CSV\_idmap\_master.xlsm. When this spreadsheet is saved, a new copy of ROWS\_ops\_Thresholds.csv is generated.
2. If an existing threshold rule is applied to an additional location (of the existing threshold locations):
  - a. add proper meta data for this location to ROWS\_CSV\_idmap\_master.xlsm
  - b. the appropriate locationSet will be automatically extended to include this location
  - c. If the threshold rule applied is a special, create the necessary transformations by using the existing location as a template:
    - i. copy all appropriate transformations in AssessThresholdsMDBC\_OPS\_specials.xml for the new location
    - ii. add the new timeSeries to AssessThresholdsMDBC\_OPS.xml to include them in the merge
    - iii. The comments in the configuration files document the function of the transformations applied.
  - d. Else, if the rule that's being extended is not a special, everything should work
  - e. The filters will be automatically updated with the new location/parameter combination
  - f. The SSD display will -not- be automatically updated.