

# 1 Hello\_NuMaker-M032BTAI

## 1.1 TL;DR

This repository demonstrates how to develop projects for the NuMaker-M032BTAI using `gcc-arm-none-eabi` with a `makefile`.

We use `pyOCD` for flashing and debugging because `OpenOCD` does not fully support the NuMaker-M032BTAI.

The example used is `SampleCode/NuMaker-M03xBT/BLE/Demo/Central/TRSP_UART_Central`.

Use `make help` to quickly see available commands.

## 1.2 Requirements

Before proceeding with the commands, ensure you have the following installed:

- Required
  - `make`
  - `gcc-arm-none-eabi` 13.2.Rel1+ or `docker`
- Optional
  - To install `pyOCD`:
    1. Install `Python` 3.7+ and `pip`
    2. Use `make install` to install `pyOCD` and required setup
  - To build documentation:
    1. Install `node.js` 18+ and `npm`
    2. Install `pandoc` and `tinytex`
    3. Use `make docs-install` to install required extensions

### 1.2.1 Windows

```
1 choco install -y make gcc-arm-embedded python3 nodejs-lts pandoc  
   tinytex
```

### 1.2.2 Linux/macOS

```
1 # Linux
2 sudo apt update && sudo apt install -y curl git
```

```
1 # macOS
2 brew install coreutils curl git
```

```
1 git clone https://github.com/asdf-vm/asdf.git ~/.asdf --branch v0.14.0
2 echo ". $HOME/.asdf/asdf.sh" >> ~/.bashrc
3 echo ". $HOME/.asdf/completions/asdf.bash" >> ~/.bashrc
4 source ~/.bashrc
```

```
1 asdf plugin add make
2 asdf plugin add gcc-arm-none-eabi
3 asdf plugin add python
4 asdf plugin add nodejs
5 asdf plugin add pandoc
6 asdf plugin add tinytex
```

```
1 asdf install make latest
2 asdf install gcc-arm-none-eabi latest
3 asdf install python latest
4 asdf install nodejs 18.18.0
5 asdf install pandoc latest
6 asdf install tinytex latest
```

```
1 asdf global make latest
2 asdf global gcc-arm-none-eabi latest
3 asdf global python latest
4 asdf global nodejs 18.18.0
5 asdf global pandoc latest
6 asdf global tinytex latest
```

## 1.3 Quick Start

- Compile

```
1 make
```

- Recompile

```
1 make clean && make
```

```
1 make rebuild
```

- Flash

```
1 make flash
```

- Recompile and Flash

```
1 make upgrade
```

- Generate Documentation

```
1 make docs
```

## 1.4 Debugging with pyOCD

To debug the firmware manually, use the following commands:

### 1.4.1 Starting the GDB Server

Start the GDB server with `pyOCD`:

```
1 pyocd gdbserver -t M032BTAIAAN --elf Source\build\TRSP_UART_Central.elf
```

### 1.4.2 Connecting GDB to the Target

In the GDB command line, connect to the target and load the firmware:

```
1 (gdb) target remote localhost:3333
2 (gdb) monitor reset halt
3 (gdb) load
```

## 1.5 More Information

- OpenNuvoton/M031BSP