



LM888C

HARDWARE REFERENCE MANUAL

LM80C COLOR COMPUTER & LM80C 64K COLOR COMPUTER HARDWARE REFERENCE MANUAL

This release covers the
LM80C Color Computer
and
LM80C 64K Color Computer

Latest revision on 19/04/2021

Copyright notices:

The names “LM80C”, “LM80C Color Computer”, “LM80C BASIC”, and “LM80C DOS”, the “rainbow LM80C” logo, the LM80C schematics, the LM80C sources, and this work belong to Leonardo Miliani, from here on the “owner”.

The “rainbow LM80C” logo and the “LM80C/LM80C Color Computer/LM80C 64K Color Computer” names can not be used in any work without explicit permission of the owner. You are allowed to use the “LM80C” name only in reference to or to describe the LM80C/LM80C 64K Color Computer.

The LM80C and LM80C 64K schematics and source codes are released under the GNU GPL License 3.0 and in the form of "as is", without any kind of warranty: you can use them at your own risk. You are free to use them for any non-commercial use: you are only asked to maintain the copyright notices, to include this advice and the note to the attribution of the original works to Leonardo Miliani, if you intend to re-distribute them. For any other use, please contact the owner.

Index

Copyright notices:.....	3
1. THE LM80C COLOR COMPUTER.....	5
1.1 Why this computer.....	5
1.2 LM80C: main features.....	5
1.3 LM80C 64K: main features.....	5
1.4 The 64K version: bank switching.....	6
1.5 System start-up.....	6
1.6 Hard reset, mild reset, and soft reset.....	7
2. I/O PORTS.....	8
3. INTERRUPTS & JUMP VECTORS.....	10
4. RAM REGISTERS.....	11
4.1 REGISTERS FOR LM80C AS PER FIRMWARE REVISION 3.23.....	11
4.2 REGISTERS FOR LM80C 64K AS PER FIRMWARE REVISION 1.19.....	13
5. STORING DATA INTO MEMORY.....	22
5.1 FLOATING POINT REPRESENTATION.....	22
5.2 How variables and arrays are stored.....	24
5.3 GOSUB and RETURN usage of the stack.....	25
5.4 FOR and NEXT usage of the stack.....	25
6. HOW A BASIC PROGRAM IS STORED IN MEMORY.....	26
7. SERIAL CONFIGURATION.....	27
8. VDP SETTINGS.....	28
9. Z80 DAISY CHAIN INTERRUPT PRIORITY.....	29
10. STATUS LEDs.....	30
11. REFERENCES.....	31
12. USEFUL LINKS.....	32

1. THE LM80C COLOR COMPUTER

1.1 Why this computer

The LM80C Color Computer is a home-brew computer designed and programmed by me, Leonardo Miliani, an Italian retro-computer enthusiast, in an effort to have my own, old-style, 80s' computer. It is built upon the Z80, an 8-bit CPU developed in the '70s by Zilog. LM80C name stands for "L"eonardo "M"iliani (Z)"80" "C"olor. The "80" has the double meaning of Z80, to recall the CPU is built on, and 80s, to recall the years of my youth, when the 8-bit computers dominated the home computer market.

1.2 LM80C: main features

The LM80C might have been a good computer at that time. In fact, its features are as follow:

- CPU: Zilog Z80B@3.68 MHz
- RAM: 32 KB SRAM
- ROM: 32 KB EEPROM with built-in LM80C BASIC
- Video: TMS9918A with 16 KB VRAM, 256×192 pixels, 15 colors, and 32 sprites
- Audio: Yamaha YM2149F (or General Instruments AY-3-8910) with 3 analog channels, 2×8-bit I/O ports (used to read the external keyboard)
- Serial I/O: 1×Z80 SIO, with serial line up to 57,600 bps
- Parallel I/O: 1×Z80 PIO
- Timer: 1×Z80 CTC
- Compact Flash adapter for CF cards

IMPORTANT NOTE: due to the better tech. Specifications & performances of the LM80C 64K, the LM80C Color Computer has been DISCONTINUED and it won't be developed anymore. New users should start using the LM80C 64K model while for current users of LM80C it is recommended to switch to the bigger model to get advantage of its features.

1.3 LM80C 64K: main features

The LM80C 64K is almost identical to its little brother. The main difference, as its name reveals, is the amount of RAM, expanded to 64 KB. Another difference is the ability to use 2x 16K banks for VRAM, allowing the VDP to keep 2 different video pages into memory:

- CPU: Zilog Z80B@3.68 MHz
- RAM: 64 KB SRAM
- ROM: 32 KB EEPROM with built-in LM80C BASIC

- Video: TMS9918A with 32 KB VRAM (splitted into 2×16 KB banks), 256×192 pixels, 15 colors and 32 sprites
- Audio: Yamaha YM2149F (or General Instrument AY-3-8910) with 3 analog channels, 2×8-bit I/O ports (used to read the external keyboard)
- Serial I/O: 1×Z80 SIO, with serial line up to 57,600 bps
- Parallel I/O: 1×Z80 PIO
- Timer: 1×Z80 CTC
- Compact Flash adapter for CF cards

1.4 The 64K version: bank switching

The LM80C Color Computer version 2 has 64 KB of RAM and 32 KB of (EEP)ROM. Due to the 16-bit address bus limitations of the CPU, only 64 KB can be directly addressed. To go around this limit a sort of bank switching has been implemented.

ROM occupies the first 32 KB of the address space, from \$0000 to \$7FFF. The RAM is formed by 2×16 KB banks, lower and upper bank, or simply bank #0 and bank #1: bank #1 occupies the address space from \$8000 to \$FFFF while bank #0 occupies the same address space of the non-volatile memory but it's not enabled by default. When you power up the system or after a reset, the Z80 jumps to address \$0000, so the CPU have to find ROM memory at bank #0. Now comes in action the bank switching technique implemented: after the start, the CPU executes a little portion of code called the “*switcher*”, that copies the whole firmware from ROM bank #0 to RAM bank #1. Then, it disables the ROM in bank #0 and enables the underlying RAM chip, switching to a real 64 KB RAM memory. After this, it copies back the BASIC firmware from RAM bank #1 to RAM bank #0, so that the firmware goes back to occupy its original location. Only the DOS remains in the higher portion of RAM, because it can be enabled/disabled at startup (see ch. 1.5).

Obviously, the entire RAM is available for user programs since he/she can overwrite the built-in firmware since it runs in a re-writable memory.

1.5 System start-up

At startup the Z80 loads the address \$0000 into the PC (Program Counter) and start initializing the HW of the computer. After each peripheral has been set up, the control passes to the bank switcher, which moves the BASIC interpreter and the whole firmware from RAM to ROM. After this, the BASIC interpreter checks if this is a cold start (i.e. after a power-up): if this isn't such case, it asks the user if he/she wants to perform a cold or warm start: the first one initializes the working space like at boot, deleting every possible program still resident in RAM and clearing every variable, while the latter preserves both these data.

If, while the logo has been showed at video, the user presses the **RUN/STOP** key, the firmware re-boot the system again and re-copy the firmware from the ROM into the RAM. This is useful if, some reason (“playing” with some POKEs around the system memory), the computer has began unstable.

Another key that can be pressed while the logo is on video is **CTRL**: by pressing it, the LM80C DOS will be disabled and the RAM occupied by its buffers will be freed up, recovering about 4.5 KB of memory. Pay attention that when disabled, the DOS will remain disabled until a hard-reset or a power off will take place.

At the end of the startup process, the control is passed to the BASIC interpreter in direct mode: this means that the computer is able to execute commands as soon as they are entered.

1.6 Hard reset, mild reset, and soft reset

The computer is provided with 2 different reset systems. The **hard reset** is called by pressing the reset button: this corresponds to a complete reset of any of the integrated circuits on the mother board of the computer since all of them receive the reset signal on their reset pins: this signal forces them to revert to their initial state. The BASIC environment is reset to its default status, too.

The **mild reset** is called by executing the **RESET** statement. This command forces the CPU to jump to execute the firmware code from its initial location. This doesn’t correspond to a hard reset because the integrated circuits don’t receive the reset signal on their corresponding pins: instead, it completely resets the BASIC environment to its default state.

The **soft reset** is called by pressing the **C=** and **CTRL** keys together. This shortcut is intercepted by the firmware and forces the system to: reset the BASIC environment, clear the variables and the system stack, set the screen to graphic mode 1, re-initialize the PSG, close any seq. file still opened, reset the serial lines, and return to the BASIC prompt. Furthermore, the program into memory is NOT deleted.

2. I/O PORTS

Peripheral I/O chips have their I/O channels mapped at the following logical ports:

PIO:

- PIO data channel A: \$00
- PIO data channel B: \$01
- PIO control channel A: \$02
- PIO control channel B: \$03

CTC:

- CTC channel 0: \$10
- CTC channel 1: \$11
- CTC channel 2: \$12
- CTC channel 3: \$13

SIO:

- SIO data channel A: \$20
- SIO data channel B: \$21
- SIO control channel A: \$22
- SIO control channel B: \$23

VDP:

- VDP data port: \$30
- VDP control port:
 - 32K version: \$32
 - 64K version: \$31

PSG:

- PSG register port: \$40
- PSG data port: \$41

CF card:

- CF data (reg. #0): \$50 (R/W)
- CF error (reg. #1): \$51 (R)
- CF features (reg. #1): \$51 (W)
- CF sector count reg. (reg. #2): \$52 (R/W)
- CF LBA reg. 0 (reg. #3): \$53 (bits 0-7) (R/W)
- CF LBA reg. 1 (reg. #4): \$54 (bits 8-15) (R/W)
- CF LBA reg. 2 (reg. #5): \$55 (bits 16-23) (R/W)
- CF LBA reg. 3 (reg. #6): \$56 (bits 24-27) (R/W)

- CF status (reg. #7): \$57 (R)
- CF command (reg. #7): \$57 (W)

The user can control these chips directly by reading/writing from/to the ports listed above.

3. INTERRUPTS & JUMP VECTORS

Several interrupt & jump vectors are stored into ROM:

- \$0000 RESET: Z80 jumps here after a reset or at power-up
- \$0004 INT vector for SIO RX_CHB_AVAILABLE interrupt signal
- \$0006 INT vector for SPEC_RXA_CONDITION (special receive condition) interrupt signal
- \$0008 RST8: this restart calls a function that sends a char via serial
- \$000C INT vector for SIO RX_CHA_AVAILABLE interrupt signal
- \$000E INT vector for SIO SPEC_RX_CONDITION (special receive condition) interrupt signal
- \$0010 RST10: this restart jumps to a function that receives a char from the input buffer (serial and/or keyboard)
- \$0018 RST18: jumps to function that checks if a char is available in the input buffer
- \$0040 CTC CH0: jumps to CTC0IV (see below) - unused
- \$0042 CTC CH1: jumps to CTC1IV (see below) - unused
- \$0044 CTC CH2: jumps to CTC2IV (see below) - unused
- \$0046 CTC CH3: jumps to CTC3IV (see below) - used by system
- \$0066 NMI IRQ: jumps to NMIUSR (see below) - unused

4. RAM REGISTERS

The LM80C uses some RAM cells to store important information and data.⁽¹⁾ By manually writing into these locations the user can alter the functioning of the system, sometimes leading to crashes and/or non-predictable behaviors.

4.1 REGISTERS FOR LM80C AS PER FIRMWARE REVISION 3.23

805E	WRKSPC	(3)	BASIC Work space
8061	NMIUSR	(3)	NMI exit point routine
8064	USR	(3)	"USR (x)" jump
8067	OUTSUB	(1)	"out p,n"
8068	OTPORT	(2)	Port (p)
806A	DIVSUP	(1)	Division support routine
806B	DIV1	(4)	<- Values
806F	DIV2	(4)	<- to
8073	DIV3	(3)	<- be
8076	DIV4	(2)	<-inserted
8078	SEED	(35)	Random number seed
809B	LSTRND	(4)	Last random number
809F	INPSUB	(1)	INP A,(x) Routine
80A0	INPORT	(2)	PORT (x)
80A2	LWIDTH	(1)	Terminal width
80A3	COMMAN	(1)	Width for commas
80A4	NULFLG	(1)	Null after input byte flag
80A5	CTLOFG	(1)	Control "0" flag
80A6	CHKSUM	(2)	Array load/save check sum
80A8	NMIFLG	(1)	Flag for NMI break routine
80A9	BRKFLG	(1)	Break flag
80AA	RINPUT	(3)	Input reflection
80AD	STRSPC	(2)	Pointer to bottom (start) of string space
80AF	LINEAT	(2)	Current line number
80B1	HLPLN	(2)	Current line with errors
80B3	KEYDEL	(1)	delay before key auto-repeat starts
80B4	AUTOKE	(1)	Delay for key auto-repeat
80B5	FNKEYS	(128)	default text of FN keys
8135	BASTXT	(3)	Pointer to start of BASIC program in memory
8138	BUFFER	(5)	Input buffer
813D	STACK	(85)	Initial stack
8192	CURPOS	(1)	Character position on line
8193	LCRFLG	(1)	Locate/Create flag for DIM statement
8194	TYPE	(1)	Data type flag
8195	DATFLG	(1)	Literal statement flag
8196	LSTRAM	(2)	Last available RAM location usable by BASIC
8198	DOSBFR	(2)	Pointer to start of temp. DOS buffer
819A	IOBUFF	(2)	Pointer to start of I/O buffer used by DOS
819C	DOSER	(1)	DOS error
819D	TMPDBF	(36)	Secondary buffer for DOS
81C0	TMSTPT	(2)	Temporary string pointer
81C2	TMSTPL	(12)	Temporary string pool

81CE	TMPSTR	(4)	Temporary string
81D2	STRBOT	(2)	Bottom of string space
81D4	CUR0PR	(2)	Current operator in EVAL
81D6	LOOPST	(2)	First statement of loop
81D8	DATLIN	(2)	Line of current DATA item
81DA	FORFLG	(1)	"FOR" loop flag
81DB	LSTBIN	(1)	Last byte entered
81DC	READFG	(1)	Read/Input flag
81DD	BRKLIN	(2)	Line of break
81DF	NXTOPR	(2)	Next operator in EVAL
81E1	ERRLIN	(2)	Line of error
81E3	CONTAD	(2)	Where to CONTInue
81E5	TMRCNT	(4)	TMR counter for 1/100 seconds
81E9	CTC0IV	(3)	CTC0 interrupt vector
81EC	CTC1IV	(3)	CTC1 interrupt vector
81EF	CTC2IV	(3)	CTC2 interrupt vector
81F2	CTC3IV	(3)	CTC3 interrupt vector
81F5	SCR_SIZE_W	(1)	screen width
81F6	SCR_SIZE_H	(1)	screen height
81F7	SCR_MODE	(1)	screen mode
81F8	SCR_NAM_TB	(2)	video name table address
81FA	SCR_CURS_X	(1)	cursor X
81FB	SCR_CURS_Y	(1)	cursor Y
81FC	SCR_CUR_NX	(1)	new cursor X position
81FD	SCR_CUR_NY	(1)	new cursor Y position
81FE	SCR_ORG_CHR	(1)	original char positioned under the cursor
81FF	CRSR_STATE	(1)	state of cursor
8200	LSTCSRSTA	(1)	last cursor state
8201	PRNTVIDEO	(1)	print on video buffer
8202	CHR4VID	(1)	char for video buffer
8203	FRGNDCLR	(1)	foreground color
8204	BKGNDCLR	(1)	background color
8205	TMPBFR1	(2)	word for general purposes use
8207	TMPBFR2	(2)	word for general purposes use
8209	TMPBFR3	(2)	word for general purposes use
820B	TMPBFR4	(2)	word for general purposes use
820D	VIDEOBUFF	(40)	temp. video buffer
8235	VIDTMP1	(2)	additional temp. video buffer
8237	VIDTMP2	(2)	additional temp. video buffer
8239	CHASNDDTN	(2)	sound Ch.A duration
823B	CHBSNDDTN	(2)	sound Ch.B duration
823D	CHCSNDDTN	(2)	sound Ch.C duration
823F	KBDNPT	(1)	temp. location for keyboard inputs
8240	KBTMP	(1)	temp. location used by keyboard scanner
8241	TMPKEYBFR	(1)	temp. location used for last key pressed
8242	LASTKEYPRSD	(1)	code of last key pressed
8243	STATUSKEY	(1)	status key, used for auto-repeat
8244	KEYTMR	(2)	timer used for auto-repeat key
8246	CONTROLKEYS	(1)	flags for control keys
8247	SERIALS_EN	(1)	serial ports status
8248	SERABITS	(1)	serial port A data bits
8249	SERBBITS	(1)	serial port B data bits
824A	DOS_EN	(1)	DOS enable/disable (1/0)
824B	PROGND	(2)	End of program
824D	VAREND	(2)	End of variables
824F	ARREND	(2)	End of arrays

8251	NXTDAT	(2) Next data item
8253	FNRGNM	(2) Name of FN argument
8255	FNARG	(4) FN argument value
8259	FPREG	(3) Floating point register
825C	FPEXP	(1) Floating point exponent
825D	SGNRES	(1) Sign of result
825E	PBUFF	(13) Number print buffer
826B	MULVAL	(3) Multiplier
826E	PROGST	(100) Start of program text area
82D2	STLOOK	Start of memory test

4.2 REGISTERS FOR LM80C 64K AS PER FIRMWARE REVISION 1.19

5401	WRKSPC	(3) BASIC Work space
5404	NMIUSR	(3) NMI exit point routine
5407	USR	(3) "USR (x)" jump
540A	OUTSUB	(1) "out p,n"
540B	OTPORT	(2) Port (p)
540D	DIVSUP	(1) Division support routine
540E	DIV1	(4) <- Values
5412	DIV2	(4) <- to
5416	DIV3	(3) <- be
5419	DIV4	(2) <-inserted
541B	SEED	(35) Random number seed
543E	LSTRND	(4) Last random number
5442	INPSUB	(1) #INP (x)" Routine
5443	INPORT	(2) PORT (x)
5445	LWIDTH	(1) Terminal width
5446	COMMAN	(1) Width for commas
5447	NULFLG	(1) Null after input byte flag
5448	CTLOFG	(1) Control "O" flag
5449	CHKSUM	(2) Array load/save check sum
544B	NMIFLG	(1) Flag for NMI break routine
544C	BRKFLG	(1) Break flag
544D	RINPUT	(3) Input reflection
5450	STRSPC	(2) Pointer to bottom (start) of string space
5452	LINEAT	(2) Current line number
5454	HLPLN	(2) Current line with errors
5456	KEYDEL	(1) delay before key auto-repeat starts
5457	AUTOKE	(1) Delay for key auto-repeat
5458	FNKEYS	(128) default text of FN keys
54D8	BASTXT	(3) Pointer to start of BASIC program in memory
54DB	BUFFER	(5) Input buffer
54E0	STACK	(85) Initial stack
5535	CURPOS	(1) Character position on line
5536	LCRFLG	(1) Locate/Create flag for DIM statement
5537	TYPE	(1) Data type flag
5538	DATFLG	(1) Literal statement flag

5539	LSTRAM	(2) Last available RAM location usable by BASIC
553B	DOSER	(1) DOS error
553C	TMPDBF	(36) Secondary buffer for DOS
5560	TMSTPT	(2) Temporary string pointer
5562	TMSTPL	(12) Temporary string pool
556E	TMPSTR	(4) Temporary string
5572	STRBOT	(2) Bottom of string space
5574	CUOPR	(2) Current operator in EVAL
5576	LOOPST	(2) First statement of loop
5578	DATLIN	(2) Line of current DATA item
557A	FORFLG	(1) "FOR" loop flag
557B	LSTBIN	(1) Last byte entered
557C	READFG	(1) Read/Input flag
557D	BRKLIN	(2) Line of break
557F	NXTOPR	(2) Next operator in EVAL
5581	ERRLIN	(2) Line of error
5583	CONTAD	(2) Where to CONTInue
5585	TMRCNT	(4) TMR counter for 1/100 seconds
5589	CTC0IV	(3) CTC0 interrupt vector
558C	CTC1IV	(3) CTC1 interrupt vector
558F	CTC2IV	(3) CTC2 interrupt vector
5592	CTC3IV	(3) CTC3 interrupt vector
5595	SCR_SIZE_W	(1) screen width
5596	SCR_SIZE_H	(1) screen height
5597	SCR_MODE	(1) screen mode
5598	SCR_NAM_TB	(2) video name table address
559A	SCR_CURS_X	(1) cursor X
559B	SCR_CURS_Y	(1) cursor Y
559C	SCR_CUR_NX	(1) new cursor X position
559D	SCR_CUR_NY	(1) new cursor Y position
559E	SCR_ORG_CHR	(1) original char under the cursor
559F	CRSR_STATE	(1) state of cursor (1=on, 0=off)
55A0	LSTCSRSTA	(1) last cursor state
55A1	PRNTVIDEO	(1) print on video buffer
55A2	CHR4VID	(1) char for video buffer
55A3	FRGNDCLR	(1) foreground color
55A4	BKGNDCLR	(1) background color
55A5	TMPBFR1	(2) word for general purposes use
55A7	TMPBFR2	(2) word for general purposes use
55A9	TMPBFR3	(2) word for general purposes use
55AB	TMPBFR4	(2) word for general purposes use
55AD	VIDEOBUFF	(40) temp. video buffer
55D5	VIDTMP1	(2) temporary video word
55D7	VIDTMP2	(2) temporary video word
55D9	CHASNDDTN	(2) sound Ch.A duration (in 1/100s)
55DB	CHBSNDDTN	(2) sound Ch.B duration (in 1/100s)
55DD	CHCSNDDTN	(2) sound Ch.C duration (in 1/100s)
55DF	KBDNPT	(1) temp. location for keyboard inputs
55E0	KBTMP	(1) temp. location used by keyboard scanner
55E1	TMPKEYBFR	(1) temp buffer for last key pressed

55E2	LASTKEYPRSD	(1) last key code pressed
55E3	STATUSKEY	(1) status key, used for auto-repeat
55E4	KEYTMR	(2) timer used for auto-repeat key
55E6	CONTROLKEYS	(1) flags for control keys
55E7	SERIALS_EN	(1) serial ports status
55E8	SERABITS	(1) serial port A data bits
55E9	SERBBITS	(1) serial port B data bits
55EA	DOS_EN	(1) DOS enable/disable (1/0)
55EB	PROGND	(2) End of program
55ED	VAREND	(2) End of variables
55EF	ARREND	(2) End of arrays
55F1	NXTDAT	(2) Next data item
55F3	FNRGNM	(2) Name of FN argument
55F5	FNARG	(4) FN argument value
55F9	FPREG	(3) Floating point register
55FC	FPEXP	(1) Floating point exponent
55FD	SGNRES	(1) Sign of result
55FE	PBUFF	(13) Number print buffer
560B	MULVAL	(3) Multiplier
560E	PROGST	(100) Start of program text area
5672	STLOOK	Start of memory test

WRKSPC: workspace. This is a jump to “Warm start” routine

USR: user-defined function USR(X). Before to call it, locations USR+\$01 and USR+\$02 must be filled up with the address of the user routine. At startup, the default is a call to an “Illegal function call” error.

OUTSUB: out sub-routine. Since the i8080 didn’t have the “OUT(c),r” instruction, this was a skeleton for such statement. Now it’s a sub-routine to write to a specific output port.

OTPORT: output port “c” for the above routine.

DIVSUP: skeleton routine used for division. Since there aren’t enough register to store dividend, divisor and quotient, the divisor is loaded into this routine, to leave registers free for dividend and quotient.

SEED: seed for random number generator and table for floating point values used by RND function.

LSTRND: last random number is stored (available by RND(0)).

INPSUB: input sub-routine. Since the i8080 didn’t have the “IN r,(c)” instruction, this was a routine that read from an input port. Actually, just a sub-routine for “IN” statement.

INPORT: input port “c” for the above routine.

NULLS: nulls. Number of null chars printed after a carriage return. The original NASCOM BASIC had the command “NULL” to change this value, but now it can only be changed with a “POKE”.

LWIDTH:	terminal width, set by “WIDTH”.
COMMAN:	width of terminal for printing with commas. Since “WIDTH” does set LWIDTH but does NOT set COMMAN, the only way to get commas spacing work correctly is just using a POKE.
NULFLG:	null after input flag. Reminiscence of old terminal computers, where this command was used to set the number of null chars to send to teletype before printing any char.
CTLOFH:	flag for Control+”O”. When this flag is set, no output will be sent to the terminal.
LINEESC:	lines counter. Initially loaded with the value of LINESM, it is decremented after every line. When it reaches zero, the BASIC interpreter stops waiting for a char from the keyboard.
LINESN:	lines number. Used for LINEESC. It can be changed with a POKE.
CHKSUM:	checksum used for array load/save (NASCOM BASIC legacy).
NMIFLG:	Non-Maskable Interrupt flag. This is used to inform the BASIC that it has been interrupted by an NMI.
BRKFLG:	break flag, to let BASIC know that the break key was pressed.
RINPUT:	Reflection for “INPUT” routine. When an “INPUT” instruction is encountered, BASIC jumps to the input routine pointed by this jump. Default is jump to “TTYLIN”, aka get a line by character. This can be changed to “CRLIN” (output CR/LF and get a line), or “GETLIN” (no CR/LF, get a line).
STRSPC:	start of string space pointer, the area where BASIC stores strings. By default, it is set 100 bytes below the end of memory but this value can be changed by the “CLEAR n” statement.
LINEAT:	current line number. This pair of bytes contains the value of the current line being executed. A value is -1 means that BASIC is executing a statement in direct mode. A value of -2 means that the computer has been reset and it’s executing the routine to calculate the memory size or, in case it can not determine the amount of RAM, the “Memory size?” routine. If the user doesn’t input a number, -2 instructs the error routine that an error has occurred and that a cold start must be executed.
HLPLN:	help line. Current line that has raised an error during the execution of a BASIC program. This value is read by “HELP” statement, and reset after a program restart (“RUN”) or by another error in direct mode.
KEYDEL:	delay before the key auto-repeat starts repeating the pressed key.
AUTOKE:	Delay for key auto-repeat between two prints.
FNKEYS:	function keys. This area stores the text of function keys. 8 function keys are present and can be individually programmed with user defined statements, whose length can be up to 16 chars. Please refer to LM80C BASIC Reference Manual” to know the pre-configured texts.

BASTXT:	BASIC program text. Pointer to where the BASIC is stored in memory. Usually this reflects the contents of PROGST and both point to the BASIC program area, but it can be changed by the user if a program is loaded elsewhere into RAM.
BUFFER:	input buffer. 88 char buffer where the system stores all the input from the keyboard or the serial line.
STACK:	temporary stack used during boot of system.
CURPOS:	cursor position. This value keeps the cursor position through the current line and is incremented every time a new char has been inserted. It is the value returned by "POS(x)" statement. A press on the "RETURN" key resets this value.
LCRFLG:	Locate/Create flag. Value used by the variable search routine to see if it's in a "DIM" statement or not, so that it can determine if it has to locate or create the specified array.
TYPE:	type of data of the current expression. A zero value stands for a numeric type, while a non-zero value for a string.
DATFLG:	literal statement flag. It's used by the BASIC to know if it's pointing at a literal statement such as a quoted string, a "REM" or a "DATA" statement.
LSTRAM:	last available RAM pointer. Address of last location available to BASIC. It can be changed by "CLEAR n" statement.
DOSBFR:	pointer to beginning of a 32-byte temporary buffer used by DOS in disk input/output operations. The DOS buffer is stored just below the I/O buffer.
IOBUFF:	pointer to beginning of a 512-byte buffer used by DOS to store a sector loaded by disk or to assemble data to save into a sector. The I/O is stored in the highest portion of RAM (from \$FFFF downwards).
DOSER:	error returned by DOS functions.
TMPDBF:	secondary 36-byte buffer used by DOS to execute statements.
TMSTPT:	temporary string pointer used to point a string into the temporary string pool.
TMSTPL:	temporary string pool. This pool contains 4 temporary strings that are created by string statements like "LEFT\$" and others.
TMPSTR:	temporary string. This is a temporary area where BASIC stores blocks of bytes that reference to the strings being constructed. Every string block consists of 4 bytes: the first byte stores the length of string; the second byte is not used; the last two bytes form the pointer to the location in memory where the string is stored.
STRBOT:	bottom of string space. This value points to the bottom of the string being used. Each time a new string is being formed, it is moved into the string area below this pointer that the pointer is decremented and moved below the new string. If there is not enough space for the new string, then a "garbage collector" is called to remove

unused strings from the string space. If, after this cleaning, there is still not enough room, then an “Out of string space error” is raised.

- CUOPR: current operator address. Pointer to the current operator being evaluated in EVAL. This pointer is used to free the CPU register used to point to the current operator being analyzed and to avoid to store it into the stack, so that both can be used to simplify the evaluation of the operator.
- LOOPST: loop start address. Pointer to the first statement in the FOR loop being constructed. This address is later moved into the FOR block on the stack .
- DATLIN: data statement line number. This register contains the line number of the current DATA statement pointer. It's used by DATSNR to report to the user the line where a DATA error has occurred.
- FORFLG: “FOR”/”FN” flag. Flag to tell what GETVAR is expected to find:
- \$00: a variable or array element
 - \$01: an array name
 - \$64: a variable only
 - \$80: an FN function
- LSTBIN: last byte entered. Flag being set whenever any input is made into the BUFFER. The RETURN routine first checks this byte to see if a GOSUB was entered into direct mode, and if so checks this flag. If the flag is set, then this means that an INPUT statement has been encountered, and so after RETURN is executed, BUFFER contains garbage and the system returns into direct mode.
- READFG: read/input flag. This flag tells the READ/INPUT routine what's the source of the data being read. If the flag is zero, then an INPUT is being executed, otherwise it's a READ reading from a DATA statement.
- BRKLIN: break line pointer. Address of the line where a break occurred. This value is used by CONT to know where to continue the execution of the program.
- NXTOPR: next operator address. Pointer into the expression being evaluated by EVAL to know where the execution is in the string.
- ERRLIN: line number of break. This register contains the line number where a break occurred. Used by CONT to know the line number where to continue from.
- CONTAD: continue address. Address of the statement where CONT will continue.
- TMRCNT: timer counter. This is a 32-bit hundredths of a second counter used as a sys-tick timer to temporize events such as sound duration, pauses and other. Its value is incremented every 1/100 s and can be read by the TMR statement.
- CTCxIV: CTC interrupt vectors. Interrupt vectors that can be changed to point the CTC interrupts to specifics interrupt service routines. CTC3IV is used by the kernel of the computer to temporize some jobs (see TMRCNT above).

SCR_SIZE_W:	screen width. This register stores the screen width of the current screen mode. See chap. 8 for more details.
SCR_SIZE_H:	screen height. This register stores the screen height of the current screen mode. See chap. 8 for more details.
SCR_MODE:	screen mode. Current screen mode. This value reflects the mode set by SCREEN statement.
SCR_NAM_TB:	screen name table address. VRAM address of the name table being used by the current screen mode. See chap. 8 for more details.
SCR_CURS_X:	current cursor X coordinate. Keeps the current horizontal coordinate of the cursor in a text mode (screen 0, 1, & 4).
SCR_CURS_Y:	current cursor Y coordinate. Keeps the current vertical coordinate of the cursor in a text mode (screen 0, 1, & 4).
SCR_CUR_NX:	new cursor X coordinate. Keeps the horizontal coordinate of the video cell that the cursor is going to occupy when being moved.
SCR_CUR_NY:	new cursor Y coordinate. Keeps the vertical coordinate of the video cell that the cursor is going to occupy when being moved.
SCR_ORG_CHR:	original char under the cursor. Register used to store the original char present in the video cell currently occupied by the cursor. It is used to restore the char during cursor flashing or when the cursor is moved into another location.
CRSR_STATE:	cursor state. Flag used to tell BASIC if the cursor is visible (1) or not (0).
LSTCSRSTA:	last cursor state. Flag used to store the current cursor state, i.e. when executing PRINT statements or when the cursor is moved around the screen.
PRNTVIDEO:	print on video buffer flag. Used to tell the BASIC if keys being pressed can be echoed on the screen or not. Usually, printing on video is off when in indirect mode (i.e. when a program is being executed).
CHR4VID:	char for video buffer. Temporary buffer that stores a char that must be printed on the screen.
FRGNDCLR:	foreground color. Foreground color set by SCREEN statement. The default value can also be changed with COLOR statement. Used to print chars on screen or to draw/plot figures/pixels on the graphic screen when no color is being specified.
BKGNDCLR:	background color. Background color set by SCREEN statement. The default value can also be changed with COLOR statement. Used for the background of the chars being printed on screen or to color the empty area of the graphic screen

TMPBFRx:	temporary buffer. 4 words used by the kernel and BASIC as temporary buffers.
VIDEOBUFF:	temporary video buffer. 40 RAM cells used by the kernel and BASIC for video scrolling in text modes and as temporary buffer.
VIDTMPx:	temporary video buffer. 2 additional buffers used by the firmware and BASIC.
CHASNDDTN:	channel A sound duration. Duration of the sound being generated by ch. A of the PSG, in hundredths of a second. This value is set by the SOUND statement and decremented by the kernel.
CHBSNDDTN:	channel B sound duration. Same as above, but for ch. B.
CHCSNDDTN:	channel C sound duration. Same as above, but for ch. C.
KBDNPT:	keyboard input. Temporary buffer to store the char being input through the keyboard.
KBTMP:	temporary keyboard scanner. Register used by the keyboard scanner routine to store the key row of the key matrix when a key is being pressed.
TMPKEYBFR:	last key pressed buffer. Temporary buffer used to store the code of the last key being pressed.
LASTKEYPRSD:	code of the last key pressed. Code of the last key being pressed.
STATUSKEY:	used by the key auto-repeat function. Stores the current state of the repeating (0 if no key is pressed, 1 if a key is being pressed for the first time, 2 if the key still continues to be pressed)
KEYTMR:	timer used by the key auto-repeat function to activate the auto-repeat function and the delay between 2 key prints.
CONTROLKEYS:	flag for control keys. Flag used by the keyboard scanner to keep track of the control keys being pressed.
SERIALS_EN:	serial lines enabled. Status of the serial lines. Bit 0 reflects the status of serial line 0, while bit 1 reflects the status of serial line 1: 0 means line OFF, 1 means line ON.
SERABITS:	serial port A data bits. Register used to store the data configuration bits used to set the serial port A, used by the kernel.
SERBBITS:	serial port B data bits. Register used to store the data configuration bits used to set the serial port B, used by the kernel.
DOS_EN:	I/O DOS enabled/disabled (1/0). When the computer's logo is shown at boot, by pressing the SHIFT key the user can disable the I/O buffer used for DOS operations, to recover 512 bytes of free RAM.

PROGND:	program end. Address of the byte after the end of the BASIC program text stored in RAM.
VAREND:	variables end. Address of the byte after the last variable stored in RAM.
ARREND:	arrays end. Address of the byte after the last array stored in RAM.
NXTDAT:	next data item. Address of the next DATA item to be read by READ.
FNRGNM:	FN argument name. Name of the argument of the current FN function. If an FN function calls another FN function, then this value is stored on the stack.
FNARG:	FN function argument. Floating point value of the argument of the current FN function. If an FN function calls another FN function, then this value is stored on the stack together with its name.
FPREG:	floating point register. Floating point value for the current value. These 3 bytes contains the mantissa.
FPEXP:	floating point exponent. Floating point value for the current value. This byte contains the exponent. See chap. 5 for floating point representation in memory.
SGNRES:	sign of the result. This register contains the sign of the result for multiplication. Both multiplicand and multiplier are tested and if their signs are different, then the product will be negative, otherwise it will be positive.
PBUFF:	number print buffer. Temporary buffer used by NUMASC to store a floating point that has to be converted into ASCII for PRINT or STR\$ statements
MULVAL:	multiplier. This 24-bit register contains the multiplier of a multiplication because there are not enough registers to store the multiplier, the multiplicand, and product at the same time.
PROGST:	program start. This is the byte before the first line of a program and it MUST be zero to tell the execution driver that the next line is to be executed. See chap. 6 to see how a BASIC program is stored into RAM.
STLOOK:	start of memory test. Address from which the memory test executed after a reset or when the system is powered up, start to look for the top of the RAM. This address is 100 bytes above the program text area so that the kernel can have at least some bytes to create the stack and store a very little program.

5. STORING DATA INTO MEMORY

5.1 FLOATING POINT REPRESENTATION

Floating point numbers are represented in memory using the Microsoft Binary Format (MBF), introduced by Microsoft in its first Microsoft BASIC in 1975. It uses a 24-bit mantissa, of which 23 bits are used for the mantissa itself and 1 bit for its sign, and an 8-bit base-2 exponent, for a total of 32 bits (4 bytes). There is always a “1” bit implied to the left of the mantissa so that the exponent is encoded with a bias of 128, so that exponents from -127 to -1 are represented by values \$01~\$7F (1~127), while exponents 0~127 are represented by \$80~\$FF (128~255). Exponent set to zero is a special case, representing the whole number being zero.⁽¹⁾⁽²⁾

MBF representation:

```
m= mantissa bits
s=mantissa sign
x=exponent
```

Byte 1	Byte 2	Byte 3	Byte 4
smmmmmmmm	mmmmmmmmmm	mmmmmmmmmm	xxxxxxxxxx

Let's try to represent the 35.25 in MBF. Firstly, the number must be converted in binary format. To convert the integer part, divide the number repeatedly by 2, writing the remainder to the right, until the quotient becomes 0:

Div.	Quot.	Rem.
35/2	= 17	1
17/2	= 8	1
8/2	= 4	0
4/2	= 2	0
2/2	= 1	0
1/2	= 0	1

Now write the remainders from bottom to top. The results is the binary representation of the integer part of the number. 35 in base-2 representation is:

100011

To convert the fractional part, multiply it repeatedly by 2 until it becomes 0. Stop after a number of steps, if the fractional part does not become zero:

0.25	x 2	= 0.50	→ 0	
0.50	x 2	= 1.00	→ 1	← stop here, as the fract. Part is now 0.

From top to bottom, write the integer parts of the results to the fractional part of the base-2 number. So 0.25₁₀ becomes 0.01₂. Finally, the complete number is:

35.25 → 100011.01

Now, consider the base-2 exponent, so that the above is the same as:

```
100011.01 * 2^00000000
```

The binary point is moved to the left most position, so that now precedes the first “1”.

This is the actual situation:

```
.10001101
```

Since the point was moved left 6 times dividing the number by 2^6 , now we must add 6 to the exponent to re-multiply by 2^6 :

```
.10001101 * 2^00000110
```

Since the bit to the right of the point is always 1, we can use this bit to store the sign of the number: 0 for a positive number, and 1 for a negative number. So +35.25 is stored as:

```
.00001101 * 2^00000110
```

In 24 bits the above is:

```
.000011010000000000000000 * 2^00000110
```

Now, 128 is added to the exponent so that overflows and underflows can be detected easily. So the number actually is:

```
00001101 00000000 00000000 10000110    binary
0   D   0   0   0   0   8   6            hex
```

The bytes of the mantissa are stored in reverse order. So, this gives the followings:

Decimal	Binary	Hexadecimal
+35.25	00001101 00000000 00000000 10000110	00 00 0D 86
-32.25	10001101 00000000 00000000 10000110	00 00 8D 86

Other examples:

Decimal	Binary	Hexadecimal
0	00000000 00000000 00000000 00000000	00 00 00 00
1	00000000 00000000 00000000 10000001	00 00 00 81
10	00100000 00000000 00001000 10000100	20 00 00 84
PI/2 (1.5708)	11011111 00001111 01001001 10000001	DB 0F 49 81

5.2 How variables and arrays are stored

Variables such as AB, AB\$, and FN AB are all stored in the variable area of memory. The start address of such area is held in (\$PROGND) while the end address is held in (\$VAREND).

Let make some examples. Let's assume that AB=10, AB\$="HELLO", and FN AB(XY) have been defined by the user. The memory would then look like this:

```
AB
$42 $41      Name of AB in reverse ($42 $41 = "B" "A")
$00 $00 $20 $84 Floating point value for 10
```

```
AB$
$C2 $41      Name for AB$ in reverse ($C2 is "B" with bit 7 set)
$04          Length of string (4 chars)
??          This byte is unused for strings
LL  HH      Address where "HELLO" is to be found (in Little Endian
format)
```

```
FN AB
$42 $C1      Name of FN AB in reverse ($C1 is "A" with bit 7 set)
LL  HH      Address of function (the portion after "=")
$59 $58      Argument name in reverse ($59 $58 = "Y" "X")
```

Arrays such as AB(1,3) are stored in the array area. The start address of this area is held in (\$VAREND) while the end address is held in (\$ARREND).

Let's assume that DIM AB(1,3), AB\$(3,1) had been encountered. Then the memory looks like this:

```
AB(1,3)
$42 $41      Name of array "AB" in reverse (see above)
$25 $00      Bytes used for array in Little Endian ($0025 = 37)
$02          2 dimensions
$04 $00      Size of 2nd dimension including zero element
$02 $00      Size of 1st element including zero element
$00 $00 $00 $00 AB(0,0)
$00 $00 $00 $00 AB(1,0)
$00 $00 $00 $00 AB(0,1)
$00 $00 $00 $00 AB(1,1)
$00 $00 $00 $00 AB(0,2)
$00 $00 $00 $00 AB(1,2)
$00 $00 $00 $00 AB(0,3)
$00 $00 $00 $00 AB(1,3)
```

```
AB$(1,3)
$C2 $41      Name of FN AB in reverse ($C1 is "A" with bit 7 set)
$25 $00      Bytes used for array ($0025 = 37)
$02          2 dimensions
$02 $00      Size of 2nd element including zero element
$04 $00      Size of 2nd element including zero element
$00 $00 $00 $00 AB(0,0)
```



```

$00 $00 $00 $00 AB(1,0)
$00 $00 $00 $00 AB(2,0)
$00 $00 $00 $00 AB(3,0)
$00 $00 $00 $00 AB(0,1)
$00 $00 $00 $00 AB(0,2)
$00 $00 $00 $00 AB(0,3)
$00 $00 $00 $00 AB(0,4)

```

5.3 GOSUB and RETURN usage of the stack

When a GOSUB statement is executed the BASIC interpreter push into the CPU stack the address of where to RETURN and the number of the line to RETURN as follows (from top of stack downwards):

```

LL HH      Address of where to RETURN to
LL HH      Line number to RETURN to
$8C        GOSUB token as marker

```

This block remains into the stack until a RETURN is executed, at which point the BASIC looks back through the stack until it finds a GOSUB block. Then it sets the stack there, recovers the line number and the address of the statement after the GOSUB and continues the execution of the program from such point.

When a GOSUB block is stored into the stack, it deactivates all active FOR loops which were set up inside the subroutine.

5.4 FOR and NEXT usage of the stack

Same behavior for a FOR statement. When it is executed, the address of the first statement of the loop, the line number of the loop statement, the TO value, the STEP value, and the sign of the STEP are stored into the stack as follows (from top of stack downwards):

```

LL HH      Address of 1st statement in loop
LL HH      Line number of loop statements
XX XX XX XX TO value in floating point (f.p.)
YY YY YY YY STEP value in f.p.
SS         Signf of STEP
LL HH      Address of index variable
$81        FOR token as marker

```

This FOR block remains into the stack until a matching NEXT is executed. When NEXT is executed, BASIC looks back through the stack to find the value of the index variable and the result is compared to the TO value. With the use of the TO value and the sign of the step, the interpreter knows if the loop has been completed or not. If it has not been completed, then the FOR block remains into the stack until the loop has been completed. The stack is set to point to this FOR block and effectively kills all FORs nested within this loop. When the completed, the FOR block is removed from the stack and the execution continues from after the NEXT instruction.

6. HOW A BASIC PROGRAM IS STORED IN MEMORY

A BASIC program is stored in memory following a specific scheme. The BASIC text area starts at the location \$PROGST (in the actual firmware revision this corresponds to address \$55E5). This location must contain \$00. This is a special marker used by the interpreter to mark the beginning of the BASIC space. From the following 2 locations over, the BASIC program is stored line by line: each program line begins with a 2-byte address to the address of the next line in memory, followed by a word (2 bytes) containing the current line number, then the program line itself, and finally a zeros to mark the end of line. The text of the line is stored in a mixed format: BASIC statements are stored using their tokenized form (a particular form that uses a 1-byte code from \$80 to \$FF to represent each single statement) while the rest of the line is stored using ASCII codes. A couple of zeros used as pointers to the next line identify the end of the program.

An example is shown below. The following single line program:

```
10 FOR A=1 TO 10
```

it's stored as:

ADRS	TK	NOTE
----	--	-----
5346	00	Marker for beginning of BASIC space
5347	56	Pointer to...
5348	53	...next line (\$5356 in little endian format (LSB/MSB))
5349	0A	Line...
534A	00	...number (\$000A = 10 in little endian format (LSB/MSB))
534B	81	Token for "FOR"
534C	20	ASCII code for "space" (\$20 = 32)
534D	41	ASCII code for "A" (\$41 = 65)
534E	C8	Token for "=" ("=" is interpreted as a STATEMENT)
534F	31	ASCII code for "1" (\$31 = 49)
5350	20	ASCII code for "space" (\$20 = 32)
5351	B7	Token for "TO"
5352	20	ASCII code for "space" (\$20 = 32)
5353	31	ASCII code for "1" (\$31 = 49)
5354	30	ASCII code for "0" (\$30 = 48)
5355	00	End of line
5356	00	Pointer to...
5357	00	...next line (\$0000 = end of program)

7. SERIAL CONFIGURATION

If you intend to connect the LM80C to a host computer through the serial port A, you have to use an FT232 module to adapt the RS232 serial lines of the LM80C to the USB port of modern systems. Moreover, to avoid serial issues during sending data to the LM80C, please configure the terminal emulator you are using (i.e. CoolTerm or TeraTerm) with these params:

PORT: choose the port your system has mounted the FT232 module to

BAUDRATE: 19,200/38,400 bps

DATA BITS: 8

PARITY: none (0)

STOP BITS: 1

FLOW CONTROL: CTS (optional, combine with TX delay)

SOFTWARE SUPPORT FOR FLOW CONTROL: yes

RTS AT STARTUP: on

HANDLE BS AND DEL CHARS: yes

HANDLE FF (FormFeed) CHAR: yes

USE TX DELAY: min. 5ms (increment it if you experience issues)

8. VDP SETTINGS

The VDP, aka Video Display Processor, is the video chip of the LM80C computer. It is a TMS9918A from Texas Instruments. It can visualize a video image of 256x192 pixels with 15 colors and 32 sprites. It has several graphics modes, each of them configured to store video data in particular areas of the VRAM. These are the main settings for the modes supported by LM80C. Before to proceed, a little explanation of the meaning of different areas:

- pattern table: it's the area where the patterns that compose the chars are stored;
- name table: this is a sort of look-up table. This area maps what's is shown by the VDP in each cell of the video. The VDP reads the byte stored into a particular cell and then looks into the pattern table to find the data needed to draw the corresponding char;
- color table: some graphics modes store the color of a particular cell into this table.
- sprite pattern table: similarly to the pattern table, this area stores the data needed to draw the sprites;
- sprite attribute table: this area contains the info needed by the VDP to locate and color the sprites.

SCREEN MODE	SCREEN WIDTH	SCREEN HEIGHT	PATTERN TABLE	NAME TABLE	COLOR TABLE	SPRITE ATTRIBUTE TABLE	SPRITE PATTERN TABLE
Screen 0	40 cols.	24 rows	\$0000-\$07FF	\$0800-\$0BBF	----	----	----
Screen 1	32 cols.	24 rows	\$0000-\$07FF	\$1800-\$1AFF	\$2000-\$201F	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 2	256 px.	192 px.	\$0000-\$17FF	\$1800-\$1AFF	\$2000-\$37FF	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 3	64 blks.	48 blks.	\$0000-\$07FF	\$0800-\$0AFF	----	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 4	32 cols.	24 rows	\$0000-\$07FF	\$1800-\$1FFF	\$3800-\$3AFF	\$1800-\$1FFF	\$3B00-\$3B7F

N.B: the addresses above are referred to Video RAM, so you must use the VPOKE and VPEEK statements to access it.

9. Z80 DAISY CHAIN INTERRUPT PRIORITY

Since the LM80C is set up to work in interrupt mode 2 (IM2), the Z80 CPU serves the interrupt signals following a priority schematic that is hard-wired in the computer itself. In IM2 interrupt signals with higher priority are served before others with lower priority. In LM80C computer:

- the highest priority periphery is the Z80 SIO, since data incoming over the serial must be collected as soon as they are available;
- then the Z80 CTC, also used for the system tick counter;
- lastly, the Z80 PIO that, at the moment, it's just used as on output periphery.

10. STATUS LEDs

Status LEDs are used by the operating system to communicate special conditions to the users. Their meaning is as follow:

0: Bank 0 selector: 0=RAM, 1=ROM	4: Serial 1 buffer overrun
1: VRAM bank # selector: 0=def., 1=alt.	5: Serial 2 buffer overrun
2: N.C.	7: Serial 1 line open
3: N.C.	8: Serial 2 line open

Please remember that LEDs #1 and #2 drive the bank switching mechanisms to switch between ROM and RAM in bank #0 of the main memory and between the two VRAM banks for the VDP, respectively. So, consider that you could get some unwanted side effects if you change them unintentionally.

11. REFERENCES

1. NASCOM ROM BASIC DIS-ASSEMBLED – PART I – BY CARL LLOYD-PARKER
2. https://en.wikipedia.org/wiki/Microsoft_Binary_Format

12. USEFUL LINKS

Project home page:

<https://www.leonardomiliani.com/en/lm80c/>

Github repository for source codes and schematics:

<https://github.com/leomil72/LM80C>

Hackaday page:

<https://hackaday.io/project/165246-lm80c-color-computer>

LM80C

Color Computer

Enjoy home-brewing computers

Leonardo Miliani