



1、USB 驱动安装与加载

1.1 USB 信息

PID	VID	接口号	注释
0x19D2	0x0199	0	ZTE CMCC AT Interface
		1	以太网卡
		2	ZTE CMCC Modem Interface
		3	ZTE CMCC Log Interface

1.2 USB 串口驱动的安装

USB 接口中的 0、2、3 三个接口需要安装 USB 转串口驱动。需要编译内核的 drivers/usb/serial 模块，编译 bus.c generic.c option.c usb-serial.c usb_wwan.c 四个文件，其中 usb_wwan.c 在较早的 Linux 版本中没有。通过 make menuconfig 配置内核编译该模块的方法如下：

```
.config - Linux/arm 3.4.5 Kernel Configuration

Linux/arm 3.4.5 Kernel Configuration
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters
are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press
<Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [ ]
excluded <M> module < > module capable

[*] Bus support --->
    Kernel Features --->
    Boot options --->
    CPU Power Management --->
    Floating point emulation --->
    Userspace binary formats --->
    Power management options --->
    [*] Networking support --->
    Device Drivers --->
    File systems --->

<Select> < Exit > < Help >
```

.config - Linux/arm 3.4.5 Kernel Configuration

Device Drivers

Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module < > module capable

```
[*]
  [*] Sonics Silicon Backplane --->
  Broadcom specific AMBA --->
  Multifunction device drivers --->
  [ ] Voltage and Current Regulator Support --->
  < > Multimedia support --->
    Graphics support --->
  < > Sound card support --->
  [ ] HID Devices --->
  [*] USB support --->
  < > MMC/SD/SDIO card support --->
```

<Select> < Exit > < Help >

.config - Linux/arm 3.4.5 Kernel Configuration

USB support

Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module < > module capable

```
[*]
  < > USB Wireless Device Management support (NEW)
  < > USB Test and Measurement Class support (NEW)
    *** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
    *** also be needed; see USB_STORAGE Help for more info ***
  [ ] The shared table of common (or usual) storage devices (NEW)
    *** USB Imaging devices ***
  < > USB Mustek MDC800 Digital Camera support (NEW)
    *** USB port drivers ***
  [*] USB Serial Converter support --->
    *** USB Miscellaneous drivers ***
```

<Select> < Exit > < Help >

.config - Linux/arm 3.4.5 Kernel Configuration

USB Serial Converter support

Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module < > module capable

```
[*]
  < > USB Safe Serial (Encapsulated) Driver (NEW)
  < > USB Siemens MPI driver (NEW)
  < > USB Sierra Wireless Driver (NEW)
  < > USB Symbol Barcode driver (serial mode) (NEW)
  < > USB TI 3410/5052 Serial Driver (NEW)
  < > USB REINER SCT cyberJack pinpad/e-com chipcard reader (NEW)
  < > USB Xircom / Entegra Single Port Serial Driver (NEW)
  [*] USB driver for GSM and CDMA modems
  < > USB ZyXEL omni.net LCD Plus Driver (NEW)
  < > USB Opticon Barcode driver (serial mode) (NEW)
```

<Select> < Exit > < Help >

在配置完内核后，需要修改文件 `drivers/usb/serial/option.c`，增加对模块 USB 的支持。首先是在 `option.c` 文件中找到全局变量 `option_ids`，将 USB 的信息添加到 `option_ids` 数组中，在数组中增加成员值如下：

```
{USB_DEVICE_AND_INTERFACE_INFO(BA_VENDOR_ID,BA_PRODUCT_B78, 0xff, 0xff, 0xff)},/* B78 products */
```

其中宏 `BA_VENDOR_ID` 和 `BA_PRODUCT_B78` 定义如下：

```
#define BA_VENDOR_ID 0x19d2
#define BA_PRODUCT_B78 0x0199
```


然后修改 `option_probe` 函数将接口 1 从 USB 串口驱动中过滤过来，如下：

```
if (serial->dev->descriptor.idVendor == BA_VENDOR_ID &&
    serial->dev->descriptor.idProduct == BA_PRODUCT_B78 &&
    serial->interface->cur_altsetting->desc.bInterfaceNumber == 0x1)
{
    printk("serial option_probe 0x%X - 0x%X - %d\n",
        serial->dev->descriptor.idVendor,
        serial->dev->descriptor.idProduct,
        serial->interface->cur_altsetting->desc.bInterfaceNumber);
    return -ENODEV;
}
```

1.3 网卡驱动安装

USB 接口中的接口 1 为网络数据接口。如果设备枚举的是标准的 CDC 类网络设备（如 ECM）驱动的加载不在此处描述。

首先需要配置将文件 `drivers/net/usb` 下的 `cdc_ether.c` 和 `usbnet.c` 编译到内核，通过 `make menuconfig` 配置内核编译该模块



.config - Linux/arm 3.4.5 Kernel Configuration

Device Drivers

Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module < > module capable

```
[*] Memory Technology Device (MTD) support --->
< > Parallel port support --->
[*] Block devices --->
    Misc devices --->
    SCSI device support --->
< > Serial ATA and Parallel ATA drivers --->
[ ] Multiple devices driver support (RAID and LVM) --->
[*] Network device support --->
[ ] ISDN support --->
    Input device support --->
```

<Select> < Exit > < Help >

.config - Linux/arm 3.4.5 Kernel Configuration

Network device support

Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module < >

```
< > Universal TUN/TAP device driver support
< > Virtual ethernet pair device
*** CAIF transport drivers ***
[ ] Ethernet driver support --->
< > PHY Device support and infrastructure --->
< > Micrel KS8995MA 5-ports 10/100 managed Ethernet switch
< > PPP (point-to-point protocol) support
< > SLIP (serial line) support
[*] USB Network Adapters --->
[*] Wireless LAN --->
```

<Select> < Exit > < Help >

```
.config - Linux/arm 3.4.5 Kernel Configuration

      USB Network Adapters
Arrow keys navigate the menu.  <Enter> selects submenus --->.
Highlighted letters are hotkeys.  Pressing <Y> includes, <N> excludes,
<M> modularizes features.  Press <Esc><Esc> to exit, <?> for Help, </>
for Search.  Legend: [*] built-in [ ] excluded <M> module < >

< > USB CATC NetMate-based Ethernet device support (EXPERIMENTAL)
< > USB KLSI KL5USB101-based ethernet device support (NEW)
< > USB Pegasus/Pegasus-II based ethernet device support (NEW)
< > USB RTL8150 based ethernet device support (EXPERIMENTAL) (NEW)
[*] Multi-purpose USB Networking Framework
  [*] ASIX AX88xxx Based USB 2.0 Ethernet Adapters (NEW)
  [-] CDC Ethernet support (smart devices such as cable modems)
  < > CDC EEM support (NEW)
  [*] CDC NCM support (NEW)
  < > Davicom DM9601 based USB 1.1 10/100 ethernet devices (NEW)

k(+)

<Select>  < Exit >  < Help >
```

```
.config - Linux/arm 3.4.5 Kernel Configuration

      USB Network Adapters
Arrow keys navigate the menu.  <Enter> selects submenus --->.
Highlighted letters are hotkeys.  Pressing <Y> includes, <N> excludes,
<M> modularizes features.  Press <Esc><Esc> to exit, <?> for Help, </>
for Search.  Legend: [*] built-in [ ] excluded <M> module < >

< > USB CATC NetMate-based Ethernet device support (EXPERIMENTAL)
< > USB KLSI KL5USB101-based ethernet device support (NEW)
< > USB Pegasus/Pegasus-II based ethernet device support (NEW)
< > USB RTL8150 based ethernet device support (EXPERIMENTAL) (NEW)
[*] Multi-purpose USB Networking Framework
  [*] ASIX AX88xxx Based USB 2.0 Ethernet Adapters (NEW)
  [-] CDC Ethernet support (smart devices such as cable modems)
  < > CDC EEM support (NEW)
  [*] CDC NCM support (NEW)
  < > Davicom DM9601 based USB 1.1 10/100 ethernet devices (NEW)

k(+)

<Select>  < Exit >  < Help >
```

内核配置完成后，需要修改内核 `drivers/net/usb/cdc_ether.c` 文件来支持网卡的驱动。首先在 `cdc_ether.c` 文件的 `products` 全局数组中增加对 USB 设备的支持，增加成员如下：

```
{
/* B78 MDM ether*/
USB_DEVICE_AND_INTERFACE_INFO(0x19D2, 0x0199, 0xFF, 0xFF, 0xFF),
.driver_info = (unsigned long) &B78_mdm_ether_info_0199,
},
```


其中变量 B78_mdm_ether_info_0199 定义为:

```
static const struct driver_info B78_mdm_ether_info_0199 = {
    .description = "ZTE Ethernet Device",
    .flags =      FLAG_ETHER,
    .bind =       cdc_bind,
    .unbind =     usbnet_cdc_unbind,
    .status =     cdc_status,
    .data =       (unsigned long) & B78_mdm_ether_iface_info_0199,
};
```

注意: Linux2.6 内核中的 cdc_bind 和 cdc_status 函数在 Linux3.0 与 Linux3.4 等高版本内核中为 usbnet_cdc_bind 和 usbnet_cdc_status。

变量 B78_mdm_ether_iface_info_0199 定义为:

```
static const struct cdc_iface_info B78_mdm_ether_iface_info_0199 = {
    .iface_number = 1
};
```

结构体 cdc_iface_info 定义为:

```
struct cdc_iface_info {
    __u8 iface_number;
};
```

然后修改驱动的 probe 函数。将 cdc_driver 的 probe 成员由原来的 usbnet_probe 修改成新增的 cdc_probe 函数。cdc_probe 先是对接口进行检查, 如果是结构 cdc_iface_info 中描述的接口, 则继续调用 usbnet_probe 函数, 否则返回 -ENODEV。cdc_probe 函数实现如下:

```
static int cdc_probe(struct usb_interface *intf, const struct usb_device_id *prod)
{
    struct driver_info *info;
    int status;
    info = (struct driver_info *) prod->driver_info;
    if (info)
        dev_dbg(&intf->dev, "%s: Probe\n", info->description);
    if (info && info->data) {
        __u8 iface_num;
        struct cdc_iface_info *iface_info;
        iface_num = intf->cur_altsetting->desc.bInterfaceNumber;
        iface_info = (struct cdc_iface_info *) info->data;
        dev_dbg (&intf->dev, "%s: trying iface %d\n",
            info->description, iface_num);
        if (iface_info->iface_number != iface_num)
            return -ENODEV;
        dev_info(&intf->dev, "%s: claiming interface %d\n",
            info->description, iface_num);
    }
```

```

}
status = usbnet_probe(intf, prod);
if (status < 0)
return status;
return 0;
}

```

最后修改 `cdc_bind` 或 `usbnet_cdc_bind` 函数。由于这里的网络接口是非标准的设备接口，因此 `usbnet_generic_cdc_bind` 函数必定失败，因此在 `usbnet_generic_cdc_bind` 返回失败后需要继续调用 `usbnet_get_endpoints` 函数。

```

static int cdc_bind(struct usbnet *dev, struct usb_interface *intf)
{
    int status;
    struct cdc_state *info = (void *) &dev->data;
    status = usbnet_generic_cdc_bind(dev, intf);
    if (status < 0) {
        status = usbnet_get_endpoints(dev, intf);
        if (status < 0)
            return status;
    }
    if (info->ether) {
        printk("\r\n %s,[%d]", __FUNCTION__, __LINE__);
        status = usbnet_get_ethernet_addr(dev, info->ether->iMACAddress);
        if (status < 0)
            goto error;
    }
    /* FIXME cdc-ether has some multicast code too, though it complains
     * in routine cases. info->ether describes the multicast support.
     * Implement that here, manipulating the cdc filter as needed.
     */
    return 0;
error:
    if (info->data) {
        usb_set_intfdata(info->data, NULL);
        usb_driver_release_interface(driver_of(intf), info->data);
    }
    return status;
}

int usbnet_cdc_bind(struct usbnet *dev, struct usb_interface *intf)
{
    int status;
    struct cdc_state *info = (void *) &dev->data;
    BUILD_BUG_ON(sizeof(((struct usbnet *)0)->data) < sizeof(struct cdc_state));
    status = usbnet_generic_cdc_bind(dev, intf);
}

```

```

if(status < 0)
{
    printk("usbnet_generic_cdc_bind failure\n");
    status = usbnet_get_endpoints(dev,intf);

    if(status < 0)
    {
        printk("usbnet_get_endpoints failure\n");
        return status;
    }
}
if(info->ether)
{
    status = usbnet_get_ethernet_addr(dev,info->ether->iMACAddress);
    if(status <0)
    {
        printk("usbnet_get_ethernet_addr failure\n");
        usb_set_intfdata(info->data,NULL);
        usb_driver_release_interface(driver_of(intf),info->data);
        return status;
    }
}

/* FIXME cdc-ether has some multicast code too, though it complains
* in routine cases.    info->ether describes the multicast support.
* Implement that here, manipulating the cdc filter as needed.
*/
return 0;
}

```



2、提示

2.1 Linux 3.8 版本的内核已经支持模块的 USB 驱动。USB 转串口的驱动的内核配置同上文描述，网络数据接口需要编译文件 `drivers/net/usb/qmi_wwan.c`。

2.2 驱动加载后，USB 转串口驱动的设备名字一般为 `ttyUSBx`(`x` 为某个数字，通常为 `ttyUSB0`、`ttyUSB1`、`ttyUSB2`)。网络设备名字根据内核版本显示不同的名字，需要使用 `ifconfig` 命令对比加载前后网络设备的变化来确定具体的设备名字。

2.3 观察对应目录下的 `Makefile` 文件可以看到编译文件依赖的配置变量，比如 `drivers/net/usb/cdc_ether.c` 文件依赖 `CONFIG_USB_NET_CDCETHER`，在 `menuconfig` 界面，可以搜索 `USB_NET_CDCETHER`，观察配置该变量的依赖关系，从而明确如何才能配置这个变量。


以我们的系统为例，搜索到的结果如下图：



```
Search Results
Symbol: USB_NET_CDCETHER [=n]
Type : tristate
Prompt: CDC Ethernet support (smart devices such as cable modems)
Defined at drivers/net/usb/Kconfig:160
Depends on: NETDEVICES [=y] && USB [=n] && NET [=y] && USB_USBNET [=n]
Location:
-> Device Drivers
    -> Network device support (NETDEVICES [=y])
        -> USB Network Adapters
            -> Multi-purpose USB Networking Framework (USB_USBNET [=n])
Selected by: USB_NET_RNDIS_HOST [=n] && NETDEVICES [=y] && USB [=n] &


(100%)
< Exit >
```

图中提示，该变量的配置路径为：



```
Location:
-> Device Drivers
    -> Network device support (NETDEVICES [=y])
        -> USB Network Adapters
            -> Multi-purpose USB Networking Framework (USB_USBNET [=n])
```

依赖关系为：



```
Depends on: NETDEVICES [=y] && USB [=n] && NET [=y] && USB_USBNET [=n]
```

因此，需要将 `NETDEVICES`、`USB`、`NET`、`USB_USBNET` 四个变量都配置成 `y`，才能在 `menuconfig` 中找到配置 `USB_NET_CDCETHER` 的项。

2.4 B78 系列模块使用的版本升级端口为 USB 转串口的驱动，加载方法同上文描述，只是 USB 的 `PID` 有变化，下载端口的 `VID` 为 `0x19D2`，`PID` 为 `0x0256`。