

# DUNK Micro-Codes

David Farrell

July 3, 2025

## 1 Micro-instructions

- 0x0000 - do nothing
- 0x0001 - begin instruction, and save  $*(pk+1)$  to `tmpC`
- 0xN002 - output `srN` to data bus
- 0xN003 - output `srN` to addr bus
- 0xN004 - output  $*srN$  to data bus
- 0xN005 - output  $*(srN+offs)$  to data bus
- 0xN006 - write to `srN` from data bus
- 0xN01M - Special register N special function M
  - 0x0N10 - add N+1 to `pk`
  - 0x0N11 - output  $*(pk+N+1)$  to data bus and add N+1 to `pk`
  - 0x0012 - write to `pk` from `tmpA`
  - 0x0013 - write to `pk` from `tmpB`
  - 0x0014 - write to `pk` from `tmpA` if data bus is zero; increment otherwise
  - 0x0015 - write to `pk` from `tmpA` if data bus is nonzero; increment otherwise
  - 0x0016 - write to `pk` from `tmpA` if data bus is negative; increment otherwise
  - 0x0017 - write to `pk` from `tmpA` if data bus is non-negative; increment otherwise
  - 0x0018 - write to `pk` from `tmpA` if data bus is positive; increment otherwise
  - 0x0019 - write to `pk` from `tmpA` if data bus is non-positive; increment otherwise
  - 0x1010 - increment `sp`
  - 0x1011 - decrement `sp`
  - 0x1N12 - put `sp-(N+1)` on the addr bus, and subtract N+1 from `sp`
  - 0x1N13 - put  $*sp$  on the data bus and add N+1 to `sp`
- 0x2010 - output `tmpA` to `pk` directly
- 0x2010 - output `tmpB` to `pk` directly
- 0xN020 - output `rN` to data bus
- 0xN021 - output `rN` to addr bus
- 0xN022 - output  $*rN$  to data bus
- 0xN023 - output  $*(rN+offs)$  to data bus
- 0xN024 - write to `rN` from data bus
- 0x0025 - write data bus to  $*(addr\ bus)$
- 0x0026 - write data bus to  $*(addr\ bus+offs)$
- 0x0027 - output  $*(addr\ bus)$  RAM to data bus

- 0x0028 - output  $*(\text{addr bus} + \text{offs})$  RAM to data bus
- 0xNM4A - output ALU operation A on (rN, rM) to data bus
- 0xN030 - set I/O pin N to input mode
- 0xN031 - set I/O pin N to output mode
- 0xN032 - set I/O pin N to low
- 0xN033 - set I/O pin N to high
- 0xN034 - output I/O pin N to data bus
- 0xN035 - write data bus to I/O pin N
- 0x0050 - prevent data bus from updating on next rising edge
- 0x0051 - prevent addr bus from updating on next falling edge
- 0x0052 - move the value on the addr bus to the data bus
- 0x0053 - move the value on the data bus to the addr bus
- 0xfffe - end instruction
- 0xffff - reset everything