




USB-C connector




USB ESD protection



USB-UART CH340N




3V3 linear reg.




Changelog revA->revB:

- added C19 (bug)
- swapped UART RX/TX (bug)
- R2 -> 5k1 (brightness)


Fuse & PWR filtering




BOOT button




RESET button



PWR LED



SWD header



MCU-Flash-Tools / puyaisp.py support:

Serial pins PA2 (PY32 TX) / PA3 (PY32 RX) selected to match with:
<https://github.com/wagiminator/MCU-Flash-Tools?tab=readme-ov-file#puyaisp>

Set your MCU to bootloader mode by using either of the following methods:

- Press and hold BOOT button (PF4 to VCC), then connect the converter to your USB port. Release BOOT button.
- Connect USB. Press and hold BOOT button, then press and release the RESET button and then release BOOT button.

Then you can flash: `python3 puyaisp.py -f firmware.bin`

See the URL above for more information.



PU(rple)PILL32 rev.B

This board is licensed under CERN-OHL-W (weakly reciprocal). See the attached LICENSE.

Sheet: /
 File: pupill32.kicad_sch

Title: **pupill32 - indie py32f030 evaluation board**

Size: A4
 KiCad E.D.A. 8.0.7

Date:

Rev: B
 Id: 1/1