

CUnit - A Unit testing framework for C.

<http://cunit.sourceforge.net/>

Automated Test Run Results

Running Suite TC01 - Initialize a PCAN Channel

Running test TC01.1 - Initialize PCAN-USB interface with default parameters ...	Passed
Running test TC01.2 - Initialize PCAN-USB interface a second time ...	Passed
Running test TC01.3 - Initialize PCAN-USB interface a second time after uninitializing ...	Passed
Running test #TC01.4 - Initialize PCAN-USB interface when interface is not present ...	Failed

File Name ../Testcases/Testcases.c

Line Number 734

Condition CU_FAIL(Semi-automatic or manual test not executed for the current library version)

Running test #TC01.5 - Initialize PCAN-USB interface when interface is used by another process ...	Failed
--	--------

File Name ../Testcases/Testcases.c

Line Number 734

Condition CU_FAIL(Semi-automatic or manual test not executed for the current library version)

Running test TC01.6 - Initialize PCAN-USB interface with parameter 'Channel == PCAN_NONEBUS' ...	Passed
Running test TC01.7 - Initialize PCAN-USB interface with parameter 'Channel == PCAN_USBBUS1 - 1' ...	Passed
Running test TC01.8 - Initialize PCAN-USB interface with parameter 'Channel == PCAN_USBBUS8 + 1' ...	Passed
Running test TC01.9 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_1M' ...	Passed
Running test TC01.10 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_500K' ...	Passed
Running test TC01.11 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_250K' ...	Passed
Running test TC01.12 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_125K' ...	Passed
Running test TC01.13 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_100K' ...	Passed

	Running test TC01.14 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_50K' ...	Passed
	Running test TC01.15 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_20K' ...	Passed
	Running test TC01.16 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_10K' ...	Passed
	Running test TC01.17 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == PCAN_BAUD_5K' ...	Passed
	Running test TC01.18 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == 0x0000' ...	Passed
	Running test TC01.19 - Initialize PCAN-USB interface with parameter 'Btr0Btr1 == 0xFFFF' ...	Passed
	Running test #TC01.20 - Initialize PCAN-USB interface with different baud rate than on real CAN ...	Failed

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		

Running Suite TC02 - Uninitialize a PCAN Channel

	Running test TC02.1 - Uninitialize PCAN-USB interface running with default parameters ...	Passed
	Running test TC02.2 - Uninitialize PCAN-USB interface when not initialized before ...	Passed
	Running test TC02.3 - Uninitialize PCAN-USB interface after reinitializing ...	Passed
	Running test #TC02.4 - Uninitialize PCAN-USB interface when interface is not present anymore ...	Failed

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		

	Running test #TC02.5 - Uninitialize PCAN-USB interface when interface is used by another process ...	Failed
--	--	--------

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		

	Running test TC02.6 - Uninitialize PCAN-USB interface with parameter 'Channel == PCAN_NONEBUS' after initializing ...	Passed
	Running test TC02.7 - Uninitialize PCAN-	

	USB interface with an invalid value for parameter 'Channel' after initializing ...	Passed	
Running Suite TC03 - Reset the receive and transmit queues			
	Running test TC03.1 - Reset queues while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC03.2 - Reset queues when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC03.3 - Reset queue with an invalid value for parameter 'Channel' ...	Passed	
	Running test #TC03.4 - Reset queues and check if the transmit queue is empty ...	Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test TC03.5 - Reset queues and check if the receive queue is empty ...	Passed	
Running Suite TC04 - Get the current BUS status			
	Running test TC04.1 - Get BUS status while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC04.2 - Get BUS status when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC04.3 - Get BUS status with an invalid value for parameter 'Channel' ...	Passed	
	Running test #TC04.4 - Get BUS status when PCAN-USB interface is not present anymore ...	Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test #TC04.5 - Get BUS status while errors on CAN bus are present ...	Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
Running Suite TC05 - Read a CAN message from the receive queue			
	Running test TC05.1 - Read a CAN message while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC05.2 - Read a CAN message when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC05.3 - Read a CAN message with an invalid value for parameter 'Channel'	Passed	

	...	
	Running test TC05.4 - Read a CAN message with illegal parameter 'MessageBuffer == NULL' ...	Passed
	Running test TC05.5 - Read CAN messages from the receive queue and check for amount and order ...	Passed
	Running test #TC05.6 - Read CAN messages from the receive queue - long term stress test ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test #TC05.7 - Read CAN messages from the receive queue - timestamp accuracy test ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test #TC05.8 - Read CAN messages from the receive queue when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test #TC05.9 - Read CAN messages from the receive queue while errors on CAN bus are present ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC05.10 - Read the status of the receive queue after an overrun ...	Passed
Running Suite TC06 - Transmit a CAN message		
	Running test TC06.1 - Transmit a CAN message while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC06.2 - Transmit a CAN message when PCAN-USB interface is not initialized before ...	Passed
	Running test TC06.3 - Transmit a CAN message with an invalid value for parameter 'Channel' ...	Passed
	Running test TC06.4 - Transmit a CAN message with illegal parameter 'MessageBuffer == NULL' ...	Passed
	Running test TC06.5 - Transmit a standard	

	CAN message with a valid 11-bit identifier and no data bytes (DLC = 0) ...	Passed
	Running test TC06.6 - Transmit a standard CAN message with a valid 11-bit identifier and one data byte (DLC = 1) ...	Passed
	Running test TC06.7 - Transmit a standard CAN message with a valid 11-bit identifier and two data bytes (DLC = 2) ...	Passed
	Running test TC06.8 - Transmit a standard CAN message with a valid 11-bit identifier and three data bytes (DLC = 3) ...	Passed
	Running test TC06.9 - Transmit a standard CAN message with a valid 11-bit identifier and four data bytes (DLC = 4) ...	Passed
	Running test TC06.10 - Transmit a standard CAN message with a valid 11-bit identifier and five data bytes (DLC = 5) ...	Passed
	Running test TC06.11 - Transmit a standard CAN message with a valid 11-bit identifier and six data bytes (DLC = 6) ...	Passed
	Running test TC06.12 - Transmit a standard CAN message with a valid 11-bit identifier and seven data bytes (DLC = 7) ...	Passed
	Running test TC06.13 - Transmit a standard CAN message with a valid 11-bit identifier and eight data bytes (DLC = 8) ...	Passed
	Running test TC06.14 - Transmit a standard CAN message with a valid 11-bit identifier and invalid data length code (DLC = 9) ...	Passed
	Running test TC06.15 - Transmit a standard CAN message with a valid 11-bit identifier and invalid data length code (DLC = 255) ...	Passed
	Running test TC06.16 - Transmit a standard CAN message with a valid 29-bit identifier (invalid for standard messages) ...	Passed
	Running test TC06.17 - Transmit a standard CAN message with an invalid 11-bit identifier (ID = 0x20000000) ...	Passed
	Running test TC06.18 - Transmit a standard CAN message with an invalid 11-bit identifier (ID = 0xFFFFFFFF) ...	Passed
	Running test TC06.19 - Request a standard CAN message with a valid 11-bit identifier and no data bytes (DLC = 0) ...	Passed
	Running test TC06.20 - Request a standard CAN message with a valid 11-bit identifier and one data byte (DLC = 1) ...	Passed
	Running test TC06.21 - Request a standard CAN message with a valid 11-bit identifier and two data bytes (DLC = 2) ...	Passed

	Running test TC06.22 - Request a standard CAN message with a valid 11-bit identifier and three data bytes (DLC = 3) ...	Passed
	Running test TC06.23 - Request a standard CAN message with a valid 11-bit identifier and four data bytes (DLC = 4) ...	Passed
	Running test TC06.24 - Request a standard CAN message with a valid 11-bit identifier and five data bytes (DLC = 5) ...	Passed
	Running test TC06.25 - Request a standard CAN message with a valid 11-bit identifier and six data bytes (DLC = 6) ...	Passed
	Running test TC06.26 - Request a standard CAN message with a valid 11-bit identifier and seven data bytes (DLC = 7) ...	Passed
	Running test TC06.27 - Request a standard CAN message with a valid 11-bit identifier and eight data bytes (DLC = 8) ...	Passed
	Running test TC06.28 - Request a standard CAN message with a valid 11-bit identifier and wrong data length code ...	Passed
	Running test TC06.29 - Request a standard CAN message with a valid 11-bit identifier and invalid data length code ...	Passed
	Running test TC06.30 - Request a standard CAN message with a valid 29-bit identifier (invalid for standard messages) ...	Passed
	Running test TC06.31 - Request a standard CAN message with an invalid 11-bit identifier (ID = 0x20000000) ...	Passed
	Running test TC06.32 - Request a standard CAN message with an invalid 11-bit identifier (ID = 0xFFFFFFFF) ...	Passed
	Running test TC06.33 - Transmit a extended CAN message with a valid 29-bit identifier and no data bytes (DLC = 0) ...	Passed
	Running test TC06.34 - Transmit a extended CAN message with a valid 29-bit identifier and one data byte (DLC = 1) ...	Passed
	Running test TC06.35 - Transmit a extended CAN message with a valid 29-bit identifier and two data bytes (DLC = 2) ...	Passed
	Running test TC06.36 - Transmit a extended CAN message with a valid 29-bit identifier and three data bytes (DLC = 3) ...	Passed
	Running test TC06.37 - Transmit a extended CAN message with a valid 29-bit identifier and four data bytes (DLC = 4) ...	Passed
	Running test TC06.38 - Transmit a extended CAN message with a valid 29-bit identifier	Passed

	and five data bytes (DLC = 5) ...	
	Running test TC06.39 - Transmit a extended CAN message with a valid 29-bit identifier and six data bytes (DLC = 6) ...	Passed
	Running test TC06.40 - Transmit a extended CAN message with a valid 29-bit identifier and seven data bytes (DLC = 7) ...	Passed
	Running test TC06.41 - Transmit a extended CAN message with a valid 29-bit identifier and eight data bytes (DLC = 8) ...	Passed
	Running test TC06.42 - Transmit a extended CAN message with a valid 29-bit identifier and invalid data length code (DLC = 9) ...	Passed
	Running test TC06.43 - Transmit a extended CAN message with a valid 29-bit identifier and invalid data length code (DLC = 255) ...	Passed
	Running test TC06.44 - Transmit a extended CAN message with an invalid 29-bit identifier (ID = 0x20000000) ...	Passed
	Running test TC06.45 - Transmit a extended CAN message with an invalid 29-bit identifier (ID = 0xFFFFFFFF) ...	Passed
	Running test TC06.46 - Request a extended CAN message with a valid 29-bit identifier and no data bytes (DLC = 0) ...	Passed
	Running test TC06.47 - Request a extended CAN message with a valid 29-bit identifier and one data byte (DLC = 1) ...	Passed
	Running test TC06.48 - Request a extended CAN message with a valid 29-bit identifier and two data bytes (DLC = 2) ...	Passed
	Running test TC06.49 - Request a extended CAN message with a valid 29-bit identifier and three data bytes (DLC = 3) ...	Passed
	Running test TC06.50 - Request a extended CAN message with a valid 29-bit identifier and four data bytes (DLC = 4) ...	Passed
	Running test TC06.51 - Request a extended CAN message with a valid 29-bit identifier and five data bytes (DLC = 5) ...	Passed
	Running test TC06.52 - Request a extended CAN message with a valid 29-bit identifier and six data bytes (DLC = 6) ...	Passed
	Running test TC06.53 - Request a extended CAN message with a valid 29-bit identifier and seven data bytes (DLC = 7) ...	Passed
	Running test TC06.54 - Request a extended CAN message with a valid 29-bit identifier and eight data bytes (DLC = 8) ...	Passed
	Running test TC06.55 - Request a extended	

	CAN message with a valid 29-bit identifier and wrong data length code ...	Passed
	Running test TC06.56 - Request a extended CAN message with a valid 29-bit identifier and invalid data length code ...	Passed
	Running test TC06.57 - Request a extended CAN message with an invalid 29-bit identifier (ID = 0x20000000) ...	Passed
	Running test TC06.58 - Request a extended CAN message with an invalid 29-bit identifier (ID = 0xFFFFFFFF) ...	Passed
	Running test TC06.59 - Transmit a CAN message with illegal parameter 'MessageBuffer.MSGTYPE == 0x80' ...	Passed
	Running test TC06.60 - Transmit a CAN message with illegal parameter 'MessageBuffer.MSGTYPE == 0xFF' ...	Passed
	Running test #TC06.61 - Transmit CAN messages when interface is not present anymore ...	Failed

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		

	Running test #TC06.62 - Transmit CAN messages while errors on CAN bus are present ...	Failed
--	---	--------

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		

Running Suite TC07 - Retrieve information from a PCAN Channel

	Running test TC07.21.1 - Get parameter PCAN_API_VERSION while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.21.2 - Get parameter PCAN_API_VERSION when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.21.3 - Get parameter PCAN_API_VERSION with legal parameter 'Channel == PCAN_NONEBUS' ...	Passed
	Running test TC07.21.4 - Get parameter PCAN_API_VERSION with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.21.5 - Get parameter PCAN_API_VERSION with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test #TC07.21.6 - Get parameter PCAN_API_VERSION when interface is not present anymore ...	Failed

File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test TC07.22.1 - Get parameter PCAN_CHANNEL_VERSION while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC07.22.2 - Get parameter PCAN_CHANNEL_VERSION when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC07.22.3 - Get parameter PCAN_CHANNEL_VERSION with an invalid value for parameter 'Channel' ...	Passed	
	Running test TC07.22.4 - Get parameter PCAN_CHANNEL_VERSION with illegal parameter 'Buffer == NULL' ...	Passed	
	Running test TC07.22.5 - Get parameter PCAN_CHANNEL_VERSION with an invalid value for parameter 'BufferLength' (too small) ...	Passed	
	Running test #TC07.22.6 - Get parameter PCAN_CHANNEL_VERSION when interface is not present anymore ...	Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test TC07.24.1 - Get parameter PCAN_LISTEN_ONLY while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC07.24.2 - Get parameter PCAN_LISTEN_ONLY when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC07.24.3 - Get parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'Channel' ...	Passed	
	Running test TC07.24.4 - Get parameter PCAN_LISTEN_ONLY with illegal parameter 'Buffer == NULL' ...	Passed	
	Running test TC07.24.5 - Get parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'BufferLength' (too small) ...	Passed	
	Running test TC07.24.6 - Get parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'BufferLength' (too big) ...	Passed	
	Running test #TC07.24.7 - Get parameter PCAN_LISTEN_ONLY when interface is not	Failed	

present anymore ...			
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test TC07.29.1 - Get parameter PCAN_CHANNEL_CONDITION while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC07.29.2 - Get parameter PCAN_CHANNEL_CONDITION when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC07.29.3 - Get parameter PCAN_CHANNEL_CONDITION with illegal parameter 'Channel == PCAN_NONEBUS' ...	Passed	
	Running test TC07.29.4 - Get parameter PCAN_CHANNEL_CONDITION with illegal parameter 'Buffer == NULL' ...	Passed	
	Running test TC07.29.5 - Get parameter PCAN_CHANNEL_CONDITION with an invalid value for parameter 'BufferLength' (too small) ...	Passed	
	Running test TC07.29.6 - Get parameter PCAN_CHANNEL_CONDITION with an invalid value for parameter 'BufferLength' (too big) ...	Passed	
	Running test #TC07.29.7 - Get parameter PCAN_CHANNEL_CONDITION when interface is not present anymore ...	Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
	Running test TC07.30.1 - Get parameter PCAN_HARDWARE_NAME while PCAN-USB interface is running with default parameters ...	Passed	
	Running test TC07.30.2 - Get parameter PCAN_HARDWARE_NAME when PCAN-USB interface is not initialized before ...	Passed	
	Running test TC07.30.3 - Get parameter PCAN_HARDWARE_NAME with an invalid value for parameter 'Channel' ...	Passed	
	Running test TC07.30.4 - Get parameter PCAN_HARDWARE_NAME with illegal parameter 'Buffer == NULL' ...	Passed	
	Running test TC07.30.5 - Get parameter PCAN_HARDWARE_NAME with an invalid value for parameter 'BufferLength' (too small) ...	Passed	

	Running test #TC07.30.6 - Get parameter PCAN_HARDWARE_NAME when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC07.33.1 - Get parameter PCAN_TRACE_LOCATION while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.33.2 - Get parameter PCAN_TRACE_LOCATION when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.33.3 - Get parameter PCAN_TRACE_LOCATION with an invalid value for parameter 'Channel' ...	Passed
	Running test TC07.33.4 - Get parameter PCAN_TRACE_LOCATION with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.33.5 - Get parameter PCAN_TRACE_LOCATION with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test #TC07.33.6 - Get parameter PCAN_TRACE_LOCATION when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC07.34.1 - Get parameter PCAN_TRACE_STATUS while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.34.2 - Get parameter PCAN_TRACE_STATUS when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.34.3 - Get parameter PCAN_TRACE_STATUS with an invalid value for parameter 'Channel' ...	Passed
	Running test TC07.34.4 - Get parameter PCAN_TRACE_STATUS with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.34.5 - Get parameter PCAN_TRACE_STATUS with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC07.34.6 - Get parameter PCAN_TRACE_STATUS with an invalid	Passed

	value for parameter 'BufferLength' (too big) ...	
	Running test #TC07.34.7 - Get parameter PCAN_TRACE_STATUS when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC07.35.1 - Get parameter PCAN_TRACE_SIZE while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.35.2 - Get parameter PCAN_TRACE_SIZE when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.35.3 - Get parameter PCAN_TRACE_SIZE with an invalid value for parameter 'Channel' ...	Passed
	Running test TC07.35.4 - Get parameter PCAN_TRACE_SIZE with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.35.5 - Get parameter PCAN_TRACE_SIZE with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC07.35.6 - Get parameter PCAN_TRACE_SIZE with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test #TC07.35.7 - Get parameter PCAN_TRACE_SIZE when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC07.36.1 - Get parameter PCAN_TRACE_CONFIGURE while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.36.2 - Get parameter PCAN_TRACE_CONFIGURE when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.36.3 - Get parameter PCAN_TRACE_CONFIGURE with an invalid value for parameter 'Channel' ...	Passed
	Running test TC07.36.4 - Get parameter PCAN_TRACE_CONFIGURE with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.36.5 - Get parameter PCAN_TRACE_CONFIGURE with an	

	invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC07.36.6 - Get parameter PCAN_TRACE_CONFIGURE with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test #TC07.36.7 - Get parameter PCAN_TRACE_CONFIGURE when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	

	Running test TC07.38 - Get parameter PCAN_EXT_BTR0BTR1 while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC07.39 - Get parameter PCAN_EXT_TX_COUNTER when PCAN-USB interface is not initialized before ...	Passed
	Running test TC07.40 - Get parameter PCAN_EXT_RX_COUNTER with illegal parameter 'Channel == PCAN_NONEBUS' ...	Passed
	Running test TC07.41 - Get parameter PCAN_EXT_ERR_COUNTER with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC07.42 - Get parameter PCAN_EXT_RX_QUE_OVERRUN with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC07.43 - Get parameter PCAN_EXT_HARDWARE_VERSION with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test #TC07.44 - Get parameter PCAN_EXT_SOFTWARE_VERSION when interface is not present anymore ...	Failed

File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	

Running Suite TC08 - Set a configuration or information value within a PCAN Channel

	Running test TC08.24.1 - Set parameter PCAN_LISTEN_ONLY while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC08.24.2 - Set parameter PCAN_LISTEN_ONLY when PCAN-USB interface is not initialized before ...	Passed
	Running test TC08.24.3 - Set parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'Channel' ...	Passed

	Running test TC08.24.4 - Set parameter PCAN_LISTEN_ONLY with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC08.24.5 - Set parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC08.24.6 - Set parameter PCAN_LISTEN_ONLY with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test TC08.24.7 - Set parameter PCAN_LISTEN_ONLY with an invalid value '*Buffer == 2' ...	Passed
	Running test TC08.24.8 - Set parameter PCAN_LISTEN_ONLY with an invalid value '*Buffer == -1' ...	Passed
	Running test TC08.24.9 - Set parameter PCAN_LISTEN_ONLY with value '*Buffer == PCAN_PARAMETER_ON' before initialization ...	Passed
	Running test TC08.24.10 - Set parameter PCAN_LISTEN_ONLY with value '*Buffer == PCAN_PARAMETER_ON' after initialization ...	Passed
	Running test TC08.24.11 - Set parameter PCAN_LISTEN_ONLY with value '*Buffer == PCAN_PARAMETER_ON' and check mode after uninitializing ...	Passed
	Running test TC08.24.12 - Set parameter PCAN_LISTEN_ONLY with value '*Buffer == PCAN_PARAMETER_OFF' after initialization in listen-only mode ...	Passed
	Running test #TC08.24.13 - Set parameter PCAN_LISTEN_ONLY when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC08.33.1 - Set parameter PCAN_TRACE_LOCATION while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC08.33.2 - Set parameter PCAN_TRACE_LOCATION when PCAN-USB interface is not initialized before ...	Passed
	Running test TC08.33.3 - Set parameter PCAN_TRACE_LOCATION with an invalid value for parameter 'Channel' ...	Passed
	Running test TC08.33.4 - Set parameter PCAN_TRACE_LOCATION with illegal	

	parameter 'Buffer == NULL' ...	Passed
	Running test TC08.33.5 - Set parameter PCAN_TRACE_LOCATION with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC08.33.6 - Set parameter PCAN_TRACE_LOCATION with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test TC08.33.7 - Set parameter PCAN_TRACE_LOCATION with valid strings for parameter '*Buffer' and read back ...	Passed
	Running test TC08.33.8 - Set parameter PCAN_TRACE_LOCATION with an empty string for parameter '*Buffer' ...	Passed
	Running test #TC08.33.9 - Set parameter PCAN_TRACE_LOCATION when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC08.34.1 - Set parameter PCAN_TRACE_STATUS while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC08.34.2 - Set parameter PCAN_TRACE_STATUS when PCAN-USB interface is not initialized before ...	Passed
	Running test TC08.34.3 - Set parameter PCAN_TRACE_STATUS with an invalid value for parameter 'Channel' ...	Passed
	Running test TC08.34.4 - Set parameter PCAN_TRACE_STATUS with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC08.34.5 - Set parameter PCAN_TRACE_STATUS with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC08.34.6 - Set parameter PCAN_TRACE_STATUS with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test TC08.34.7 - Set parameter PCAN_TRACE_STATUS with valid values for parameter '*Buffer' and read back ...	Passed
	Running test TC08.34.8 - Set parameter PCAN_TRACE_STATUS with invalid values for parameter '*Buffer' ...	Passed
	Running test #TC08.34.9 - Set parameter PCAN_TRACE_STATUS when interface is	Failed

not present anymore ...			
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
Running test #TC08.34.10 - Trace a lot of CAN messages and check the trace file for format and content ...		Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
Running test TC08.35.1 - Set parameter PCAN_TRACE_SIZE while PCAN-USB interface is running with default parameters ...		Passed	
Running test TC08.35.2 - Set parameter PCAN_TRACE_SIZE when PCAN-USB interface is not initialized before ...		Passed	
Running test TC08.35.3 - Set parameter PCAN_TRACE_SIZE with an invalid value for parameter 'Channel' ...		Passed	
Running test TC08.35.4 - Set parameter PCAN_TRACE_SIZE with illegal parameter 'Buffer == NULL' ...		Passed	
Running test TC08.35.5 - Set parameter PCAN_TRACE_SIZE with an invalid value for parameter 'BufferLength' (too small) ...		Passed	
Running test TC08.35.6 - Set parameter PCAN_TRACE_SIZE with an invalid value for parameter 'BufferLength' (too big) ...		Passed	
Running test TC08.35.7 - Set parameter PCAN_TRACE_SIZE with valid values for parameter '*Buffer' and read back ...		Passed	
Running test TC08.35.8 - Set parameter PCAN_TRACE_SIZE with invalid values for parameter '*Buffer' ...		Passed	
Running test #TC08.35.9 - Set parameter PCAN_TRACE_SIZE when interface is not present anymore ...		Failed	
File Name	../Testcases/Testcases.c	Line Number	734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)		
Running test TC08.36.1 - Set parameter PCAN_TRACE_CONFIGURE while PCAN-USB interface is running with default parameters ...		Passed	
Running test TC08.36.2 - Set parameter PCAN_TRACE_CONFIGURE when PCAN-USB interface is not initialized before ...		Passed	
Running test TC08.36.3 - Set parameter			

	PCAN_TRACE_CONFIGURE with an invalid value for parameter 'Channel' ...	Passed
	Running test TC08.36.4 - Set parameter PCAN_TRACE_CONFIGURE with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC08.36.5 - Set parameter PCAN_TRACE_CONFIGURE with an invalid value for parameter 'BufferLength' (too small) ...	Passed
	Running test TC08.36.6 - Set parameter PCAN_TRACE_CONFIGURE with an invalid value for parameter 'BufferLength' (too big) ...	Passed
	Running test TC08.36.7 - Set parameter PCAN_TRACE_CONFIGURE with valid values for parameter '*Buffer' and read back ...	Passed
	Running test TC08.36.8 - Set parameter PCAN_TRACE_CONFIGURE with invalid values for parameter '*Buffer' ...	Passed
	Running test #TC08.36.9 - Set parameter PCAN_TRACE_CONFIGURE when interface is not present anymore ...	Failed
File Name	../Testcases/Testcases.c	Line Number 734
Condition	CU_FAIL(Semi-automatic or manual test not executed for the current library version)	
	Running test TC08.45 - Set parameter PCAN_EXT_LOG_USB and write all function calls to a log-file ...	Passed
Running Suite TC10 - Retrieve an error text		
	Running test TC10.1 - Get error text while PCAN-USB interface is running with default parameters ...	Passed
	Running test TC10.2 - Get error text when PCAN-USB interface is not initialized before ...	Passed
	Running test TC10.3 - Get error text with illegal parameter 'Error == 4294967295' ...	Passed
	Running test TC10.4 - Get error text with illegal parameter 'Language == 57005' ...	Passed
	Running test TC10.5 - Get error text with illegal parameter 'Buffer == NULL' ...	Passed
	Running test TC10.6 - Get the English error text for each defined error code and check it ...	Passed
	Running test TC10.7 - Get the German error text for each defined error code and check it ...	Passed
	Running test TC10.8 - Get the French error text for each defined error code and check it ...	Passed
	Running test TC10.9 - Get the Italian error text	Passed

	for each defined error code and check it ...	
	Running test TC10.10 - Get the Spanish error text for each defined error code and check it ...	Passed
	Running test TC10.11 - Get error text for OR-ed parameter 'Error == PCAN_ERROR_ANYBUSERR' ...	Passed
	Running test TC10.12 - Get error text for OR-ed parameter 'Error == PCAN_ERROR_ILLHANDLE' ...	Passed

Cumulative Summary for Run					
Type	Total	Run	Succeeded	Failed	Inactive
Suites	9	9	- NA -	0	0
Test Cases	238	238	208	30	0
Assertions	363847	363847	363817	30	n/a

File Generated By CUnit v2.1-1 - Sun Feb 23 21:50:59 2014