

# Maintenance Procedure


## No. MP915

Page 1 of 1

<b>TASK DESCRIPTION</b>
TEST OPERATOR'S CONSOLE INDICATOR LAMPS
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b>
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 9
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b>
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

### PROCEDURE

Press the front of each indicator lamp on the left side of the operator console. Replace any bulb which fails to properly function.



DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment