

Maintenance Procedure  
**No. MP445**

Page 1 of 2

<b>TASK DESCRIPTION</b> DRAIN RETENTION TANK
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b> MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 4
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b> CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

**PROCEDURE**

1. Remove lock pins from cam lock drain cap (see figure 1).
2. Unlatch cam lock handles, then unscrew drain cap.
3. Connect a transfer line from the railroad collection tank to the locomotive's retention tank drain fitting.
4. Open the drain valve and allow all fluid and any particulates to drain.
5. Close the drain valve.
6. Disconnect the transfer pipe.
7. Reinstall the drain cap, latch cam locks, and secure lock pins.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION        1	August 2009	TITLE: <div style="text-align: right; margin-top: 10px;">Manager, Rail Equipment</div>

Maintenance Procedure  
**No. MP445**

Page 2 of 2




Figure 1

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment