

Yosun SX9513 Touch Command Syntax



Copyright © 2010 Yosun Singapore Pte Ltd. All Rights Reserved.

Though every care has been taken to ensure the accuracy of this document, Yosun Singapore Pte Ltd. cannot accept responsibility for any errors or omissions or for any loss occasioned to any person, whether legal or natural, from acting, or refraining from action, as a result of the information contained herein. Information in this document is subject to change at any time without obligation to notify any person of such changes.

Yosun Singapore Pte Ltd. may have patents or patent pending applications, trademarks copyrights or other intellectual property rights covering subject matter in this document. The furnishing of this document does not give the recipient or reader any license to these patents, trademarks copyrights or other intellectual property rights.

No part of this document may be communicated, distributed, reproduced or transmitted in any form or by any means, electronic or mechanical or otherwise, for any purpose, without the prior written permission of Yosun Singapore Pte Ltd.

The document is subject to revision without further notice.

All brand names and product names mentioned in this document are trademarks or registered trademarks of their respective owners.

Contact Address

**Yosun Singapore Pte Ltd.
16 TAI SENG STREET #05-00
Singapore 534138**

**e-mail : mark_ma@yosun.com.sg
Home Page: <http://www.yosungroup.com>**

Revision History

Date	Version	Author	Remark
17/10/2014	1.0.0	MA LIYU	Creation

	Revision History	3
1	Introduction	5
1.1	Definitions	5
2	Command Syntax	6
3	Command Availability Table	7

1 Introduction

The Yosun SX9513 Touch module can be driven via the serial interface using specific commands. The command is similar to standard AT command.

1.1 Definitions

The following syntactical definitions apply:

<CR>

Carriage return character, is the command line and result code terminator character, which value, in decimal ASCII between 0 and 255, is specified within parameter S3. The default value is 13.

<...>

Name enclosed in angle brackets is a syntactical element. They do not appear in the command line.

[...]

Optional sub-parameter of a command or an optional part of TA information response is enclosed in square brackets. Brackets themselves do not appear in the command line. When sub-parameter is not given in AT commands which have a Read command, new value equals to its previous value. In AT commands which do not store the values of any of their sub-parameters, and so have not a Read command, which are called action type commands, action should be done on the basis of the recommended default setting of the sub-parameter.

2 Command Syntax

<at+><cmd body><=><S1>[,][S2]<CR>

Rule 1: All chars within command are small letters.

Rule 2: All commands must be terminated by Carriage Return <CR>.

Rule 3: Space is treated as parameter within command.

Rule 4: Prefix of command is “at+”.

3 Command Availability Table

COMMAND	Description
at+version=?<CR>	Check MCU firmware version. It is stored in EEPROM of MCU.
at+diffdata=<S1>,<S2><CR>	<p>The Touch Status register will indicate when a touch occurs on one of the BL channels. A touch is indicated when a channels DiffData value goes at least the Hyst value above its threshold level for debounce number of consecutive measurement cycles. A touch is lost when a channels DiffData value goes at least Hyst value below it's threshold for debounce number of measurement cycles. This is a dynamic read only register that is not stored in NVM.</p> <p>Example: BL2 is set to a threshold of 400 (0x21 = 0x19), a Hyst of 8 (0x37 [7:5] = 3'b001), a touch debounce of 0 (0x33 [3:2] = 2'b00) and a release debounce of 2 (0x33 [1:0] = 2'b01). A touch will be indicated the first measurement cycle that the DiffData goes above 408 and the touch will be lost when the DiffData value goes below 392 on two successive measurement cycles.</p> <p>Parameter: <S1> selected channel. S1 is one digit number and ranges from 0 to 7. <S2> number of display data. S2 is 2 digit number and ranges from 00 to 99.</p> <p>Response: MCU will continuously read the data then display them. The display data is separated by <SPACE>.</p>
at+comp=?<CR>	Display offset compensation DAC code.