

## EDCIDR1, External Debug Component Identification Register 1

The EDCIDR1 characteristics are:

### Purpose

Provides information to identify an external debug component.

For more information, see 'About the Component Identification scheme'.

### Configuration

When FEAT\_DoPD is implemented, EDCIDR1 is in the Core power domain. Otherwise, EDCIDR1 is in the Debug power domain.

Implementation of this register is optional.

This register is required for CoreSight compliance.

### Attributes

EDCIDR1 is a 32-bit register.

### Field descriptions

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RES0																CLASS				PRMBL 1											

#### Bits [31:8]

Reserved, res0.

#### CLASS, bits [7:4]

Component class.

CLASS	Meaning
0b1001	CoreSight component.

Other values are defined by the CoreSight Architecture.

This field reads as 0x9.

**PRMBL\_1, bits [3:0]**

Preamble.

Reads as 0b0000.

Access to this field is **RO**.

**Accessing EDCIDR1**

**EDCIDR1 can be accessed through the external debug interface:**

Component	Offset	Instance
Debug	0xFF4	EDCIDR1

This interface is accessible as follows:

- When FEAT\_DoPD is not implemented or IsCorePowered(), accesses to this register are **RO**.
- Otherwise, accesses to this register generate an error response.