

POWER ON / POWER OFF

THE CLOCK REQUIRES POWER FROM A USB-C POWER DELIVERY CHARGER
CAPABLE OF SUPPLYING 12 V AND A MINIMUM CURRENT OF 1 A

BUTTON

●

SHORT PRESS

●

DOUBLE PRESS

●●

LONG PRESS 1 SEC

▬

LONG PRESS 2 SEC

▬▬

LED INDICATORS

● ● ●

BUTTONS

●

●

●

●

▬

USB-C PD POWER INPUT

POWER ON

●

●

LONG PRESS 2 SEC

POWER OFF

●

LONG PRESS 2 SEC

●

POWER OK

● ●

INDICATORS ARE CONSTANTLY ON

POWER ERROR

● ● ●

YELLOW AND RED INDICATORS FLASH
VOLTAGE LOW: SLOW FLASH (1 PER SECOND)
VOLTAGE HIGH: VERY FAST FLASH (4 TIMES PER SECOND)

TURN THE CLOCK OFF. UNPLUG THE CABLE.
PLUG THE CABLE BACK IN. TURN THE CLOCK ON.
IF THE PROBLEM PERSISTS, USE A DIFFERENT CHARGER.

1

01 - EVERY 1 MINUTE

1

60 - EVERY HOUR

1

00 - OFF

2

11 - SYMBOL TYPE: DIGITS

2

●● SYMBOL TYPE: DICE

3

NORMAL MODE

DURING NORMAL CLOCK OPERATION,
DOUBLE-PRESS THE TOP BUTTON
TO ENTER EFFECT SETTINGS.

<p>ENTER SETTINGS</p> <p>●●</p> <p>●</p> <p>●</p>	<p>ADJUST SETTINGS</p> <p>●</p> <p>+</p> <p>●</p>	<p>SAVE/CONTINUE AND EXIT</p> <p>▬</p> <p>●</p> <p>●</p>
--	--	---

1 THE FIRST SETTING IS THE RANDOM FLIP-DISC EFFECT.
YOU CAN SET THE EFFECT TO RUN EVERY MINUTE, EVERY FULL HOUR,
OR TURN IT OFF COMPLETELY.

THE SECOND SETTING IS THE DISPLAY FORMAT.
TIME CAN BE DISPLAYED AS DIGITS OR AS DICE / DOMINO DOTS. 2


3 NORMAL CLOCK OPERATION

LONG PRESS THE TOP BUTTON TO SAVE THE RANDOM FLIP-DISC EFFECT
AND GO TO DISPLAY FORMAT SETTINGS.
LONG PRESS AGAIN TO SAVE AND RETURN TO NORMAL MODE.


TIME SETTINGS

USE THE TOP AND MIDDLE BUTTONS FOR SETTINGS
PRESS THE TOP BUTTON TO ENTER OR EXIT SETTINGS
USE THE MIDDLE BUTTON TO CHANGE OR ADJUST EACH SETTING


BUTTON




SHORT PRESS




DOUBLE PRESS







LONG PRESS 1 SEC





LONG PRESS 2 SEC







ENTER SETTINGS










ADJUST SETTINGS









SAVE AND CONTINUE








DURING NORMAL CLOCK OPERATION, PRESS AND HOLD THE TOP BUTTON FOR 1 SECOND TO ENTER TIME SETTINGS.

1 THE FIRST SETTING IS THE 12/24-HOUR FORMAT. USE THE MIDDLE BUTTON TO CHANGE THE SETTING.


TO SAVE THE TIME FORMAT AND PROCEED TO HOUR SETTINGS, PRESS AND HOLD THE TOP BUTTON FOR 1 SECOND. **2**

1




12-HOUR FORMAT

2




HOUR TENS

3




HOUR UNITS

1




24-HOUR FORMAT

4



MINUTE TENS

5



MINUTE UNITS

STEPS 2-5 ARE THE SAME.

TO SAVE THE CURRENT DIGIT, PRESS AND HOLD THE TOP BUTTON FOR 1 SECOND.

USE THE MIDDLE BUTTON TO CHANGE THE VALUE OF EACH DIGIT.

AFTER SETTING THE LAST DIGIT, PRESS AND HOLD THE TOP BUTTON FOR 1 SECOND TO RETURN TO NORMAL CLOCK OPERATION.

2 SET HOUR TENS


3 SET HOUR UNITS


4 SET MINUTE TENS


5 SET MINUTE UNITS

6 BACK TO NORMAL MODE


SAVE/CONTINUE AND EXIT









ADJUST SETTINGS







6

