

KA Series Remote Control Syntax

Command format : VSET<X>:<NR2>

1. VSET: command header
2. X: output channel
3. : separator
4. NR2: parameter

Command Details:

1. ISET<X>:<NR2>

Description: Sets the output current.

Example: **ISET1:2.225**

Sets the CH1 output current to 2.225A

2. ISET<X>?

Description: Returns the output current setting.

Example: **ISET1?**

Returns the CH1 output current setting.

3. VSET<X>:<NR2>

Description: Sets the output voltage.

Example **VSET1:20.50**

Sets the CH1 voltage to 20.50V

4. VSET<X>?

Description: Returns the output voltage setting.

Example **VSET1?**

Returns the CH1 voltage setting

5. IOUT<X>?

Description: Returns the actual output current.

Example **IOUT1?**

Returns the CH1 output current

6. VOUT<X>?

Description: Returns the actual output voltage.

Example **VOUT1?**

Returns the CH1 output voltage

7. TRACK<NR1>

Description: Selects the operation mode: independent, tracking series, or tracking parallel.

NR1 0: Independent

1: Tracking series

2: Tracking parallel

Example: **TRACK0**

Selects the independent mode.

Note: This command is applied to Multiple-channel models only.

8. BEEP<Boolean>

Description: Turns on or off the beep. **Boolean**: boolean logic.

Example **BEEP1** Turns on the beep.

9. OUT<Boolean>

Description: Turns on or off the output.

Boolean: 0 OFF, 1 ON

Example: **OUT1** Turns on the output

10. STATUS?

Description: Returns the POWER SUPPLY status.

Contents 8 bits in the following format

Bit Item Description

0 CH1 0=CC mode, 1=CV mode

1 CH2 0=CC mode, 1=CV mode

2, 3 Tracking 00=Independent, 01=Tracking series, 11=Tracking parallel

4 Beep 0=Off, 1=On

5 Lock 0=Lock, 1=Unlock

6 Output 0=Off, 1=On

7 N/A N/A

11. IDN?

Description: Returns the KA3000-6000 identification.

Example **IDN?**

Contents KORAD KA3005P V1.3 (Manufacturer, model name,).

12. RCL<NR1>

Description: Recalls a panel setting.

NR1 1 – 5: Memory number 1 to 5

Example **RCL1** Recalls the panel setting stored in memory number 1

13. SAV<NR1>

Description: Stores the panel setting.

NR1 1 – 5: Memory number 1 to 5

Example : **SAV1** Stores the panel setting in memory number 1