

## COMMAND STRUCTURE FOR DISPLAYS:

	STRUCTURE	DISPLAY	COMMAND	PARAMETER
Move display/displays to target segment	DISPLAY:COMMAND:PARAMETER	DX	move or MOVE	S,D S - segment number, D - "+" or "-" describe direction
Jump display/displays to next/previous segment			jump or JUMP	D D - "+" or "-" describe direction
Reset display/displays to zero position (works only in one direction)	DISPLAY:COMMAND	DA - all displays	reset or RESET	

## COMMANDS EXAMPLES:

COMMAND	COMMAND DESCRIPTION
D1:move:3,+	Display 1. move to segment 3 incrementally.
DA:jump:-	All displays jump to previous segment.
D4:reset	Display 4. go to zero position.