

# Quick Start Guide for ETSI Adaptivity and Carrier Sensing Test ver. 1.1.0

## Contents

|  |          |
|--|----------|
| <b>Release History.....</b>  | <b>2</b> |
| <b>1. Introduction.....</b>  | <b>3</b> |
| <b>2. Driver configuration.....</b>  | <b>3</b> |
| <b>3. Driver configuration – disable (default setting).....</b>  | <b>3</b> |
| <b>4. Driver configuration – enable for ETSI Adaptivity test.....</b>  | <b>4</b> |
| <b>5. Driver configuration – enable for Carrier Sense test.....</b>  | <b>4</b> |
| <b>6. Driver configuration – adapt runtime setting with the selection of channel<br/>plan (driver version &gt;= 5.14).....</b> | <b>4</b> |

### Release History

|       |            |   |
|-------|------------|---|
| 1.1.0 | 2021/07/19 | 1. Add configuration of adapting runtime setting with the selection of channel plan |
| 1.0.1 | 2018/09/28 | 1. Add periodic idle time declaration.  |
| 1.0.0 | 2014/09/26 | 1. Add documentation for ADAPTIVITY_VERSION 7.0, 7.1, 7.2                           |

## 1. Introduction

Realtek Wi-Fi solutions support both ETSI Adaptivity test and Carrier Sense test. This document describes ways to configure Wi-Fi driver for the corresponding test and simple debug methods.

※ The test item "periodic idle time" can be skipped by a declaration document from chip vendor. Please get the document from chip vendor for Certification Lab reference **Before** starting test.

※ According to the test requirement, the Wi-Fi performance will drop at interfering environment. Please enable this function only when you really need it.

## 2. Driver configuration

There are 2 configuration arguments in Makefile to control:

- **CONFIG\_RTW\_ADAPTIVITY\_EN**

- **disable**

- Disable adaptivity function

- **enable**

- Enable adaptivity function

- **auto (driver version >= 5.14)**

- Adapt runtime settings (disable/adaptivity/carrier sense) with the selection of channel plan.

- **CONFIG\_RTW\_ADAPTIVITY\_MODE**

- **normal**

- For ETSI adaptivity test

- **carrier\_sense**

- For carrier sense test

## 3. Driver configuration – disable (default setting)

To disable Realtek adaptivity function (also the default setting):

|   |
|---|
| <code>CONFIG_RTW_ADAPTIVITY_EN = disable</code> |
|---|

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 9.7.08
RTW_ADAPTIVITY_EN_DISABLE
th_12h_ini th_edcca_h1_diff
0x2d      7
```

#### 4. Driver configuration – enable for ETSI Adaptivity test

If your product needs to fit the requirement of ETSI Adaptivity test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable
CONFIG_RTW_ADAPTIVITY_MODE = normal
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 9.7.08
RTW_ADAPTIVITY_EN_ENABLE
RTW_ADAPTIVITY_MODE_NORMAL
th_12h_ini th_edcca_h1_diff
0x2d      7
```

#### 5. Driver configuration – enable for Carrier Sense test

If your product needs to fit the requirement of Carrier Sense test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable
CONFIG_RTW_ADAPTIVITY_MODE = carrier_sense
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 9.7.08
RTW_ADAPTIVITY_EN_ENABLE
RTW_ADAPTIVITY_MODE_CARRIER_SENSE
th_12h_ini th_edcca_h1_diff
0x2d      7
```

#### 6. Driver configuration – adapt runtime setting with the selection of channel

**plan (driver version >= 5.14)**

If your product needs to adapt runtime setting with the selection of channel plan:

```
CONFIG_RTW_ADAPTIVITY_EN = auto
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 9.7.08
RTW_ADAPTIVITY_EN_AUTO
th_l2h_ini th_edcca_hl_diff
0x2d      7
```