

Software Development and Debug

Zynq
Vivado 2017.1 Version



Objectives

- > **After completing this module, you will be able to:**
 - >> Describe device drivers architecture
 - >> Distinguish between Level-1 and Level-2 device drivers
 - >> List types of processor timers
 - >> Understand CPU's private timer API
 - >> Describe GNU Debugger (GDB) functionality
 - >> Describe Xilinx Microprocessor Debugger (XMD) functionality
 - >> Describe Eclipse Target Communications Framework

Outline

- > ***Device Drivers Architecture***
- > **Timers and API**
- > **Debugging Tools**
 - >> Hardware Tools
 - >> Software Tools
- > **Debug in SDK**
- > **Summary**



Device Drivers

- > **The Xilinx device drivers are designed to meet the following objectives:**
 - >> Provide maximum portability
 - The device drivers are provided as ANSI C source code
 - >> Support FPGA configurability
 - Supports multiple instances of the device without code duplication for each instance, while at the same time managing unique characteristics on a per-instance basis
 - >> Support simple and complex use cases
 - A layered device driver architecture provides both
 - Simple device drivers with minimal memory footprints
 - Full-featured device drivers with larger memory footprints
 - >> Ease of use and maintenance
 - Xilinx uses coding standards and provides well-documented source code for developers

Drivers: Level 0/Level 1

- > **The layered architecture provides seamless integration with...**
 - >> (Level 2) RTOS application layer
 - >> (Level 1) High-level device drivers that are full-featured and portable across operating systems and processors
 - >> (Level 0) Low-level drivers for simple use cases

Level 2, RTOS Adaptation
Level 1, High-level Drivers
Level 0, Low-level Drivers

Drivers: Level 0

- > **Consists of low-level device drivers**
- > **Implemented as macros and functions that are designed to allow a developer to create a small system**
- > **Characteristics:**
 - >> Small memory footprint
 - >> Little to no error checking is performed
 - >> Supports primary device features only
 - >> No support of device configuration parameters
 - >> Supports multiple instances of a device with base address input to the API
 - >> Polled I/O only
 - >> Blocking function calls

Drivers: Level 1

- > **Consists of high-level device drivers**
- > **Implemented as macros and functions and designed to allow a developer to utilize all of the features of a device**
- > **Characteristics:**
 - >> Abstract API that isolates the API from hardware device changes
 - >> Supports device configuration parameters
 - >> Supports multiple instances of a device
 - >> Polled and interrupt driven I/O
 - >> Non-blocking function calls to aid complex applications
 - >> May have a large memory footprint
 - >> Typically, provides buffer interfaces for data transfers as opposed to byte interfaces

Comparison Example

UARTPS Level 1

- > **XUartPs_CfgInitialize()**
 - >> Initializes a specific XUartPs instance
- > **XUartPs_Send()**
 - >> Sends the specified buffer using the device
 - >> polled or interrupt mode
- > **XUartPs_Recv()**
 - >> Receive a specified number of bytes
 - >> store it into the specified buffer
- > **XUartPs_SetBaudRate()**
 - >> Sets the baud rate

UARTPS Level 0

- > **XUartPs_SendByte()**
 - >> Sends one byte
- > **XUartPs_RecvByte()**
 - >> Receives one byte

Driver Settings

- > Select the Drivers panel
- > By default, the Driver panel displays which device driver is used for each hardware instance in the design
- > Enables selection of custom drivers and versions for each device in the design

Overview

- standalone
- drivers**
- cpu_cortexa9

Drivers

The table below lists all the components found in your hardware system. You can modify the driver assigned for each component. If you do not want to assign a driver to a component or you want to assign a custom driver, select 'none'.

Component	Component Type	Driver	Dr...
ps7_cortexa9_0	ps7_cortexa9	cpu_cortexa9	1....
axi_bram_ctrl_0	axi_bram_ctrl	bram	3....
dip	axi_gpio	gpio	3....
led_ip_0	led_ip	generic	1....
ps7_ddr_0	ps7_ddr	none	1....
ps7_ddrc_0	ps7_ddrc	generic	1....
ps7_dev_cfg_0	ps7_dev_cfg	led_ip	2....
ps7_dma_ns	ps7_dma	dmapi	1....

Outline

- > Device Drivers Architecture
- > ***Timers and API***
- > Debugging Tools
 - >> Hardware Tools
 - >> Software Tools
- > Debug in SDK
- > Summary



Timers: Cortex-A9 Processor

- > **Timers are an important part of an embedded system**
- > **CPU Private Timer and Watchdog Timer**
- > **Global timer (GTC)**
- > **Two 16-bit triple timer counter (TTC)**
- > **System watchdog timer (SWDT)**



Private Timer/Counter (Standalone)

- > By default 32-bit count down timer
- > xscutimer.h, xscutimer_hw.h header files
- > **XScuTimer_LookupConfig()**
 - >> Looks up the device configuration based on the unique device ID
- > **XScuTimer_CfgInitialize()**
 - >> Initialize a specific XTtcPs instance such that the driver is ready to use
- > **XScuTimer_Start()** – Start the timer
- > **XScuTimer_Stop()** – Stop the timer
- > **XScuTimer_GetPrescaler()** – Get the pre-scalar value
- > **XscuTimer_SetPrescaler()** – Set the pre-scalar value between 1 and 16

Private Timer/Counter (Standalone)

- > **XScuTimer_EnableAutoReload()** – Load the counter with the initial value when time out occurs
- > **XScuTimer_IsExpired()** – Check if the timer has reached the final value
- > **XScuTimer_RestartTimer()** – Read the counter value and write it back
- > **XScuTimer_LoadTimer()** – Load the timer with the provided value
- > **XScuTimer_GetCounterValue()** – Get current counter value; useful for determining lapse time
- > **XScuTimer_EnableInterrupt()** – Enable interrupt mechanism
- > **XScuTimer_GetInterruptStatus()** – Get the interrupt status
- > **XScuTimer_ClearInterruptStatus()** – Clear source of interrupt flag

Timers: Triple Timer Counter API (Standalone)

- > **XTtcPs_LookupConfig()** - Looks up the device configuration based on the unique device ID
- > **XTtcPs_CfgInitialize()** - Initialize a specific XTtcPs instance such that the driver is ready to use
- > **XTtcPs_SetMatchValue()** - Set the value of the match registers
- > **XTtcPs_SetOptions()** - Set the options for the TTC device
- > **XTtcPs_SetPreScalar()** - Set the prescaler enable bit
- > **XTtcPs_GetMatchValue()** - Get the value of the match registers
- > **XTtcPs_GetOptions()** - Gets the settings for the options for the TTC device
- > **XTtcPs_GetPrescaler()** - Gets the input clock prescaler

AXI Timer

- > **XTmrCtr_Initialize()** - Initialize a specific timer/counter instance/driver
- > **XTmrCtr_InterruptHandler()** - Interrupt Service Routine (ISR) for the driver
- > **XTmrCtr_SetHandler()** - Sets the timer callback function, which the driver calls when the specified timer times out
- > **XTmrCtr_GetOptions()** - Enables the specified options for the specified timer counter
- > **XTmrCtr_Start()** - Starts the specified timer counter of the device such that it starts running
- > **XTmrCtr_Stop()** - Stops the timer counter by disabling it
- > **XTmrCtr_GetCaptureValue()** - Returns the timer counter value that was captured the last time the external capture input was asserted

AXI Timer

- > **XTmrCtr_GetOptions()** - Get the options for the specified timer counter
- > **XTmrCtr_GetStats()** - Get a copy of the XtmrCtrStats structure, which contains the current statistics for this driver
- > **XTmrCtr_Getvalue()** - Get the current value for the timer counter
- > **XTmrCtr_Reset()** - Reset the specified timer counter of the device

Outline

- > Device Drivers Architecture
- > Timers and API
- > ***Debugging Tools***
 - >> Hardware Tools
 - >> Software Tools
- > Debug in SDK
- > Summary



Debugging

- > **Debugging is an integral part of embedded systems development**
- > **The debugging process is defined as testing, stabilizing, localizing, and correcting errors**
- > **Two methods of debugging:**
 - >> Hardware debugging via a logic probe, logic analyzer, in-circuit emulator, or background debugger
 - >> Software debugging via a debugging instrument
 - A software debugging instrument is source code that is added to the program for the purpose of debugging
- > **Debugging types:**
 - >> Functional debugging
 - >> Performance debugging

Software Debugging Support

- > **Vivado/SDK supports software debugging through**
 - >> GDB tools
 - Unified graphical interface for debugging and verifying processing systems
 - >> Xilinx Microprocessor Debugger (XMD)
 - Runs all the hardware debugging tools and communicates with the hardware
 - Shell for hardware communication
 - Tool command language (Tcl) syntax and command interpreter
 - >> GNU tools communicate with the hardware through XMD
 - >> Xilinx System Debugger, Eclipse Target Communications Framework (TCF)

Hardware Debugging Support

> Vivado supports hardware debugging via the following tools

- >> Vivado Logic Analyzer software
 - Soft-core base logic analyzer
 - Operates through a Xilinx download cable

> Zynq™ AP SoC virtual platform

- >> Functional simulation of physical hardware for the purpose of software development, integration, and test
- >> Runs on the desktop
- >> Facilitates early software development and test

> Zynq AP SoC open-source QEMU model

- >> Open-source machine emulator and virtualizer for Linux environment

XMD Debugger

- > **The Xilinx Microprocessor Debug (XMD) utility provides a variety of user debug services**
 - >> Physical connection between your workstation and the software design
 - >> Connection to an internal BSCAN controller
 - >> Program download
 - >> Processor identification and control
 - >> Low-level debug commands
 - >> Interface to the GNU debugger
 - >> General Tcl interface and command interpreter

XMD Functionality

- > **XMD engine**
 - >> Program that facilitates a unified GDB interface
 - >> Tcl interface and command interpreter
- > **XMD supports application debugging on different targets**
- > **GDB/TCF can connect to XMD on the same computer or on a remote computer on the Internet**

XMD Commands


- > **There are many XMD commands**
- > **Popular commands for boot and program control**
 - >> connect – connect to processor
 - >> dow – download ELF executable file
 - >> elf_verify – verify ELF file with memory image
 - >> run – begin program execution from reset
 - >> con – continue program execution from current program counter
 - >> stop – stop the target processor
 - >> exit – close XMD window
- > **XMD will search for a processor when started and launched from the SDK Run > Debug menu**
- > **connect command will execute automatically**
 - >> connect arm 64

XMD Tcl Interface

- > **xhelp**: Lists all Tcl commands
- > **xrmem target addr [num]**: Reads num bytes or 1 byte from the memory *addr*
- > **xwmem target addr value**: Writes an 8-bit byte value at the specified memory *addr*
- > **xrreg target [reg]**: Reads all registers or only register number *reg*
- > **xwreg target reg value**: Writes a 32-bit value into register number *reg*
- > **xdownload target [-data] filename [addr]**: Downloads the given ELF or data file (with -data option) onto the memory of the current target
- > **xcontinue target [addr]**: Continues execution from the current PC or from the optional address argument



System Debugger

- > **Eclipse Target Communication Framework**
 - >> Extensible network protocol for communicating with embedded systems
- > **Single Configuration per target**
 - >> (Not per tool like gdb)
- > **Homogenous, and heterogeneous, SMP &**
- > **Neon Support**
- > **True multicore debug through a single JTAG**
- > **Faster than GDB/XMD**



Eclipse Target Communication Framework

- > Open, extensible network protocol
- > Allows services to transparently plug in
- > All communication links can share the same protocol
- > Transport-agnostic channel abstraction
 - >> (No specific transport layer. E.g. TCP/IP, Serial Line, SS



Debug Functionality

- > **Source-level debugger (GDB/System Debugger)**
- > **Start your program**
 - >> Set breakpoints (make your program stop on specified conditions)
 - >> Examine what has happened, when your program encounters breakpoints
 - Registers
 - Memory
 - Stack
 - Variables
 - Expressions
 - >> Change things in your program so that you can experiment with correcting the effects of one bug and go on to another
- > **You can debug programs written in C and C++**

Debug

The image shows a debugger window with two panes. The left pane displays C code from a file named `PushButtonTest.c`. The right pane displays the corresponding assembly instructions. Blue arrows point from labels to specific lines in the code:

- C Code** points to line 28: `push_check1 = XGpio_DiscreteRead(&Push,1);`
- Memory Location** points to the assembly instruction `addik r3, r19, 52` at address `0x00000268`.
- Assembly Instructions** points to the assembly instruction `addik r5, r3, r0` at address `0x0000026c`.

C Code:


```
20 XGpio_SetDataDirection(&Push,1,0xffffffff);
21
22 xil_printf("Press center push button to exit\r\n");
23 xil_printf("Any other to see corresponding LED turn ON\r\n");
24 push_check = XGpio_DiscreteRead(&Push,1);
25
26 while(1)
27 {
28     push_check1 = XGpio_DiscreteRead(&Push,1);
29     if(push_check1 != push_check)
30     {
31         push_check=push_check1;
32         if(push_check)
33             xil_printf("Push buttons status %0x\r\n", push_check1);
34     }
35     if(push_check==0x01)
36         break;
37     XGpio_DiscreteWrite(&led,1,push_check);
38 }
39 xil_printf("-- Exiting main() --\r\n");
40 return 0;
```

Assembly Instructions:

```
0x0000025c <main+180>: brlid r15, 2060 // 0xa68 <XGpio_DiscreteRead>
0x00000260 <main+184>: or    r0, r0, r0
0x00000264 <main+188>: swi   r3, r19, 28
                                while(1)
                                {
0x00000268 <main+192>: addik r3, r19, 52
0x0000026c <main+196>: addik r5, r3, r0
0x00000270 <main+200>: addik r6, r0, 1 // 0x1 <_start+1>
0x00000274 <main+204>: brlid r15, 2036 // 0xa68 <XGpio_DiscreteRead>
0x00000278 <main+208>: or    r0, r0, r0
0x0000027c <main+212>: swi   r3, r19, 32
                                if(push_check1 != push_check)
0x00000280 <main+216>: lwi   r4, r19, 32
0x00000284 <main+220>: lwi   r3, r19, 28
0x00000288 <main+224>: rsubk r18, r3, r4
0x0000028c <main+228>: beqi  r18, 36 // 0x2b0 <main+264>
                                {
0x00000290 <main+232>: lwi   r3, r19, 32
0x00000294 <main+236>: swi   r3, r19, 28
```


Debug GUI

> Run-time control






Debug Functionality

- > Breakpoints can be enabled or disabled
- > To change any memory value, click a memory field



Debug Functionality

- > Yellow represents registers that have changed (useful when following assembly code)
- > To change any value, click to edit, or right-click the field




Outline

- > Device Drivers Architecture
- > Timers and API
- > Debugging Tools
 - >> Hardware Tools
 - >> Software Tools
- > ***Debug in SDK***
- > Summary




Debugging Using SDK (TCF)



SDK Debug Perspective

- > Stack frame for target threads
- > Variables, breakpoints, and registers views
- > C/C++ editor
 - >> Disassembly view can be added using Window > Show View > Disassembly
- > Console, SDK Log, and Memory views



Outline

- > Device Drivers Architecture
- > Timers and API
- > Debugging Tools
 - >> Hardware Tools
 - >> Software Tools
- > Debug in SDK
- > ***Summary***



Summary

- > **Debugging is an integral part of embedded systems development**
- > **Vivado provides tools to facilitate hardware and software debugging**
 - >> Hardware debugging is done through using Vivado Logic Analyzer
 - >> Software debugging is performed using xmd and GNU debugger
- > **SDK provides environment, perspective, and underlying tools to enable seamless software debugging**
- > **XMD/GDB Debug**
 - >> Single service on dedicated connection
- > **System Debugger/TCF**
 - >> Multicore Debug, shared connection

Questions?

