

# ENGINE IMMOBILISER SYSTEM

## SERVICE HINTS

### EFI RELAY

5-3 : Closed with the ignition SW at **ON** position

### U1 UNLOCK WARNING SW

1-2 : Closed with ignition key in cylinder

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B6	A	98 (LHD)	D8	108 (RHD)	J9
		106 (RHD)	D9	100 (LHD)	
B7	B	98 (LHD)		108 (RHD)	J11
		106 (RHD)	D10	100 (LHD)	J13
C10	A	98 (LHD)		108 (RHD)	
		106 (RHD)	E2	A	T7
C11	B	98 (LHD)			
		106 (RHD)	E3	B	U1
D7		100 (LHD)			
		108 (RHD)	J1	105 (RHD)	
D8		100 (LHD)	J5	107 (RHD)	

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2I	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)
	128 (RHD)	

**: GROUND POINTS**

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
	124 (RHD)	
IH	114 (LHD)	Front Floor Panel Center LH
	124 (RHD)	Front Floor Panel Center RH
BJ	128 (RHD)	Front Floor Panel LH
BL	118 (LHD)	Front Floor Panel RH