

## SERVICE HINTS

### D12 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW FRONT RH

- 8-GROUND : Approx. 12 volts with door lock motor at lock operate
- 7-GROUND : Approx. 12 volts with door lock motor at unlock operate

### D13 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW FRONT LH

- 8-GROUND : Approx. 12 volts with door lock motor at lock operate
- 7-GROUND : Approx. 12 volts with door lock motor at unlock operate

### D15 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR LH

- 8-GROUND : Approx. 12 volts with door lock motor at lock operate
- 7-GROUND : Approx. 12 volts with door lock motor at unlock operate

### D16 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR RH

- 8-GROUND : Approx. 12 volts with door lock motor at lock operate
- 7-GROUND : Approx. 12 volts with door lock motor at unlock operate

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A14	A	D8	108 (RHD)	E3	B
A15	B	D9	108 (RHD)	J5	107 (RHD)
B6	A	D10	108 (RHD)	J9	107 (RHD)
B7	B	D12	108 (RHD)	J10	107 (RHD)
C10	106 (RHD)	D13	108 (RHD)	J11	107 (RHD)
D2	106 (RHD)	D15	108 (RHD)	J13	108 (RHD)
D4	106 (RHD)	D16	108 (RHD)	T5	107 (RHD)
D7	108 (RHD)	E2	A	U1	107 (RHD)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G		
1H		
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
2E	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH2	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)
BA1	128 (RHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	128 (RHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC1	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)

## DOUBLE LOCKING (RHD)

---



### : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
BJ	128 (RHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH

