

REAR FOG LIGHT (RHD)

SERVICE HINTS

R7 REAR FOG LIGHT SW

- 1-GROUND : Approx. **12** volts with the light control SW at **HEAD** or **TAIL** position and the rear fog light SW at **ON** position
- 5-GROUND : Approx. **12** volts with the light control SW at **HEAD** or **TAIL** position
- 7-GROUND : Always continuity
- 2, 3, 4-GROUND : Always approx. **12** volts

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C14	A	106 (RHD)	J9	107 (RHD)	R7
	B	106 (RHD)	J14	108 (RHD)	R12
J5	107 (RHD)	J16	108 (RHD)	R13	109 (RHD)
J8	107 (RHD)	J17	108 (RHD)	T4	107 (RHD)

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B		
1F	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1I		
2F	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
BK	128 (RHD)	Left Quarter Panel LH

