

I GROUND POINT (RHD)

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
J2	A	105 (RHD)	J7	107 (RHD)	J16	108 (RHD)
J3	B	105 (RHD)	J9	107 (RHD)	J17	108 (RHD)
J4		105 (RHD)	J12	108 (RHD)		
J5		107 (RHD)	J13	108 (RHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)
3	94 (RHD)	Engine Room No.3 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B		
1E	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F		
1G		
1I		
1J		
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
2B	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2E	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2J	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	122 (RHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	124 (RHD)	Instrument Panel Wire and A/C Sub Wire (Right Side of the Blower Unit)
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)
BA1	128 (RHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	128 (RHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BD1	128 (RHD)	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)
BD2		
BE1	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

**: GROUND POINTS**

Code	See Page	Ground Points Location
EA	122 (RHD)	Front Side of Cylinder Head
EB	122 (RHD)	Rear Side of Cylinder Head
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IE	124 (RHD)	Instrument Panel Reinforcement LH
IF	124 (RHD)	Cowl Side Panel RH
IG	124 (RHD)	Front Floor Panel Center LH
IH	124 (RHD)	Front Floor Panel Center RH
BJ	128 (RHD)	Front Floor Panel LH
BK	128 (RHD)	Left Quarter Panel LH
BL	128 (RHD)	Front Floor Panel RH
BM	128 (RHD)	Roof Panel

**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	122 (RHD)	Engine Wire	B1	128 (RHD)	Roof Wire
E9		Engine Room Main Wire	B3	130 (RHD)	Front Seat RH Wire
I4	126 (RHD)	Engine Room Main Wire			