

REAR WINDOW DEFOGGER AND MIRROR HEATER

SERVICE HINTS

RR DEF RELAY

2-1, 3-5 : Closed with ignition SW at **ON** position and defogger SW [A/C control assembly] on

○ : PARTS LOCATION

Code		See Page		Code		See Page		Code		See Page	
A14	A	98 (LHD)		D2		106 (RHD)		N7	101 (LHD)		
		106 (RHD)		E2	A	96 (LHD)			109 (RHD)		
A15	B	98 (LHD)				E3	B	104 (RHD)		R16	101 (LHD)
		106 (RHD)		96 (LHD)				109 (RHD)			
B6	A	98 (LHD)		J5		104 (RHD)		R17	101 (LHD)		
		106 (RHD)				99 (LHD)			109 (RHD)		
C10		98 (LHD)		J12		100 (LHD)		T5	107 (RHD)		
		106 (RHD)				108 (RHD)					

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1C	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1D	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1I	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
1O	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)

**: GROUND POINTS**

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
BJ	128 (RHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH