

SERVICE HINTS

FLSH RELAY

4-GROUND : Always approx. **12** volts

1-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position

7-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A15	106 (RHD)	F5	104 (RHD)	J7	107 (RHD)
B6	106 (RHD)	F6	104 (RHD)	J17	108 (RHD)
C10	106 (RHD)	F7	104 (RHD)	R10	109 (RHD)
C14	A	F8	104 (RHD)	R11	109 (RHD)
	B	J5	107 (RHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B		
1E	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F		
1H		
1I		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IH	124 (RHD)	Front Floor Panel Center RH
BK	128 (RHD)	Left Quarter Panel LH