

SERVICE HINTS

TAIL RELAY

5-3 : Closed with light control SW at **TAIL** or **HEAD** position

C14 (A), (B) LIGHT CONTROL SW [COMB. SW]

(A)14-(A)16, (B)16-(B)17 : Closed with light control SW at **TAIL** or **HEAD** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A14	106 (RHD)	J5	107 (RHD)	R8	107 (RHD)
A19	106 (RHD)	J7	107 (RHD)	R9	107 (RHD)
A30	106 (RHD)	J8	107 (RHD)	S6	107 (RHD)
C9	106 (RHD)	J9	107 (RHD)	S7	107 (RHD)
C10	106 (RHD)	J13	108 (RHD)	S9	A 107 (RHD)
C14	A	M1	107 (RHD)	S10	B 107 (RHD)
	B	N3	A 109 (RHD)	T4	107 (RHD)
E10	107 (RHD)	N6	D 109 (RHD)	T6	A 107 (RHD)
G1	107 (RHD)	R4	C 107 (RHD)		B 107 (RHD)
H13	107 (RHD)	R6	B 107 (RHD)		
H14	107 (RHD)	R7	107 (RHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1C		
1D	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F		
1I		
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IG	124 (RHD)	Front Floor Panel Center LH
BJ	128 (RHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	126 (RHD)	Instrument Panel Wire			