

CELLULAR MOBILE TELEPHONE

SERVICE HINTS

T8 (A) TELEPHONE TRANSCEIVER AND SPEAKER RELAY

- (A) 6-GROUND : Always approx. **12** volts
 (A) 7-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
 (A) 1-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code		See Page	Code		See Page
C13	98 (LHD)	J17		108 (RHD)	S10	B	99 (LHD)
	106 (RHD)	R2	A	99 (LHD)			107 (RHD)
J9	99 (LHD)			R4	C	107 (RHD)	T3
	107 (RHD)	99 (LHD)	107 (RHD)				
J14	100 (LHD)	107 (RHD)	T8			A	101 (LHD)
	108 (RHD)	R14					101 (LHD)
J16	100 (LHD)	R15		109 (RHD)	T9	B	101 (LHD)
	108 (RHD)	S9	A	99 (LHD)			109 (RHD)
J17	100 (LHD)			107 (RHD)			

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1I	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IB2	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
BC1	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
BJ	128 (RHD)	Front Floor Panel LH
BK	118 (LHD)	Left Quarter Panel LH
	128 (RHD)	
BL	118 (LHD)	Front Floor Panel RH

